BUREAU OF EXPLOSIVES

BUREAU OF EXPLOSIVES

SUPERVISOR, MILITARY & INTERMODAL SERVICES

DATE 4/4/3/1

LOADING AND BRACING (CL & LCL) IN BOX CARS OF PALLETIZED PROPELLING CHARGES PACKED IN CYLINDRICAL METAL CONTAINERS MIO SERIES CONTAINER

INDEX

<u>ITEM</u>	PAGE (S)
GENERAL NOTES	2, 3
MATERIAL SPECIFICATIONSPALLET UNIT DETAILS	2
PALLET UNIT DETAILS	4, .5
ALTERNATED CONTAINERS UNITS (BASIC HEIGHT):	
LOADS	6-15
DETAILS	16-19
ALTERNATED CONTAINERS UNITS (INCREASED HEIGHT):	
LOADS	20-29
DETAILS	30-33
FLAT DUNNAGE METHOD UNITS (BASIC HEIGHT):	
LOADS	34-43
DETAILS	44-47
FLAT DUNNAGE METHOD UNITS (DECREASED HEIGHT):	
LOADS	48-57
DETAILS	58-61
ROUTED DUNNAGE METHOD UNITS (BASIC HEIGHT):	
LOADS	62-71
DETAILS	72-75
ROUTED DUNNAGE METHOD UNITS (DECREASED HEIGHT):	
LOADS DETAILS	76-85
DETAILS	86-89
LCL PROCEDURES FOR CARS EQUIPPED WITH MECHANICAL BRACING DEVICES	90, 91
LCL PROCEDURES FOR CONVENTIONAL BOX CARS	92-120
GENERAL DETAILS	121-128
PROVISIONS FOR BOX CARS FOULPPED WITH LOAD DIVIDER BULKHFADS	129 130

THIS OUTLOADING PROCEDURE DRAWING INCLUDES PROCEDURES FOR CONVENTIONAL TYPE BOX CARS, BOX CARS EQUIPPED WITH MECHANICAL BRACING DEVICES OF VARIOUS BESIGN AND MANUFACTURE, AND CUSHIONED BOX CARS EQUIPPED WITH LOAD DIVIDER BULKHEADS.

THIS DRAWING SUPERSEDES THE CARLOADING PORTIONS DELINEATED ON PAGES 42 THRU 73 OF DRAWING 19-48-4042-1-2-5-11-14PM1000, DATED 8 FEBRUARY 1965 AND REVISION 1, DATED 29 AUGUST 1969.

		REVIS	SIONS			/www	
Γ				LPPREVED.	34 67	AMENT MATERIEL S	EAGURESS COMMAND
	ļ	<u>И</u> ,		1	Man	11	
							U. S. ARMY
\vdash	 					BACKATION CE AMERICANIA DE COMMANDE COMMANDE COMMANDE COMMANDE COMMANDE CE COMMANDE CE COMMANDE CE CE COMMANDE CE CE COMMANDE CE CE COMMANDE CE CE CE COMMANDE CE	
						ARCOM I	
					MAY	1981	
L				CLASS	DIVISION	DEAWING	PILE
				10	48	4042B/	5PM
				19	40	١	1000

DO NOT SCALE

GENERAL NOTES

- A. THIS DOCUMENT HAS BEEN PREPARED AND ISSUED IN ACCORDANCE WITH AR 740-1 AND AUGMENTS TM 743-200-1 (CHAPTER 5).
- B. THE OUTLOADING PROCEDURES SPECIFIED IN THIS DRAWING ARE APPLICABLE FOR THE MID SERIES PROPELLING CHARGE CONTAINER WHEN UNITIZED ON A 40" X 48" PALLET. SEE THE PICTORIAL VIEWS ON PAGES 4 AND 5. REFER TO THE US ARMY DARCOM DRAWING 19-48-4042A/1-20PM1001 FOR UNITIZATION PROCEDURES FOR THE MID SERIES CONTAINER.
- C. THE OUTLOADING PROCEDURES DEPICTED WITHIN THIS DOCUMENT ARE APPLICABLE FOR SHIPMENTS IN CONVENTIONAL TYPE BOX CARS, FOR SHIP-MENTS IN BOX CARS EQUIPPED WITH VARIOUS TYPES OF SELF-CONTAINED MECHANICAL BRACING DEVICES, AND FOR SHIPMENTS IN CUSHIONED BOX CARS EQUIPPED WITH LOAD DIVIDER BULKHEADS.
- D. CAUTION: METAL PROPELLING CHARGE CONTAINERS THAT OVERHANG THE PALLET END MUST NOT BE ALLOWED TO CONTACT STEEL SIDEWALLS OR END WALLS OF BOX CARS. THIS TYPE OF UNIT LOAD SHOULD BE SHIPPED IN BOX CARS HAVING WOOD SIDEWALLS AND/OR END WALLS. IF CARS WITH WOOD SIDEWALLS AND/OR END WALLS ARE NOT AVAILABLE, AND ALL-STEEL CARS ARE USED, THE SIDEWALLS AND/OR END WALLS MUST BE LINED WITH DIMENSIONAL LUMBER, PLYWOOD, HARDBOARD, OR SOLID FIBERBOARD. THE LINING SHOULD BE PROVIDED WHEREVER METAL-OF-CONTAINER TO METAL-OF-CAR CONTACT IS POSSIBLE. REFER TO PAGE 121 FOR GUIDANCE.
- E. EXCEPT FOR PALLET UNITS OF ALTERNATED CONTAINERS, UNITS WILL BE POSITIONED WITH THE BASE ENDS OF CONTAINERS AGAINST THE CAR END WALL OR SIDEWALL AS APPLICABLE TO THE LOAD BEING SHIPPED. LONGITUDINALLY ADJACENT LENGTHWISE UNITS WILL BE POSITIONED WITH BASE END AGAINST BASE END OR BELL END AGAINST BELL END, EXCEPT FOR UNITS HAVING ALTERNATED CONTAINERS.
- F. THE SELECTION OF RAIL CARS FOR THE TRANSPORT OF PALLETIZED UNITS OF PROPELLING CHARGES IS THE RESPONSIBILITY OF THE ORIGINATING CARRIER AND THE SHIPPER. ONLY CARS WHICH HAVE "SOUND" FLOORS AND ARE IN OTHERWISE PROPER CONDITION, IN ACCORDANCE WITH THE REQUIREMENTS OF THE APPLICABLE REGULATORY DOCUMENTS, WILL BE SELECTED.
- G. WHEN SELECTING RAIL CARS, EVERY EFFORT SHOULD BE MADE TO OBTAIN BOX CARS THAT DO NOT HAVE BOWED END WALLS. CARS HAVING BOWED ENDS CAN BE USED, HOWEVER, IF AN END WALL IS BOWED OUTWARD MORE THAN TWO INCHES (2"), EITHER FROM SIDE TO SIDE OR FROM FLOOR TO ROOF, AN END-OF-CAR BULKHEAD MUST BE INSTALLED TO PROVIDE A "SQUARED OFF" SURFACE FOR THE LOAD AT THE END OF THE CAR. REFER TO PAGE 122 FOR GUIDANCE
- H. BOX CARS EQUIPPED WITH CONVENTIONAL SLIDING DOORS HAVE BEEN SHOWN. HOWEVER, THE DEPICTED OUTLOADING PROCEDURES ARE ALSO APPLICABLE FOR CARS EQUIPPED WITH PLUG DOORS. CAUTION: DUNNAGE MATERIAL MUST NOT BE NAILED TO ANY PLUG DOOR, WETHER AUXILIARY OR MAIN. ALSO, AFTER THE PLUG DOORS ON A CAR ARE CLOSED AND READY FOR THE INSTALLATION OF CAR SEALS, A PIECE OF WIRE OF SUITABLE SIZE WILL BE USED IN ADDITION TO, AND IN CONJUNCTION WITH EACH CAR SEAL USED TO SEAL THE CAR. THE WIRE WILL BE THREADED THRU THE HOLES IN THE DOOR LATCH ASSEMBLY ONE OR MORE TIMES, AND THE WIRE ENDS WILL BE TWISTED TOGETHER.
- J. THE USE OF AN OFFSET LOADING PATTERN WILL FACILITATE LOADING AND UNLOADING OPERATIONS IN THE DOORWAY AREA OF THE CAR. WHEN POSSIBLE TO DO SO, A FULL LOAD SHOULD BE BUILT USING AN OFFSET LOADING PATTERN. FOR INSTANCE, A LOAD CONSISTING OF AN EVEN NUMBER OF LOAD UNITS AND HAVING TWO MORE LOAD UNITS IN ONE END OF THE CAR THAN IN THE OPPOSITE END, OR A LOAD CONSISTING OF AN ODD NUMBER OF LOAD UNITS AND HAVING ONE MORE LOAD UNIT IN ONE END THAN IN THE OTHER IS CONSIDERED TO BE AN OFFSET LOAD.
- K. OTHER TYPES OF LADING ITEMS MAY BE LOADED IN CARS WHICH ARE PARTIALLY LOADED WITH PALLETIZED UNITS OF PROPELLING CHARGES, PROVIDING THE TOTAL LOAD IS COMPATIBLE, EXISTING DIRECTIVES ARE NOT VIOLATED, AND THE OTHER LADING ITEMS ARE BLOCKED AND BRACED TO EQUAL THE BLOCKING AND BRACING CRITERIA SPECIFIED HEREIN. MIXED ITEMS TO BE SHIPPED IN CARS EQUIPPED WITH MECHANICAL BRACING DEVICES MUST BE SEPARATELY BLOCKED, USING THE PROCEDURES SHOWN FOR THESE CARS AS GUIDANCE.

(CONTINUED AT RIGHT)

MATERIAL SPECIFICATIONS

OR STRONGER.

PAGE 2

LUMBER ;	SEE TM 743-200-1, DUNNAGE LUMBER; FED SPEC MM-L-751.
NAILS::	COMMON, FED SPEC FF-N-105.
STRAPPING, STEEL :	CLASS 1, TYPE I OR $\overline{\mathbf{M}}$, HEAVY DUTY, FINISH A OR 8 (GRADE 2), FED SPEC QQ-5-781.
STRAP SEAL::	TYPE D, STYLE I, II, OR IX, CLASS H. FED SPEC QQ-S-781.
STRAP STAPLE:	COMMERCIAL GRADE.
PLYWOOD ;	GROUP B OR C, GRADE C-D (EXTERIOR). FED SPEC NN-P-530, IF SPECIFIED GRADE IS NOT AVAILABLE, A BETTER EXTERIOR GRADE MAY BE SUBSTITUTED.
<u>WIRE</u> :	FED SPEC QQ-W-461.
HARDBOARD:	FED SPEC LL-8-810
	FED SPEC PP-F-920. TYPE SF, CLASS DOMESTIC, GRADE 175 OR STRONGER; OR TYPE SF, CLASS WEATHER-RESISTANT, GRADE W6S

(GENERAL NOTES CONTINUED)

- L. DUNNAGE LUMBER SPECIFIED THROUGHOUT THIS PROCEDURAL DRAWING IS OF NOMINAL SIZE. FOR EXAMPLE 2" X 4" MATERIAL IS ACTUALLY 1-1/2" THICK BY 3-1/2" WIDE AND 2" X 6" MATERIAL IS ACTUALLY 1-1/2" THICK BY 5-1/2" WIDE. IF THOSE MEMBERS SPECIFICALLY IDENTIFIED AS "STRUTS" WITHIN THE KEY NUMBERS OF A DEPICTED LOAD ARE SPECIFIED TO BE 4" X 4" MATERIAL, IT IS PERMISSABLE TO USE TWO LAMINATED PIECES OF 2" X 6" MATERIAL IN LIEU OF EACH 4" X 4" STRUT. POUBLED 2" X 6" STRUTS WILL BE LAMINATED W/1-104 NAIL EVERY 6".
- M. NOTICE: A STAGGERED NAILING PATTERN WILL BE USED WHEREVER POSSIBLE WHEN NAILS ARE DRIVEN INTO JOINIS OF DUNNAGE ASSEMBLIES. ALSO, A STAGGERED NAILING PATTERN WILL BE USED WHEN DUNNAGE IS NAILED TO THE FLOOR OF SIDEWALL OF THE TRANSPORTING VEHICLE, OR WHEN LAMINATING DUNNAGE. THE NAILING PATTERN WILL BE ADJUSTED AS REQUIRED SO THAT A NAIL DOES NOT PENETATE INTO OR NEAR A CRACK BETWEEN FLOOR BOARDS OR SIDEWALL BOARDS. ADDITIONALLY, THE NAILING PATTERN FOR AN UPPER PIECE OF LAMINATED DUNNAGE WILL BE ADJUSTED AS REQJIRED SO THAT A NAIL FOR THAT PIECE WILL NOT BE DRIVEN THROUGH ONTO OR RIGHT BESIDE A NAIL IN A LOWER PIECE.
- N. WHEN STEEL STRAPPING IS SEALED AT AN END-OVER-END LAP JOINT, A MINIMUM OF TWO (2) SEALS, BUTTED TOGETHER, WITH TWO (2) PAIR OF CRIMPS PER SEAL WILL BE USED TO SEAL THE JOINT.
- O. THROUGHOUT THIS PROCEDURAL DRAWING, PORTIONS OF THE BLOCKING COMPONENTS AND OF THE DEPICTED CASS, SUCH AS A CAR SIDE WALL, HAVE BEEN OMITTED FROM THE LOAD VIEW FOR CLARITY PURPOSES.
- P. THE NUMBER OF LADING UNITS MAY BE ADJUSTED TO FIT THE SIZE OF THE BOX CAR BEING LOADED OR THE QUANTITY TO BE SHIPPED. HOWEVER, THE APPROVED METHODS SPECIFIED HEREIN MUST BE FOLLOWED AS CLOSELY AS POSSIBLE FOR BLOCKING, BRACING, AND STAYING OF THE UNITS. NOTICE: A SHIPMENT WILL BE POSITIONED IN THE RAIL CAR IN COMPLIANCE WITH THE WEIGHT DISTRIBUTION REQUIREMENTS OF THE AAR.

GENERAL NOTES

(FOR CONVENTIONAL TYPE BOX CARS)

- Q. IF THE CAR BEING USED FOR A SHIPMENT IS EQUIPPED WITH A NAILABLE METAL FLOOR AND A NAIL SIZE FOR FLOOR NAILLING IS MARKED ON THE SIDEWALL OF THE CAR, THAT GUIDANCE SHOULD BE APPLIED TO THE NAILING OF THE "DOORWAY BLOCKING" PIECES IN THE FULL LOADS AND TO THE NAILING TO THE CAR FLOOR OF THE LCL BRACES AND KNEE BRACE ASSEMBLIES IN THE LESS-THAN-FULL LOADS. IF A NAIL SIZE IS NOT SPECIFIED IN THE CAR, 300 NAILS SHOULD BE USED IN LIEU OF THOSE SPECIFIED IN THE APPLICABLE KEY NUMBERS. SEE GENERAL NOTE "M" ABOVE.
- R. NOTICE: WHEN POSITIONING PALLETIZED UNITS IN A CAR THEY SHOULD BE PLACED TIGHTLY AGAINST A CAR SIDEWALL AND ARE TO BE PRESSED TIGHTLY TOGETHER LENGTHWISE SO AS TO ACHIEVE A TIGHT LOAD. TO AID IN ACHIEVING TIGHTNESS LENGTHWISE IN A FULL LOAD, A LOAD-COMPRESSING JACK MAY BE EMPLOYED IN THE AREA OF THE CENTER GATES TO MOVE THE PALLETIZED UNITS INTO THEIR FINAL SHIPPING POSITION. A HYDRAULIC JACK IS RECOMMENDED FOR THIS OPERATION. CAUTION: WHEN USING A JACK TO COMPACT A LOAD, THE JACK MUST BE USED AGAINST STRONG POINTS OF THE PALLETIZED UNITS, SUCH AS THE JOINTS BETWEEN THE LAYERS OF CONTAINERS ON THE UNIT. PADDING, OF 2-INCH (2") THICK LUMBER OR ANY OTHER MATERIAL OF SIMILAR CONSISTENCY, SHOULD BE PLACED BETWEEN THE LACK AND THE LADING.
- S. LOAD-BLOCKING STRUTS WHICH ARE 48" OR LONGER MUST BE STIFFENED BY THE APPLICATION OF HORIZONTAL AND VERTICAL STRUT BRACING AS SHOWN BY THE "STRUT BRACING" DETAIL ON PAGE 124. BRACING IS NOT REQUIRED IF THE STRUTS FOR THE LOAD BEING SHIPPED ARE SHORTER THAN 48". THE LENGTH OF THE LOAD-BLOCKING STRUTS SHOULD BE KEPT AS SHORT AS POSSIBLE (APPROX 18" MINIMLM), BUT IN THE EVENT IT IS NECESSARY TO USE STRUTS WHICH ARE 8"-0" OR MORE IN LENGTH, IT WILL BE NECESSARY TO APPLY AN ADDITIONAL SET OF HORIZONTAL AND VERTICAL STRUT BRACING PIECES. STRUT BRACING SHOULD BE APPLIED SC AS TO PROVIDE NEARLY EQUAL SPACES BETWEEN THE BRACING PIECES AND THE CENTER GATES AND/OR BETWEEN ADJACENT STRUT BRACING PIECES, NOTE THAT HORIZONTAL STRUT BRACING PIECES FOR THE UPPER LEVEL OF STRUTS FOR ALL BUT THE UPPERMOST TIER OF A LOAD MAY BE DIFFICULT TO APPLY TO THE TOP SURFACES OF THE STRUTS AS DEPICTED, STRUT BRACING WILL BE EQUALLY EFFECTIVE IF APPLIED TO THE UNDER SIDE OF THOSE STRUTS.
- T. TO ACHIEVE A TIGHTLY BLOCKED LOAD, A STRUT WILL BE CUT SLIGHTLY LONGER THAN THE MEASURED DISTANCE BETWEEN THE STRUT BEARING AREAS ON THE TWO CENTER GATES. ONE END OF THE STRUT WILL BE POSITIONED AT ITS BEARING AREA JUST ABOVE THE STRUT LEDGER ON ONE GATE. THE OTHER END, WHICH CAN BE BEVELED ON THE LOWER CORNER IF DESIRED, WILL THEN BE DRIVEN DOWNWARD UNTIL IT CONTACTS THE STRUT LEDGER ON THE OTHER GATE. EACH END OF THE STRUT WILL BE TOENAILED TO THE ADJACENT CENTER GATE, AS SPECIFIED WITHIN THE KEY NUMBERS FOR A LOAD, IN SUCH A MANNER SO THAT AS NEARLY AS PRACTICAL EQUAL LENGTHS OF A NAIL ARE EMBEDDED IN THE STRUT AND IN THE VERTICAL PIECE OF THE CENTER GATE. SEE THE "BEVEL CUT" DETAIL ON PAGE 124 FOR BEVELING INSTRUCTIONS AND THE "STRUT INSTALLATION" DETAIL ON THAT PAGE FOR A PICTORIAL VIEW SHOWING THE PROPER POSITIONING OF A BEVELED STRUT FOR INSTALLATION. NOTE THAT THE UPPER CORNER NEEDS TO BE BEVELED ONLY IF THE STRUTS ARE VERY SHORT. IF ONLY ONE END IS BEVEL-CUT, THE BEVELED EDGE WILL BE PLACED IN THE DOWNWARD POSITION SO THAT IT WILL ALLOW THE STRUT END TO SLIDE MORE PREELY DOWN THE FACE OF THE VERTICAL PIECE ON THE ADJACENT CENTER GATE AS THE STRUT IS DRIVEN DOWN INTO ITS FINAL BLOCKING POSITION.
- U. FOR ADDITIONAL GUIDANCE, ATTENTION IS DIRECTED TO THE "SPECIAL NOTES" SECTIONS WHICH ARE IMMEDIATELY ADJACENT TO THE DEPICTED OUTLOADING METHODS.

GENERAL NOTES

(FOR BOX CARS EQUIPPED WITH MECHANICAL BRACING DEVICES)

- W. THE OUTLOADING PROCEDURES FOR BOX CARS EQUIPPED WITH MECHANICAL BRACING DEVICES MAY BE ADAPTED AS REQUIRED TO FACILITATE THE USE OF BOX CARS EQUIPPED WITH VARIOUS TYPES OF SELF-CONTAINED MECHANICAL BRACING DEVICES. HOWEVER, FIXED OR ADJUSTABLE WALL MEMBERS AND DOORWAY MEMBERS WITHIN THESE CARS MUST PROVIDE FOR THE INSTALLATION OF LOAD BLOCKING CROSS MEMBERS AT THE HEIGHTS SPECIFIED. CAUTION: BOX CARS EQUIPPED WITH MEMBERS WHICH DO NOT MEET THE LOCATION REQUIREMENTS MUST NOT BE USED.
 - 1. FOR BLOCKING THE LOADS WHICH ARE DEPICTED, A CROSS MEMBER WILL NOT BE RELIED UPON TO RETAIN MORE LADING ON EITHER SIDE THAN AS SHOWN. VOIDS LENGTHWISE WITHIN THE LOAD MUST BE HELD TO A MINIMUM AND CROSS MEMBERS MUST BE PLACED AGAINST THE LADING AS TIGHTLY AS THE SPACING OF THE LOCKING HOLES IN THE WALL MEMBERS PERMIT. LOCKING BARS (LEVER JACKS) SHOULD BE USED FOR THIS PURPOSE. AN ADDITIONAL 1/2" OF ADJUSTMENT CAN BE MADE BY TURNING A CROSS MEMBER END-FOR-END WHEN LOCKING PINS ON THE MEMBER ARE OFF-CENTER. NOTE: IT IS RECOMMENDED THAT EACH CROSS MEMBER BE INSTALLED WITH THE ENDS ATTACHED AS NEARLY AS POSSIBLE IN "MATED" POSITIONS (AT EQUAL HEIGHTS AND AT EQUAL DISTANCES FROM THE END OF THE CAR).
 - 2. CAUTION: ALL BLOCKING AND BRACING COMPONENTS IN EMPTY CARS AND ALL UNUSED COMPONENTS IN LOADED CARS MUST BE "SECURED" FOR SHIPMENT—-ADJUSTABLE WALL MEMBERS TO VERTICAL WALL ATTACHMENT RAILS, AND CROSS MEMBERS TO ADJUSTABLE WALL MEMBERS OR TO FIXED HORIZONTAL WALL MEMBERS OR TO DOORWAY MEMBERS, AND DOORWAY MEMBERS TO DOOR POSTS. COMPONENTS ASSIGNED TO EACH CAR MUST REMAIN THEREWITH EVEN THOUGH UNUSED DURING SOME SHIPMENTS.
- X. IN A CAR EQUIPPED WITH ADJUSTABLE WALL MEMBERS, PROVIDING THE FIXED WALL MEMBERS WHICH ARE PRESENT IN SOME "ADJUSTABLE" CARS ARE NOT PROPERLY POSITIONED TO PROVIDE SIDE BEARING SURFACES BETWEEN THE UNITS AND THE CAR SIDEWALLS, ADJUSTABLE WALL MEMBERS (AS REQUIRED) MUST BE INSTALLED TO PROVIDE A MINIMUM OF ONE SURFACE AREA FOR SIDE BEARING AT SOME LOCATION WITHIN THE UPPER HALF OF EACH UNIT.
- y. FOR ADDITIONAL GUIDANCE, ATTENTION IS DIRECTED TO THE "SPECIAL NOTES" SECTIONS WHICH ARE IMMEDIATELY ADJACENT TO THE DEPICTED OUTLOADING METHODS.

GENERAL NOTES


(FOR CARS EQUIPPED WITH LOAD DIVIDER BULKHEADS)

- AA. CAUTION: FOR CUSHIONED BOX CARS EQUIPPED WITH LOAD DIVIDER BULKHEADS, ONLY CARS EQUIPPED WITH LOAD DIVIDERS MANUFACTURED BY TRANSC, OR PRECO MAY BE USED. LOAD DIVIDERS MANUFACTURED BY TRANSCO ARE NOT ACCEPTABLE, WHETHER OF ALLMINIUM OR STEEL CONSTRUCTION. THE DEPICTED PROCEDURES ARE APPLICABLE FOR CARS OF VARIOUS LENGTHS AND WIDTHS. THE AAR MECHANICAL DESIGNATION CLASS FOR THESE CARS, AS IDENTIFIED IN THE OFFICIAL RAILWAY EQUIPMENT REGISTER," WILL BE RBL, XL, OR XLI.
- BB. THE USE OF LOAD DIVIDER EQUIPPED CARS WILL ELIMINATE THE NEED FOR CENTER GATES AND STRUTS, AND GATE HOLD DOWNS (WHEN APPLICABLE) WHICH ARE REQUIRED IN CONVENTIONAL BEXT CAR LOADS. THIS WILL ACCOUNT FOR A CONSIDERABLE SAVING IN MATERIAL AND LABOR COSTS. THEREFORE, EVERY EFFORT SHOULD BE MADE TO ACQUIRE CUSHIONED CARS EQUIPPED WITH LOAD DIVIDERS FOR SHIPMENT OF PROPELLING CHARGES, NOTICE: ONLY CUSHIONED CARS THAT HAVE SLIDING CENTER SILL TYPE CUSHIONING DEVICES OR END-OF-CAR TYPE DEVICES WHICH HAVE AT LEAST FIFTEEN INCHES (15") OF TRAVEL ARE ACCEPTABLE.
- CC. IF NAILING TO A CAR SIDEWALL IS NOT REQUIRED, BOX CARS EQUIPPED WITH ADJUSTABLE SIDE FILLERS THAT HAVE 3/8" OR THICKER PANELS MAY BE USED. HOWEVER, THESE SIDE FILLERS MUST NOT BE USED FOR LATERAL BLOCKING; THEY MUST BE RETRACTED AND LOCKED AGAINST THE CAR SIDEWALL. A "FILL PIECE" MUST BE INSTALLED IN THE VOID BETWEEN THE CAR SIDEWALL AND THE SIDE FILLER PANEL. SEE THE "TYPICAL TYPE A" VIEW ON PAGE 130 FOR GUIDANCE. IF THE BACK OF THE SIDE FILLER PANELS ARE REINFORCED WITH VERTICAL AND HORIZONTAL STEEL MEMBERS AS SHOWN IN THE "TYPICAL TYPE B" VIEW ON PAGE 130, THE "FILL PIECE" MATERIAL IS NOT REQUIRED.
- DD. NOTICE: AFTER THE LOAD DIVIDER BULKHEADS ARE POSITIONED AGAINST THE LADING, AND THE LOCKING PINS ARE ENGAGED IN THE HOLES OF THE RAILS, THE LOWER LOCKING PINS MUST BE INSPECTED TO ENSURE THAT THE PINS ARE FULLY ENGAGED IN THE LOCKING HOLES. IF THE PINS ARE NOT FULLY SEATED IN THE LOCKING HOLES, THE LINKAGE MECHANISM WILL BE ADJUSTED AS REQUIRED SO THAT THE PINS WILL BE FULLY SEATED INTO THE LOCKING HOLES OF THE LOWER RAILS. IF PRESENT, DEBRIS MUST BE REMOVED FROM BENEATH THE LOCKING HOLES WHICH HAVE BEEN SELECTED FOR SECURING A LOAD DIVIDER BULKHEAD.
- EE. A "STRUT ASSEMBLY" MUST BE INSTALLED BETWEEN THE LOAD DIVIDER BULKHEADS IF THE CAR CONTAINS CLASS A OR CLASS B EXPLOSIVES AND THE LOAD IN EITHER END OF THE CAR WEIGHS 50,000 POUNDS OR MORE. A STRUT ASSEMBLY IS NOT REQUIRED FOR LOADS OF CLASS C EXPLOSIVES. NOTE THAT THE STRUT ASSEMBLY MAY BE OMITTED FROM LOADS OF CLASS A OR B EXPLOSIVES WEIGHING 50,000 POUNDS WHEN THE LADING AND ADEQUATE BLOCKING AND BRACING ARE POSITIONED TO COMPLETELY FILL THE SPACE BETWEEN THE INSTALLED BULKHEADS AS SPECIFIED IN GENERAL NOTE "FF-3" AT RIGHT, DETAILS OF STRUT ASSEMBLIES FOR USE BETWEEN 2-PIECE BULKHEADS AND BETWEEN 1-PIECE BULKHEADS ARE SHOWN ON PAGE 129.

(CONTINUED AT RIGHT)


(GENERAL NOTES CONTINUED)

- FF. THE NORMAL LOADING PATTERN IN CARS EQUIPPED WITH LOAD DIVIDER BULKHEADS IS TO POSITION THE LADING BETWEEN A CAR END WALL AND A LOAD DIVIDER BULKHEAD IN FULL LAYERS. OBVIOUSLY, A LOAD QUANTITY MUST THEN BE A MULTIPLE OF THE NUMBER OF PALLETIZED UNITS WHICH ARE IN ONE LOAD UNIT. A LOAD UNIT IS DEFINED AS A STACK OF CONTAINERS WHICH IS FULL CAR WIDTH BY FULL LOAD HEIGHT BY ONE UNIT IN LENGTH. IF THE QUANTITY TO BE SHIPPED CANNOT BE ATTAINED BY ADJUSTING THE NUMBER OF TIERS IN ONE OR BOTH ENDS OF A CAR, OR BY ADJUSTING THE NUMBER OF LOAD UNITS IN EITHER END OF THE CAR, ONE OF THE FOLLOWING PROCEDURES MUST BE USED IN ORDER TO OBTAIN THE DESIRED QUANTITY.
 - ONE OR MORE RISERS CAN BE POSITIONED WITHIN A LOAD TO IN-CREASE A LOAD QUANTITY. SEE THE RISER PROCEDURES AND DETAILS ON PAGE 102 THRU 105.
 - THE "GATES AND STRUTS" METHOD OF OMITTING A PALLET UNIT MAY BE USED TO ADJUST A LOAD QUANTITY DOWNWARD BY OTHER THAN A MULTIPLE OF A LOAD UNIT, SEE THE PROCEDURES ON PAGES 96 THRU 101 FOR GUIDANCE.
 - 3. AT LOCATION (S) WHERE K-BRACES MIGHT NORMALLY BE USED IN A LOAD IN A CONVENTIONAL CAR, LOAD DIVIDER BULKHEADS CAN BE POSITIONED. LOADING CAN THEN CONTINUE TOWARD THE CENTER OF THE CAR FROM EACH INSTALLED LOAD DIVIDER BULKHEAD, IN EVEN LAYERS WHICH ARE ONE OR MORE LESS IN HEIGHT THAN THE LOAD IN THE ENDS OF THE CAR. INSTALL CENTER GATES, STRUTS AND GATE HOLD DOWNS AS SHOWN IN THE APPLICABLE CONVENTIONAL BOX CAR DRAWING HEREIN, TO PROVIDE FOR A TIGHT LOAD BETWEEN THE BULKHEADS.
 - 4. ONE OR MORE UNITS CAN BE POSITIONED IN CONTACT WITH A LOAD DIVIDER BULKHEAD ON THE CENTER-OF-CAR SIDE. BLOCK AND BRACE WITH LCL BRACES AS SHOWN ON PAGE 116, OR WITH KNEE BRACE ASSEMBLIES, AS SHOWN ON PAGE 112.
- GG. FOR ADDITIONAL GUIDANCE, ATTENTION IS DIRECTED TO THE "SPECIAL NOTES" SECTIONS WHICH ARE IMMEDIATELY ADJACENT TO THE DEPICTED OUTLOADING METHODS.




ALTERNATED CONTAINERS UNIT (BASIC HEIGHT)

REFER TO PAGES 6 THRU 15 FOR OUTLOADING PROCEDURES.




ALTERNATED CONTAINERS UNIT (INCREASED HEIGHT)

REFER TO PAGES 20 THRU 29 FOR OUTLOADING PROCEDURES.



FLAT DUNNAGE METHOD UNIT (BASIC HEIGHT)


REFER TO PAGES 34 THRU 43 FOR OUTLOADING PROCEDURES.



FLAT DUNNAGE METHOD UNIT (DECREASED HEIGHT)

REFER TO PAGES 48 THRU 57 FOR CUTLOADING PROCEDURES.


PALLET UNIT DETAILS



ROUTED DUNNAGE METHOD UNIT (BASIC HEIGHT)


CONTAINER ----- 16 EACH @ 121 LBS (APPROX)
CUBE ----------- 65.4 CUBIC FEET (APPROX)
GROSS WEIGHT ---- 2,122 LBS (APPROX)


REFER TO PAGES 62 THRU 71 FOR OUTLOADING PROCEDURES.



ROUTED DUNNAGE METHOD UNIT (DECREASED HEIGHT)

REFER TO PAGES 76 THRU 85 FOR OUTLOADING PROCEDURES.





- 9. THE DEPICTED LOAD CAN BE REDUCED TO SUIT THE QUANTITY TO BE SHIPPED. THE LOAD CAN BE REDUCED BY ONE OR TWO PALLET UNITS BY EMPLOYING THE PROCEDURES ON PAGE 96. THREE (3) PALLET UNITS CAN BE OMITTED FROM 3-TIER LOAD BY LEAVING OUT THE CROSSWISE STACK NO. 9 AND THE ADJACENT CRIB FILL. NOTE THAT STRUT BRACING MUST BE APPLIED TO THE STRUTS, PIECES MARKED (1), AND AN ADDITIONAL PIECE MARKED (2) WILL BE REQUIRED FOR THE OTHER CENTER GATE MARKED (3). OR, THE ENTIRE ONE OR TWO TOP TIERS ABE OMITTED. A PARTIAL 1-TIER LOAD CAN BE SHIPPED IN ONE OR BOTH ENDS OF A CAR BY USING KNEE BRACES AS SHOWN ON PAGES 112 AND 113.
- 10. IF PALLETIZED UNITS WHICH DO NOT CONTAIN A FULL QUANTITY OF CONTAINERS ARE TO BE TRANSPORTED, REFER TO PAGE 117 FOR SHIPPING GUIDANCE FOR LENGTHWISE UNITS AND PAGES 118 AND 120 FOR CROSSWISE UNITS.
- 11. FOR SHIPMENT OF ONE OR MORE LEFTOVER CONTAINERS, SEE THE PROCEDURES FOR SHIPMENT OF LEFTOVER CONTAINERS." ON PAGE 119 FOR GUIDANCE.

BILL OF MATERIAL		
LUMBER	LINEAR FEET	BOARD FEET
1" X 4"	132	44
1" X 6"	300	150
2" X 2"	68	23
2" X 3"	42	21
2" X 4"	1113	742
2" X 6"	190	190
4" X 4"	94	126
NAILS	NO. REQD	POUNDS
6d (2*)	252	1-1/2
10d (3")	1846	28-1/2
12d (3-1/4")	46	1
16d (3-1/2")	128	3

SPECIAL NOTES:

- A 60'-8" LONG BY 9'-2" WIDE WOOD-LINED CONVENTIONAL TYPE BOX CAR EQUIPPED WITH 10'-0" WIDE DOOR OPENINGS IS SHOWN, CARS OF OTHER DIMENSIONS AND CARS HAVING WIDER OR NARROWER DOOR OPENINGS CAN BE USED, SEE GENERAL NOTE "D" ON PAGE 2.
- 2. THE PALLET UNIT SHOWN IN THE TYPICAL LOAD ON PAGE 6 IS THE ALTERNATED CONTAINERS UNIT (BASIC HEIGHT). A MAXIMUM OF SEVENTY-TWO (72) OF THESE UNITS, FOR AN APPROXIMATE LADING WEIGHT OF 117,792 POUNDS. CAN BE PLACED IN A 50'-6" LONG CAR WHEN USING THE DEPICTED PROCEDURES; FIFTY-SEVEN (57) UNITS, FOR A LADING WEIGHT OF 93,252 POUNDS, CAN BE OUTLOADED IN A 40'-6" LONG CAR.
- THE "HIGH" CRIB, SHOWN AS PIECE MARKED (1), MUST BE INSTALLED IN EACH END OF THE LOAD. FOUR (4) ASSEMBLIES ARE REQUIRED IN EACH END OF A LOAD REGARDLESS OF THE CAR LENGTH.
- 4. THE SEPARATOR GATES, SHOWN AS PIECES MARKED ② IN THE LOAD ON PAGE 6, ARE DESIGNATED "RIGHT HAND" AND "LEFT HAND" TO FACILITATE POSITIONING OF THE PALLET UNITS AS LOADING PROGRESSES. WHEN LOADING THE CAR, POSITION A PALLET UNIT STACK AGAINST THE END WALL, THEN POSITION A SEPARATOR GATE SO THE 1" X 4" TIE PIECES ARE LOCATED UNDER THE "OVERHANG" OF THE BOITOM AND TOP PALLET UNITS IN THE FIRST STACK. REPEAT THIS PROCEDURE FOR THE REMAINING STACKS.
- 5. ALL SEPARATOR GATES, PIECES MARKED ②, WHICH ARE WITHIN THE DOORWAY AREA OF A CAR EQUIPPED WITH CONVENTIONAL SLIDING DOORS MUST BE WIRE TIED TO THE ADJACENT CRIB FILL TO PREVENT DISPLACEMENT. ENCIRCLE THE STOP PIECE OF THE SEPARATOR GATE AND THE UPPER HORIZONTAL PIECE OF THE CRIB FILL WITH NO. 14 GAGE WIRE AND TWIST TAUT.
- 6. SEPARATOR GATES MAY BE FORMED FROM 3/8" OR THICKER PLYWOOD IN LIEU OF DIMENSIONAL LUMBER, IF DESIRED, FOR ONE OR TWO-LAYER LOADS; PLYWOOD SEPARATOR GATES FOR A 3-LAYER LOAD ARE NOT ECONOMICALLY FEASIBLE. CONSTRUCT EACH SEPARATOR GATE FOR ONE OR TWO-HIGH LOADS FROM 40-3/4" WIDE PLYWOOD OF AN APPROPRIATE LENGTH.
- 7. CENTER GATES "A" AND "B" MAY BE PARTIALLY FORMED FROM 1/2" OR THICKER PLYWOOD, IF DESIRED. PLYWOOD MAY BE USED IN LIEU OF THE 2"X 6" HORIZONTAL PIECES. SEE THE "PLYWOOD CENTER GATE ALTERNATIVE" DETAIL ON PAGE 123 FCR GUIDANCE.
- DOORWAY PROTECTION IS REQUIRED FOR ALL PALLET UNIT STACKS WHICH ARE COMPLETELY WITHIN THE DOORWAY AREA OR WHICH EXTENDS INTO THE DOORWAY AREA BY ONE-HALF OR MORE OF THE STACK WIDTH OR LENGTH. THE WOODEN GATE TYPE OF DOORWAY PROTECTION, SHOWN AS PIECES MARKED (1) AND (2) IN THE LOAD ON PAGE 6, IS APPLICABLE FOR BOX CARS EQUIPPED WITH CONVENTIONAL SLIDING DOORS AND NAILABLE DOOR POSTS, REFER TO PAGES 126 THRU 128 FOR ALTERNATIVE DOORWAY PROTECTION FOR CARS EQUIPPED WITH CONVENTIONAL SLIDING DOORS. IF THE CAR BEING LOADED IS EQUIPPED WITH PLUG TYPE DOORS, NAILED FLOORLINE BLOCKING AND LOAD-BUNDLING STRAPS MUST BE USED. SEE THE "ALTERNATIVE DOOR PROTECTION F" AND "ALTERNATIVE DOORWAY PROTECTION F" DETAILS ON PAGE 128 FOR GUIDANCE, A COMBINATION OF THE TWO METHCOS MUST BE USED. NAILED SIDE BLOCKING WILL BE USED UNDER THE CRIB FILL SHOWN IN THE DOORWAY AREA OF THE LOAD. POSITION DOUBLED 2" X 4" X 7"-0" PIECES (APPROXIMATELY 52" FROM THE NEAR SIDE CAR WALL) SC AS TO BE AGAINST THE CROSSWISE STACKS NUMBERED 8 AND 9. THESE PIECES WILL BE USED IN LIEU OF THE 40" AND 48" LONG PIECES SHOWN BY THE ALTERNATIVE DETAILS. A SPACER ASSEMBLY, AS SHOWN IN THE "ALTERNATIVE DOORWAY PROTECTION F" DETAIL, MUST BE MODIFIED FOR USE BY CHANGING THE END WHICH EXTENDS OVER THE CROSSWISE CONTAINERS TO BE LIKE THE NEAR END OF THE STRAPPING BOARD SHOWN IN THE "ALTERNATIVE DOORWAY PROTECTION F" DETAIL, MUST BE MODIFIED FOR USE BY CHANGING THE END WHICH EXTENDS OVER THE CROSSWISE CONTAINERS TO BE LIKE THE NEAR END OF THE STRAPPING BOARD SHOWN IN THE "ALTERNATIVE DOORWAY PROTECTION F" DETAIL, MUST BE MODIFIED FOR USE BY CHANGING THE END WHICH EXTENDS OVER THE CROSSWISE CONTAINERS TO BE LIKE THE NEAR END OF THE STRAPPING BOARD SHOWN IN THE "ALTERNATIVE DOORWAY PROTECTION F" DETAIL, MUST BE MODIFIED FOR USE DOT THE CRIB FILL, PIECES MARKED (3), MUST HAVE THREE INCHES (3") CUT OFF THE BOTTOM END OF ONE SIDE SO THE CRIB WILL REST EVENLY ON THE NAILED SIDE BLOCKING WHICH IS ADJACENT TO THE LENGTHWISE UNITS. ALSO NOTE THAT THE CENTER GATES "A" MUST BE


(CONTINUED AT LEFT)

LOAD AS SHOWN

ITEM	QUANTITY	WEI	<u>GHT</u>	(APPROX)
PALLET UNIT	87	142,332	LBS	
DUNNAGE		2,626	LBS	
TOI	AL WEIGHT	144,958	LBS	

ALTERNATED CONTAINERS UNIT (BASIC HEIGHT)

87-UNIT LOAD IN A 60'-8" LONG BY 9'-2" WIDE CONVENTIONAL BOX CAR



- 12. DOORWAY PROTECTION IS REQUIRED FOR ALL PALLET UNIT STACKS WHICH ARE COMPLETELY WITHIN THE DOORWAY AREA OR WHICH EXTEND INTO THE DOORWAY AREA BY ONE-HALF OR MORE OF THE STACK WIDTH. THE WOODEN GATE TYPE OF DOORWAY PROTECTION, SHOWN AS PIECES MARKED (2) IN THE LOAD ON PAGE 8, IS APPLICABLE FOR BOXCARS EQUIPPED WITH CONVENTIONAL SLIDING DOORS AND NAILABLE DOOR POSTS. REFER TO PAGES 126 THRU 128 FOR ALTERNATIVE DOORWAY PROTECTION FOR CARS EQUIPPED WITH CONVENTIONAL SLIDING DOORS, IF THE CAR BEING LOADED IS EQUIPPED WITH PLUG TYPE DOORS, NAILED FLOORLINE BLOCKING AND LOAD BUNDLING STRAPS MUST BE USED. SEE THE "ALTERNATIVE DOORWAY PROTECTION F" DETAIL ON PAGE 128 FOR GUIDANCE. SEE SPECIAL NOTE 13.
- 13. IF THE "ALTERNATIVE DOORWAY PROTECTION F" PROCEDURES SHOWN ON PAGE 128 ARE USED IN LIEU OF THE WOODEN DOORWAY PROTECTION, PIECES MARKED ②, THE CENTER GATES MUST BE RESTRAINED FROM LATERAL MOVEMENT. THIS CAN BE ACCOMPLISHED BY NAILING TO THE CAR FLOOR A DOUBLED 2" X 4" X 18" PIECE POSITIONED LONGITUDINALLY SO AS TO BE CENTERED AGAINST THE FILL PIECE OF A CENTER GATE. TWO (2) PIECES WILL BE REQUIRED FOR EACH CENTER GATE WHICH IS IN THE DOOR OPENING OR WITHIN SIX INCHES (6") OF BEING IN THE OPENING.
- 14. THE DEPICTED LOAD CAN BE REDUCED TO SUIT THE QUANTITY TO BE SHIPPED. A 3-TIER LOAD CAN BE REDUCED BY A MULTIPLE OF SIX (6) PALLET UNITS, A 2-TIER LOAD CAN BE REDUCED BY A MULTIPLE OF FOUR (4) UNITS, OR A 1-TIER LOAD CAN BE REDUCED BY A MULTIPLE OF TWO (2) UNITS BY OMITTING ONE OR MORE LOAD UNITS FROM THE CENTER PORTION OF THE LOAD. OR, THE ENTIRE ONE OR TWO TOP TIERS CAN BE OMITTED. FOR OTHER METHODS OF REDUCING A LOAD, AND FOR TYPICAL LCL PROCEDURES, REFER TO PAGES 92 THRU 120 FOR GUIDANCE.
- 15. IF PALLET UNITS WHICH DO NOT CONTAIN A FULL QUANTITY OF CONTAINERS ARE TO BE TRANSPORTED, REFER TO PAGE 117 FOR SHIPPING GUIDANCE.
- FOR SHIPMENT OF ONE OR MORE LEFTOVER CONTAINERS, SEE THE "PROCEDURES FOR SHIPMENT OF LEFTOVER CONTAINERS" ON PAGE 119 FOR GUIDANCE.


BILL OF MATERIAL LUMBER LINEAR FEET BOARD FEET 1" X 4" 1" X 6" 480 95 240 2" X 2" 32 2" X 3" 33 17 526 351 2" X 6" 196 100 134 NO. REQD POUNDS 6d (2") 324 104 (3") 12d (3-1/4") 16d (3-1/2") 2-1/4 36' REQD WIRE, NO. 14 GAGE -

SPECIAL NOTES:

- A 60'-8" LONG BY 9'-2" WIDE WOOD-LINED CONVENTIONAL TYPE BOXCAR EQUIPPED WITH 10'-0" WIDE DOOR OPENINGS IS SHOWN. CARS OF OTHER DIMENSIONS AND CARS HAVING WIDER OR NARROWER DOOR OPENINGS CAN BE USED. SEE GENERAL NOTE "D" ON PAGE 2 AND SPECIAL NOTE 3 BELOW.
- 2. THE PALLET UNIT SHOWN IN THE TYPICAL LOAD ON PAGE 8 IS THE ALTERNATED CONTAINERS UNIT (BASIC HEIGHT). A MAXIMUM OF SOLTY (60) OF THESE UNITS, FOR AN APPROXIMATE LADING WEIGHT OF 98,160 POUNDS, CAN BE PLACED IN A 501-6" LONG CAR WHEN USING THE DEPICTED PROCEDURES; FORTY-EIGHT (48) UNITS, FOR AN APPROXIMATE LADING WEIGHT OF 78,528 POUNDS, CAN BE OUTLOADED IN A 40'-6" LONG CAR.
- 3. THE DEPICTED LOADING PATTERN IS A DEQUATE FOR CARS HAVING DOOR OPENINGS BY THRU 101 OR WIDER. IF THE CAR TO BE LCADED HAS DOOR OPENINGS LESS THAN B'-0" WIDE AND NOT OF SUFFICIENT HEIGHT TO ALLOW PERSONNEL TO EXIT THE CAR OVER THE TOP OF THE LOAD WHEN NECESSARY, THE PALLETS SHOULD BE POSITIONED SC THERE ARE SIX (6) LOAD UNITS IN EACH END. NOTE THAT ALTHOUGH CARS HAVING DOOR OPENINGS AS NARROW AS 6'-0" WIDE CAN BE USED FOR FULL LOADS, LOADING IS PROGRESSIVELY MORE DIFFICULT AS THE WIDTH OF THE DOOR OPENING DECREASES.
- 4. IF THE "ALTERNATIVE DOORWAY PROTECTION F" PROCEDURES AS SHOWN ON PAGE 128 ARE USED IN LIEU OF THE WOODEN DOOR GATE TYPE PROTECTION, PIECE MARKED (3), NAILED FLOCALINE BLOCKING MUST BE USED IN LIEU OF EACH LOWER ANTI-SWAY BRACE IN THE DOORWAY AREA. NAILED BLOCKING IS REQUIRED FOR ALL PALLET STACKS WHICH ARE COMPLETELY WITHIN THE DOORWAY AREA OR WHICH EXTEND INTO THE DOORWAY AREA BY ONE-HALF OR MORE OF THE STACK WIDTH ON EITHER SIDE OF THE CAR. SEE SPECIAL NOTE 12.
- 5. TOP-OF-LOAD ANTI-SWAY BRACES, SHOWN AS PIECES MARKED ② IN THE LOAD ON PAGE 8, MUST BE INSTALLED IN EACH END OF THE CAR AND WIRE TIED TO A UNITIZING STRAP WITH NO. 14 GAGE WIRE AS TYPICALLY SHOWN BY THE "TIE WIRE APPLICATION A" DETAIL ON PAGE 122. THREE (3) BRACES ARE REQUIRED IN EACH END OF A LOAD REGARDLESS OF THE CAR LENGTH.
- 6. TO FACILITATE POSITIONING OF THE PALLET UNITS AS LOADING PROGRESSES, POSITION PALLET UNIT STACKS AGAINST THE END WALL, THEN POSITION A SEPARATOR GATE, SHOWN AS PIECE MARKED (3), SO THE 1"X 4" TIE PIECES ARE LOCATED UNDER THE "CVERHANG" OF THE PALLET UNITS. REPEAT THIS PROCEDURE FOR THE REMAINING STACKS.
- SEPARATOR GATES IN THE DOORWAY MUST BE PREVENTED FROM SHIFTING INTO A DOOR OPENING BY THE APPLICATION OF THE STOP PIECES, PIECES MARKED (4). IN CARS EQUIPPED WITH STAGGERED DOORS, STOP PIECES MAY BE REQUIRED ON UP TO FOUR SEPARATOR GATES.
- 8. SEPARATOR GATES MAY BE FORMED FROM 3/8" OR THICKER PLYWOOD IN LIEU OF DIMENSIONAL LUMBER, IF DESIRED, FOR ONE OR TWO-LAYER LOADS; PLYWOOD SEPARATOR GATES FOR A 3-LAYER LOAD ARE NOT ECONOMICALLY FEASIBLE. SEE THE "ALTERNATIVE SEPARATOR GATE" DETAIL ON PAGE 122 FOR CONSTRUCTION GUIDANCE.
- CENTER GATE "C" MAY BE PARTIALLY FORMED FROM 1/2" OR THICKER PLYWOOD, IF DESIRED. PLYWOOD MAY BE USED IN LIEU OF THE 2" X 6" HORIZONTAL PIECES. SEE THE "PLYWOOD CENTER GATE ALTERNA-TIVE" DETAIL ON PAGE 123 FOR GUIDANCE.
- 10. FOR EASE OF HANDLING, SPLIT CENTER GATES, WHICH ARE NOT DEPENDENT UPON THE WIDTH OF THE CAR, MAY BE USED AS AN ALTERNATIVE TO THE CAR-WIDTH GATES. IN LIEU OF EACH "CENTER GATE C", SHOWN AS PIECE MARKED (3) IN THE LOAD ON PAGE 8, INSTALL TWO (2) "CENTER GATES A" AS SHOWN ON PAGE 16. AFTER THE SPLIT GATES AND STRUTS HAVE BEEN INSTALLED, THE SPLIT GATES MUST BE TIED TOGETHER AS DEPICTED BY THE "TIE PIECE APPLICATION" DETAIL ON PAGE 123. OMIT THE STOP PIECES FROM CENTER GATE A"
- DOOR SPANNER TYPE GATE HOLD DOWN MAY BE USED IN LIEU OF THE DOUBLED 2" X 4" MATERIAL NAILED TO CENTER GATE C, PROVIDING THE CAR BEING LOADED HAS NAILABLE SIDEWALLS. SEE THE DETAILS ON PAGE 125 FOR GUIDANCE.

(CONTINUED AT LEFT)

ALTERNATED CONTAINERS UNIT (BASIC HEIGHT)
72-UNIT LOAD IN A 60'-8' LONG BY 9'-2' WIDE CONVENTIONAL BOX CAR



- 1. A 50'-6" LONG BY 9'-4" WIDE WOOD-LINED CONVENTIONAL TYPE BOXCAR EQUIPPED WITH 8'-0" WIDE DOOR OPENINGS IS SHOWN, WIDER CARS OF OTHER LENGTHS AND CARS HAVING WIDER OR NARROWER DOOR OPENINGS CAN BE USED, SEE GENERAL NOTE "D" ON PAGE 2 AND SPECIAL NOTE 3 BELOW.
- 2. THE PALLET UNIT SHOWN IN THE TYPICAL LOAD ON PAGE 10 IS THE ALTERNATED CONTAINERS UNIT (BASIC HEIGHT), A MAXIMUM CF SIXTY-SIX (66) OF THESE UNITS, FOR AN APPROXIMATE LADING WEIGHT OF 107,976 POUNDS, CAN BE PLACED IN A 40'-6" LONG CAR WHEN USING THE DEPICTED PROCEDURES. IF A 60'-8" LONG BY 9"-4" OR WIDER CAR IS AVAILABLE, ONE HUNDRED AND TWO (102) PALLET UNITS FOR AN APPROXIMATE LADING WEIGHT OF 165,236 POUNDS CAN BE LOADED, LOAD LIMIT OF THE CAR PERMITTING.
- 3. THE DEPICTED LOADING PATTERN IS ADEQUATE FOR CARS HAVING DOOR OPENINGS 8" OR WIDER. IF THE CAR TO BE LOADED HAS DOOR OPENINGS LESS THAN 8"-0" WIDE AND NOT OF SUFFICIENT HEIGHT TO ALLOW PERSONNEL TO EXIT THE CAR OVER THE TOP OF THE LOAD WHEN NECESSARY, THE PALLETS SHOULD BE POSITIONED SO THERE ARE SEVEN (7) LOAD UNITS IN EACH END. NOTE THAT ALTHOUGH CARS HAVING DOOR OPENINGS AS NARROW AS 6"-0" WIDE CAN BE USED FOR FULL LOADS, LOADING IS PROGRESSIVED MORE DIFFICULT AS THE WIDTH OF THE DOOR OPENING DECREASES.
- ANTI-SWAY BRACING BETWEEN LATERALLY ADJACENT ROWS OF PALLET UNITS IS NOT REQUIRED REGARDLESS OF THE WIDTH OF THE CAR BEING LOADED.
- CENTER GATE "D" MAY BE PARTIALLY FORMED FROM 1/2" OR THICKER PLYWOOD, IF DESIRED, PLYWOOD MAY BE USED IN LIEU OF THE 2" X 6" HORIZONTAL PIECES. SEE THE "PLYWOOD CENTER GATE ALTERNATIVE" DETAIL ON PAGE 123 FOR GUIDANCE.
- 6. FOR EASE OF HANDLING, SPLIT CENTER GATES, WHICH ARE NOT DEPENDENT UPON THE WIDTH OF THE CAR, MAY BE USED AS AN ALTERNATIVE TO THE CAR-WIDTH GATES. IN LIEU OF EACH "CENTER GATE D", SHOWN AS PIECE MARKED [] IN THE LOAD ON PAGE 10, INSTALL TWO (2) "CENTER GATES B" AS SHOWN ON PAGE 17. AFTER THE SPLIT GATES AND STRUTS HAVE BEEN INSTALLED, THE SPLIT GATES MUST BE TIED TOGETHER AS DEPICTED BY THE "TIE PIECE APPLICATION" DETAIL ON PAGE 123.
- DOOR SPANNER TYPE GATE HOLD DOWN MAY BE USED IN LIEU OF THE DOUBLED 2" X 3" HOLD DOWNS ON CENTER GATES "D", PROVIDING THE CAR BEING LOADED HAS NAILABLE SIDEWALLS. SEE THE DETAILS ON PAGE 125 FOR GUIDANCE.
- DOORWAY PROTECTION IS REQUIRED FOR ALL PALLET UNIT STACKS WHICH ARE COMPLETELY WITHIN THE DOORWAY AREA OR WHICH EXTEND INTO THE DOORWAY AREA VONE-HALF OR MORE OF THE STACK LENGTH. THE WOODEN GATE TYPE OF DOORWAY PROTECTION SHOWN AS PIECES MAKED ③ IN THE LOAD ON PAGE 10 IS APPLICABLE FOR BOXCARS EQUIPPED WITH CONVENTIONAL SLIDING DOORS AND NAILABLE DOOR POSTS. REFER TO PAGES 126 THRU 128 FOR ALTERNATIVE DOORWAY PROTECTION FOR CARS EQUIPPED WITH CONVENTIONAL SLIDING DOORS. IF THE CAR BEING LOADED IS EQUIPPED WITH PLUG TYPE DOORS, NAILED FLOORLING BLOCKING AND LOAD BUNDLING STRAPS MUST BE USED. SEE THE "ALTERNATIVE DOORWAY PROTECTION E" DETAIL ON PAGE 128 FOR GUIDANCE.
- 9. THE DEPICTED LOAD CAN BE REDUCED TO SUIT THE QUANTITY TO BE SHIPPED. A 3-TIER LOAD CAN BE REDUCED BY A MULTIPLE OF SIX (6) PALLET UNITS, A 2-TIER LOAD CAN BE REDUCED BY A MULTIPLE OF FOUR (4) UNITS, OR A 1-TIER LOAD CAN BE REDUCED BY A MULTIPLE OF TWO (2) UNITS BY OMITTING ONE OR MORE LOAD UNITS FROM THE CENTER PORTION OF THE LOAD. OR, THE ENTIRE ONE OR TWO TOP TIERS CAN BE OMITTED. FOR OTHER METHODS OF REDUCING A LOAD, AND FOR TYPICAL LCL PROCEDURES, REFER TO PAGES 92 THRU 120 FOR GUIDANCE.
- IF PALLETIZED UNITS WHICH DO NOT CONTAIN A FULL QUANTITY OF CONTAINERS ARE TO BE TRANSPORTED, REFER TO PAGES 118 AND 120 FOR SHIPPING GUIDANCE.
- 11. FOR SHIPMENT OF ONE OR MORE LEFTOVER CONTAINERS, SEE THE
 "PROCEDURES FOR SHIPMENT OF LEFTOVER CONTAINERS" ON
 PAGE 119 FOR GUIDANCE.

LUMBER	LINEAR FEET	BOARD FEET
1" X 6"	96	48
2" X 2" 2" X 3"	112 41	38 21
2" X 4" 2" X 6"	19 215	13 215
4" X 4"	89	119
NAILS	NO. REQD	POUNDS
6d (2")	72	1/2
10d (3") 12d (3-1/4")	420 32	6-1/2

144

3-1/4


16d (3-1/2")

BILL OF MATERIAL

LOAD AS SHOWN

ALTERNATED CONTAINERS UNIT (BASIC HEIGHT)

84-UNIT LOAD IN A 50'-6' LONG BY 9'-4' WIDE CONVENTIONAL BOX CAR




- A 50"-6" LONG BY 9"-0" WIDE (INSIDE CLEARANCE) WOOD-LINED BOX CAR EQUIPPED WITH ADJUSTABLE AND/OR FIXED WALL MEMBERS, AND WITH 10"-0" WIDE DOOR OPENINGS IS SHOWN. CARS OF OTHER DIMENSIONS AND CARS HAVING WIDER OR NARROWER DOOR OPENINGS CAN BE USED. SEE GENERAL NOTE "D" ON PAGE 2.
- THE PALLET UNIT SHOWN IN THE TYPICAL LOAD ON PAGE 12 IS THE ALTERNATED CONTAINERS UNIT (BASIC HEIGHT). A MAXIMUM OF FORTY-FOUR (44) OF THESE UNITS, FOR AN APPROXIMATE LADING WEIGHT OF 71,984 POUNDS, CAN BE PLACED IN A 40"-6" LONG CAR.
- 3. IF A CAR HAS BOWED END WALLS WHICH ARE BOWED OUTWARD TWO INCHES (2") OR MORE EITHER FROM SIDE-TO-SIDE OR FROM FLOOR-TO-ROOF, CROSS MEMBERS CAN BE INSTALLED NEAR THE END WALL OF THE CAR TO PROVIDE A "SQUARED END" RATHER THAN INSTALLING DUNNAGE AS SPECIFIED IN GENERAL NOTE "G" ON PAGE 2. THESE CROSS MEMBERS SHOULD BE INSTALLED AT THE SAME HEIGHTS AS THE CROSS MEMBERS USED THROUGHOUT THE LOAD AS BLOCKING MEMBERS. A SEPARATOR GATE SHOWN AS PIECE MARKED (4), MUST BE POSITIONED AGAINST THESE CROSS MEMBERS PRIOR TO LOADING.
- 4. TOP-OF-LOAD ANTI-SWAY BRACES, SHOWN AS PIECES MARKED (3) IN THE LOAD ON PAGE 12, MUST BE INSTALLED IN EACH END OF THE CAR AND WIRE TIED TO A UNITIZING STRAP WITH NO. 14 GAGE WIRE AS TYPICALLY SHOWN BY THE "TIE WIRE APPLICATION A" DETAIL ON PAGE 122. THREE (3) BRACES ARE REQUIRED IN EACH END OF A LOAD REGARDLESS OF THE CAR LENGTH.
- 5. TO FACILITATE POSITIONING OF THE PALLET UNITS AS LOADING PROGRESSES, POSITION PALLET UNIT STACKS AGAINST THE END WALL, THEN POSITION A SEPARATOR GATE SHOWN AS PIECES MARKED (4) SO THE 1" X 4" TIE PIECES ARE LOCATED UNDER THE "OVERHANG" OF THE BOTTOM AND TOP PALLET UNITS. REPEAT THIS PROCEDURE FOR THE REMAINING STACKS.
- 6. SEPARATOR GATES IN THE DOORWAY MUST BE PREVENTED FROM SHIFTING INTO A DOOR OPENING BY THE APPLICATION OF THE STOP PIECES, PIECES MARKED (7) IN CARS EQUIPPED WITH STAGGERED DOORS, STOP PIECES MAY BE REQUIRED ON UP TO FOUR SEPARATOR GATES.
- 7. SEPARATOR GATES MAY BE FORMED FROM 3/8" OR THICKER PLYWOOD IN LIEU OF DIMENSIONAL LUMBER, IF DESIRED, FOR ONE OR TWO-LAYER LOADS; PLYWOOD SEPARATOR GATES FOR A3-LAYER LOAD ARE NOT ECONOMICALLY FEASIBLE. SEE THE "ALTERNATIVE SEPARATOR GATE" DETAIL ON PAGE 122 FOR CONSTRUCTION GUIDANCE.
- IF THE CAR BEING LOADED IS EQUIPPED WITH AT LEAST TWELVE (12) DOORWAY MEMBERS, AN ADDITIONAL FOUR PALLET UNITS CAN BE LOADED IN THE DOORWAY AREA.
- 9. THE DEPICTED LOAD CAN BE REDUCED TO SUIT THE QUANTITY TO BE SHIPPED. A LOAD MAY BE REDUCED BY MULTIPLES OF TWO (2) PALLET UNITS BY OMITTING LATERALLY ADJACENT UNITS FROM THE TOP ONE OR TWO LAYERS OF ONE OR MORE LOAD UNITS, OR BY MULTIPLES OF SIX (6) PALLET UNITS BY OMITTING ONE OR MORE ENTIRE LOAD UNITS. TO REDUCE A LOAD BY ONE (1) PALLET UNIT, REFER TO THE LCL PROCEDURES ON PAGES 90 AND 91 FOR GUIDANCE.
- FOR SHIPMENT OF ONE OR MORE LEFTOVER CONTAINERS, SEE THE "PROCEDURES FOR SHIPMENT OF LEFTOVER CONTAINERS" ON PAGE 119 FOR GUIDANC E.

LUMBER	LINEAR FEET	BOARD FEET
1" X 4"	248	83
1" X 6"	432	216
2" X 4"	399	266
NAILS	NO. REQD	POUNDS
6d (2")	336	2
10d (3")	336	5-1/4
12d (3-1/4")	30	1/2

LOAD AS SHOWN

ALTERNATED CONTAINERS UNIT (BASIC HEIGHT)
56-UNIT LOAD IN A 50'-6' LONG BY 9-0' WIDE BOX CAR EQUIPPED WITH MECHANICAL BRACING DEVICES



- 10. THE DEPICTED LOAD CAN BE REDUCED TO SUIT THE QUANTITY TO BE SHIPPED.

 A 3-TIER LOAD CAN BE REDUCED BY A MULTIPLE OF SIX (6) PALLET UNITS, OR

 A 2-TIER LOAD CAN BE REDUCED BY A MULTIPLE OF FOUR (4) UNITS, OR A

 1-TIER LOAD CAN BE REDUCED BY A MULTIPLE OF TWO (2) UNITS BY OMITTING

 ONE OR MORE LOAD UNITS FROM THE CENTER PORTION OF THE LOAD. OR,

 THE ENTIRE ONE OR TWO TOP TIERS CAN BE OMITTED. FOR OTHER METHODS OF

 REDUCING A LOAD, AND FOR TYPICAL LCI PROCEDURES, REFER TO PAGES 94

 THRU 105 AND GENERAL NOTE **FF* ON PAGES 3 FOR GUIDANSE.
- IF PALLET UNITS WHICH DO NOT CONTAIN A FULL QUANTITY OF CONTAINERS ARE TO BE TRANSPORTED, REFER TO PAGE 117 AND/OR PAGES 118 AND 120 FOR SHIPPING GUIDANCE.
- 12. FOR SHIPMENT OF ONE OR MORE LEFTOVER CONTAINERS, SEE THE "PROCEDURES FOR SHIPMENT OF LEFTOVER CONTAINERS" ON PAGE 119 FOR GUIDANCE.

LUMBER	LINEAR FEET	BOARD FEET
1" X 4"	209	70
1" X 6"	480	240
2" X 3"	35	18
2" X 4"	435	290
NAILS	NO. REQD	POUNDS
6d (2")	336	2
10d (3")	360	5-3/4
12d (3-1/4*)	66	1-1/4

SPECIAL NOTES:

- A 50'-6" LONG BY 9'-2" WIDE WOOD-LINED CUSHICNED BCX CAR EQUIPPED WITH LOAD DIVIDER BUILKHEADS AND WITH 10'-0" WIDE DOOR OPENINGS IS SHOWN, CARS OF CTHER DIMENSIONS AND CARS HAVING NARROWER OR WIDER DOOR OPENINGS CAN BE USED. SEE GENERAL NCTES "AA" THRU "EE" ON PAGE 3.
- 2. THE PALLET UNIT SHOWN IN THE TYPICAL LOAD ON PAGE 14 IS THE ALTERNATED CONTAINERS UNIT (BASIC HEIGHT). A MAXIMUM OF SEVENTY-TWO (72) OF THESE UNITS, FOR AN APPROXIMATE LADING WEIGHT OF 117,792 POUNDS, CAN BE PLACED IN A 60'-8" LONG CAR, OR A MAXIMUM OF FORTY-EIGHT (48) UNITS CAN BE LOADED IN A 40'-6" CAR FOR AN APPROXIMATE LADING WEIGHT OF 78,528 POUNDS, WHEN USING THE DEPICTED PROCEDURES. IF CARS 9'-4" OR WIDER ARE AVAILABLE, THE CROSSWISE LOADING PATTERN SHOWN ON PAGE 10 MAY BE EMPLOYED. THEN, NINETY-SIX (96) PALLET UNITS FOR AN APPROXIMATE LADING WEIGHT OF 157,056 POUNDS CAN BE PLACED IN A 60'-8" LONG CAR, SEVENTY-EIGHT (78) UNITS CAN BE LOADED IN A 50'-6" LONG CAR FOR AN APPROXIMATE LADING WEIGHT OF 127,608 POUNDS, AND SIXTY (60) UNITS CAN BE LOADED IN A 40'-8" LONG CAR FOR AN APPROXIMATE LADING
- WEIGHT OF 127,608 POUNDS, AND SIXTY (80) UNITS CAN BE LOADED IN A 40'-6" LONG CAR FOR AN APPROXIMATE LADING WEIGHT OF 98,160 POUNDS.


 3. IF THE "ALTERNATIVE DOCRWAY PROTECTION F" PROCEDURES AS SHOWN ON PAGE 128 ARE USED IN LIEU OF THE WOODEN DOOR GATE TYPE PROTECTION, PIECE MARKED (3), NAILED FLOORLINE BLOCKING MUST BE USED IN LIEU OF THE LOWER ANTI-SWAY BRACES IN THE DOCRWAY AREA. NAILED BLOCKING IS REQUIRED FOR ALL PALLET STACKS WHICH ARE COMPLETELY WITHIN THE DOCRWAY AREA OR WHICH EXTEND INTO THE DOCRWAY AREA BY ONE-HALF OR MORE OF THE STACK WIDTH ON EITHER SIDE OF THE CAR.
- 4. TOP-OF-LOAD ANTI-SWAY BRACES, SHOWN AS PIECES MARKED ② IN THE LOAD ON PAGE 14, MUST BE INSTALLED IN EACH END OF THE CAR AND WIRE TIED TO UNITIZING STRAPS WITH NO. 14 GAGE WIRE AS TYPICALLY SHOWN BY THE "TIE WIRE APPLICATION A" DETAIL ON PAGE 122. THREE (3) BRACES ARE REQUIRED IN EACH END OF A LOAD REGARDLESS OF THE CAR LENGTH.
- 5. TO FACILITATE POSITIONING OF THE PALLET UNITS AS LOADING PROGRESSES, POSITION PALLET UNIT STACKS AGAINST THE END WALL, THEN POSITION A SEPARATOR GATE SHOWN AS PIECE MARKED ③, SO THE 1"X 4" TIE PIECES ARE LOCATED UNDER THE "CVERHANG" OF THE BOTTOM AND TOP PALLET UNITS. REPEAT THIS PROCEDURE FOR THE REMAINING STACKS.
- 6. SEPARATOR GATES IN THE DOORWAY MUST BE PREVENTED FROM SHIFTING INTO A DOOR OPENING BY THE APPLICATION OF THE STOP PIECES, PIECES MARKED (4). IN CARS EQUIPPED WITH STAGGERED DOORS, STOP PIECES MAY BE REQUIRED ON UP TO FOUR SEPARATOR GATES.
- SEPARATOR GATES MAY BE FORMED FROM 3/8" OR THICKER PLYWOOD IN LIEU
 OF DIMENSIONAL LUMBER, IF DESIRED. SEE THE "ALTERNATIVE SEPARATOR
 GATE" DETAIL ON PAGE 122 FOR CONSTRUCTION GUIDANCE.
- 8. DOORWAY PROTECTION IS REQUIRED FOR ALL PALLET UNIT STACKS WHICH ARE COMPLETELY WITHIN THE DOORWAY AREA OR WHICH EXTEND INTO THE DOORWAY AREA BY CNE-HALF OR MORE OF THE STACK WIDTH. THE WOODEN GATE TYPE OF DOORWAY PROTECTION, SHOWN AS PIECES MARKED (S) IN THE LOAD ON PAGE 14-15 APPLICABLE FOR BCX CARS EQUIPPED WITH CONVENTIONAL SLIDING DOORS AND NAILABLE DOOR POSTS, REFER TO PAGES 126 THRU 128 FOR ALTERNATIVE DOORWAY PROTECTION FOR CARS EQUIPPED WITH CONVENTIONAL SLIDING DOORS. IF THE CAR BEING LOADED IS EQUIPPED WITH CONVENTIONAL SLIDING DOORS. IF THE CAR BEING LOADED IS EQUIPPED WITH PLUE TYPE DOORS, NAILED FLOORILIPE BLOCKING AND LOAD BUNDLING STRAPS MUST BE USED. SEE THE "ALTERNATIVE DOORWAY PROTECTION F" DETAIL ON PAGE 128 FOR GUIDANCE IF THE PALLET UNITS ARE POSITIONED AS SHOWN ON PAGE 14. SEE THE "ALTERNATIVE DOORWAY PROTECTION E" DETAIL ON THAT PAGE IF THE PALLET UNITS ARE POSITIONED CROSSWISE.
- 9. A STRUT ASSEMBLY, SHOWN AS PIECE MARKED (3) IN THE LOAD ON PAGE 42, IS REQUIRED BETWEEN THE LOAD DIVIDER BULKHEADS WHEN THE LOAD IN EITHER END OF THE CAR IS 50,000 POUNDS OR MORE. FOR THE DEPICTED PALLET UNIT, A STRUT ASSEMBLY WILL BE REQUIRED IF THE LOAD IN ONE END OF THE CAR CONSISTS OF MORE THAN FIVE (5) LOAD UNITS, WHICH WOULD BE THE CASE IF AN OFFSET LOADING PATTERN IS EMPLOYED. THE STRUT ASSEMBLY WILL ALWAYS BE REQUIRED FOR FULL LOADS IN 60' OR LONGER CARS.

(CONTINUED AT LEFT)

LOAD AS SHOWN

ITEM	QUANTITY	WEIGHT	(APPROX
1	OTAL WEIGHT	99,405	LBS

ALTERNATED CONTAINERS UNIT (BASIC HEIGHT)
60-UNIT LOAD IN A 50'-6" LONG BY 9'-2" WIDE BOX CAR EQUIPPED WITH LOAD DIVIDERS




-HORIZONTAL PIECE, 2" X 4" X 40-3/4" (6 REQD). NAIL TO THE VERTICAL PIECES W/3-10d NAILS AT EACH END. STRUT, 2" X 4" BY A LENGTH TO SUIT (6 REQD). NAIL TO THE STRUT SUPPORT 40 3 PIECES W/2-10d NAILS AT EACH END. -VERTICAL PIECE, 2" X 4" X 7'-6" (4 REQD). 7-12 FOR 3-HIGH 50 1 FOR 2-HIGH 7'-4" FOR 3-HIGH 53" FOR 2-HIGH 50½ 53 -STRUT SUPPORT PIECE. 2" X 4" X 5-1/2" (12 REQD). NAIL TO A VERTICAL PIECE

CRIB FILL A

CRIB FILL ASSEMBLIES "A" AND "B" SHOULD BE PRE-FABRICATED.
CONSTRUCT TO BE 1/2" TO 3/4" LESS IN WIDTH THAN THE DISTANCE
BETWEEN LATERALLY ADJACENT ROWS OF PALLET UNITS. OMIT THE
MID-HEIGHT HORIZONTAL PIECES, STRUTS, AND STRUT SUPPORT
PIECES WHEN USING CRIB FOR A 1 OR 2-HIGH LOAD.


CRIB FILL B


OMIT THE MID-HEIGHT HORIZONTAL PIECES, STRUTS, AND STRUT SUPPORT PIECES WHEN USING CRIB FOR A 2-HIGH LOAD, CRIB FILL "B" IS NOT REQUIRED FOR A 1-HIGH LOAD; USE CRIB FILL "A" THROUGHOUT THE LENGTH OF THE LOAD.





DETAILS FOR ALTERNATED CONTAINERS UNIT (BASIC HEIGHT)


1 RIGHT HAND AND 1 LEFT HAND GATE REQUIRED. NOTE THAT THE SECOND 2"X 2" STRUT LEDGER FROM THE BOTTOM MUST BE 32-1/2" LONG FOR A 1-HIGH LOAD.











LUMBER	LINEAR FEET	BOARD FEET
I" X 4"	137	46
1" X 6"	224	112
?" X 2"	57	19
2" X 3"	36	18
2" X 4"	791	528
?" X 6"	172	172
" X 4"	89	119
NAILS	NO. REQD	POUNDS
6d (2")	228	1-1/2
04 (3")	1330	20-1/2
2d (3-1/4")	28	1/2
6d (3-1/2")	120	2-3/4

- A 60°-8" LONG BY 9'-2" WIDE WOOD-LINED CONVENTIONAL TYPE BOX-CAR EQUIPPED WITH 10'-0" WIDE DOOR OPENINGS IS SHOWN. CARS OF OTHER DIMENSIONS AND CARS HAVING WIDER OR NARROWER DOOR OPENINGS CAN BE USED. SEE GENERAL NOTE "D" ON PAGE 2.
- THE PALLET UNIT SHOWN IN THE TYPICAL LOAD ON PAGE 20 IS THE
 ALTERNATED CONTAINER UNIT (INCREASED HEIGHT). A MAXIMUM OF
 FORTY-EIGHT (48) OF THESE UNITS, FOR AN APPROXIMATE LADING
 WEIGHT OF 103, 104 POUNDS, CAN BE PLACED IN A 50"-6" LONG CAR
 WHEN USING THE DEPICTED PROCEDURES; THIRTY-EIGHT (38) UNITS; FOR A
 LADING WEIGHT OF 81,624 POUNDS, CAN BE OUTLOADED IN A 40"-6"
 LONG CAR.
- 3. THE "HIGH" CRIB, SHOWN AS PIECE MARKED ①, MUST BE INSTALLED IN EACH END OF THE LOAD. FOUR (4) ASSEMBLIES ARE REQUIRED IN EACH END OF A LOAD REGARDLESS OF THE CAR LENGTH.
- 4. THE SEPARATOR GATES, SHOWN AS PIECES MARKED ② , IN THE LOAD ON PAGE 20, ARE DESIGNATED "RIGHT HAND" AND "LEFT HAND" TO FACILITATE POSITIONING OF THE PALLET UNITS AS LOADING PROGRESSES. WHEN LOADING THE CAR, POSITION A PALLET UNIT STACK AGAINST THE END WALL, THEN POSITION A SEPARATOR GATE SO THE 1" X 4" TIE PIECES ARE LOCATED UNDER THE "OVERHANG" OF THE PALLET UNITS IN THE FIRST STACK. REPEAT THIS PROCEDURE FOR THE REMAINING STACKS.
- 5. ALL SEPARATOR GATES, PIECES MARKED ② , WHICH ARE WITHIN THE DOORWAY AREA OF A CAR EQUIPPED WITH CONVENTIONAL SLIDING DOORS MUST BE WIRE TIED TO THE ADJACENT CRIB FILL TO PREVENT DISPLACEMENT. ENCIRCLE THE STOP PIECE OF THE SEPARATOR GATE AND THE UPPER HORIZONTAL PIECE OF THE CRIB FILL WITH NO. 14 GAGE WIRE AND TWIST TAUT.
- SEPARATOR GATES MAY BE FORMED FROM 3/8" OR THICKER PLYWOOD IN LIEU OF DIMENSIONAL LUMBER, IF DESIRED. CONSTRUCT EACH GATE 40-3/4" WIDE BY 8'-0" LONG.
- CENTER GATES "E" AND "F" MAY BE PARTIALLY FORMED FROM 1/2" OR
 THICKER PLYWOOD, IF DESIRED, PLYWOOD MAY BE USED IN LIEU OF THE
 2" X 6" HORIZONTAL PIECES. SEE THE "PLYWOOD CENTER GATE ALTERNATIVE" DETAIL ON PAGE 123 FOR GUIDANCE.
- 8. DOORWAY PROTECTION IS REQUIRED FOR ALL PALLET UNIT STACKS WHICH ARE COMPLETELY WITHIN THE DOORWAY AREA OR WHICH EXTEND INTO THE DOORWAY AREA BY ONE-HALF OR MORE OF THE STACK WIDTH OR LENGTH. THE WOODEN GATE TYPE OF DOORWAY PROTECTION, SHOWN AS PIECES MARKED (1) IN THE LOAD ON PAGE 20, IS APPLICABLE FOR BOXCARS EQUIPPED WITH CONVENTIONAL SLIDING DOORS AND NAILABLE DOOR POSTS. REFER TO PAGE 125 THRU 128 FOR ALTERNATIVE DOORWAY PROTECTION FOR CARS EQUIPPED WITH CONVENTIONAL SLIDING DOORS. IF THE CAR BEING LOADED IS EQUIPPED WITH PLUG TYPE DOORS, NAILED FLOORLINE BLOCKING AND LOAD-BUNDLING STRAPS MUST BE USED. SEE THE "ALTERNATIVE DOORWAY PROTECTION F" DETAILS ON PAGE 128 FOR GUIDANCE; A COMBINATION OF THE TWO METHODS MUST BE USED. NAILED SIDE BLOCKING WILL BE USED UNDER THE CRIB FILL SHOWN IN THE DOORWAY AREA OF THE LOAD. POSITION DOUBLED 2" X 4" X 34" PIECES AGAINST THE LENGTHWSE STACK NUMBERED 6, AND PRE-POSITION DOUBLED 2" X 4" X 7"-0" PIECES (APPROXIMATELY 52" ROOM THE NEAR SIDE CAR WALL) SO AS TO BE AGAINST THE CROSS WISE STACKS NUMBERED 8 AND 9. THESE PIECES WILL BE USED IN LIEU OF THE 40" AND 48" LONG PIECES SHOWN BY THE ALTERNATIVE DETAILS. A SPACER ASSEMBLY, AS SHOWN IN THE "ALTERNATIVE DOORWAY PROTECTION F" DETAIL, MUST BE MODIFIED FOR USE BY CHANGING THE END WHICH EXTENDS OVER THE CROSS WISE CONTAINERS TO BE LIKE THE NEAR END OF THE STRAPPING BOARD SHOWN IN THE "ALTERNATIVE DOORWAY PROTECTION F" DETAIL. A 2" X 4" X 40" DOUBLED BATTEN AS SHOWN IN THAT VIEW IS ALSO REQUIRED. NOTE THAT THE VERTICAL PIECES MAD BOTTOM SUPPORT PIECES OF THE CRIB FILL, PIECES MARKED (3), MUST HAVE THREE INCHES (3") CUT OFF THE BOTTOM END OF ONE SIDE SO THE CRIB WILL REST EVENLY ON THE NAILED SIDE BLOCKING WHICH IS ADJACENT TO THE LENGTHWISE UNITS. ALSO NOTE THAT THE VERTICAL PIECES AND BOTTOM SUPPORT PIECES OF THE CRIB FILL, PIECES MARKED (3), MUST HAVE THREE INCHES EVENLY ON THE NAILED SIDE BLOCKING WHICH IS ADJACENT TO THE LENGTHWISE UNITS. ALSO NOTE THAT THE CENTER GATES "E" MUST BE VERLY ON THE MUST DE BLOCKING WHICH IS
- 9. THE DEPICTED LOAD CAN BE REDUCED TO SUIT THE QUANTITY TO BE SHIPPED. A 2-TIER LOAD CAN SE REDUCED BY ONE PALLET UNIT BY EMPLOYING THE PROCEDURS ON PAGE %. TWO (2) PALLET UNITS CAN BE OMITTED BY LEAVING OUT CROSSWIES STACK NO. 9 AND THE ADJACENT CRIB FILL. NOTE THAT STRUT BRACING MUST BE APPLIED TO THE STRUTS, PIECES MARKED ③ , AND AN ADDITIONAL PIECE MARKED ⑥ WILL BE REQUIRED FOR THE OTHER CENTER GATE MARKED ⑥.OR, THE ENTIRE TOP TIER CAN BE OMITTED. A PARTIAL 1-TIER LOAD CAN BE SHIPPED IN ONE OR BOTH ENDS OF A CAR BY USING KNEE BRACES AS SHOWN ON PAGES 112 AND 113.
- 10. IF PALLET UNITS WHICH DO NOT CONTAIN A FULL QUANTITY OF CONTAINERS ARE TO BE TRANSPORTED, REFER TO PAGE 117 FOR SHIPPING GUIDANCE FOR LENGTHWISE UNITS AND PAGES 118 AND 120 FOR CROSSWEE UNITS.
- 11. FOR SHIPMENT OF ONE OR MORE LEFTOVER CONTAINERS, SEE THE "PROCEDURES FOR SHIPMENT OF LEFTOVER CONTAINERS" ON PAGE 119 FOR GUIDANCE.


	FOAD AS SHOWN		
ITEM	QUANTITY	WEIGHT (APPR	OX)
PALLET UNIT	58	124,584 LBS	
DUNNAGE		2,054 LBS	

TOTAL WEIGHT----

ALTERNATED CONTAINERS UNIT (INCREASED HEIGHT)
58-UNIT LOAD IN A 60'-8' LONG BY 9'-2' WIDE CONVENTIONAL BOX CAR

PAGE 21

- 126.638 LBS



- 14. THE DEPICTED LOAD CAN BE REDUCED TO SUIT THE QUANTITY TO BE SHIPPED. A 2-TIER LOAD CAN BE REDUCED BY A MULTIPLE OF FOUR (4) MALLET UNITS OR A 1-TIER LOAD CAN BE REDUCED BY A MULTIPLE OF TWO (2) UNITS BY OMITEING ONE OR MORE LOAD UNITS FROM THE CENTER PORTION OF THE LOAD. OR, THE BYTREE TOP TIER CAN BE OMITTED. FOR OTHER METHODS OF REDUCING A LOAD, AND FOR JYPICAL LCL PROCEDURES, REFER TO MAGES 92 THRU 120 FOR GUIDANCE.
- 15, IF PALLET UNITS WHICH DO NOT CONTAIN A FULL QUANTITY OF CONTAINES ARE TO BE TRANSPORTED, REFER TO PAGE 117 FOR SHIPPING GUIDANCE.
- 16. FOR SHIPMENT OF ONE OR MORE LEFTOVER CONTAINERS, SEE THE PROCEDURES FOR SHIPMENT OF LEFTOVER CONTAINERS* ON PAGE 119 FOR GUIDANCE.

BILL OF MATERIAL		
LUMBER	LINEAR FEET	BOARD FEE
1" X 4"	192	64
1" X 6"	400	200
2" X 2"	73	25
2" X 3"	28	14
2" X 4"	367	245
2" X 6"	163	183
4" X 4"	100	134
NAILS	NO. REQU	POUNDS
6d (2")	300	1-3/4
104 (3")	620	9-2/4
124 (3-1/4")	58	1
16d (3-1/2")	96	2-1/4

SPECIAL NOTES:


- A 60"-8" LONG BY 9"-2" WIDE WOOD-LINED CONVENTIONAL TYPE BOXCAR EQUIPPED WITH 10"-0" WIDE DOOR OPENINGS IS SHOWN, CAIS OF OTHER DIMENSIONS AND CAIS HAVING WIDER OR NAMEOWER DOOR OPENINGS CAN BE USED, SEE GENERAL NOTE "D" ON PAGE 2 AND SPECIAL NOTE 3 BELOW.
- 2. THE PALLETIZED UNIT SHOWN IN THE TYPICAL LOAD ON PAGE 22 IS THE ALTERNATED CONTAINER UNIT (INCREASED HEIGHT). A MAXIMUM OF PORTY (40) OF THESE UNITS, FOR AN APPROXIMATE LADING WEIGHT OF 85,920 POUNDS, CAN BE PLACED IN A 50'-6" LONG CAR WHEN USING THE DEPICTED PROCEDURES; THETY-TWO (32) UNITS, FOR AN APPROXIMATE WEIGHT OF 68,736 POUNDS, CAN BE OUTLOADED IN A 40'-6" LONG CAR.
- 3. THE DEPICTED LOADING PATTERN IS ADEQUATE FOR CARS HAVING DOOR OPENINGS 8" THRU 10" OR WIDER, IF THE CAR TO BE LOADED HAS DOOR OPENINGS LESS THAN 8"-0" WIDE AND NOT OF SUFFICIENT HEIGHT TO ALLOW PRISONNEL TO EXIT THE CAR OVER THE TOP OF THE LOAD WHEN NECSSARY, THE PALLETS SHOULD BE POSITIONED SO THERE ARE SIX (6) LOAD UNITS IN EACH END, NOTE THAT ALTHOUGH CABS HAVING DOOR OPENINGS AS NARROW AS 6"-0" WIDE CAN BE USED FOR RULL LOADS, LOADING B PROGRESSIVELY MORE DIFFICULT AS THE WIDTH OF THE DOOR OPENING DECREASES.
- 4. IF THE "ALTERNATIVE DOORWAY MODECTION F" PROCEDURES AS SHOWN ON PAGE 128 ARE USED IN LIEU OF THE WOODEN DOOR GATE TYPE PROTECTION, PIECE MARKED (?), NAILED FLOORLINE BLOCKING MUST BE USED IN LIEU OF EACH LOWER ANTI-BWAY BRACE IN THE DOORWAY AREA. NAILED BLOCKING IS REQUIRED FOR ALL PALLET STACKS WHICH ARE COMPLETELY WITHIN THE DOORWAY AREA OR WHICH EXTEND INTO THE DOORWAY AREA BY ONE-HALF OR MORE OF THE STACK WIDTH ON EITHER SIDE OF THE CAR. SEE SPECIAL NOTE 12.
- 5. TOP-OF-LOAD ANTI-SWAY BRACES, SHOWN AS PIECES MARKED ② IN THE LOAD ON PAGE 22, MUST BE INSTALLED IN BACH END OF THE 'CAR AND WIRE TIED TO A UNITIZING STRAP WITH NO. 14 GAGE WIRE AS TYPICALLY SHOWN BY THE "TIE WIRE APPLICATION A" DETAIL ON PAGE 122. THREE 3.9 BRACES ARE REQUIRED IN EACH END OF A LOAD REGARDLESS OF THE CAR LENGTH.
- 6. TO FACILITATE POSITIONING OF THE PALLET UNITS AS LOADING PROGRESSES, WHEN LOADING THE BOXCAR, POSITION PALLET UNIT STACKS AGAINST THE END WALL, THEN POSITION A SEPARATOR GATE, SHOWN AS PIECE MARKED 3 SO THE 1" X 4" TIE FIECES ARE LOCATED UNDER THE "OVERHANG" OF THE PALLET UNITS. REPEAT THIS PROCEDURE FOR THE REMAINING STACKS.
- 7. SEPARATOR GATES IN THE DOORWAY MUST BE PREVENTED FROM SHIFTING INTO A DOOR OPENING BY THE APPLICATION OF THE STOP PIECES, PIECES MARKED (4), IN CARS EQUIPPED WITH STAGGERED DOORS, STOP PIECES MAY BE REQUIRED ON UP TO POUR SEPARATOR GATES.
- 8. SEPARATOR GATES MAY BE FORMED FROM 3/8" OR THICKER PLYWOOD IN LIEU OF DIMENSIONAL LUMBER, IF DESIRED. SEE THE "ALTERNATIVE SEPARATOR GATE" DETAIL ON PAGE 122 FOR CONSTRUCTION GUIDANCE.
- CENTER GATE "G" MAY BE PARTIALLY FORMED FROM 1/2" OR THICKER PLYWOOD,
 IF DESIRED. PLYWOOD MAY BE USED IN LIEU OF THE 2" X 6" HORIZONTAL
 PIECES. SEE THE "PLYWOOD CENTER GATE ALTERNATIVE" DETAIL ON PAGE 123
 FOR GUIDANCE.
- 10. FOR EASE OF HANDLING, SPLIT CENTER GATES, WHICH ARE NOT DEPENDENT UPON THE WIDTH OF THE CAR, MAY BE USED AS AN ALTERNATIVE TO THE CAR WIDTH GATES. IN LIEU OF EACH "CENTER GATE G", SHOWN AS PIECE MARKED (3) IN THE LOAD ON PAGE 22, INSTAIL TWO (2) "CENTER GATES E" AS SHOWN ON PAGE 30, AFTER THE SPLIT GATES AND STRUTS HAVE BEEN INSTALLED, THE SPLIT GATES MUST BE TIED TOGETHER AS DEPICTED BY THE "TIE PIECE APPLICATION" DETAIL ON PAGE 123.
- DOOR SPANNER TYPE GATE HOLD DOWN MAY BE USED IN LIEU OF THE DOUBLED 2" X 4" MATERIAL NAILED TO CENTER GATE G, PROVIDING THE CAR BEING LOADED HAS NAILABLE SIDEWALLS. SEE THE DETAILS ON PAGE 125 FOR GUIDANCE.
- 12. DOORWAY PROTECTION IS REQUIRED FOR ALL PALLET UNIT STACKS WHICH ARE COMPLETELY WITHIN THE DOORWAY AREA OR WHICH EXTEND INTO THE DOORWAY AREA BY ONE-HALF OR MORE OF THE STACK WIDTH. THE WOODEN GATE TYPE OF DOORWAY PROTECTION, SHOWN AS PIECE MARKED (?) IN THE LICAD ON PAGE 22, IS APPLICABLE FOR BOXCARS EQUIPPED WITH CONVENTIONAL SUDING DOORS AND NAILABLE DOOR FOSTS. REFER TO PAGES 126 THRU 128 FOR ALTERNATIVE DOORWAY PROTECTION FOR CAIS EQUIPPED WITH CONVENTIONAL SLIDING DOORS. IF THE CAR BEING LOADED IS EQUIPPED WITH PLUG TYPE DOORS, NAILED FLOORLINE BLOCKING AND LOAD BUNDLING STRAPS MUST BE USED. SET THE "ALTERNATIVE DOORWAY PROTECTION F" DETAIL ON PAGE 128 FOR GUIDANCE.
- 13. IF THE ALTERNATIVE DOORWAY PROTECTION TO PROCEDURES SHOWN ON PAGE 128 ARE USED IN LIEU OF THE WOODEN DOORWAY PROTECTION, PIECES MARKED (2). THE CENTER GATES MUST BE RESTRAINED FROM LATERAL MOVEMENT. THIS CAN BE ACCOMPLISHED BY NAILING TO THE CAR FLOOR A DOUBLED 2" X 4" X 18-PIECE POSITIONED LONGTITUDINALLY SO AS TO BE CENTERED AGAINST THE FILL PIECE OF A CENTER GATE. TWO (2) PIECES WILL BE REQUIRED FOR EACH CENTER GATE WHICH IS IN THE DOOR OPENING OR WITHIN SIX INCHES (6") OF BEING IN THE DOOR OPENING.

(CONTINUED AT LEFT)

LOAD AS SHOWN

ITEM	QUANTITY	WEIGHT (APPROX
	T	
	TOTAL WEIGHT	104, 849 LBS

ALTERNATED CONTAINERS UNIT (INCREASED HEIGHT)
48-UNIT LOAD IN A 60'-8' LONG BY 9'-2" WIDE CONVENTIONAL BOX CAR




- A 50'-6" LONG BY 9'-4" WIDE WOOD-LINED CONVENTIONAL TYPE BOX CAR EQUIPPED WITH 8'-0" WIDE DOOR OPENINGS IS SHOWN, WIDER CARS OF OTHER LENGTHS AND CARS HAVING WIDER OR NARROWER DOOR OPENINGS CAN BE USED. SEE GENERAL NOTE "D" ON PAGE 2 AND SPECIAL NOTE 3 BELOW.
- 2. THE PALLETIZED UNIT SHOWN IN THE TYPICAL LOAD ON PAGE 24 IS THE ALTERNATED CONTAINER UNIT (INCREASED HEIGHT). A MAXIMUM OF FORTY-FOUR (44) OF THESE UNITS, FOR AN APPROXIMATE LADING WEIGHT OF 94,512 POUNDS CAN BE PLACED IN A 40'-6" LONG CAR WHEN USING THE DEPICTED PROCEDURES. IF A 60'-8" LONG BY 9'-4" OR WIDER CAR IS AVAILABLE, SIXTY-EIGHT (68) PALLET UNITS FOR AN APPROXIMATE LADING WEIGHT OF 146,064 POUNDS CAN BE LOADED. SEE SPECIAL NOTE 10 FOR CENTER GATE MODIFICATIONS WHICH MUST BE MADE IF 60' LONG CARS ARE TO BE USED.
- 3. THE DEPICTED LOADING PATTERN IS ADEQUATE FOR CARS HAVING DOOR OPENINGS 8" OR WIDER. IF THE CAR TO BE LOADED HAS DOOR OPENINGS LESS THAN 8"-0" WIDE AND NOT OF SUFFICIENT HEIGHT TO ALLOW PERSONNEL TO EXIT THE CAR OVER THE TOP OF THE LOAD WHEN NECESSARY, THE PALLETS SHOULD BE POSITIONED SO THERE ARE SEVEN (7) LOAD UNITS IN EACH END. NOTE THAT ALTHOUGH CARS HAVING DOOR OPENINGS AS NARROW AS 6"-0" WIDE CAN BE USED FOR FULL LOADS, LOADING IS PROGRESSIVELY MORE DIFFICULT AS THE WIDTH OF THE DOOR OPENING DECREASES.
- ANTI-SWAY BRACING BETWEEN LATERALLY ADJACENT ROWS OF PALLET UNITS IS NOT REQUIRED REGARDLESS OF THE WIDTH OF THE CAR BEING LOADED.
- CENTER GATE "H" MAY BE PARTIALLY FORMED FROM 1/2" OR THICKER PLYWOOD,
 IF DESIRED, PLYWOOD MAY BE USED IN LIEU OF THE 2" X 6" HORIZONTAL PIECES.
 SEE THE "PLYWOOD CENTER GATE ALTERNATIVE" DETAIL ON PAGE 123 FOR
 GUIDALOFE
- 6. FOR EASE OF HANDLING, SPLIT CENTER GATES, WHICH ARE NOT DEPENDENT UPON THE WIDTH OF THE CAR, MAY BE USED AS AN ALTERNATIVE TO THE CAR-WIDTH GATES. IN LIEU OF EACH "CENTER GATE H", SHOWN AS PIECE MARKED (1) IN THE LOAD ON PAGE 24, INSTALL TWO (2) "CENTER GATES F" AS SHOWN ON PAGE 31, AFTER THE SPLIT GATES AND STRUTS HAVE BEEN INSTALLED, THE SPLIT GATES MUST BE TIED TOGETHER AS DEPICTED BY THE "TE PIECE APPLICATION" DETAIL ON PAGE 123.
- 7. DOOR SPANNER TYPE GATE HOLD DOWN MAY BE USED IN LIEU OF THE DOUBLED 2" X 3" HOLD DOWNS ON CENTER GATES "H" PROVIDING THE CAR BEING LOADED HAS NAILABLE SIDEWALLS. SEE THE DETAILS ON PAGE 125 FOR GUIDANCE.
- 8. DOORWAY PROTECTION IS REQUIRED FOR ALL PALLET UNIT STACKS WHICH ARE COMPLETELY WITHIN THE DOORWAY AREA OR WHICH EXTEND INTO THE DOORWAY AREA BY ONE-HALF OR MORE OF THE STACK LENGTH. THE WOODEN GATE TYPE OF DOORWAY PROTECTION, SHOWN AS PIECES MARKED ③ IN THE LOAD ON PAGE 24, IS APPLICABLE FOR BOXCARS EQUIPPED WITH CONVENTIONAL SLIDING DOORS AND NAILABLE DOOR POSTS, REFER TO PAGES 126 THRU 128 FOR ALTERNATIVE DOORWAY PROTECTION FOR CARS EQUIPPED WITH CONVENTIONAL SLIDING DOORS. IF THE CAR BEING LOADED IS EQUIPPED WITH PLUG TYPE DOORS, NAILED FLOORLINE BLOCKING AND LOAD BUNDLING STRAPS MUST BE USED. SEE THE "ALTERNATIVE DOORWAY PROTECTION E" DETAIL ON PAGE 128 FOR GUIDANCE.
- 9. THE DEPICTED LOAD CAN BE REDUCED TO SUIT THE QUANTITY TO BE SHIPPED. A 2-TIER LOAD CAN BE REDUCED BY A MULTIPLE OF FOUR (4) PALLET UNITS OR A 1-TIER LOAD CAN BE REDUCED BY A MULTIPLE OF TWO (2) UNITS BY OMITTING ONE OR MORE LOAD UNITS FROM THE CENTER PORTION OF THE LOAD, OR THE ENTIRE TOP TIER CAN BE OMITTED. FOR OTHER METHODS OF REDUCING A LOAD, AND FOR TYPICAL LCL PROCEDURES, REFER TO PAGES 92 THRU 120 FOR GUIDANCE.
- 10. IF A FULL LOAD IS TO BE SHIPPED IN A 60' LONG CAR, NINE (9) STRUTS WILL BE REQUIRED PER ROW/TIER. TO ACCOMMODATE THESE ADDITIONAL STRUTS, A HORIZONTAL PIECE AND STRUT LEDGER MUST BE ADDED TO CENTER GATE "H" FOR EACH TIER AS SHOWN BY THE PHANTOMED LINES ON THE DETAIL ON PAGE 33.
- 11. IF PALLET UNITS WHICH DO NOT CONTAIN A FULL QUANTITY OF CONTAINERS ARE TO BE TRANSPORTED, REFER TO PAGES 118 AND 120 FOR SHIPPING GUIDANCE.
- 12. FOR SHIPMENT OF ONE OR MORE LEFTOVER CONTAINERS, SEE THE "PROCEDURES FOR SHIPMENT OF LEFTOVER CONTAINERS" ON PAGE 119 FOR GUIDANCE.

LUMBER	LINEAR FEET	BOARD FEET
1" X 6"	64	32
2" X 2"	68	23
2" X 3"	36	18
2" X 4"	19 .	13
2" X 6"	162	162
4" X 4"	59	79
NAILS	NO. REQD	POUNDS
6d (2")	48	1/2
10d (3")	300	4-3/4
12d (3-1/4")	28	1/2
16d (3-1/2")	96	2-1/4

LOAD AS SHOWN

ITEM	QUANTITY	WEIGHT	(APPROX)
PALLET UNIT-	56	120,288	1 BS
DUNNA GE	DUNNA GE		
	TOTAL WEIGHT	120,950	LBS

ALTERNATED CONTAINERS UNIT (INCREASED HEIGHT)
56-UNIT LOAD IN A 50'-6' LONG BY 9'-4" WIDE CONVENTIONAL BOX CAR




- 1. A 50'-6" LONG BY 9'-0" WIDE (INSIDE CLEARANCE) WOOD-LINED BCX CAR EQUIPPED WITH ADJUSTABLE AND/OR FIXED WALL MEMBERS, AND WITH 10'-0" WIDE DOOR OPENINGS IS SHOWN. CARS OF OTHER DIMENSIONS AND CARS HAVING WIDER OR NARROWER DOOR OPENINGS CAN BE USED. SEE GENERAL NOTE "D" ON PAGE 2.
- 2. THE PALLET UNIT SHOWN IN THE TYPICAL LCAD ON PAGE 26 IS THE ALTERNATED CONTAINERS UNIT (INCREASED HEIGHT). A MAXIMUM OF TWENTY-EIGHT (28) OF THESE UNITS, FOR AN APPROXIMATE LADING WEIGHT OF 60, 144 POUNDS, CAN BE PLACED IN A 40'-6' LONG CAR.
- 3. IF A CAR HAS BOWED END WALLS WHICH ARE BOWED OUTWARD TWO INCHES (2") OR MORE EITHER FROM SIDE-TO-SIDE OR FROM FLOOR-TO-ROCF, CROSS MEMBERS CAN BE INSTALLED NEAR THE END WALL OF THE CAR TO PROVIDE A "SQUARED END" RATHER THAN INSTALLING DUNNAGE AS SPECIFIED IN GENERAL NOTE "G" ON PAGE 2. THESE CROSS MEMBERS SHOULD BE INSTALLED AT THE SAME HEIGHTS AS THE CROSS MEMBERS LUSED THROUGHOUT THE LOAD AS BLOCKING MEMBERS. A SEPARATOR GATE, SHOWN AS PIECE MARKED (2), MUST BE POSITIONED AGAINST THESE CROSS MEMBERS PRIOR TO LOADING.
- 4. TOP-OF-LOAD ANTI-SWAY BRACES, SHOWN AS PIECES MARKED ③ IN THE LOAD ON PAGE 26, MUST BE INSTALLED IN EACH END OF THE CAR AND WIRE TIED TO A UNITIZING STRAP WITH NO. 14 GAGE WIRE AS TYPICALLY SHOWN BY THE "TIE WIRE APPLICATION A" DETAIL ON PAGE 122. THREE (3) BRACES ARE REQUIRED IN EACH END OF A LOAD REGARDLESS OF THE CAR LENGTH.
- 5. TO FACILITATE POSITIONING OF THE PALLET UNITS AS LOADING PROGRESSES POSITION PALLET UNIT STACKS AGAINST THE END WALL, THEN POSITION A SEPARATOR GATE, SHOWN AS PIECE MARKED (4), SO THE 1" X 4" TIE PIECES ARE LOCATED UNDER THE "OVERHANG" OF THE PALLET UNITS. REPEAT THIS PROCEDURE FOR THE REMAINING STACKS.
- 6. SEPARATOR GATES IN THE DOORWAY MUST BE PREVENTED FROM SHIFTING INTO A DOOR OPENING BY THE APPLICATION OF THE STOP PIECES, PIECES MARKED (3). IN CARS EQUIPPED WITH STAGGERED DOORS, STOP PIECES MAY BE REQUIRED ON UP TO FOUR SEPARATOR GATES.
- SEPARATOR GATES MAY BE FORMED FROM 3/8" OR THICKER PLYWOOD IN LIEU OF DIMENSIONAL LUMBER, IF DESIRED. SEE THE "ALTERNATIVE SEPARATOR GATE" DETAIL ON PAGE 122 FOR CONSTRUCTION GUIDANCE.
- 8. THE DEPICTED LOAD CAN BE REDUCED TO SUIT THE QUANTITY TO BE SHIPPED. A LOAD MAY BE REDUCED BY MULTIPLES OF TWO (2) PALLET UNITS BY OMITTING LATERALLY ADJACENT UNITS FROM THE TOP LAYER OF ONE OR MORE LOAD UNITS, OR BY MULTIPLES OF FOUR (4) PALLET UNITS BY CMITTING ONE OR MORE ENTIRE LOAD UNITS. TO REDUCE A LOAD BY ONE (1) PALLET UNIT, REFER TO THE LCL PROCEDURES ON PAGES 90 AND 91 FOR GUIDANCE.
- 9. FOR SHIPMENT OF ONE OR MORE LEFTOVER CONTAINERS, SEE THE "PROCEDURES FOR SHIPMENT OF LEFTOVER CONTAINERS" ON PAGE 119

LUMBER	LINEAR FEET	BOARD FEET
1" X 4"	251	84
1" X 6"	416	208
2" X 4"	293	196
NAILS	NO. REQD	POUNDS
6d (2")	336	2
10d (3")	240	3-3/4
12d (3-1/4")	30	1/2

LOAD AS SHOWN

ITEM	QUANTITY	WEIGHT (APPROX)
	NT 40	
1	TOTAL WEIGHT	86,903 LBS

ALTERNATED CONTAINERS UNIT (INCREASED HEIGHT)
40-UNIT LOAD IN A 50'-6' LONG BY 9'-0' WIDE BOX CAR EQUIPPED WITH MECHANICAL BRACING DEVICES



- 10. THE DEPICTED LOAD CAN BE REDUCED TO SUIT THE QUANTITY TO BE SHIPPED. A 2-TIER LOAD CAN BE REDUCED BY A MULTIPLE OF FOUR (4) PALLET UNITS OR A 1-TIER LOAD CAN BE REDUCED BY A MULTIPLE OF TWO (2) UNITS BY OMITTING ONE OR MORE LOAD UNITS FROM THE CENTER PORTION OF THE LOAD. OR, THE ENTIRE TOP TIER CAN BE OMITTED. FOR OTHER METHODS OF REDUCING A LOAD, AND FOR TYPICAL LCL PROCEDURES, REFER TO PAGES 94 THRU 105 AND GENERAL NOTE "FF" ON PAGE 3 FOR GUIDANCE.
- 11 IF PALLET UNITS WHICH DO NOT CONTAIN A FULL QUANTITY OF CONTAINERS
 ARE TO BE TRANSPORTED, REFER TO PAGE 117 AND/OR PAGES 118 AND 120 FOR SHIPPING GUIDANCE.
- 12 FOR SHIPMENT OF ONE OR MORE LEFTOVER CONTAINERS, SEE THE "PROCEDURES FOR SHIPMENT OF LEFTOVER CONTAINERS" ON PAGE 119 FOR GUIDANCE.

SPECIAL NOTES:

- A 50'-6" LONG BY 9'-2" WIDE WOOD-LINED, CUSHIONED BOX CAR EQUIPPED WITH LOAD DIVIDER BULKHEADS AND WITH 10'-0" WIDE DOOR OPENINGS IS SHOWN. CARS OF OTHER DIMENSIONS AND CARS HAVING NARROWER OR WIDER DOOR OPENINGS CAN BE USED. SEE GENERAL NOTES "AA" THRU "EE" ON PAGE 3.
- 2. THE PALLET UNIT SHOWN IN THE TYPICAL LOAD ON PAGE 28 IS THE ALTERNATED CONTAINERS UNIT (INCREASED HEIGHT). A MAXIMUM OF FORTY-EIGHT (48) OF THESE UNITS, FOR AN APPROXIMATE LADING WEIGHT OF 103, 104 POUNDS, CAN BE PLACED IN A 60'-8" LONG CAR, OR A MAXIMUM OF THIRTY-TWO (32) UNITS CAN BE LOADED IN A 40'-6" CAR FOR AN APPROXIMATE LADING WEIGHT OF 68,736 POUNDS, WHEN USING THE DEPICTED PROCEDURES. IF CARS 9'-4" OR WIDER ARE AVAILABLE, THE CROSSWISE LOADING PATTERN SHOWN ON PAGE 24 MAY BE EMPLOYED. THEN, SIXTY-FOUR (64) PALLET UNITS FOR AN APPROXIMATE LADING WEIGHT OF 137,472 POUNDS CAN BE PLACED IN A 60'-8" LONG CAR, FIFTY-TWO (52) UNITS CAN BE LOADED IN A 50'-6" LONG CAR FOR AN APPROXIMATE LADING WEIGHT OF 111,696 POUNDS, AND FORTY (40) UNITS CAN BE LOADED IN A 40'-6" LONG CAR FOR AN APPROXIMATE LADING WEIGHT OF 111,696 POUNDS, AND FORTY (40) UNITS CAN BE LOADED IN A 40'-6" LONG CAR FOR AN APPROXIMATE LADING WEIGHT OF TREASURED WEIGHT OF STORE AND POUNDS.
- XIMATE LADING WEIGHT OF 85,920 POUNDS.

 3. IF THE "ALTERNATIVE DOORWAY PROTECTION F" PROCEDURES AS SHOWN ON PAGE 128 ARE USED IN LIEU OF THE WOODEN DOOR GATE TYPE PROTECTION, PIECE MARKED (3), NAILED FLOORLINE BLOCKING MUST BE USED IN LIEU OF THE LOWER ANTI-SWAY BRACES IN THE DOORWAY AREA. NAILED BLOCKING IS REQUIRED FOR ALL PALLET STACKS WHICH ARE COMPLETELY WITHIN THE DOORWAY AREA OR WHICH EXTEND INTO THE DOORWAY AREA BY ONE-HALF OR MORE OF THE STACK WIDTH ON EITHER SIDE OF THE CAR.
- 4. TOP-OF-LOAD ANTI-SWAY BRACES, SHOWN AS PIECES MARKED ② IN THE LOAD ON PAGE 28, MUST BE INSTALLED IN EACH END OF THE CAR AND WIRE TIED TO UNITIZING STRAPS WITH NO. 14 GAGE WIRE AS TYPICALLY SHOWN BY THE "TIE WIRE APPLICATION A" DETAIL ON PAGE 122. THREE (3) BRACES ARE REQUIRED IN EACH END OF A LOAD REGARDLESS OF THE CAR LENGTH.
- 5. TO FACILITATE POSITIONING OF THE PALLET UNITS AS LOADING PROGRESSES, POSITION PALLET UNIT STACKS AGAINST THE END WALL, THEN POSITION A SEPARATOR GATE SHOWN AS PIECE MARKED ③, SO THE 1" X 4" TIE PIECES ARE LOCATED UNDER THE "OVERHANG" OF THE PALLET UNITS. REPEAT THIS PROCEDURE FOR THE REMAINING STACKS.
- 6. SEPARATOR GATES IN THE DOORWAY MUST BE PREVENTED FROM SHIFTING INTO A DOOR OPENING BY THE APPLICATION OF THE STOP PIECES, PIECES MARKED (A). IN CARS EQUIPPED WITH STAGGERED DOORS, STOP PIECES MAY BE REQUIRED ON UP TO FOUR SEPARATOR GATES.
- SEPARATOR GATES MAY BE FORMED FROM 3/8" OR THICKER PLYWOOD IN LIEU OF DIMENSIONAL LUMBER, IF DESIRED. SEE THE "ALTERNATIVE SEPARA-TOR GATE " DETAIL ON PAGE 122 FOR CONSTRUCTION GUIDANCE.
- 8. DODRWAY PROTECTION IS REQUIRED FOR ALL PALLET UNIT STACKS WHICH ARE COMPLETELY WITHIN THE DOORWAY AREA OR WHICH DETEND INTO THE DOORWAY AREA BY ONE-HALF OR MORE CF THE STACK WIDTH. THE WOODEN GATE TYPE CF DOORWAY PROTECTION, SHOWN AS PIECES MARKED ③ IN THE LOAD ON PAGE 28, IS APPLICABLE FOR BOX CARS EQUIPPED WITH CONVENTIONAL SLIDING DOORS AND NAILABLE. DOOR POSTS. REFER TO PAGES 126 THRU 128 FOR ALTERNATIVE DOORWAY PROTECTION FOR CARS EQUIPPED WITH CONVENTIONAL SLIDING DOORS. IF THE CAR BEING LOADED IS EQUIPPED WITH PLUG TYPE DOORS, NAILED FLOORLINE BLOCKING AND LOAD BUNDLING STRAPS MUST BE USED. SEE THE "ALTERNATIVE DOORWAY PROTECTION F" DETAIL ON PAGE 128 FOR GUIDANCE IF THE PALLET UNITS ARE POSITIONED AS SHOWN ON PAGE 28. SEE THE "ALTERNATIVE DOORWAY PROTECTION F" DETAIL ON THAT PAGE IF THE PALLET UNITS ARE POSITIONED AS SHOWN ON
- 9. A STRUT ASSEMBLY, SHOWN AS PIECE MARKED ③ IN THE LOAD ON PAGE 42, IS REQUIRED BETWEEN THE LOAD DIVIDER BULKHEADS WHEN THE LOAD IN EITHER END OF THE CAR IS 50,000 POUNDS OR MCRE. FOR THE DEPICTED PALLET UNIT, A STRUT ASSEMBLY WILL BE REQUIRED IF THE LOAD IN ONE END OF THE CAR CONSISTS OF MORE THAN FIVE (5) LOAD UNITS, WHICH WOULD BE THE CASE IF AN OFFSET LOADING PATTERN IS EMPLOYED. THE STRUT ASSEMBLY WILL ALWAYS BE REQUIRED FOR FULL LOADS IN 60 OR LONGER CARS.


(CONTINUED AT LEFT)

LUMBER	LINEAR FEET	BOARD FEET
1" X 4"	200	67
1" X 6"	400	200
2" X 3"	28	14
2" X 4"	302	202
NAILS	NO. REQD	POUNDS
6d (2")	312	2
10d (3")	240	3-3/4
12d (3-1/4")	58	1

LOAD AS SHOWN

TOTAL WEIGHT --- 86,893 LBS


ALTERNATED CONTAINERS UNIT (INCREASED HEIGHT)
40-UNIT LOAD IN A 50'-6' LONG BY 9'-2' WIDE BOX CAR EQUIPPED WITH LOAD DIVIDERS




CRIB FILL C


CRIB FILL ASSEMBLIES "C" AND "D" SHOULD BE PRE-FABRICATED.
CONSTRUCT TO BE 1/2" TO 3/4" LESS IN WIDTH THAN THE
DISTANCE BETWEEN LATERALLY ADJACENT ROWS OF BALLET UNITS.


CRIB FILL "D" IS NOT REQUIRED FOR A 1-HIGH LOAD; CRIB FILL "C" WILL BE USED THROUGHOUT THE LENGTH OF THE LOAD.





DETAILS FOR ALTERNATED CONTAINERS UNIT (INCREASED HEIGHT)











- IF PALLETIZED UNITS WHICH DO NOT CONTAIN A FULL QUANTITY OF CONTAINERS ARE TO BE TRANSPORTED, REFER TO PAGE 117 FOR SHIPPING GUIDANCE FOR LENGTHWISE UNITS AND PAGES 118 AND 120 FOR CROSSWISE UNITS.
- FOR SHIPMENT OF ONE OR MORE LEFTOVER CONTAINERS, SEE THE "PROCEDURES FOR SHIPMENT OF LEFTOVER CONTAINERS" ON PAGE 119 FOR GUIDANCE.

BILL OF MATERIAL		
LUMBER	LINEAR FEET	BOARD FEET
1" X 4"	147	49
1" X 6"	245	123
2" X 2"	95	32
2" X 3"	31	16
2" X 4"	816	544
4" X 4"	96	128
NAILS	NO. REQD	POUNDS
6d (2")	228	1-1/2
104 (3*)	1,256	19-1/2
12d (3-1/4°)	40	3/4
16d (3-1/2°)	120	2-3/4

SPECIAL NOTES:

- A 60'-8" LONG BY 9'-2" WIDE WOOD-LINED CONVENTIONAL TYPE BOX CAR EQUIPPED WITH 10'-0" WIDE DOOR OPENINGS IS SHOWN. CARS OF OTHER DIMENSIONS AND CARS HAVING WIDES OR NARROWER DOOR OPENINGS CAN BE USED. SEE SPECIAL NOTE 3 BELOW AND GENERAL NOTE "D" ON PAGE 2.
- 2. THE PALLET UNIT SHOWN IN THE TYPICAL LOAD ON PAGE 34 IS THE FLAT DUNNAGE METHOD UNIT (BASIC HEIGHT). A MAXIMUM OF FORTY-SIX (46) OF THESE UNITS, FOR AN APPROXIMATE LADING WEIGHT OF 97,842 POUNDS, CAN BE PLACED IN A 50'-6" LONG CAR WHEN USING THE DEPICTED PROCEDURES; THRTY-SIX (36) UNITS, FOR A LADING WEIGHT OF 76,572 POUNDS, CAN BE OUTLOADED IN A 40'-6" LONG CAR.
- 3. THE DEPICTED LOADING PATTERN IS ADEQUATE FOR CARS HAVING DOOR OPENINGS AS NARROW AS 8'-0". IF THE CAR TO BE LOADED HAS DOOR OPENINGS LESS THAN 8'-0" WIDE AND NOT OF SUFFICIENT HEIGHT TO ALLOW PERSONNEL TO EXIT THE CAR OVER THE TOP OF THE LOAD, THE LENGTHWISE UNITS SHOULD BE LOADED SIX (6) STACKS LONG IN EACH END OF THE CAR AND THE CROSS WISE STACKS SHOULD BE LOADED EIGHT (8) STACKS LONG IN EACH END. PIECE MARKED (7) WILL NOT BE REQUIRED; THE BALANCE OF THE DUNNAGE WILL NOT CHANGE.
- THE "HIGH" CRIB, SHOWN AS PIECE MARKED ①, MUST BE INSTALLED IN EACH END OF THE LOAD. FOUR (4) ASSEMBLIES ARE REQUIRED IN EACH END OF A LOAD REGARDLESS OF THE CAR LENGTH.
- 5. THE SEPARATOR GATES, SHOWN AS PIECES MARKED ② IN THE LOAD ON PAGE 34, ARE DESIGNATED "RIGHT HAND" AND "LEFT HAND" TO FACILITATE POSITIONING OF THE PALLET UNITS AS LOADING PROGRESSES. WHEN LOADING THE CAR, POSITION A PALLET UNIT STACK AGAINST THE END WALL, THEN POSITION A SEPARATOR GATE SO THE 1" X 4" TIE PIECES ARE LOCATED UNDER THE "OVERHANG" OF THE BOTTOM AND TOP PALLET UNITS IN THE FIRST STACK. REPEAT THIS PROCEDURE FOR THE REMAINING STACKS.
- 6. ALL SEPARATOR GATES WHICH ARE WITHIN THE DOORWAY AREA OF A CAR EQUIPPED WITH CONVENTIONAL SLIDING DOORS MUST BE WIRE TIED TO THE ADJACENT CRIB FILL TO PREVENT DISPLACEMENT. ENCRYCLE THE STOP PIECE OF THE SEPARATOR GATE AND THE UPPER HORIZONTAL PIECE OF THE CRIB FILL WITH NO. 14 GAGE WIRE AND TWIST TAUT.
- SEPARATOR GATES MAY BE FORMED FROM 3/8" OR THICKER PLYWOOD IN LIEU
 OF DIMENSIONAL LUMBER, IF DESIRED. CONSTRUCT EACH GATE 43" WIDE BY
 8'-0" LONG.
- 6. CENTER GATES "J" AND "K" MAY BE PARTIALLY FORMED FROM 1/2" OR THICKER PLYWOOD, IF DESIRED. PLYWOOD MAY BE USED IN LIEU OF THE 2" X 6" HORIZONTAL PIECES. SEE THE "PLYWOOD CENTER GATE ALTERNATIVE" DETAIL ON PAGE 123 FOR GUIDANCE.
- 9. DOORWAY PROTECTION IS REQUIRED FOR ALL PALLET UNIT STACKS WHICH ARE COMPLETELY WITHIN THE DOORWAY AREA OR WHICH EXTEND INTO THE DOORWAY AREA BY ONE-HALF OR MORE OF THE STACK WIDTH OR LENGTH. THE WOODEN GATE TYPE OF DOORWAY PROTECTION, SHOWN AS PIECES MARKED (1) AND (12) IN THE LOAD ON PAGE 34, IS APPLICABLE FOR BOX CARS EQUIPPED WITH CONVENTIONAL SLIDING DOORS AND MAILABLE DOOR POSTS. REFER TO PAGES 126 THRU 128 FOR ALTERNATIVE DOORWAY PROTECTION FOR CARS EQUIPPED WITH CONVENTIONAL SLIDING DOORS. IF THE CAR BEING LOADED IS EQUIPPED WITH PLUG TYPE DOORS, NAILED FLOORLINE BLOCKING AND LOAD-BUNDDING STRAPS MUST BE USED. SEE THE "ALTERNATIVE DOORWAY PROTECTION E" AND "ALTERNATIVE DOORWAY PROTECTION F" DETAILS ON PAGE 128 FOR GUIDANCE; A COMBINATION OF THE TWO METHODS MUST BE USED. NAILED SIDE BLOCKING, DOUBLED 2" X 4" X 7"-6" LONG, WILL BE USED UNDER THE CRIB FILL SHOWN IN THE DOORWAY AREA OF THE LOAD, POSITION ONE SIDE BLOCKING ADJACENT TO THE CROSSWISE STACKS NUMBERED 8 AND 9 AND ONE DIRECTLY OPPOSITE AGAINST ALL OR A PORTION. OF THE LENGTHWISE STACKS NUMBERED 6 AND 7. THESE PIECES WILL BE USED IN LIEU OF THE 40" AND 48" LONG PIECES SHOWN BY THE ALTERNATIVE DETAILS A SPACER ASSEMBLY, AS SHOWN IN THE ALTERNATIVE DOORWAY PROTECTION F" DETAIL, MUST BE MODIFIED FOR USE BY CHANGING THE END OF THE STRAPPING BOARD SHOWN IN THE "REAR END OF THE STRAPPING BOARD SHOWN IN THE WARD OF THE STRAPPING BOARD SHOWN IN THE WARD OF THE CROSSWISE CONTAINERS TO BE LIKE THE NEAR END OF THE STRAPPING BOARD SHOWN IN THE VALTERNATIVE DOORWAY PROTECTION F" DETAIL, MUST BE MODIFIED FOR USE BY CHANGING THE END OF THE STRAPPING BOARD SHOWN IN THE "ALTERNATIVE DOORWAY PROTECTION F" DETAIL, A SOOD ONE SIDE SO THE CRIB WILL REST EVENLY ON THE CRIB. FILL PROTECTS AND BOTTOMS UPPORT PIECES OF THE CRIB. FILL REST EVENLY ON THE CRIB. SIDE BLOCKING FOR THE CROSSWISE UNITS, ALSO NOTE THAT THE VERTICAL PIECES AND BOTTOMS MUST PROTECT ON THE NAILED SIDE BLOCKING WHICH IS ADJACENT TO THE LENGTHWISE UNITS, ALSO NOTE THAT THE SIDE BLOCKING FOR THE CROS
- 10. THE DEPICTED LOAD CAN BE REDUCED TO SUIT THE QUANTITY TO BE SHIPPED. A 2-TIER LOAD CAN BE REDUCED BY ONE OR MORE PALLET UNITS BY EMPLOYING THE PROCEDURES ON PAGE 96, FOUR (4) UNITS CAN BE OMITTED FROM A 2-TIER LOAD BY LEAVING OUT THE LENGTHWISE STACKS NO. 7 AND THE CROSSWISE STACK NO. 9. NOTE THAT STRUT BRACING WILL THEN BE REQUIRED. OR, THE ENTIRE TOP TIER CAN BE OMITTED. A PARTIAL 1-TIER LOAD CAN BE SHIPPED IN ONE OR BOTH ENDS OF A CAR BY USING KNEE BRACES AS SHOWN ON PAGES 112 AND 113.

(CONTINUED AT LEFT:)

LOAD AS SHOWN


ITEM	QUANTITY	WEIGHT	(APRROX
	56	119,112 LBS 1,809 LBS	

FLAT DUNNAGE METHOD UNIT (BASIC HEIGHT)
56-UNIT LOAD IN A 60'-8' LONG BY 9'-2' WIDE CONVENTIONAL BOX CAR

PAGE 35

120,921 LBS

TOTAL WEIGHT ----



- 13. IF THE ALTERNATIVE DOORWAY PROTECTION "F" PROCEDURES SHOWN ON PAGE 128 ARE USED IN LIEU OF THE WOODEN DOORWAY PROTECTION PIECES MARKED (**), THE CENTER GATES MUST BE RESTRAINED FROM LATERAL MOVEMENT. THIS CAN BE ACCOMPLISHED BY NAILING TO THE CAR FLOOR A DOUBLED 2" X 4" X 18" PIECE POSITIONED LONGITUDINALLY \$C AS TO BE CENTERED AGAINST THE FILL PIECE OF A CENTER GATE. TWO (2) PIECES WILL BE REQUIRED FOR EACH CENTER GATE WHICH IS IN THE DOOR OPENING OR WITHIN SIX INCHES (6") OF BEING IN THE DOOR OPENING.
- 14. THE DEPICTED LOAD CAN BE REDUCED TO SUIT THE QUANTITY TO BE SHIPPED. A 2-TIER LOAD CAN BE REDUCED BY A MULTIPLE OF FOUR (4) PALLET UNITS OR A 1-TIER LOAD CAN BE REDUCED BY A MULTIPLE OF TWO (2) UNITS BY OMITTING ONE OR MORE LOAD UNITS FROM THE CENTER PORTION OF THE LOAD. OR, THE ENTIRE TOP TIER CAN BE OMITTED. FOR CHER METHODS OF REDUCING A LOAD, AND FOR TYPICAL LCL PROCEDURES, REFER TO PAGES 92 THRU 120 FOR GUIDANCE.
- IF PALLET UNITS WHICH DO NOT CONTAIN A FULL QUANTITY OF CONTAINERS ARE TO BE TRANSPORTED, REFER TO PAGE 117 FOR SHIPPING GUIDANCE.
- 16. FOR SHIPMENT OF ONE OR MORE LEFTOVER CONTAINERS, SEE THE "PROCEDURES FOR SHIPMENT OF LEFTOVER CONTAINERS" ON PAGE 119 FOR GUIDANCE.

LUMBER	LINEAR FEET	BOARD FEET
I * X 4 *	193	65
1" X 6"	410	205
2" X 2"	94	32
2" X 3"	32	16
2" X 4"	359	240
2" X 6"	207	207
4" X 4"	100	134
NAILS	NO. REQD	POUNDS
6d (2")	400	2-1/2
10d (3")	1048	16-1/4
12d (3-1/4")	32	3/4
16d (3-1/2")	96	2-1/4


SPECIAL NOTES:

- A 60'-8" LONG BY 9'-2" WIDE WOOD-LINED CONVENTIONAL TYPE BOX CAR EQUIPPED WITH 10'-0" WIDE DOOR OPENINGS IS SHOWN. CARS OF CTHER DIMENSIONS AND CARS HAVING WIDER OR NARROWER DOOR CPENINGS CAN BE USED, SEE GENERAL NOTE "D" ON PAGE 2 AND SPECIAL NOTE 3 BELOW.
- 2. THE PALLETIZED UNIT SHOWN IN THE TYPICAL LOAD ON PAGE 36 IS THE FLAT DUNNAGE METHOD UNIT (BASIC HEIGHT). A MAXIMUM OF FORTY (40) OF THESE UNITS, FOR AN APPROXIMATE LADING WEIGHT OF 85,080 PCUNDS, CAN BE PLACED IN A 50'-6" LONG CAR WHEN USING THE DEPICTED PROCEDURES; THIRTY-TWO (32) UNITS, FOR AN APPROXIMATE LADING WEIGHT OF 68,064 POUNDS, CAN BE OUTLOADED IN A 40'-6" LONG CAR.
- 3. THE DEPICTED LOADING PATTERN IS A DEQUATE FOR CARS HAVING DCCR OPENINGS 81 THRU IC1 OR WIDER. IF THE CAR TO BE LOADED HAS DCOR CPENINGS LESS THAN 81-0" WIDE AND NOT OF SUFFICIENT HEIGHT TO ALLOW PERSONNEL TO EXIT THE CAR OVER THE TOP OF THE LOAD, THE PALLETS SHOULD BE POSITIONED SC THERE ARE SIX (6) LOAD UNITS IN EACH END. NOTE THAT ALTHOUGH CARS HAVING DOOR OPENINGS AS NARROW AS 61-0" WIDE CAN BE USED FOR FULL LOADS, LOADING IS PROGRESSIVELY MORE DIFFICULT AS THE WIDTH OF THE DOOR OPENING DECREASES.
- 4. IF THE "ALTERNATIVE DOORWAY PROTECTION F" PROCEDURES AS SHOWN ON PAGE 128 ARE USED IN LIEU OF THE WOODEN DOOR GATE TYPE PROTECTION, PIECE MARKED () , NAILED FLOCRLINE BLOCKING MUST BE USED IN LIEU OF EACH LOWER ANTI-SWAY BRACE IN THE DOORWAY AREA. NAILED BLOCKING IS REQUIRED FOR ALL PALLET STACKS WHICH ARE COMPLETELY WITHIN THE DOORWAY AREA OR WHICH EXTEND INTO THE DOORWAY AREA BY ONE-HALF OR MORE OF THE STACK WIDTH ON EITHER SIDE OF THE CAR.
- 5. TOP-OF-LOAD ANTI-SWAY BRACES, SHOWN AS PIECES MARKED ② IN THE LOAD ON PAGE 36, MUST BE INSTALLED IN EACH END OF THE CAR AND WIRE TIED TO A STRAPPING BOARD WITH NO. 14 GAGE WIRE AS TYPICALLY SHOWN BY THE "TIE WIRE APPLICATION B" DETAIL ON PAGE 122. THREE (3) BRACES ARE REQUIRED IN EACH END OF A LOAD REGARDLESS OF THE CAR LENGTH.
- 6. TO FACILITATE POSITIONING OF THE PALLET UNITS AS LOADING PROGRESSES, POSITION PALLET UNIT STACKS AGAINST THE END WALL, THEN POSITION A SEPARATOR GATE, SHOWN AS PIECE MARKED ③, SC THE 1" X 4" TIE PIECES ARE LOCATED UNDER THE "CVERHANG" OF THE PALLET UNITS, REPEAT THIS PROCEDURE FOR THE REMAINING STACKS.
- 7. SEPARATOR GATES IN THE DOCRWAY MUST BE PREVENTED FROM SHIFTING INTO A DOOR OPENING BY THE APPLICATION OF THE STOP PIECES, PIECES MARKED (3) IN CARS EQUIPPED WITH STAGGERED DOORS, STOP PIECES MAY BE REQUIRED ON UP TO FOUR SEPARATOR GATES.
- 8. SEPARATOR GATES MAY BE FORMED FROM 3/8" OR THICKER PLYWCCD IN LIEU OF DIMENSIONAL LUMBER, IF DESIRED. SEE THE "ALTERNATIVE SEPARATOR GATE" DETAIL ON PAGE 122 FOR CONSTRUCTION GUIDANCE.
- CENTER GATE "L" MAY BE PARTIALLY FORMED FROM 1./2" OR THICKER PLYWOOD,
 IF DESIRED. PLYWOOD MAY BE USED IN LIEU OF THE 2" X 6" HORIZONTAL
 PIECES. SEE THE "PLYWOOD CENTER GATE ALTERNATIVE" DETAIL ON PAGE 123
 FOR CHIDANICE.
- 10. FOR EASE OF HANDLING, SPLIT CENTER GATES, WHICH ARE NOT DEPENDENT UPON THE WIDTH OF THE CAR, MAY BE USED AS AN ALTERNATIVE TO THE CARWIDTH GATES. IN LIEU OF EACH "CENTER GATE L" SHOWN AS PIECE MARKED (3) IN THE LOAD ON PAGE 36, INSTALL TWO (2) "CENTER GATES J" AS SHOWN ON PAGE 44. AFTER THE SPLIT GATES AND STRUTS HAVE BEEN INSTALLED, THE SPLIT GATES MUST BE TIED TOGETHER AS DEPICTED BY THE "TIE PIECE APPLICATION" DETAIL ON PAGE 123. OMIT THE STOP PIECES FROM "CENTER GATE J".
- 11. DOOR SPANNER TYPE GATE HOLD DOWN MAY BE USED IN LIEU OF THE DOUBLED 2" X 4" MATERIAL NAILED TO CENTER GATE"L, PROVIDING THE CAR BEING LOADED HAS NAILABLE SIDEWALLS. SEE THE DETAILS ON PAGE 125 FOR GUIDANCE.
- 12. DOORWAY PROTECTION IS REQUIRED FOR ALL PALLET UNIT STACKS WHICH ARE COMPLETELY WITHIN THE DOORWAY AREA OR WHICH EXTEND INTO THE DOORWAY AREA BY ONE-HALF OR MORE OF THE STACK WIDTH. THE WOODEN GATE TYPE OF DOORWAY PROTECTION, SHOWN AS PIECE MARKED (2) IN THE LOAD ON PAGE 36, IS APPLICABLE FOR BOX CARS EQUIPPED WITH CONVENTIONAL SLIDING DOORS AND NAILABLE DOOR POSTS. REFER TO PAGES 126 THRU 128 FOR ALTERNATIVE DOORWAY PROTECTION FOR CARS EQUIPPED WITH CONVENTIONAL SLIDING DOORS. IF THE CAR BEING LOADED IS EQUIPPED WITH PLUG TYPE DOORS, NAILED FLOORLINE BLOCKING AND LOAD BUNDLING STRAPS MUST BE USED. SEE THE "ALTERNATIVE DOORWAY PROTECTION F" DETAIL ON PAGE 128 FOR GUIDANCE.

(CONTINUED AT LEFT)

LOAD AS SHOWN

FLAT DUNNAGE METHOD UNIT (BASIC HEIGHT)
48-UNIT LOAD IN A 60'-8' LONG BY 9'-2' WIDE CONVENTIONAL BOX CAR



BILL OF MATERIAL BOARD FEET LUMBER LINEAR FEET 1" X 6" 32 110 37 2" X 2" 2" X 3" 2" X 4" 15 30 12 . 2" X 6" 209 4. X 4. 82 110 NAILS NO. REQD POUNDS 6d (2") 10d (3") 1/2 304 12d (3-1/4") 16d (3-1/2") 32 3/4 76 2-1/4


SPECIAL NOTES:

- A 50"-6" LONG BY 9"-4" WIDE WOOD-LINED CONVENTIONAL TYPE BOX CAR EQUIPPED WITH 8"-0" WIDE DOOR OPENINGS IS SHOWN, WIDER CARS OF OTHER LENGTHS AND CARS HAVING WIDER OR NARROWER DOOR OPENINGS CAN BE USED. SEE GENERAL NOTE "D" ON PAGE 2.
- 2. THE PALLETIZED UNIT SHOWN IN THE TYPICAL LOAD ON PAGE 38 IS THE FLAT DUNINAGE METHOD UNIT (BASIC HEIGHT). A MAXIMUM OF FORTY (40) OF THESE UNITS, FOR AN APPROXIMATE LADING WEIGHT OF 85,080 POUNDS, CAN BE PLACED IN A 40'-6" LONG CAR WHEN USING THE DEPICTED PROCEDURES. IF A 60'-8" LONG BY 9'-4" OR WIDER CAR IS AVAILABLE, SKTY-FOUR (64) PALLET UNITS FOR AN APPROXIMATE LADING WEIGHT OF 136,128 POUNDS CAN BE LOADED. NOTE THAT EIGHT (8) STRUTS ARE REQUIRED FOR EACH ROW/LAYER IN A 60' CAR; SEE THE PHANTOMED STRUT LEDGERS WHICH MUST BE ADDED TO THE GATES, AS SHOWN ON THE "CENTER GATE M" DETAIL ON PAGE 47.
- ANTI-SWAY BRACING BETWEEN LATERALLY ADJACENT ROWS OF PALLET UNITS IS NOT REQUIRED REGARDLESS OF THE WIDTH OF THE CAR BEING LOADED.
- CENTER GATE "M" MAY BE PARTIALLY FORMED FROM 1/2" OR THICKER PLYWOOD, IF DESIRED, PLYWOOD-MAY BE USED IN LIEU OF THE 2" X 6" HORIZONTAL PIECES, SEE THE "PLYWOOD CENTER GATE ALTERNATIVE" DETAIL ON PAGE 123 FOR GUIDANCE.
- 5. FOR EASE OF HANDLING, SPLIT CENTER GATES, WHICH ARE NOT DEPENDENT UPON THE WIDTH OF THE CAR, MAY BE USED AS AN ALTERNATIVE TO THE CAR-WIDTH GATES. IN LIEU OF EACH "CENTER GATE M" SHOWN AS PIECE MARKED (1) IN THE LOAD ON PAGE 38, INSTALL TWO (2) "CENTER GATES K" AS SHOWN ON PAGE 45. AFTER THE SPLIT GATES AND STRUTS HAVE BEEN INSTALLED, THE SPLIT GATES MUST BE TIED TOGETHER AS DEPICTED BY THE "TIE PIECE APPLICATION" DETAIL ON PAGE 123.
- 6. AN ALTERNATIVE TO THE GATE HOLD DOWN SHOWN AS PIECE MARKED (3) IN THE LOAD ON PAGE 38 MAY BE USED, IF DESIRED, WHEN THE CAR FURNISHED FOR LOADING IS EQUIPPED WITH 8"-0" OR WIDER DOORS, AN ALTERNATIVE MUST BE USED WHEN THE CAR FURNISHED HAS DOOR OPENINGS LESS THAN 8"-0" WIDE. DOOR SPANNER TYPE HOLD DOWN AS SHOWN BY THE DETAILS ON PAGE 125 MAY BE USED IF THE CAR HAS NAILABLE SIDEWALLS, OR HOLD DOWN PIECES MAY BE APPLIED TO THE CENTER GATES AS SHOWN BY THE CENTER GATE. "AN" DETAIL ON PAGE 47.
- 7. DOORWAY PROTECTION IS REQUIRED FOR ALL PALLET UNIT STACKS WHICH ARE COMPLETELY WITHIN THE DOORWAY AREA OR WHICH EXTEND INTO THE DOORWAY AREA PO NON-PAULE OR MORE OF THE STACK LENGTH, THE WOODEN GATE TYPE OF DOORWAY PROTECTION, SHOWN AS PIECES MARKED (3) IN THE LOAD ON PAGE 38, IS APPLICABLE FOR BOX CARS EQUIPPED WITH CONVENTIONAL SLIDING DOORS AND NAILABLE DOOR POSTS, REFER TO PAGES 126 THRU 128 FOR ALTERNATIVE DOORWAY PROTECTION FOR CARS EQUIPPED WITH CONVENTIONAL SLIDING DOORS, IF THE CAR BEING LOADED IS EQUIPPED WITH PLUG TYPE DOORS, NAILED FLOCKLINE BLOCKING AND LOAD BUNDLING STRAPS MUST BE USED. SEE THE "ALTERNATIVE DOORWAY PROTECTION E" DETAIL ON PAGE 128 FOR GUIDANCE.
- 8. THE DEPICTED LOAD CAN BE REDUCED TO SUIT THE QUANTITY TO BE SHIPPED. A 2-TIER LOAD CAN BE REDUCED BY A MULTIPLE OF FOUR (4) PALLET UNITS OR A 1-TIER LOAD CAN BE REDUCED BY A MULTIPLE OF TWO (2) UNITS BY OMITTING ONE OR MORE LOAD. UNITS FROM THE CENTER PORTION OF THE LOAD. OR, THE ENTIRE TOP TIER CAN BE OMITTED. FOR OTHER METHODS OF REDUCING A LOAD, AND FOR TYPICAL LCL PROCEDURES, REFER TO PAGES 92 THRU 120 FOR GUIDANCE.
- IF A FULL LOAD IS TO BE SHIPPED IN A 60' LONG CAR, EIGHT (8) STRUTS
 WILL BE REQUIRED PER ROW/TIER. TO ACCOMMODATE THESE ADDITIONAL
 STRUTS, A STRUT LEDGER MUST BE ADDED TO CENTER GATE "M" FOR EACH
 TIER AS SHOWN BY THE PHANTOMED LINES ON THE DETAIL ON PAGE 47.
- IF PALLETIZED UNITS WHICH DO NOT CONTAIN A FULL QUANTITY OF CONTAINERS ARE TO BE TRANSPORTED, REFER TO PAGES 118 AND 120 FOR SHIPPING GUIDANCE.
- 11. FOR SHIPMENT OF ONE OR MORE LEFTOVER CONTAINERS, SEE THE
 "PROCEDURES FOR SHIPMENT OF LEFTOVER CONTAINERS" ON PAGE 119
 FOR GUIDANCE.

LOAD AS SHOWN

TOTAL WEIGHT---- 111,435 LBS

FLAT DUNNAGE METHOD UNIT (BASIC HEIGHT)
52-UNIT LOAD IN A 50'-6' LONG BY 9'-4" WIDE CONVENTIONAL BOX CAR




SPECIAL NOTES:

- A 50'-6" LONG BY 9'-0" WIDE (INSIDE CLEARANCE) WOOD-LINED BOX CAR EQUIPPED WITH ADJUSTABLE AND/OR FIXED WALL MEMBERS, AND WITH 10'-0" WIDE DOOR OPENINGS IS SHOWN. CARS OF OTHER DIMENSIONS AND CARS HAVING WIDER OR NARROWER DOOR OPENINGS CAN BE USED. SEE GENERAL NOTE "D" ON PAGE 2.
- THE PALLET UNIT SHOWN IN THE TYPICAL LOAD ON PAGE 40 IS THE FLAT DUNNAGE METHOD UNIT (BASIC HEIGHT). A MAXIMUM OF TWENTY-EIGHT (28) OF THESE UNITS, FOR AN APPROXIMATE LADING WEIGHT OF 59,556 POUNDS, CAN BE PLACED IN A 40'-6" LONG CAR.
- 3. IF A CAR HAS BOWED END WALLS WHICH ARE BOWED OUTWARD TWO INCHES (2") OR MORE EITHER FROM SIDE-TO-SIDE OR FROM FLOOR-TO-ROOF, CROSS MEMBERS CAN BE INSTALLED NEAR THE END WALL OF THE CAR TO PROVIDE A "SQUARED END" RATHER THAN INSTALLING DUNNAGE AS SPECIFIED IN GENERAL NOTE "G" ON PAGE 2. THESE CROSS MEMBERS SHOULD BE INSTALLED AT THE SAME HEIGHTS AS THE CROSS MEMBERS USED THROUGHOUT THE LOAD AS BLOCKING MEMBERS. A SEPÄRATOR GATE SHOWN AS PIECE MARKED (4), MUST BE POSITIONED AGAINST THESE CROSS MEMBERS PRIOR TO LOADING.
- 4. TOP-OF-LOAD ANTI-SWAY BRACES, SHOWN AS PIECES MARKED ③ IN THE LOAD ON PAGE 40, MUST BE INSTALLED IN EACH END OF THE CAR AND WIRE TIED TO THE STRAPPING BOARDS WITH NO. 14 GAGE WIRE AS TYPICALLY SHOWN BY THE "TIE WIRE APPLICATION B" DETAIL ON PAGE 122. THREE (3) BRACES ARE REQUIRED IN EACH END OF A LOAD REGARDLESS OF THE CAR LENGTH.
- 5. TO FACILITATE POSITIONING OF THE PALLET UNITS AS LOADING PROGRESSES, POSITION PALLET UNIT STACKS AGAINST THE END WALL, THEN POSITION A SEPARATOR GATE, SHOWN AS PIECE MARKED (4), SO THE 1" X 4" TIE PIECES ARE LOCATED UNDER THE "OVERHAMG" OF THE PALLET UNITS. REPEAT THIS PROCEDURE FOR THE REMAINING STACKS.
- 6. SEPARATOR GATES IN THE DOORWAY MUST BE PREVENTED FROM SHIFTING INTO A DOOR OPENING BY THE APPLICATION OF THE STOP PIECES, PIECES MARKED (7) IN CARS EQUIPPED WITH STAGGERED DOORS, STOP PIECES MAY BE REQUIRED ON UP TO FOUR SEPARATOR GATES.
- SEPARATOR GATES MAY BE FORMED FROM 3/8" OR THICKER PLYWOOD IN LIEU OF DIMENSIONAL LUMBER, IF DESIRED. SEE THE "ALTERNATIVE SEPARATOR GATE" DETAIL ON PAGE 122 FOR CONSTRUCTION GUIDANCE.
- IF THE CAR BEING LOADED IS EQUIPPED WITH AT LEAST TWELVE (12) DOORWAY
 MEMBERS, AN ADDITIONAL FOUR PALLET UNITS CAN BE LOADED IN THE DOORWAY
 AREA.
- 9. THE DEPICTED LOAD CAN BE REDUCED TO SUIT THE QUANTITY TO BE SHIPPED. A LOAD MAY BE REDUCED BY MULTIPLES OF TWO (2) PALLET UNITS BY OMITTING LATERALLY ADJACENT UNITS FROM THE TOP LAYER OF ONE OR MORE LOAD UNITS OR BY MULTIPLES OF FOUR (4) PALLET UNITS BY OMITTING ONE OR MORE ENITEE LOAD UNITS. TO REDUCE A LOAD BY ONE (1) PALLET UNIT, REFER TO THE LCL PROCEDURES ON PAGES 90 AND 91 FOR GUIDANCE.
- FOR SHIPMENT OF ONE OR MORE LEFTOVER CONTAINERS, SEE, THE "PROCEDURES FOR SHIPMENT OF LEFTOVER CONTAINERS" ON PAGE 119 FOR GUIDANCE.

LUMBER	LINEAR FEET	BOARD FEET
I" X 4"	252	84
1" X 6"	387	194
2" X 4"	255	170
2" X 6"	19	19
NAILS	NO. REQD	POUNDS
6d (2")	336	2
10d (3")	300	4-3/4

LOAD AS SHOWN

FLAT DUNNAGE METHOD UNIT (BASIC HEIGHT)
40-UNIT LOAD IN A 50'-6' LONG BY 9'- 0' WIDE BOX CAR EQUIPPED WITH MECHANICAL BRACING DEVICES



- 10. THE DEPICTED LOAD CAN BE REDUCED TO SUIT THE QUANTITY TO BE SHIPPED. A 2-TIER LOAD CAN BE REDUCED BY A MULTIPLE OF FOUR (4) PALLET UNITS OR A 1-TIER LOAD CAN BE REDUCED BY A MULTIPLE OF TWO (2) UNITS BY OMITTING ONE OR MORE LOAD UNITS FROM THE CENTER PORTION OF THE LOAD. OR, THE ENTIRE TOP TIER CAN BE OMITTED. FOR CTHER METHODS OF REDUCING A LOAD, AND FOR TYPICAL LCL PROCEDURES, REFER TO PAGES 94 THRU 105 AND GENERAL NOTE "FF" ON PAGE 3 FOR GUIDANCE.
- 11. IF PALLET UNITS WHICH DO NOT CONTAIN A FULL QUANTITY OF CONTAINERS ARE TO TRANSPORTED, REFER TO PAGE 117 AND/OR PAGES 118 AND 120 FOR SHIPPING GUIDANCE.
- FOR SHIPMENT OF ONE OR MORE LEFTOVER CONTAINERS, SEE THE "PROCEDURES FOR SHIPMENT OF LEFTOVER CONTAINERS" ON PAGE 119 FOR GUIDANCE.

SPECIAL NOTES:


- A 50'-6" LONG BY 9'-2" WIDE WOOD-LINED CUSHIONED BOX CAR EQUIPPED WITH LOAD DIVIDER BULKHEADS AND WITH 10'-0" WIDE DOOR OPENINGS IS SHOWN. CARS OF OTHER DIMENSIONS AND CARS HAVING NARROWER OR WIDER DOOR OPENINGS CAN BE USED. SEE GENERAL NOTES "AA" THRU "EE" ON PAGE 3.
- 2. THE PALLET UNIT SHOWN IN THE TYPICAL LOAD ON PAGE 42 IS THE FLAT DUNNAGE METHOD UNIT (BASIC HEIGHT). A MAXIMUM OF FCRTY-EIGHT (48) OF THESE UNITS, FOR AN APPROXIMATE LADING WEIGHT OF 102,096 POUNDS, CAN BE PLACED IN A 60'-8" LONG CAR, OR A MAXIMUM OF THIRTY-TWO UNITS CAN BE LOADED IN A 40'-6" CAR FOR AN APPROXIMATE LADING WEIGHT OF 68,064 PCUNDS, WHEN USING THE DEPICTED PROCEDURES. IF CARS 9'-4" OR WIDER ARE AVAILABLE, THE CROSSWISE LOADING PATTERN SHOWN ON PAGE 38 MAY BE EMPLOYED. THEN, SIXTY-FOUR (64) PALLET UNITS FOR AN APPROXIMATE LADING WEIGHT OF 136,128 PCUNDS CAN BE PLACED IN A 60'-8" LONG CAR, FIFTY-TWO (52) UNITS CAN BE PLACED IN A 50'-6" LONG CAR FOR AN APPROXIMATE LADING WEIGHT OF 110,604 POUNDS, AND FORTY (40) UNITS CAN BE LOADED IN A 40'-6" LONG CAR FOR AN APPROXIMATE LADING WEIGHT OF 110,604 POUNDS, AND FORTY (40) UNITS CAN BE LOADED IN A 40'-6" LONG CAR FOR AN APPROXIMATE LADING WEIGHT OF 185,080 POUNDS.
- 3. IF THE "ALTERNATIVE DOORWAY PROTECTION F" PROCEDURES AS SHOWN ON PAGE 128 ARE USED IN LIEU OF THE WOODEN DOOR GATE TYPE PROTECTION, PIECE MARKED (\$\frac{3}{2}\), NAILED FLOORLINE BLOCKING MUST BE USED IN LIEU OF THE LOWER ANTI-SWAY BRACE IN THE DOORWAY AREA. NAILED BLOCKING IS REQUIRED FOR ALL PALLET STACKS WHICH ARE COMPLETELY WITHIN THE DOORWAY AREA OR WHICH EXTEND INTO THE DOORWAY AREA BY ONE-HALF OR MORE OF THE THE STACK WIDTH ON EITHER SIDE OF THE CAR.
- 4. TOP-OF-LOAD ANTI-SWAY BRACES, SHOWN AS PIECES MARKED ② IN THE LOAD ON PAGE 42, MUST BE INSTALLED IN EACH END OF THE CAR AND WIRE TIED TO STRAPPING BOARDS WITH NO. 14 GAGE WIRE AS TYPICALLY SHOWN BY THE "TIE WIRE APPLICATION B" DETAIL ON PAGE 122. THREE (3) BRACES ARE REQUIRED IN EACH END OF A LOAD REGARDLESS OF THE CAR LENGTH.
- 5. TO FACILITATE POSITIONING OF THE PALLET UNITS AS LOADING PROGRESSES, POSITION PALLET UNIT STACKS AGAINST THE END WALL, THEN POSITION A SEPARATOR GATE SHOWN AS PIECE MARKED ③, SO THE 1" X 4" TIE PIECES ARE LOCATED UNDER THE "CVERHANG" OF THE PALLET UNITS. REPEAT THIS PROCEDURE FOR THE REMAINING STACKS.
- 6. SEPARATOR GATES IN THE DOORWAY MUST BE PREVENTED FROM SHIFTING INTO A DOOR OPENING BY THE APPLICATION OF THE STOP PIECES, PIECES MARKED ④ IN CARS EQUIPPED WITH STAGGERED DOORS, STOP PIECES MAY BE REQUIRED ON UP TO FOUR SEPARATOR GATES.
- SEPARATOR GATES MAY BE FORMED FROM 3/8" OR THICKER PLYWOOD IN LIEU OF DIMENSIONAL LUMBER, IF DESIRED. SEE THE "ALTERNATIVE SEPARATOR GATE" DETAIL ON PAGE 122 FOR CONSTRUCTION GUIDANCE.
- B. DOORWAY PROTECTION IS REQUIRED FOR ALL PALLET UNIT STACKS WHICH ARE COMPLETELY WITHIN THE DOORWAY AREA OR WHICH EXTEND INTO THE DOCRWAY AREA BY ONE-HALF OR MORE OF THE STACK WIDTH. THE WOODEN GATE TYPE OF DOORWAY PROTECTION, SHOWN AS PIECES MARKED (§) IN THE LOAD ON PAGE 42, IS APPLICABLE FOR BOX CARS EQUIPPED WITH CONVENTIONAL SLIDING DOORS AND NAILABLE DOOR POSTS. REFER TO PAGES 126 THRU 128 FOR ALTERNATIVE DOCRWAY PROTECTION FOR CARS EQUIPPED WITH CONVENTIONAL SLIDING DOORS. IF THE CAR BEING LOADED IS EQUIPPED WITH CUNVENTIONAL SLIDING DOORS, NAILED FLOORLINE BLOCKING AND LOAD BUNDLING STRAPS MUST BE USED. SEE THE "ALTERNATIVE DOORWAY PROTECTION F" DETAIL ON PAGE 128 FOR GUIDANCE IF THE PALLET UNITS ARE POSITIONED AS SHOWN ON PAGE 42. SEE THE "ALTERNATIVE DOORWAY PROTECTION F" DETAIL ON THAT PAGE IF THE PALLET UNITS ARE POSITIONED AS SHOWN ON PAGE 42.
- 9. THE STRUT ASSEMBLY, SHOWN AS PIECE MARKED (3) IN THE LOAD ON PAGE 42, IS REQUIRED WHEN THE LOAD IN EITHER END OF A CAR IS 50,000 POUNDS OR MORE. FOR THE DEPICTED LOAD THE STRUT ASSEMBLY WOULD NOT BE REQUIRED IF THE LOAD CONSISTED OF FIVE (5) LOAD UNITS IN EACH END OF THE CAR. THE STRUT ASSEMBLY WILL ALWAYS BE REQUIRED FOR FULL LOADS IN 60' OR LONGER CARS.

(CONTINUED AT LEFT)

LUMBER	LINEAR FEET	BOARD FEET
1" X 4"	202	68
1" X 6"	410	205
1" X 8"	18	12
2" X 3"	32	16
2" X 4"	323	216
2" X 6"	19	19
4" X 4"	10	14
NAILS	NO. REQD	POUNDS
6d (2*)	330	2
10d (3")	358	5-1/2
12d (3-1/4")	32	3/4

LOAD AS SHOWN

FLAT DUNNAGE METHOD UNIT (BASIC HEIGHT)
40-UNIT LOAD IN A 50'-6" LONG BY 9'-2" WIDE BOX CAR EQUIPPED WITH LOAD DIVIDERS




CRIB FILL E


CRIB FILL ASSEMBLIES "E" AND "F" SHOULD BE PRE-FABRICATED. CONSTRUCT TO BE 1/2" TO 3/4" LESS IN WIDTH THAN THE DISTANCE BETWEEN LATERALLY ADJACENT ROWS OF PALLET UNITS.


CRIB FILL F


CRIB FILL "F" IS NOT REQUIRED FOR A 1-HIGH LOAD; USE CRIB FILL "E" THROUGHOUT THE LENGTH OF THE LOAD.





DETAILS FOR FLAT DUNNAGE METHOD (BASIC HEIGHT)











PIECES AND BOTTOM SUPPORT PIECES OF THE CRIB FILL, PIECES MARKED ③, MUST HAVE THREE INCHES (3") CUT OFF THE BOTTOM END OF ONE SIDE SO THE CRIB WILL REST EVENLY ON THE NAILED SIDE BLOCKING WHICH IS ADJACENT TO THE LENGTHWISE UNITS. ALSO NOTE THAT THE SIDE BLOCKING FOR THE CROSSWISE UNITS MUST BE PREPOSITIONED APPROXIMATELY FIFTY-TWO INCHES (52") FROM THE NEARSIDE CAR WALL, AND THE CENTER GATE "N" WHICH IS IN THE DOORWAY MUST BE WIRE TIED TO PIECE MARKED ⑥ TO PREVENT DISPLACEMENT.

- 10. THE DEPICTED LOAD CAN BE REDUCED TO SUIT THE QUANTITY TO BE SHIPPED. THE LOAD CAN BE REDUCED BY ONE OR MORE PALLET UNITS BY EMPLOYING THE PROCEDURES SHOWN ON PAGE 96. SIX (6) PALLET UNITS CAN BE OMITTED FROM A 3-TIER LOAD BY LEAVING OUT THE LENGTHWISE STACK NUMBERED 7, THE CROSSWISE STACK NUMBERED 9 AND THE ADJACENT CRIB FILL. NOTE THAT STRUT BRACING MUST BE APPLIED TO ALL THE STRUTS. OR, THE ENTIRE ONE OR TWO TOP TIERS CAN BE OMITTED. A PARTIAL 1-TIER LOAD CAN BE SHIPPED IN ONE OR BOTH ENDS OF A CAR BY USING KNEE BRACES AS SHOWN ON PAGES 112 AND 113.
- 11. IF PALLETIZED UNITS WHICH DO NOT CONTAIN A FULL QUANTITY OF CONTAINERS ARE TO BE TRANSPORTED, REFER TO PAGE 117 FOR SHIPPING GUIDANCE FOR LENGTHWISE UNITS AND PAGES 118 AND 120 FOR CROSSWISE UNITS.
- FOR SHIPMENT OF ONE OR MORE LEFTOVER CONTAINERS, SEE THE "PROCEDURES FOR SHIPMENT OF LEFTOVER CONTAINERS" ON PAGE 119 FOR GUIDANCE.

LUMBER	LINEAR FEET	BOARD FEET
1" X 4"	142	48
1" X 6"	314	157
2" X 2"	98	33
2" X 3"	36	18
2" X 4"	1075	717
2" X 6"	206	206
4" X 4"	73	98
NAILS	NO. REQD	POUNDS
6d (2")	252	1-1/2
10d (3")	1704	26-1/4
12d (3-1/4")	48	1
16d (3-1/2")	128	3

SPECIAL NOTES:


- A 60'-8" LONG BY 9'-2" WIDE WOOD-LINED CONVENTIONAL TYPE BOX CAR EQUIPPED WITH 10'-0" WIDE DOOR OPENINGS IS SHOWN. CARS OF OTHER DIMENSIONS AND CARS HAVING WIDER OR NARROWER DOOR OPENINGS CAN BE USED. SEE GENERAL NOTE "D" ON PAGE 2 AND SPECIAL NOTE 3 BELOW.
- 2. THE PALLET UNIT SHOWN IN THE TYPICAL LOAD ON PAGE 48 IS THE FLAT DUNNAGE METHOD UNIT (DECREASED HEIGHT). A MAXIMUM OF SIXTYNINE (69) OF THESE UNITS, FOR AN APPROXIMATE LADING WEIGHT OF 111,366 POUNDS, CAN BE PLACED IN A 50'-6" LONG CAR WHEN USING THE DEPICTED PROCEDURES; FIFTY-FOUR (54) UNITS, FOR A LADING WEIGHT OF 87,156 POUNDS, CAN BE CUILOADED IN A 40'-6" LONG CAR.
- 3. THE DEPICTED LOADING PATTERN IS ADEQUATE FOR CARS HAVING DOOR OPENINGS AS NARROW AS 8"-0". IF A CAR HAVING DOOR CPENINGS LESS THAN 8"-0" WIDE IS TO BE LOADED, THE LENGTHWISE UNITS SHOULD BE LOADED SIX (6) STACKS LONG IN EACH END OF THE CAR AND THE CROSSWISE UNITS SHOULD BE LOADED EIGHT (8) STACKS LONG IN EACH END. PIECE MARKED (7) WILL NOT BE REQUIRED; THE BALANCE OF THE DUNNAGE WILL NOT CHANGE.
- 4. THE "HIGH" CRIB, SHOWN AS PIECE MARKED (), MUST BE INSTALLED IN EACH END OF THE LOAD. FOUR (4) ASSEMBLIES ARE REQUIRED IN EACH END OF A LOAD REGARDLESS OF THE CAR LENGTH.
- 5. THE SEPARATOR GATES, SHOWN AS PIECES MARKED ② IN THE LOAD ON PAGE 48, ARE DESIGNATED "RIGHT HAND" AND "LEFT HAND" TO FACILITATE POSITIONING OF THE PALLET UNITS AS LOADING PROGRESSES. WHEN LOADING THE CAR, POSITION A PALLET UNITS TACK AGAINST THE END WALL, THEN POSITION A SEPARATOR GATE SO THE 1" X 4" TIE PIECES ARE LOCATED UNDER THE "OVERHANG" OF THE BOTTOM AND TOP PALLET UNITS. REPEAT THIS PROCEDURE FOR THE REMAINING STACKS,
- 6. ALL SEPARATOR GATES, PIECES MARKED ②, WHICH ARE WITHIN THE DOORWAY AREA OF A CAR EQUIPPED WITH CONVENTIONAL SLIDING DOORS MUST BE WIRE TIED TO THE ADJACENT CRIB FILL TO PREVENT DISPLACEMENT. ENCIRCLE THE STOP PIECE OF THE SEPARATOR GATE AND THE UPPER HORIZONTAL PIECE OF THE CRIB FILL WITH NO. 14 GAGE WIRE AND TWIST TAUT.
- 7. SEPARATOR GATES MAY BE FORMED FROM 3/8" OR THICKER PLYWOOD IN LIEU OF DIMENSIONAL LUMBER, IF DESIRED, FOR ONE OR TWO-LAYER LOADS; PLYWOOD SEPARATOR GATES FOR A 3-LAYER LOAD ARE NOT ECONOMICALLY FEASIBLE. CONSTRUCT EACH SEPARATOR GATE FOR ONE OR TWO-LAYER LOADS FROM 43" WIDE PLYWOOD OF AN APPROPRIATE LENGTH.
- 8. CENTER GATES "N" AND "C" MAY BE PARTIALLY FORMED FROM 1/2" OR THICKER PLYWOOD, IF DESIRED, PLYWOOD MAY BE USED IN LIEU OF THE 2" X 6" HORIZONTAL PIECES. SEE THE "PLYWOOD CENTER GATE ALTER-NATIVE" DETAIL ON PAGE 123 FOR GUIDANCE.
- 9. DOORWAY PROTECTION IS REQUIRED FOR ALL PALLET UNIT STACKS WHICH ARE COMPLETELY WITHIN THE DOORWAY AREA OR WHICH EXTEND INTO THE DOORWAY AREA BY ONE-HALF OR MORE OF THE STACK WIDTH OR LENGTH. THE WCODEN GATE TYPE OF DOORWAY PROTECTION, SHOWN AS PIECES MARKED (1) AND (2) IN THE LOAD ON PAGE 48, IS APPLICABLE FOR BOX CARS EQUIPPED WITH CONVENTIONAL SLIDING DOORS AND NAILABLE DOOR POSTS. REFER TO PAGES 126 THRU 128 FOR ALTERNATIVE DOORWAY PROTECTION FOR CARS EQUIPPED WITH CONVENTIONAL SLIDING DOORS, IT THE CAR BEING LOADDED IS EQUIPPED WITH PLUG TYPE DOORS, NAILED FLOORLINB BLOCKING AND LOAD-BUNDLING STRAPS MUST BE USED. SEE THE "ALTERNATIVE DOORWAY PROTECTION F" DETAILS ON PAGE 128 FOR GUIDANCE; A COMBINATION OF THE TWO METHODS MUST BE USED. NAILED SIDE BLOCKING, DOUBLED 2" X 4" X 7"-6" LONG, WILL BE USED UNDER THE CRIB FILL SHOWN IN THE DOORWAY AREA OF THE LOAD. POSITION ONE SIDE BLOCKING ADJACENT TO THE GOSSWISE STACKS NUMBERED B AND 9 AND ONE DIRECTLY OPPOSITE AGAINST ALL OR A PORTION OF THE LENGTHMISE STACKS NUMBERED 6 AND 7. THESE PIECES WILL BE USED IN LIEU OF THE 40" AND 48" LONG PIECES SHOWN BY THE ALTERNATIVE DETAILS. A SPACER ASSEMBLY, AS SHOWN IN THE "ALTERNATIVE DOORWAY PROTECTION F" DETAILS, MUSTENDS OVER THE CROSSWISE CONTAINERS TO BE LIKE THE NEAR END OF THE STRAPPING BOARD SHOWN IN THE "ALTERNATIVE DOORWAY PROTECTION F" DETAIL, ALS" X 4" X 4" X 4" AU" DOUBLED BATTEN AS SHOWN IN THAT WERTICAL

(CONTINUED AT LEFT)

LOAD AS SHOWN

ITEM	QUANTITY	WEI	GHT (APPROX)
	TOTAL WEIGHT	138, 162	LBS

FLAT DUNNAGE METHOD UNIT (DECREASED HEIGHT)
84-UNIT LOAD !N A 60'-8" LONG BY 9'-2" WIDE CONVENTIONAL BOX CAR



- 12. DOORWAY PROTECTION IS REQUIRED FOR ALL PALLET UNIT STACKS WHICH ARE COMPLETELY WITHIN THE DOORWAY AREA OR WHICH EXTEND INTO THE DOORWAY AREA BY ONE-HALF OR MORE OF THE STACK WIDTH. THE WOODEN GATE TYPE OF DOORWAY PROTECTION, SHOWN AS PIECES MARKED (2) IN THE LOAD ON PAGE 50, IS APPLICABLE FOR BOX CARS EQUIPPED WITH CONVENTIONAL SLIDING DOORS AND NAILABLE DOOR POSTS. REFER TO PAGES 126 THRU 128 FOR ALTERNATIVE DOORWAY PROTECTION FOR CARS EQUIPPED WITH CONVENTIONAL SLIDING DOORS. IF THE CAR BEING LOADED IS EQUIPPED WITH PLUG TYPE DOORS, NAILED FLOCRLINE BLOCKING AND LOAD BUNDLING STRAPS MUST BE USED. SEE THE "ALTERNATIVE DOORWAY PROTECTION F" DETAIL ON PAGE 128 FOR GUIDANCE. SEE SPECIAL NOTE 13.
- 13. IF THE ALTERNATIVE DOORWAY PROTECTION "F" PROCEDURES SHOWN ON PAGE
 128 ARE USED IN LIEU OF THE WOODEN DOORWAY PROTECTION, PIECES MARKED
 (2), THE CENTER GATES MUST BE RESTRAINED FROM LATERAL MOVEMENT. THIS
 CAN BE ACCOMPLISHED BY NAILING TO THE CAR FLOOR A DOUBLED 2" X 4" X 18"
 PIECE POSITIONED LONGITUDINALLY SO AS TO BE CENTERED AGAINST THE FILL
 PIECE OF A CENTER GATE. TWO (2) PIECES WILL BE REQUIRED FOR EACH CENTER
 GATE WHICH IS IN THE DOOR OPENING OR WITHIN SIX INCHES (6") OF BEING
 IN THE DOOR OPENING.
- 14. THE DEPICTED LOAD CAN BE REDUCED TO SUIT THE QUANTITY TO BE SHIPPED.

 A 3-TIER LOAD CAN BE REDUCED BY A MULTIPLE OF SIX (6) PALLET UNITS, OR

 A 2-TIER LOAD CAN BE REDUCED BY A MULTIPLE OF FOUR (4) UNITS, OR A

 1-TIER LOAD CAN BE REDUCED BY A MULTIPLE OF TWO (2) UNITS BY OMITTING

 ONE OR MORE LOAD UNITS FROM THE CENTER PORTION OF THE LOAD. OR,
 THE ENTIRE ONE OR TWO TOP TIERS CAN BE OMITTED. FOR OTHER METHODS

 OF REDUCING A LOAD, AND FOR TYPICAL LCL PROCEDURES, REFER TO PAGES

 92 THRU 120 FOR GUIDANCE.
- 15. IF PALLET UNITS WHICH DO NOT CONTAIN A FULL QUANTITY OF CONTAINERS ARE TO BE TRANSPORTED, REFER TO PAGE 117 FOR SHIPPING GUIDANCE.
- 16. FOR SHIPMENT OF ONE OR MORE LEFTOVER CONTAINERS, SEE THE "PROCEDURES FOR SHIPMENT OF LEFTOVER CONTAINERS" ON PAGE 119 FOR GUIDANCE.

LUMBER	LINEAR FEET	BOARD FEET
1" X 4"	197	66
1" X 6"	507	254
2" X 2"	94	32
2" X 3"	36	18
2" X 4"	. 523	349
2" X 6"	219	219
4" X 4"	100	134
NAILS	NO, REQD	POUNDS
6d (2")	324	2
10d (3")	820	12-3/4
12d (3-1/4")	36	3/4
16d (3-1/2")	96	2-1/4

SPECIAL NOTES:


- A 60'-8" LONG BY 9'-2" WIDE WCOD-LINED CONVENTIONAL TYPE BOX CAR EQUIPPED WITH 10'-0" WIDE DOOR OPENINGS IS SHOWN, CARS OF OTHER DIMENSIONS AND CARS HAVING WIDER OR NARROWER DOOR OPENINGS CAN BE USED. SEE GENERAL NOTE "D" ON PAGE 2 AND SPECIAL NOTE 3 BELOW.
- 2. THE PALLETIZED UNIT SHOWN IN THE TYPICAL LOAD ON PAGE 50 IS THE FLAT DUNNAGE METHOD UNIT (DECREASED HEIGHT). A MAXIMUM OF SIXTY (60) OF THESE UNITS, FOR AN APPROXIMATE LADING WEIGHT OF 96,840 POUNDS, CAN BE PLACED IN A 50'-6" LONG CAR WHEN USING THE DEPICTED PROCEDURES; FORTY-EIGHT (48) UNITS, FOR AN APPROXIMATE LADING WEIGHT OF 77,472 POUNDS, CAN BE OUTLOADED IN A 40'-4" LONG CAR
- 3. THE DEPICTED LOADING PATTERN IS ADEQUATE FOR CARS HAVING DOOR OPENINGS 8" THRU 10" OR WIDER. IF THE CAR TO BE LOADED HAS DOOR OPENINGS LESS THAN 8"-0" WIDE AND NOT OF SUFFICIENT HEIGHT TO ALLOW PERSONNEL TO EXIT THE CAR OVER THE TOP OF THE LOAD WHEN NECESSARY, THE PALLETS SHOULD BE POSITIONED SO THERE ARE SIX (6) LOAD UNITS IN EACH END. NOTE THAT ALTHOUGH CARS HAVING DOOR OPENINGS AS NARROW AS 6"-0" WIDE CAN BE USED FOR FULL LOADS, LOADING IS PROGRESSIVELY MORE DIFFICULT AS THE WIDTH OF THE DOOR OPENING
- 4. IF THE "ALTERNATIVE DOORWAY PROTECTION F" PROCEDURES AS SHOWN ON PAGE 128 ARE USED IN LIEU OF THE WOODEN DOOR GATE TYPE PROTECTION, PIECE MARKED ②, NAILED FLOCKINE BLOCKING MUST BE USED IN LIEU OF THE LOWER ANTI-SWAY BRACE IN THE DOORWAY AREA. NAILED BLOCKING IS REQUIRED FOR ALL PALLET STACKS WHICH ARE COMPLETELY WITHIN THE DOORWAY AREA OR WHICH EXTEND INTO THE DOORWAY AREA BY ONE-HALF OR MORE OF THE STACK WIDTH ON EITHER SIDE OF THE CAR.
- 5. TOP-OF-LOAD ANTI-SWAY BRACES, SHOWN AS PIECES MARKED ② IN THE LOAD ON PAGE 50, MUST BE INSTALLED IN EACH END OF THE CAR AND WIRE THED TO A STRAPPING BOARD WITH NO. 14 GAGE WIRE AS TYPICALLY SHOWN BY THE "TIE WIRE APPLICATION B" DETAIL ON PAGE 122. THREE (3) BRACES ARE REQUIRED IN EACH END OF A LOAD REGARDLESS OF THE CAR I FINGTH.
- 6. TO FACILITATE POSITIONING OF THE PALLET UNITS AS LOADING PROGRESSES, WHEN LOADING THE BOX CAR, POSITION PALLET UNIT STACKS AGAINST THE END WALL, THEN POSITION A SEPARATOR GATE, SHOWN AS PIECE MARKED 3, SO THE 1" X 4" TIE PIECES ARE LOCATED UNDER THE "OVERHANG" OF THE BOTTOM AND TOP PALLET UNITS. REPEAT THIS PROCEDURE FOR THE REMAINING STACKS.
- 7. SEPARATOR GATES IN THE DOORWAY MUST BE PREVENTED FROM SHIFTING INTO A DOOR OPENING BY THE APPLICATION OF THE STOP PIECES, PIECES MARKED (4). IN CARS EQUIPPED WITH STAGGERED DOORS, STOP PIECES MAY BE REQUIRED ON UP TO FOUR SEPARATOR GATES.
- 8. SEPARATOR GATES MAY BE FORMED FROM 3/8" OR THICKER PLYWOOD IN LIEU OF DIMENSIONAL LUMBER, IF DESIRED, FOR ONE OR TWO-LAYER LOADS; PLYWOOD SEPARATOR GATES FOR A 3-LAYER LOAD ARE NOT ECONOMICALLY FEASIBLE. SEE THE "ALTERNATIVE SEPARATOR GATE" DETAIL ON PAGE 122 FOR CONSTRUCTION GUIDANCE.
- CENTER GATE "P" MAY BE PARTIALLY FORMED FROM 1/2" OR THICKER PLYWCOD
 IF DESIRED. PLYWCOD MAY BE USED IN LIEU OF THE 2" X 6" HORIZONTAL
 PIECES. SEE THE "PLYWCOD CENTER GATE ALTERNATIVE" DETAIL ON PAGE
 123 FOR GUIDANCE.
- 10. FOR EASE OF HANDLING, SPLIT CENTER GATES, WHICH ARE NOT DEPENDENT UPON THE WIDTH OF THE CAR, MAY BE USED AS AN ALTERNATIVE TO THE CAR-WIDTH GATES. IN LIEU OF EACH "CENTER GATE P", SHOWN AS PIECE MARKED (3) IN THE LOAD ON PAGE 5C, INSTALL TWO (2) "CENTER GATES N" AS SHOWN ON PAGE 58. AFTER THE SPLIT GATES AND STRUTS HAVE REEN INSTALLED, THE SPLIT GATES MUST BE TIED TOGETHER AS DEPICTED BY THE "TIE PIECE APPLICATION" DETAIL ON PAGE 123. OMIT THE STOP PIECES FROM "CENTER GATE N".
- 11. DOOR SPANNER TYPE GATE HOLD DOWN MAY BE USED IN LIEU OF THE DOUBLED 2" X 4" MATERIAL NAILED TO CENTER GATE "P." PROVIDING THE CAR BEING LOADED HAS NAILABLE SIDEWALLS. SEE THE DETAILS ON PAGE 125 FOR GUIDANCE.

(CONTINUED AT LEFT)

LOAD AS SHOWN

ITEM	QUANTITY	WEIG	GHT (APPROX)
	72		
TC	TAL WEIGHT	118,371	LBS

FLAT DUNNAGE METHOD UNIT (DECREASED HEIGHT)
72-UNIT LOAD IN A 60'-8" LONG BY 9'-2" WIDE CONVENTIONAL BOX CAR



BILL OF MATERIAL LUMBER LINEAR FEET BOARD FEET 1" X 6" 2" X 2" 112 38 2" X 3" 36 12 18 184 184 4" X 4" 82 110 NAILS NO. REQD POUNDS 72 264 36 4-1/4 12d (3-1/4") 3/4 16d (3-1/2") 2-1/4


SPECIAL NOTES:

- 1. A 50'-6" LONG BY 9'-4" WIDE WOOD-LINED CONVENTIONAL TYPE BCX CAR EQUIPPED WITH 8'-0" WIDE DOOR OPENINGS IS SHOWN. WIDER CARS OF CTHER LENGTHS AND CARS HAVING WIDER OR NARROWER DOOR OPENINGS CAN BE USED, SEE GENERAL NOTE "D" ON PAGE 2 AND SPECIAL NOTE 9 BEIOW
- 2. THE PALLETIZED UNIT SHOWN IN THE TYPICAL LOAD ON PAGE 52 IS THE FLAT DUNNAGE METHOD UNIT (DECREASED HEIGHT). A MAXIMUM OF SIXTY (50) OF THESE UNITS, FOR AN APPROXIMATE LADING WEIGHT OF 96,840 POUNDS, CAN BE PLACED IN A 40'-6" LONG CAR WHEN USING THE DEPICTED PROCEDURES. IF A 60'-8" LONG BY 9'-4" OR WIDER CAR IS AVAILABLE, NINETYSIX (96) PALLET UNITS FOR AN APPROXIMATE LADING WEIGHT OF 154,944 POUNDS CAN BE LOADED. SEE SPECIAL NOTE 9 FOR CENTER GATE MODIFICATIONS WHICH MUST BE MADE IF 60' LONG CARS ARE TO BE USED.
- 3. ANTI-SWAY BRACING BETWEEN LATERALLY ADJACENT ROWS OF PALLET UNITS IS NOT REQUIRED REGARDLESS OF THE WIDTH OF THE CAR BEING LOADED.
- 4. CENTER GATE "Q" MAY BE PARTIALLY FORMED FROM 1/2" OR THICKER PLYWOOD, IF DESIRED. PLYWOOD MAY BE USED IN LIEU OF THE 2" X 6" HORIZONTAL PIECES. SEE THE "PLYWOOD CENTER GATE ALTERNATIVE" DETAIL ON PAGE 123 FOR GUIDANCE.
- 5. FOR EASE OF HANDLING, SPLIT CENTER GATES, WHICH ARE NOT DEPENDENT UPON THE WIDTH OF THE CAR, MAY BE USED AS AN ALTERNATIVE TO THE CAR-WIDTH GATES. IN LIEU OF EACH "CENTER GATE Q", SHOWN AS PIECE MARKED (1) IN THE LOAD ON PAGE 52, INSTALL TWO (2) "CENTER GATES O" AS SHOWN ON PAGE 59. AFTER THE SPLIT GATES AND STRUTS HAVE BEEN INSTALLED, THE SPLIT GATES MUST BE TIED TOGETHER AS DEPICTED BY THE "TIE PIECE APPLICATION" DETAIL ON PAGE 123.
- 6. AN ALTERNATIVE TO THE GATE HOLD DOWN SHOWN AS PIECE MARKED ③
 IN THE LOAD ON PAGE 52 MAY BE USED, IF DESIRED, WHEN THE CAR
 FURNISHED FOR LOADING IS EQUIPPED WITH 8+-0+ OR WIDER DOORS. AN
 ALTERNATIVE MUST BE USED WHEN THE CAR FURNISHED HAS DOOR CPENINGS
 LESS THAN 8'-0+ WIDE. DOOR SPANNER TYPE HOLD DOWN AS SHOWN ON
 PAGE 125 MAY BE USED, OR HOLD DOWN PIECES MAY BE APPLIED TO THE
 CENTER GATES AS SHOWN BY THE CENTER GATE "Q+ DETAIL ON PAGE 61.
- 7. DOCRWAY PROTECTION IS REQUIRED FOR ALL PALLET UNIT STACKS WHICH ARE COMPLETELY WITHIN THE DOCRWAY AREA OR WHICH EXTEND INTO THE DOCRWAY AREA BY ONE-HALF OR MORE OF THE STACK LENGTH. THE WOODEN GATE TYPE OF DOCRWAY PROTECTION, SHOWN AS PIECES MARKED (3) IN THE LOAD ON PAGE 52, IS APPLICABLE FOR BOX CARS EQUIPPED WITH CONVENTIONAL SLIDING DOORS AND NAILABLE DOOR POSTS. REFER TO PAGES 126 THRU 128 FOR ALTERNATIVE DOCRWAY PROTECTION FOR CARS EQUIPPED WITH CONVENTIONAL SLIDING DOORS. IF THE CAR BEING LOADED IS EQUIPPED WITH PLUG TYPE DOORS, NAILED FLOCRLINE BLOCKING AND LOAD BUNDLING STRAPS MUST BE USED. SEE THE "ALTERNATIVE DOCRWAY PROTECTION E" DETAIL ON PAGE 128 FOR GUIDANCE.
- 8. THE DEPICTED LOAD CAN BE REDUCED TO SUIT THE QUANTITY TO BE SHIPPED.
 A 3-TIER LOAD CAN BE REDUCED BY A MULTIPLE OF SIX (6) PALLET UNITS,
 A 2-TIER LOAD CAN BE REDUCED BY A MULTIPLE OF FOUR (4) UNITS, OR A
 1-TIER LOAD CAN BE REDUCED BY A MULTIPLE OF FOUR (2) UNITS BY CMITTING
 ONE OR MORE LOAD UNITS FROM THE CENTER PORTION OF THE LOAD. OR,
 THE ENTIRE ONE OR TWO TOP TIERS CAN BE OMITTED. FOR OTHER METHODS
 OF REDUCING A LOAD, AND FOR TYPICAL LCL PROCEDURES, REFER TO PAGES
 92 THRU 120 FOR GUIDANCE.
- 9. IF A FULL LOAD IS TO BE SHIPPED IN A 60' LONG CAR, SIX (6) STRUTS ARE REQUIRED FOR EACH ROW/TIER. TO ACCOMMODATE THESE ADDITIONAL STRUTS, A STRUT LEDGER MUST BE ADDED TO CENTER GATE "Q" FOR EACH TIER AS SHOWN BY THE PHANTOMED LINES ON THE DETAIL ON PAGE 61.
- IF PALLET UNITS WHICH DO NOT CONTAIN A FULL QUANTITY OF CONTAINERS ARE TO BE TRANSPORTED, REFER TO PAGES 118 AND 120 FCR SHIPPING GUIDA NCF.
- 11. FOR SHIPMENT OF ONE OR MORE LEFTOVER CONTAINERS, SEE THE "PROCEDURES FOR SHIPMENT OF LEFTOVER CONTAINERS" ON PAGE 119 FOR GUIDANCE.

LOAD AS SHOWN

ITEM	QUANTITY	WEI	GHT	(APPRCX)
	78			
T	OTAL WEIGHT	126,712	LBS	

FLAT DUNNAGE METHOD UNIT (DECREASED HEIGHT)
78-UNIT LOAD IN A 50'-6' LONG BY 9'-4' WIDE CONVENTIONAL BOX CAR




BILL OF MATERIAL LUMBER LINEAR FEET BOARD FEET 214 1" X 4" 104 381 254 2" X 4" 18 POUNDS NO. REQD NAILS 1-3/4 6d (2") 104 (3" 420 6-1/2 WIRE, NO. 14 GAGE 60' REQD 1 18

SPECIAL NOTES:

- A 50'-6" LONG BY 9'-0" WIDE (INSIDE CLEARANCE) WOOD-LINED BOX CAR EQUIPPED WITH ADJUSTABLE AND/OR FIXED WALL MEMBERS, AND WITH 10'-0" WIDE DOOR OPENINGS IS SHOWN, CARS OF OTHER DIMENSIONS AND CARS HAVING WIDER OR NARROWER DOOR CPENINGS CAN BE USED. SEE GENERAL NOTE "D" ON PAGE 2.
- THE PALLETIZED UNIT SHOWN IN THE TYPICAL LOAD ON PAGE 54 IS THE FLAT DUNNAGE METHOD UNIT (DECREASED HEIGHT). A MAXIMUM OF FORTY-FOUR (44) OF THESE UNITS, FOR AN APPROXIMATE LADING WEIGHT OF 71,016 POUNDS, CAN BE PLACED IN A 40"-6" LONG CAR.
- 3. IF A CAR HAS BOWED END WALLS WHICH ARE BOWED OUTWARD TWO INCHES (2") OR MORE EITHER FROM SIDE-TO-SIDE OR FROM FLOOR-TO-ROOF, CROSS MEMBERS CAN BE INSTALLED NEAR THE END WALL OF THE CAR TO PROVIDE A "SQUARED END" RATHER THAN INSTALLING DUNNAGE AS SPECIFIED IN GENERAL NOTE "G" ON PAGE 2. THESE CROSS MEMBERS SHOULD BE INSTALLED AT THE SAME HEIGHTS AS THE CROSS MEMBERS USED THROUGHOUT THE LOAD AS BLOCKING MEMBERS. A SEPARATOR GATE, SHOWN AS PIECE MARKED (4), MUST BE POSITIONED AGAINST THESE CROSS MEMBERS PRIOR TO LOADING.
- 4. TOP-OF-LOAD ANTI-SWAY BRACES, SHOWN AS PIECES MARKED ③ IN THE LOAD ON PAGE 54, MUST BE INSTALLED IN EACH END OF THE CAR AND WIRE TIED TO THE STRAPPING BOARDS WITH NO, 14 GAGE WIRE AS TYPICALLY SHOWN BY THE "TIE WIRE APPLICATION B" DETAIL ON PAGE 122, THREE (3) BRACES ARE REQUIRED IN EACH END OF A LOAD REGARDLESS OF THE CAR LENGTH.
- 5. TO FACILITATE POSITIONING OF THE PALLET UNITS AS LOADING PROGRESSES, POSITION PALLET UNIT STACKS AGAINST THE END WALL, THEN POSITION A SEPARATOR GATE, SHOWN AS PIECE MARKED (4), SO THE 1" X 4" TIE PIECES ARE LOCATED UNDER THE "OVERHANG" OF THE BOTTOM AND TOP PALLET UNITS. REPEAT THIS PROCEDURE FOR THE REMAINING STACKS.
- 6. SEPARATOR GATES IN THE DOORWAY MUST BE PREVENTED FROM SHIFTING INTO A DOOR OPENING BY THE APPLICATION OF THE STOP PIECES, PIECES MARKED ②. IN CARS EQUIPPED WITH STAGGERED DOORS, STOP PIECES MAY BE REQUIRED ON UP TO FOUR SEPARATOR GATES.
- 7. SEPARATOR GATES MAY BE FORMED FROM 3/8" OR THICKER PLYWOOD IN LIEU OF DIMENSIONAL LUMBER, IF DESIRED, FOR ONE OR TWO-LAYER LOADS; PLYWOOD SEPARATOR GATES FOR A 3-LAYER LOAD ARE NOT ECONOMICALLY FEASIBLE. SEE THE "ALTERNATIVE SEPARATOR GATE" DETAIL ON PAGE 122 FOR CONSTRUCTION GUIDANCE.
- 8. IF THE CAR BEING LOADED IS EQUIPPED WITH AT LEAST TWELVE (12) DOORWAY MEMBERS, AN ADDITIONAL FOUR PALLET UNITS CAN BE LOADED IN THE DOORWAY AREA.
- 9. THE DEPICTED LOAD CAN BE REDUCED TO SUIT THE QUANTITY TO BE SHIPPED. A LOAD MAY BE REDUCED BY MULTIPLES OF TWO (2) PALLET UNITS BY OMITTING LATERALLY ADJACENT UNITS FROM THE TOP ONE OR TWO LAYERS OF ONE OR MORE LOAD UNITS, OR BY MULTIPLES OF SIX (6) PALLET UNITS BY OMITTING ONE OR MORE ENTIRE LOAD UNITS. TO REDUCE A LOAD BY ONE (1) PALLET UNIT, REFER TO THE LCL PROCEDURES ON PAGES 90 AND 91 FOR GUIDANCE.
- 10. FOR SHIPMENT OF C'NE OR MORE LEFTOVER CONTAINERS, SEE THE "PROCEDURES FOR SHIPMENT OF LEFTOVER CONTAINERS" ON PAGE 119 FOR GUIDANCE.

LOAD AS SHOWN

ITEM		QUANTITY	WEI	GHT (APPROX)
		56		
	TOTAL WEIGHT		91,470	LBS



- 10. THE DEPICTED LOAD CAN BE REDUCED TO SUIT THE QUANTITY TO BE SHIPPED. A 3-TIER LOAD CAN BE REDUCED BY A MULTIPLE OF SIX (6) PALLET UNITS, OR A 2-TIER LOAD CAN BE REDUCED BY A MULTIPLE OF FOUR (4) UNITS, OR A 1-TIER LOAD CAN BE REDUCED BY A MULTIPLE OF TWO (2) UNITS BY OMITTING ONE OR MORE LOAD UNITS FROM THE CENTER PORTION OF THE LOAD. OR, THE ENTIRE ONE OR TWO TOP TIERS CAN BE OMITTED. FOR OTHER METHODS OF REDUCING A LOAD, AND FOR TYPICAL LCL PROCEDURES, REFER TO PAGES 94 THRU 105 AND GENERAL NOTE "FF" ON PAGE 3 FOR GUIDANCE.
- If PALLET UNITS WHICH DO NOT CONTAIN A FULL QUANTITY OF CONTAINERS ARE TO BE TRANSPORTED, REFER TO PAGE 117 AND/OR PAGES 118 AND 120 FOR SHIPPING GUIDANCE.
- 12 FOR SHIPMENT OF ONE OR MORE LEFTOVER CONTAINERS, SEE THE "PROCEDURES FOR SHIPMENT OF LEFTOVER CONTAINERS" ON PAGE 119 FOR GUIDANCE.

LUMBER	LINEAR FEET	BOARD FEET
1" X 4"	211	71
1" X 6"	507	254
2" X 3"	36	18
2" X 4"	418	279
2" X 6"	20	20
NAILS	NO. REQD	POUNDS
6d (2°)	366	2-1/4
10d (3")	444	7
12d (3-1/4*)	36	3/4

SPECIAL NOTES:


- A 50"-6" LONG BY 9"-2" WIDE WOOD-LINED CUSHIONED BOX CAR EQUIPPED WITH LOAD DIVIDER BULKHEADS AND WITH 10"-0" WIDE DOOR OPENINGS IS SHOWN, CARS OF OTHER DIMENSIONS AND CARS HAVING NARROWER OR WIDER DOOR OPENINGS CAN BE USED. SEE GENERAL NOTES "AA THRU "EE ON PAGE 3.
- 2. THE PALLET UNIT SHOWN IN THE TYPICAL LOAD ON PAGE 56 IS THE FLAT DUNNAGE METHOD UNIT (DECREASED HEIGHT). A MAXIMUM OF SEVENTY-TWO (72) OF THESE UNITS, FOR AN APPROXIMATE LADING WEIGHT OF 116,208 POUNDS, CAN BE PLACED IN A 60'-8" LONG CAR, OR A MAXIMUM OF FORTY-EIGHT (48) UNITS CAN BE LOADED IN A 40'-6" CAR FOR AN APPROXIMATE LADING WEIGHT OF 77,472 POUNDS, WHEN USING THE DEPICTED PROCEDURES, IF CARS 9'-4" OR WIDER ARE AVAILABLE, THE CROSSWISE LOADING PATTERN SHOWN ON PAGE 32 MAY BE EMPLOYED. THEN, NINETY-SIX (96) PALLET UNILS FOR AN APPROXIMATE LADING WEIGHT OF 154,944 POUNDS CAN BE PLACED IN A 60'-8" LONG CAR, SEVENTY-EIGHT (78) UNITS CAN BE PLACED IN A 50'-6" LONG CAR FOR AN APPROXIMATE LADING WEIGHT OF 125,892 POUNDS, AND SIXTY (60) UNITS CAN BE LOADED IN A 40'-6" LONG CAR FOR AN APPROXIMATE LADING WEIGHT OF 125,892 POUNDS, AND MATE LADING WEIGHT OF 96,840 POUNDS.
- 3. IF THE "ALTERNATIVE DOORWAY PROTECTION F" PROCEDURES AS SHOWN ON PAGE 128 ARE USED IN LIEU OF THE WOODEN DOOR GATE TYPE PROTECTION, PIECE MARKED \$\(\). NAILED FLOORLING BLOCKING MUST BE USED IN LIEU OF THE LOWER ANTI-SWAY BRACE IN THE DOORWAY AREA. NAILED BLOCKING IS REQUIRED FOR ALL PALLET STACKS WHICH ARE COMPLETELY WITHIN THE DOORWAY AREA OR WHICH EXTEND INTO THE DOORWAY AREA BY ONE-HALF OR MORE OF THE STACK WIDTH ON EITHER SIDE OF THE CAR.
- 4. TOP-OF-LOAD ANTI-SWAY BRACES, SHOWN AS PIECES MARKED ② IN THE LOAD ON PAGE 56, MUST BE INSTALLED IN EACH END OF THE CAR AND WIRE TIED TO STRAPPING BOARDS WITH NO. 14 GAGE WIRE AS TYPICALLY SHOWN BY THE "TIE WIRE APPLICATION B" DETAIL ON PAGE 122. THREE (3) BRACES ARE REQUIRED IN EACH END OF A LOAD REGARDLESS OF THE CAR LENGTH.
- 5. TO FACILITATE POSITIONING OF THE PALLET UNITS AS LOADING PROGRESSES, POSITION PALLET UNIT STACKS AGAINST THE END WALL, THEN POSITION A SEPARATOR GATE SHOWN AS PIECE MARKED ③, SO THE 1" X 4" TIE PIECES ARE LOCATED UNDER THE "OVERHANG" OF THE BOTTOM AND TOP PALLET UNITS, REPEAT THIS PROCEDURE FOR THE REMAINING STACKS.
- 6. SEPARATOR GATES IN THE DOORWAY MUST BE PREVENTED FROM SHIFTING INTO A DOOR OPENING BY THE APPLICATION OF THE STOP PIECES, PIECES MARKED (4) IN CARS EQUIPPED WITH STAGGERED DOORS, STOP PIECES MAY BE REQUIRED ON UP TO FOUR SEPARATOR GATES.
- SEPARATOR GATES MAY BE FORMED FROM 3/8" OR THICKER PLYWOOD IN LIEU OF DIMENSIONAL LUMBER, IF DESIRED. SEE THE "ALTERNATIVE SEPARATOR GATE" DETAIL ON PAGE 122 FOR CONSTRUCTION GUIDANCE.
- 8. DOORWAY PROTECTION IS REQUIRED FOR ALL PALLET UNIT STACKS WHICH ARE COMPLETELY WITHIN THE DOORWAY AREA OR WHICH EXTEND INTO THE DOORWAY AREA BY ONE-HALF OR MORE OF THE STACK WIDTH. THE WOODEN GATE TYPE OF DOORWAY PROTECTION, SHOWN AS PIECES MARKED (3) IN THE LOAD ON PAGE 56, IS APPLICABLE FOR BOX CARS EQUIPPED WITH CONVENTIONAL SLIDING DOORS AND NAILABLE DOOR POSTS. REFER TO PAGES 126 THRU 128 FOR ALTERNATIVE DOORWAY PROTECTION FOR CARS EQUIPPED WITH CONVENTIONAL SLIDING DOORS. IF THE CAR BEING LOADED IS EQUIPPED WITH PLUG TYPE DOORS, NAILED FLOORLING STRAPS MUST BE USED. SEE THE "ALTERNATIVE DOORWAY PROTECTION F" DETAIL ON PACE 128 FOR GUIDANCE IF THE PALLET UNITS ARE POSITIONED AS SHOWN ON PAGE 56. SEE THE "ALTERNATIVE DOORWAY PROTECTION E" DETAIL ON THAT PAGE IF THE PALLET UNITS ARE POSITIONED AS SHOWN ON PAGE 150.
- 9. A STRUT ASSEMBLY, SHOWN AS PIECE MARKED ③ IN THE LOAD ON PAGE 42, IS REQUIRED BETWEEN THE LOAD DIVIDER BULKHEADS WHEN THE LOAD IN EITHER END OF THE CAR IS 50,000 POUNDS OR MORE. FOR THE DEPICTED PALLET UNIT, A STRUT ASSEMBLY WILL BE REQUIRED IF THE LOAD IN ONE END OF THE CAR CONSISTS OF MORE THAN FIVE (5) LOAD UNITS, WHICH WOULD BE THE CASE IF AN OFFSET LOADING PATTERN IS EMPLOYED. THE STRUT ASSEMBLY WILL ALWAYS BE REQUIRED FOR FULL LOADS IN 60' OR LONGER CARS.


(CONTINUED AT LEFT)


LOAD AS SHOWN


ITEM	QUANTITY	WEIGHT	(APPRCX)
	60		
	TOTAL WEIGHT	98, 135	LBS


FLAT DUNNAGE METHOD UNIT (DECREASED HEIGHT)
60-UNIT LOAD IN A 50'-6' LONG BY 9'-2' WIDE BOX CAR EQUIPPED WITH LOAD DIVIDERS














- THE DEPICTED LOAD CAN BE REDUCED TO SUIT THE QUANTITY TO BE SHIPPED. A 2-TER LOAD CAN BE REDUCED BY ONE OR MORE PALLET UNITS BY EMPPLOY-ING THE PROCEDURES ON PAGE 96. FOUR (4) UNITS CAN BE OMITTED FROM A 2-TER LOAD BY LEAVING OUT THE LENGTHWISE STACK NO, 7 AND THE CROSSWISE STACK NO. 9. NOTE THAT STRUT BRACKING WILL THEN BE REQUIRED. OR, THE ENTIRE TOP TIER CAN BE OMITTED. A PARTIAL 1-TIER LOAD CAN BE SHIPPED IN ONE OR BOTH ENDS OF A CAR BY USING KNEE BRACES AS SHOWN ON PAGES 112 AND 113.
- IF PALLETIZED UNITS WHICH DO NOT CONTAIN A FULL QUANTITY OF CONTAINERS ARE TO BE TRANSPORTED, REFER TO PAGE 117 FOR SHIPPING GUIDANCE. FOR LENGTHWISE UNITS AND PAGES 118 AND 120 FOR CROSS-
- FOR SHIPMENT OF ONE OR MORE LEFTOVER CONTAINERS, SEE THE "PROCEDURES FOR SHIPMENT OF LEFTOVER CONTAINERS" ON PAGE 119 FOR GUIDANCE.

LUMBER	LINEAR FEET	BOARD FEET
1" X 4"	144	48
1" X 6"	245	123
2" X 2"	76	26
2" X 3"	39	20
2" X 4"	810	540
2" X 6"	195	195
4" X 4"	125	167
NAILS	NO. REQD	POUNDS
6d (2")	228	1-1/2
10d (3")	1290	19-3/4
12d (3-1/4")	38	3/4
16d (3-1/2")	128	3

SPECIAL NOTES:


- A 60'-8" LONG BY 9'-2" WIDE WOOD-LINED CONVENTIONAL TYPE BOXCAR EQUIPPED WITH 10'-0" WIDE DOOR OPENINGS IS SHOWN, CARS OF OTHER DIMENSIONS AND CARS HAVING WIDER OR NARROWER DOOR OPENINGS CAN BE USED. SEE GENERAL NOTE "D" ON PAGE 2 AND SPECIAL NOTE 3 BELOW.
- THE PALLET UNIT SHOWN IN THE TYPICAL LOAD ON PAGE 62 IS THE ROUTED DUNNAGE METHOD UNIT (BASIC HEIGHT), A MAXIMUM OF FORTY-SIX (46.) OF THESE UNITS, FOR AN APPROXIMATE LADING WEIGHT OF 97.612 POUNDS, CAN BE PLACED IN A 50'-6" LONG CAR WHEN USING THE DEPICTED PROCEDURES THRTY-SIX (36.) UNITS, FOR A LADING WEIGHT OF 76,392 POUNDS, CAN BE OUTLOADED IN A 40'-6" LONG CAR.
- THE DEPICTED LOAD PATTERN IS ADEQUATE FOR CARS HAVING DOOR OPENINGS AS NARROW AS 7'-0". IF THE CAR TO BE LOADED HAS DOOR OPENINGS LESS THAN 7'-0" WIDE AND NOT OF SUFFICEINT HEIGHT TO ALLOW PERSONNEL TO EXIT OVER THE TOP OF THE LOAD, THE LENGTHWISE UNITS SHOULD BE LOADED SIX (6) STACKS LONG IN EACH END OF THE CAR AND THE CROSSWISE UNITS SHOULD BE LOADED EIGHT (8) STACKS LONG IN EACH END, AN ADDITIONAL PIECE MARKED (7) WILL BE REQUIRED; THE BALANCE OF THE DUNNAGE WILL NOT CHANGE.
- THE "HIGH" CRIB, SHOWN AS PIECE MARKED $\widehat{\mathbf{1}}$, MUST BE INSTALLED IN EACH END OF THE LOAD. FOUR (4) ASSEMBLIES ARE REQUIRED IN EACH END OF A LOAD REGARDLESS OF THE CAR LENGTH.
- THE SEPARATOR GATES, SHOWN AS PIECES MARKED ② IN THE LOAD ON PAGE 62, ARE DESIGNATED "RIGHT HAND" AND LEFT HAND" TO FACILITATE POSITIONING OF THE PALLET UNITS AS LOADING PROGRESSES. WHEN LOADING THE CAR, POSITION A PALLET UNIT STACK AGAINST THE END WALL THEN POSITION A SEPARATOR GATE SO THE 1" X 4" TIE PIECES ARE LOCATED UNDER THE "OVERHANG" OF THE PALLET UNITS IN THE FIRST STACK. REPEAT THIS PROCEDURE FOR THE REMAINING STACKS.
 - ALL SEPARATOR GATES, PIECES MARKED ② , WHICH ARE WITHIN THE DOORWAY AREA OF A CAR EQUIPPED WITH CONVENTIONAL SLIDING DOORS MUST BE WIRE TIED TO THE ADJACENT CRIB FILL TO PREVENT DISPLACEMENT. ENCIRCLE THE STOP PIECE OF THE SEPARATOR GATE AND THE UPPER HORIZONTAL PIECE OF THE CRIB FILL WITH NO. 14 GAGE WIRE AND TWIST TAUT.
- SEPARATOR GATES MAY BE FORMED FROM 3/8" OR THICKER PLYWOOD IN LIEU OF DIMENSIONAL LUMBER, IF DESIRED. CONSTRUCT EACH GATE 42" WIDE BY 8'-0" LONG.
- CENTER GATES "R" AND "5" MAY BE PARTIALLY FORMED FROM 1/2" OR THICKER PLYWOOD , IF DESIRED. PLYWOOD MAY BE USED IN LIEU OF THE 2" X 6" HORIZONTAL PECES. SEE THE "PLYWOOD CENTER GATE ALTERNATIVE" DETAIL ON PAGE 123 FOR GUIDANCE.
- DOORWAY PROTECTION IS REQUIRED FOR ALL PALLET UNIT STACKS WHICH ARE COMPLETELY WITHIN THE DOORWAY AREA OR WHICH EXTEND INTO THE DOORWAY AREA BY ONE-HALF OR MORE OF THE STACK WIDTH OR LENGTH. THE WOODEN GATE TYPE OF DOORWAY PROTECTION, SHOWN AS PIECES MARKED 1 AND 12 IN THE LOAD ON PAGE 62, IS APPLICABLE FOR BOXCARS EQUIPPED WITH CONVENTIONAL SLIDING DOORS AND NAILABLE DOOR POSTS. REFER TO PAGES 125 THRU 128 FOR ALTERNATIVE DOORWAY PROTECTION FOR CARS EUIPPED WITH CONVENTIONAL SLIDING DOORS. IF THE CAR BEING LOADED IS PAGES 126 THRU 128 FOR ALTERNATIVE DOORWAY PROTECTION FOR CARS EUIPPED WITH CONVENTIONAL SLIDING DOORS, IF THE CAR BEING LOADED IS EUIPPED WITH PUIG TYPE DOORS, NAILED FLOORLINE BLOCKING AND LOAD-BUNDLING STRAPS MUST BE USED, SEE THE "ALTERNATIVE DOORWAY PROTECTION E" AND "ALTERNATIVE DOORWAY PROTECTION F" DETAILS ON PAGE 128 FOR GUIDANCE; A COMBINATION OF THE TWO METHODS MUST BE USED, NAILED SIDE BLOCKING WILL BE USED UNDER THE CRIB FILL SHOWN IN THE DOORWAY AREA OF THE LOAD, POSITION DOUBLED 2" X 4" X 8"-0" PRECES AGAINST THE LENGTHWISE STACKS NUMBERED 6 AND 7, AND PRE-POSITION DOUBLED 2" X 4" X 7"-0" PRECES (APPROXIMATELY 52" FROM THE NEAR SIDE CAR WALL) SO AS TO BE AGAINST THE CROSSWISE STACKS NUMBERED 8 AND 9, THESE PIECES WILL BE USED IN LIEU OF THE 40" AND 48" LONG PRECES SHOWN BY THE ALTERNATIVE DETAILS. A SPACER ASSEMBLY, AS SHOWN IN THE "ALTERNATIVE DOORWAY PROTECTION F" DETAIL MUST BE MODIFIED FOR USE BY CHANGING THE END WHICH EXTENDS OVER THE CROSSWISE CONTAINERS TO BE LIKE THE NEAR END OF THE STRAPPING BOARD SHOWN IN THE "ALTERNATIVE DOORWAY PROTECTION E" DETAIL. A 2" X 4" X 40" DOUBLED BATTEN AS SHOWN IN THAT VIEW IS ALSO REQUIRED. NOTE THAT THE VERTICAL PIECES AND BOTTOM SUPPORT PIECES OF THE CRIB FILL, PIECES MARKED (3), MUST HAVE THREE INCHES (3") CUT OFF THE BOTTOM END OF ONE SIDE SO THE CRIB WILL REST EVENLY ON THE NAILED SIDE BLOCKING WHICH IS ADJACENT TO THE LENGTHWISE UNITS. ALSO NOTE THAT THE CENTER GATE "R" WHICH IS IN THE DOOR OPENING MUST BE WIRE TIED TO PIECE MARKED (8) TO PREVENT DISPLACEMENT.

(CONTINUED AT LEFT)

LOAD AS SHOWN

ITEM	QUANTITY	WEI	GHT	(APPROX
PALLET UNIT	56	118.832	LBS	
DUNNAGE		2,263	LBS	
	TOTAL WEIGHT	121.095	LBS	

ROUTED DUNNAGE METHOD UNIT (BASIC HEIGHT) 56-UNIT LOAD IN A 60'-8' LONG BY 9'-2" WIDE CONVENTIONAL BOX CAR



- 13: IF THE ALTERNATIVE DOORWAY PROTECTION "F" PROCEDURES SHOWN ON PAGE 128 ARE USED IN LIEU OF THE WOODEN DOORWAY PROTECTION, PIECES MARKED (?), THE CENTER GATES MUST BE RESTRAINED FROM LATERAL MOVEMENT. THIS CAN BE ACCOMPLISHED BY NAILING TO THE CAR FLOOR A DOUBLED 2" X 4" X 18" PIECE POSITIONED LONGITUDINALLY SO AS TO BE CENTERED AGAINST THE FILL PIECE OF A CENTER GATE. TWO (2) PIECES WILL BE REQUIRED FOR EACH CENTER GATE WHICH IS IN THE DOOR OPENING OR WITHIN SIX INCHES (6") OF BEING IN THE DOOR OPENING.
- 14. THE DEPICTED LOAD CAN BE REDUCED TO SUIT THE QUANTITY TO BE SHIPPED. A 2-TIER LOAD CAN BE REDUCED BY A MULTIPLE OF FOUR (4) PALLET UNITS OR A 1-TIER LOAD CAN BE REDUCED BY A MULTIPLE OF TWO (2) UNITS BY OMITTING ONE OR MORE LOAD UNITS FROM THE CENTER PORTION OF THE LOAD. OR, THE ENTIRE TOP TIER CAN BE OMITTED. FOR OTHER METHODS OF REDUCING A LOAD, AND FOR TYPICAL LCL PROCEDURES, REFER TO PAGES 92 THRU 120 FOR GUIDANCE.
- IF PALLETIZED UNITS WHICH DO NOT CONTAIN A FULL QUANTITY OF CONTAINERS ARE TO BE TRANSPORTED, REFER TO PAGE 117 FOR SHIPPING GUIDANCE.
- FOR SHIPMENT OF ONE OR MORE LEFTOVER CONTAINERS, SEE THE "PROCEDURES FOR SHIPMENT OF LEFTOVER CONTAINERS" ON PAGE 119 FOR GUIDANCE.

LUMBER	LINEAR FEET	BOARD FEET
1" X 4"	193	65
1" X 6"	410	205
2" X 2"	94	32
2" X 3"	32	16
2" X 4"	357	238
2" X 6"	215	215
4" X 4"	100	134
NAILS	NO. REQD	POUNDS
6d (2")	290	1-3/4
IOd (3*)	676	10-1/2
2d (3-1/4")	32	3/4
16d (3-1/2")	96	2-1/4

SPECIAL NOTES:


- A 60'-8" LONG BY 9'-2" WIDE WOOD-LINED CONVENTIONAL TYPE BOXCAR EQUITED WITH 10'-0" WIDE DOOR OPENINGS IS SHOWN. CARS OF OTHER DIMENSIONS AND CARS HAVING WIDER OR NARROWER DOOR OPENINGS CAN BE USED. SEE GENERAL NOTE "D" ON PAGE 2 AND SPECIAL NOTE 3 BELOW.
- 2. THE PALLETIZED UNIT SHOWN IN THE TYPICAL LOAD ON PAGE 64 IS THE ROUTED DUNNAGE METHOD UNIT (BASIC HEIGHT). A MAXIMUM OF FORTY (40) OF THESE UNITS, FOR AN APPROXIMATE LADING WEIGHT OF 84,880 POUNDS, CAN BE PLACED IN A 50'-6" LONG CAR WHEN USING THE DEPICTED PROCEDURES; THIRTY-TWO (32) UNITS, FOR AN APPROXIMATE WEIGHT OF 67,904 POUNDS, CAN BE OUTLOADED IN A 40'-6" LONG CAR.
- 3. THE DEPICTED LOADING PATTERN IS ADEQUATE FOR CARS HAVING DOOR OPENINGS 8" THRU 10", OR WIDER. IF THE CAR TO BE LOADED HAS DOOR OPENINGS LESS THAN 8"-0" WIDE AND NOT OF SUFFICIENT HEIGHT TO ALLOW PERSONNEL TO EXIT THE CAR O'VER THE TOP OF THE LOAD, THE PALLETS SHOULD BE POSITIONED SO THERE ARE SIX (6) LOAD UNITS IN EACH END. NOTE THAT ALTHOUGH CARS HAVING DOOR OPENINGS AS NABROW AS 6"-0" WIDE CAN BE USED FOR FULL LOADS, LOADING IS PROGRESSIVELY MORE DIFFICULT AS THE WIDTH OF THE DOOR OPENING DECREASES.
- 4. IF THE "ALTERNATIVE DOORWAY PROTECTION F" PROCEDURES AS SHOWN ON PAGE 128 ARE USED IN LIEU OF THE WOODEN DOOR GATE TYPE PROTECTION, PIECE MARKED (?) , NAILED FLOORLINE BLOCKING MUST BE USED IN LIEU OF EACH LOWER ANTI-SWAY BRACE IN THE DOORWAY AREA. NAILED BLOCKING IS REQUIRED FOR ALL PALLET STACKS WHICH ARE COMPLETELY WITHIN THE DOORWAY AREA OR WHICH EXTEND INTO THE DOORWAY AREA BY ONE-HALF OR MORE OF THE STACK WIDTH ON EITHER SIDE OF THE CAR.
- 5. TOP-OF-LOAD ANTI-SWAY BRACES, SHOWN AS PIECES MARKED ② IN THE LOAD ON PAGE 44, MUST BE INSTALLED IN EACH END OF THE CAR AND WIRE TIED TO A STRAPPING BOARD WITH NO. 14 GAGE WIRE AS SHOWN. THREE (3) BRACES ARE REQUIRED IN EACH END OF A LOAD REGARDLESS OF THE CAR LENGTH.
- 6. TO FACILITATE POSITIONING OF THE PALLET UNITS AS LOADING PROGRESSES, WHEN LOADING THE BOXCAR, POSITION PALLET UNIT STACKS AGAINST THE END WALL, THEN POSITION A SEPARATOR GATE, SHOWN AS PIECE MARKED ③, SO THE 1* X 4* TIE PIECES ARE LOCATED UNDER THE "OVERHANG" OF THE PALLET UNITS. REPEAT THIS PROCEDURE FOR THE REMAINING STACKS.
- SEPARATOR GATES IN THE DOORWAY MUST BE PREVENTED FROM SHIFTING INTO A
 DOOR OPENING BY THE APPLICATION OF THE STOP PIECES, PIECES MARKED (4).
 IN CARS EQUIPPED WITH STAGGERED DOORS, STOP PIECES MAY BE REQUIRED ON
 UP TO FOUR SEPARATOR GATES.
- SEPARATOR GATES MAY BE FORMED FROM 3/8" OR THICKER PLYWOOD IN LIEU OF DIMENSIONAL LUMBER, IF DESIRED. SEE THE "ALTERNATIVE SEPARATOR GATE" DETAIL ON PAGE 122 FOR CONSTRUCTION GUIDANCE.
- CENTER GATE "T" MAY BE PARTIALLY FORMED FROM 1/2" OR THICKER PLYWOOD,
 IF DESIRED. PLYWOOD MAY BE USED IN LIEU OF THE 2" X 6" HORIZONTAL
 PROCES. SEE THE "PLYWOOD CENTER GATE ALTERNATIVE" DETAIL ON PAGE 123
 FOR GUIDANCE.
- 10. FOR EASE OF HANDLING, SPLIT CENTER GATES, WHICH ARE NOT DEPENDENT UPON THE WIDTH OF THE CAR, MAY BE USED AS AN ALTERNATIVE TO THE CARWIDTH GATES. IN LIEU OF EACH "CENTER GATE T", SHOWN AS PIECE MARKED (3) IN THE LOAD ON PAGE 64, INSTALL TWO (2) "CENTER GATES R" AS SHOWN ON PAGE 72. AFTER THE SPLIT GATES AND STRUTS HAVE BEEN INSTALLED, THE SPLIT GATES MUST BE TED TOGETHER AS DEPICTED BY THE "TIE PIECE APPLICATION" DETAIL ON PAGE 123. OMIT THE STOP PIECES FROM "CENTER GATES R".
- 11. DOOR SPANNER TYPE GATE HOLD DOWN MAY BE USED IN LIEU OF THE DOUBLED 2" X 4" MATERIAL NAILED TO CENTER GATE "T, PROVIDING THE CAR BEING LOADED HAS NAILABLE SIDEWALLS. SEE THE DETAILS ON PAGE 125 FOR CHINANCE.
- 12. DOORWAY PROTECTION IS REQUIRED FOR ALL PALLET UNIT STACKS WHICH ARE COMPLETELY WITHIN THE DOORWAY AREA OR WHICH EXTEND INTO THE DOORWAY AREA BY ONE-HALF OR MORE OF THE STACK WIDTH. THE WOODEN GATE TYPE OF DOORWAY PROTECTION, SHOWN AS PECE MARKED 70 IN THE LOAD ON PAGE 64, IS APPLICABLE FOR BOXCARS EQUIPPED WITH CONVENTIONAL SLIDING DOORS AND NAILABLE DOOR POSTS. REFER TO PAGES 126 THRU 128 FOR ALTERNATIVE DOORWAY PROTECTION FOR CARS EQUIPPED WITH CONVENTIONAL SLIDING DOORS. IF THE CAR BEING LOADED IS EQUIPPED WITH PLUG TYPE DOORS, NAILED FLOORLINE BLOCKING AND LOAD BUNDLING STRAPS MUST BE USED. SEE THE "ALTERNATIVE DOORWAY PROTECTION F" DETAIL ON PAGE 128 FOR GUIDANCE."

(CONTINUED AT LEFT)

LOAD AS SHOWN

ITEM	QUANTITY	. WEIGHT (APPROX
PALLET UNIT-	·	101,856 LBS
DUNNAGE		1,827 LBS
	TOTAL WEIGHT	103 AR3 1RS

ROUTED DUNNAGE METHOD UNIT (BASIC HEIGHT);
48-UNIT LOAD IN A 60'-8" LONG BY 9'-2" WIDE CONVENTIONAL BOX CAR



- (3) GATE HOLD DOWN 2" X 4" BY LENGTH OF CENTER VOID PLUS 24" (REF. 7'-0") (2 REQD), POSITION UNDER THE ENDS OF THE CONTAINERS AND NAIL TO THE VERTICAL PIECES OF THE CENTER GATES W/2-104 NAILS AT EACH JOINT. SEE SPECIAL NOTE 6 ON PAGE 67.
- 6 GATE HOLD DOWN SUPPORT PIECE, 2" X 2" X 15" (4 REQD). POSITION UNDER PIECE MARKED (3) AND NAIL TO A VERTICAL PIECE OF PIECE MARKED (1) W/4-10d NAILS.
- DOORWAY PROTECTION (2 REQD), SEE THE "DOORWAY PROTECTION J"
 DETAIL ON PAGE 75, NAIL TO DOOR POSTS W/12d NAILS, SEE SPECIAL
 NOTE 7 ON PAGE 67.

ROUTED DUNNAGE METHOD UNIT (BASIC HEIGHT)
52-UNIT LOAD IN A 50'-6" LONG BY 9'-4" WIDE CONVENTIONAL BOX CAR

BILL OF MATERIAL LUMBER LINEAR FEET BOARD FEET 1" × 6" 64 32 2" × 2" 108 36 2" × 3" 30 15 2" × 4" 99 66 2" × 6" 1993 199 4" × 4" 108 144 NAILS NO. REGD POUNDS

456 28 7-1/4 1/2

6d (2")

12d (3-1/4") 16d (3-1/2")


SPECIAL NOTES:

- A 50'-6" LONG BY 9'-4" WIDE WOOD-LINED CONVENTIONAL TYPE BOXCAR EQUIPPED WITH 8'-0" WIBE DOOR OPENINGS IS SHOWN. WIDER CARS OF OTHER LENGTHS AND CARS HAVING WIDER OR NARROWER DOOR OPENINGS CAN BE USED. SEE GENERAL NOTE "D" ON PAGE 2 AND SPECIAL NOTE 9 BELOW.
- 2. THE PALLETIZED UNIT SHOWN IN THE TYPICAL LOAD ON PAGE 66 IS THE ROUTED DUNNAGE METHOD UNIT (BASIC HEIGHT). A MAXIMUM OF FORTY (40) OF THESE UNITS, FOR AN APPROXIMATE LADING WEIGHT OF 84,880 POUNDS CAN BE PLACED IN A 40"-6" LONG CAR WHEN USING THE DEPICTED PROCEDURES. IF A 60"-8" LONG BY 9"-4" OR WIDER CAR IS AVAILABLE, SIXTY-FOUR (64) PALLET UNITS FOR AN APPROXIMATE LADING WEIGHT OF 135,808 POUNDS CAN BE LOADED. SEE SPECIAL NOTE 9 FOR CENTER GATE MODIFICATIONS WHICH MAY BE REQUIRED IF 60" LONG CARS ARE TO BE USED.
- 3. ANTI-SWAY BRACING BETWEEN LATERALLY ADJACENT ROWS OF PALLET UNITS IS REQUIRED IF A CAR WHICH IS WIDER THAN 9'-4" IS FURNISHED FOR LOADING. SEE THE "ANTI-SWAY BRACE B" DETAIL ON PAGE 74 FOR CONSTRUCTION GUIDANCE. TO PREVENT LONGITUDINAL DISPLACEMENT OF THE ANTI-SWAY BRACE BETWEEN THE UPPER UNITS, A STOP PIECE MUST BE NAILED TO EACH CENTER GATE "U" AS SHOWN ON THE DETAIL ON PAGE 75. TO PREVENT DISPLACEMENT OF THE FLOORLINE ANTI-SWAY BRACE (IF USED), POSITION A DOUBLED 2" X 4" X 12" PIECE LONGITUDINALLY BETWEEN THE FILL PIECES ON THE GATE SO AS TO BE IN CONTACT WITH THE ANTI-SWAY BRACE AND NAIL TO THE CAR FLOOR W/3-12d NAILS EACH LAYER. IF DESIRED IN CARS HAVING NAILABLE SIDEWALLS, 1" X 6" OR 2" X 6" FILL MATERIAL MAY BE NAILED TO ONE OR BOTH SIDEWALLS AT HEIGHTS SPECIFIED FOR THE DOORWAY PROTECTION HORIZONTAL PIECES, IN LIEU OF USING THE ANTI-SWAY BRACES. NOTE THAT THE TOTAL ACCUMULATED SPACE ACROSS A CAR SHOULD NOT EXCEED TWO INCHES (2")
- 4. CENTER GATE "U" MAY BE PARTIALLY FORMED FROM 1/2" OR THICKER PLYWOOD IF DESRED. PLYWOOD MAY BE USED IN LIEU OF THE 2" X 6" HORIZONTAL PIECES. SEE THE "PLYWOOD CENTER GATE ALTERNATIVE" DETAIL ON PAGE 123 FOR GUIDANCE.
- 5. FOR EASE OF HANDLING, SPLIT CENTER GATES, WHICH ARE NOT DEPENDENT UPON THE WIDTH OF THE CAR, MAY BE USED AS AN ALTERNATIVE TO THE CAR-WIDTH GATES. IN LIEU OF EACH "CENTER GATE U", SHOWN AS PIECE MARKED D IN THE LOAD ON PAGE 66, INSTALL TWO (2) "CENTER GATES S" AS SHOWN ON PAGE 73. AFTER THE SPLIT GATES AND STRUTS HAVE BEEN INSTALLED, THE SPLIT GATES MUST BE TIED TOGETHER AS DEPICTED BY THE "TIE PIECE APPLICATION" DETAIL ON PAGE 123.
- 6. AN ALTERNATIVE TO THE GATE HOLD DOWN SHOWN AS PIECE MARKED ③ IN THE LOAD ON PAGE 66 MAY BE USED, IF DESIRED, WHEN THE CAR FURNISHED FOR LOADING IS EQUIPPED WITH 8'-O" OR WIDER DOORS. NOTE THAT IN A CAR HAVING DOOR OPENINGS JUST 8'-O" WIDE IT MAY BE NECESSARY TO LAMINATE ONE OR TWO THICKNESS OF 2-INCH MATERIAL TO THE ADJACENT CENTER GATE VERTICAL PIECES TO PROVIDE AN AREA FOR NAILING OF PIECES MARKED ⑤ AND ⑥ . AN ALTERNATIVE HOLD DOWN MUST BE USED WHEN THE CAR FURNISHED HAS DOOR OPENINGS LESS THAN 8'-O" WIDE. DOOR SPANNER TYPE HOLD DOWN ASSHOWN ON PAGE 125 MAY BE USED IF THE CAR HAS NAILABLE SIDEWALLS, OR DOUBLED 2" X 3" HOLD DOWN PIECES MAY BE APPLIED TO THE CENTER GATES AS SHOWN BY THE CENTER GATE "U" DETAIL ON PAGE 75.
- 7. DOORWAY PROTECTION IS REQUIRED FOR ALL PALLET UNIT STACKS WHICH ARE COMPLETELY WITHIN THE DOORWAY AREA OR WHICH EXTEND INTO THE DOORWAY AREA BY ONE-HALF OR MORE OF THE STACK LENGTH. THE WOODEN GATE TYPE OF DOORWAY PROTECTION, SHOWN AS PIECES MARKED (?) IN THE LOAD ON PAGE 66, IS APPLICABLE FOR BOXCARS EQUIPPED WITH CONVENTIONAL SLIDING DOORS AND NAILABLE DOOR POSTS. REFER TO PAGES 126 THRU 128 FOR ALTERNATIVE DOORWAY PROTECTION FOR CARS EQUIPPED WITH CONVENTIONAL SLIDING DOORS. IF THE CAR BEING LOADED IS EQUIPPED WITH PLUG TYPE DOORS, NAILED FLOORLINE BLOCKING AND LOAD BUNDLING STRAPS MUST BE USED. SEE THE "ALTERNATIVE DOORWAY PROTECTION E" DETAIL ON PAGE 128 FOR GUIDANCE.
- 8. THE DEPICTED LOAD CAN BE REDUCED TO SUIT THE QUANTITY TO BE SHIPPED. A 2-TIER LOAD CAN BE REDUCED BY A MULTIPLE OF FOUR (4) PALLET UNITS OR A 1-TIER LOAD CAN BE REDUCED BY A MULTIPLE OF TWO (2) UNITS BY OMITTING ONE OR MORE LOAD UNITS FROM THE CENTER PORTION OF THE LQAD. OR, THE ENTIRE TOP TIER CAN BE OMITTED. FOR OTHER METHODS OF REDUCING A LOAD, AND FOR TYPICAL LCL PROCEDURES, REFER TO PAGES 92 THRU 126 FOR GUIDANCE.
- 9. IF A_FULL LOAD IS TO BE SHIPPED IN A 60' LONG CAR IN AN OFFSET LOADING PATTERN, NINE (9) STRUTS WILL BE REQUIRED PEP ROW/TIER. TO ACCOMMODATE THESE ADDITIONAL STRUTS, A VERTICAL PIECE MUST BE ADDED TO CENTER GATE "U" FOR EACH ROW AS SHOWN BY THE PHANTOMED LINES ON THE DETAIL ON PAGE 75.
- IF PALLETIZED UNITS WHICH DO NOT CONTAIN A FULL QUANTITY OF CONTAINERS
 ARE TO BE TRANSPORTED, REFER TO PAGES 118 AND 120 FOR SHIPPING GUIDANCE.
- 11. FOR SHIPMENT OF ONE OR MORE LEFTOVER CONTAINERS, SEE THE "PROCEDURES FOR SHIPMENT OF LEFTOVER CONTAINERS" ON PAGE 119 FOR GUIDANCE.

LOAD AS SHOWN

ITEM	QUANTITY	WEIGHT (APPROX)
	52		
DUNNAGE			<u> </u>
	TOTAL WEIGHT		BC

ROUTED DUNNAGE METHOD UNIT (BASIC HEIGHT)
52-UNIT LOAD IN 50'-6" LONG BY 9'-4" WIDE CONVENTIONAL BOX CAR




SPECIAL NOTES:

- A 50'-6" LONG BY 9'-0" WIDE (INSIDE CLEARANCE) WOOD-LINED BOX CAR EQUIPPED WITH ADJUSTABLE AND/OR FIXED WALL MEMBERS, AND WITH 10'-0" WIDE DOOR OPENINGS IS SHOWN. CARS OF OTHER DIMENSIONS AND CARS HAVING WIDER OR NARROWER DOOR OPENINGS CAN BE USED. SEE GENERAL NOTE "D" ON PAGE 2.
- THE PALLETIZED UNIT SHOWN IN THE TYPICAL LOAD ON PAGE 68 IS THE ROUTED DUNNAGE METHOD UNIT (BASIC HEIGHT). A MAXIMUM OF TWENTY-EIGHT (28) OF THESE UNITS, FOR AN APPROXIMATE LADING WEIGHT OF 59, 416 POUNDS, CAN BE PLACED IN A 40'-6" LONG CAR.
- 3. IF A CAR HAS BOWED END WALLS WHICH ARE BOWED OUTWARD TWO INCHES (2") OR MORE EITHER FROM SIDE-TO-SIDE OR FROM FLOOR-TO-ROOF, CROSS MEMBERS CAN BE INSTALLED NEAR THE END WALL OF THE CAR TO PROVIDE A "SQUARED END" RATHER THAN INSTALLING DUNNAGE AS SPECIFIED IN GENERAL NOTE "G" ON PAGE 2. THESE CROSS MEMBERS SHOULD BE INSTALLED AT THE SAME HEIGHTS AS THE CROSS MEMBERS USED THROUGHOUT THE LOAD AS BLOCKING MEMBERS. A SEPARATOR GATE, SHOWN AS PIECE MARKED (4), MUST BE POSITIONED AGAINST THESE CROSS MEMBERS PRIOR TO LOADING.
- 4. TOP-OF-LOAD ANTI-SWAY BRACES, SHOWN AS PIECES MARKED ③ IN THE LOAD ON PAGE 68, MUST BE INSTALLED IN EACH END OF THE CAR AND WIRE TIED TO THE STRAPPING BOARDS WITH NO. 14 GAGE WIRE AS TYPICALLY SHOWN BY THE "TIE WIRE APPLICATION B" DETAIL ON PAGE 122. THREE (3) BRACES ARE REQUIRED IN EACH END OF A LOAD REGARDLESS OF THE CAR LENGTH.
- 5. TO FACILITATE POSITIONING OF THE PALLET UNTS AS LOADING PROGRESSES, POSITION PALLET UNIT STACKS AGAINST THE END WALL, THEN POSITION A SEPARATOR GATE, SHOWN AS PIECE MARKED (4), SO THE 1" X 4" TIE PIECES ARE LOCATED UNDER THE "OVERHANG" OF THE PALLET UNITS. REPEAT THIS PROCEDURE FOR THE REMAINING STACKS.
- 6. SEPARATOR GATES IN THE DOORWAY MUST BE PREVENTED FROM SHIFTING INTO A DOOR OPENING BY THE APPLICATION OF THE STOP PIECES, PIECES MARKED . IN CARS EQUIPPED WITH STAGGERED DOORS, STOP PIECES MAY BE REQUIRED ON UP TO FOUR SEPARATOR GATES.
- SEPARATOR GATES MAY BE FORMED FROM 3/8" OR THICKER PLYWOOD IN LIEU OF DIMENSIONAL LUMBER, IF DESIRED. SEE THE "ALTERNATIVE SEPARATOR GATE" DETAIL ON PAGE 122 FOR CONSTRUCTION GUIDANCE.
- 8. IF THE CAR BEING LOADED IS EQUIPPED WITH AT LEAST TWELVE (12) DOORWAY MEMBERS, AN ADDITIONAL FOUR PALLET UNITS CAN BE LOADED IN THE DOORWAY AREA.
- 9. THE DEPICTED LOAD CANBE REDUCED TO SUIT THE QUANTITY TO BE SHIPPED. A LOAD MAY BE REDUCED BY MULTIPLES OF TWO (2) PALLET UNITS BY OMITTING LATERALLY ADJACENT UNITS FROM THE TOP LAYER OF ONE OR MORE LOAD UNITS, OR BY MULTIPLES OF FOUR (4) PALLET UNITS BY OMITTING ONE OR MORE ENTIRE LOAD UNITS FROM THE CENTER PORTION OF THE LOAD. TO REDUCE A LOAD BY ONE (1) PALLET UNIT, REFER TO THE LCL PROCEDURES ON PAGES 90 AND 91 FOR GUIDANCE.
- 10. FOR SHIPMENT OF ONE OR MORE LEFTOVER CONTAINERS, SEE THE
 "PROCEDURES FOR SHIPMENT OF LEFTOVER CONTAINERS" ON PAGE 119 FOR
 GUIDANCE.

BILL OF MATERIAL		
LUMBER	LINEAR FEET	BOARD FEET
- 1" X 4" 1" X 6" 2" X 4" 2" X 6"	431 385 258 19	144 193 172 19
NAILS	NO. REQD	POUNDS
6d (2") 10d (3")	424 300	2-1/2 4-3/4

LOAD AS SHOWN

ITEM	QUANTITY	WEIGHT (APPROX)
PALLET UNIT	· 36	76,392 LBS
DUNNAGE -		1,065 LBS
	TOTAL WEIGHT	77 AET 1 BC



- 10. THE DEPICTED LOAD CAN BE REDUCED TO SUIT THE QUANTITY TO BE SHIPPED. A 2-TIER LOAD CAN BE REDUCED BY A MULTIPLE OF FOUR (4) PALLET UNITS OR A 1-TIER LOAD CAN BE REDUCED BY A MULTIPLE OF TWO (2) UNITS BY OMITTING ONE OR MORE LOAD UNITS FROM THE CENTER PORTION OF THE LOAD. OR, THE ENTIRE TOP TIER CAN BE OMITTED. FOR OTHER METHODS OF REDUCING A LOAD, AND FOR TYPICAL LCL PROCEDURES, REFER TO PAGES 94 THRU 105 AND GENERAL NOTE "FF" ON PAGE 3 FOR GUIDANCE.
- IF PALLET UNITS WHICH DO NOT CONTAIN A FULL QUANTITY OF CONTAINERS ARE TO BE TRANSPORTED, REFER TO PAGE. 117 AND/OR PAGES 118 AND 120 FOR SHIPPING GUIDANCE.
- FOR SHIPMENT OF ONE OR MORE LEFTOVER CONTAINERS, SEE THE "PROCEDURES FOR SHIPMENT OF LEFTOVER CONTAINERS" ON PAGE 119 FOR GUIDANCE.

LUMBER	LINEAR FEET	BOARD FEET
		JOHN TEET
1" X 4"	201	67
1" X 6"	410	205
2" X 3"	32	16
2" X 4"	293	196
2" X 6"	21	21
NAILS	NO, REQD	POUNDS
6d (2")	312	2
10d (3")	324	5
12d (3-1/4°)	32	3/4


SPECIAL NOTES:


- A 50'-6" LONG BY 9'-2" WIDE WOOD-LINED CUSHIONED BOX CAR EQUIPPED WITH LOAD DIVIDER BULKHEADS AND WITH 10'-0" WIDE DOOR OPENINGS IS SHOWN, CARS OF OTHER DIMENSIONS AND CARS HAVING NARROWER OR WIDER DOOR OPENINGS CAN BE USED. SEE GENERAL NOTES "AA" THRU "EE" ON PAGE 3.
- 2. THE PALLET UNIT SHOWN IN THE TYPICAL LOAD ON PAGE 70 IS THE ROUTED DUNNAGE METHOD UNIT (BASIC HEIGHT). A MAXIMUM OF FORTY-EIGHT (48) OF THESE UNITS, FOR AN APPROXIMATE LADING WEIGHT OF 101,856 POUNDS, CAN BE PLACED IN A 60'-8" LONG CAR, OR A MAXIMUM OF THRTY-TWO (32) UNITS CAN BE LOADED IN A 40'-6" CAR FOR AN APPROXIMATE LADING WEIGHT OF 67,904 POUNDS, WHEN USING THE DEPICTED PROCEDURES. IF CARS 9'-4" OR WIDER ARE AVAILABLE, THE CROSSWISE LOADING PATTERN SHOWN ON PAGE 66 MAY BE EMPLOYED, SKITY-FOUR (64) PALLET UNITS FOR AN APPROXIMATE LADING WEIGHT OF 135,808 POUNDS CAN BE PLACED IN A 60'-8" LONG CAR, FIFTY-TWO (52) UNITS CAN BE LOADED IN A 50'-6" LONG CAR FOR AN APPROXIMATE LADING WEIGHT OF 110,344 POUNDS, AND FORTY (40) UNITS CAN BE LOADED IN A 40'-6" LONG CAR FOR AN BPROXIMATE LADING WEIGHT OF 84,880 POUNDS.
- 3. IF THE "ALTERNATIVE DOORWAY PROTECTION F" PROCEDURES AS SHOWN ON PAGE 128 ARE USED IN LIEU OF THE WOODEN DOOR GATE TYPE PROTECTION, PIECE MARKED (3), NAILED FLOORLINE BLOCKING MUST BE USED IN LIEU OF THE LOWER ANTI-SWAY BRACE IN THE DOORWAY AREA. NAILED BLOCKING IS REQUIRED FOR ALL PALLET STACKS WHICH ARE COMPLETELY WITHIN THE DOORWAY AREA BY ONE-HALF OR MORE OF THE STACK WIDTH ON EITHER SIDE OF THE CAR.
- 4. TOP-OF-LOAD ANTI-SWAY BRACES, SHOWN AS PIECES MARKED ② IN THE LOAD ON PAGE 70, MUST BE INSTALLED IN EACH END OF THE CAR AND WIRE TIED TO STRAPPING BOARDS WITH NO. 14 GAGE WIRE AS TYPICALLY SHOWN BY THE "TIE WIRE APPLICATION B" DETAIL ON PAGE 122. THREE (3) BRACES ARE REQUIRED IN EACH END OF A LOAD REGARDLESS OF THE CAR LENGTH,
- 5. TO FACILITATE POSITIONING OF THE PALLET UNITS AS LOADING PROGRESSES, POSITION PALLET UNIT STACKS AGAINST THE END WALL, THEN POSITION A SEPARATOR GATE, SHOWN AS PIECE MARKED (3), SO THE 1" X 4" TIE PIECES ARE LOCATED UNDER THE "OVERHANG" OF THE PALLET UNITS. REPEAT THIS PROCEDURE FOR THE REMAINING STACKS.
- 6. SEPARATOR GATES IN THE DOORWAY MUST BE PREVENTED FROM SHIFTING INTO A DOOR OPENING BY THE APPLICATION OF THE STOP PIECES, PIECES MARKED (4). IN CARS EQUIPPED WITH STAGGERED DOORS, STOP PIECES MAY BE REQUIRED ON UP TO FOUR SEPARATOR GATES.
- SEPARATOR GATES MAY BE FORMED FROM 3/8" OR THICKER PLYWOOD IN LIEU OF DIMENSIONAL LUMBER, IF DESIRED. SEE THE "ALTERNATIVE SEPARA-TOR GATE" DETAIL ON PAGE 122 FOR CONSTRUCTION GUIDANCE.
- B. DOORWAY PROTECTION IS REQUIRED FOR ALL PALLET UNIT STACKS WHICH ARE COMPLETELY WITHIN THE DOORWAY AREA OR WHICH EXTEND INTO THE DOORWAY AREA BY ONE-HALF OR MORE OF THE STACK WIDTH. THE WOODEN GATE TYPE OF DOORWAY PROTECTION, SHOWN AS PIECES MARKED (3) IN THE LOAD ON PAGE 70 IS APPLICABLE FOR BOX CARS EQUIPPED WITH CONVENTIONAL SLIDING DOORS AND NAILABLE DOOR POSTS, REFER TO PAGES 126 THRU 128 FOR ALTERNATIVE DOORWAY PROTECTION FOR CARS EQUIPPED WITH CONVENTIONAL SLIDING DOORS, IF THE CAR BEING LOADED IS EQUIPPED WITH PLUG TYPE DOORS, NAILED FLOORLINE BLOCKING AND LOAD BUNDLING STRAPS MUST BE USED. SEE THE "ALTERNATIVE DOORWAY PROTECTION F" DETAIL ON PAGE 128 FOR GUIDANCE IF THE PALLET UNITS ARE POSITIONED AS SHOWN ON PAGE 70. SEE THE "ALTERNATIVE DOORWAY PROTECTION E" DETAIL ON THAT PAGE IF THE PALLET UNITS ARE POSITIONED ROSSWISE.
- 9. A STRUT ASSEMBLY, SHOWN AS PIECE MARKED (3) IN THE LOAD ON PAGE 42, IS REQUIRED BETWEEN THE LOAD DIVIDER BULKHEADS WHEN THE LOAD IN EITHER END OF THE CAR IS 50,000 POUNDS OR MORE. FOR THE DEPICTED PALLET UNIT, A STRUT ASSEMBLY WILL BE REQUIRED IF THE LOAD IN ONE END OF THE CAR CONSISTS OF MORE THAN FIVE (5) LOAD UNITS, WHICH WOULD BE THE CASE IF AN OFFSET LOADING PATTERN IS EMPLOYED. THE STRUT ASSEMBLY WILL ALWAYS BE REQUIRED FOR FULL LOADS IN 60'CR LONGER CARS.


(CONTINUED AT LEFT)


LOAD AS SHOWN


ROUTED DUNNAGE METHOD UNIT (BASIC HEIGHT)
40-UNIT LOAD IN A 50'-6" LONG BY 9'-2" WIDE BOX CAR EQUIPPED WITH LOAD DIVIDERS














(SPECIAL NOTES CONTINUED)

- 10. THE DEPICTED LOAD CAN BE REDUCED TO SUIT THE QUANTITY TO BE SHIPPED. THE LOAD CAN BE REDUCED BY ONE OR MORE PALLET UNITS BY EMPLOYING THE PROCEDURES SHOWN ON PAGE 96. SIX (6) PALLET UNITS CAN BE OMITTED FROM A 3-TIER LOAD BY LEAVING OUT THE LENGTHWISE STACK NUMBERED 7, THE CROSSWISE STACK NUMBERED 9, AND THE ADJACENT CRIB FILL. NOTE THAT STRUT BRACING MUST BE APPLIED TO ALL THE STRUTS. OR, THE ENTIRE ONE OR TWO TOP TIERS CAN BE OMITTED. A PARTIAL 1-TIER LOAD CAN BE SHIPPED IN ONE OR BOTH ENDS OF A CAR BY USING KNEE BRACES AS SHOWN ON PAGES 112 AND 113.
- IF PALLETIZED UNITS WHICH DO NOT CONTAIN A FULL QUANTITY OF CON-TAINBES ARE TO BE TRANSPORTED, REFER TO PAGE 117 FOR SHIPPING GUIDANCE FOR LENGTHWISE UNITS AND PAGES 118 AND 120 FOR CROSSWISE UNITS.
- 12. FOR SHIPMENT OF ONE OR MORE LEFTOVER CONTAINERS, SEE THE "PROCEDURES FOR SHIPMENT OF LEFTOVER CONTAINERS" ON PAGE 119 FOR GUIDANCE.

LUMBER	LINEAR FEET	BOARD FEET
1" X 4"	140	47
1" X 6"	310	155
2" X 2"	127	43
2" X 3"	44	22
2" X 4"	1106	738
2" X 6"	204	204
4" X 4"	125	167
NAILS	NO, REQD	POUND
6d (2")	252	1-1/2
10d (3")	1766	27-1/4
12d (3-1/4")	48	3/4
16d (3-1/2")	128	3

SPECIAL NOTES:


- A 60'-8" LONG BY 9'-2" WIDE WOOD-LINED CONVENTIONAL TYPE BOX CAR EQUIPPED WITH 10'-0" WIDE DOOR OPENINGS IS SHOWN, CARS OF OTHER DIMENSIONS AND CARS HAVING WIDER OR NARROWER DOOR OPENINGS CAN BE USED, SEE GENERAL NOTE "D" ON PAGE 2 AND SPECIAL NOTE 3 BELOW.
- THE PALLET UNIT SHOWN IN THE TYPICAL LOAD ON PAGE 76 IS THE ROUTED DUNNAGE METHOD UNIT (DECREASED HEIGHT). A MAXIMUM OF SIXTY-INIE (49) OF THESE UNITS, FOR AN APPROXIMATE LADING WEIGHT OF 111,504 POUNDS, CAN BE PLACED IN A 50'-6" LONG CAR WHEN USING THE DEPICTED PROCEDURES, FIFTY-FOUR (54) UNITS, FOR A LADING WEIGHT OF 87,264 POUNDS, CAN BE OUTLOADED IN A 40'-6" LONG CAR.
- 3. THE DEPICTED LOAD PATTERN IS ADEQUATE FOR CARS HAVING DOOR OPENINGS AS NARROW AS 7'-0". IF A CAR HAVING DOOR OPENINGS LESS THAN 7'-0" WIDE IS TO BE LOADED, THE LENGTHWISE UNITS SHOULD BE LOADED SIX (6) STACKS LONG IN EACH END OF THE CAR AND THE CROSSWISE UNITS SHOULD BE LOADED EIGHT (8) STACKS LONG IN EACH END. AN ADDITIONAL PIECE MARKED (7) WILL BE REQUIRED; THE BALANCE OF THE DUNNAGE WILL NOT CHANGE.
- 4. THE "HIGH" CRIB, SHOWN AS PIECE MARKED (1), MUST BE INSTALLED IN EACH END OF THE LOAD, FOUR (4) ASSEMBLIES ARE REQUIRED IN EACH END OF A LOAD REGARDLESS OF THE CAR LENGTH.
- 5. THE SEPARATOR GATES, SHOWN AS PIECES MARKED ② IN THE LOAD ON PAGE 76, ARE DESIGNATED "RIGHT HAND" AND "LEFT HAND" TO FACILITATE POSITIONING OF THE PALLET UNITS AS LOADING PROGRESSES. WHEN LOADING THE CAR, POSITION A PALLET UNIT STACK AGAINST THE END WALL, THEN POSITION A SEPARATOR GATE, SO THE 1" X 4" TIE PIECES ARE LOCATED UNDER THE "OVERHANG" OF THE BOTTOM AND TOP PALLET UNITS. REPEAT THIS PROCEDURE FOR THE REMAINING STACKS.
- 6. ALL SEPARATOR GATES, PIECES MARKED ②, WHICH ARE WITHIN THE DOCRWAY AREA OF A CAR EQUIPPED WITH CONVENTIONAL SLIDING DOORS MUST BE WIRE TIED TO THE ADJACENT CRIB FILL TO PREVENT DISPLACEMENT. ENCIRCLE THE STOP PIECE OF THE SEPARATOR GATE AND THE UPPER HORIZONTAL PIECE OF THE CRIB FILL WITH NO. 14 GAGE WIRE AND TWIST TAUT.
- 7. SEPARATOR GATES MAY BE FORMED FROM 3/8" OR THICKER PLYWOOD IN LIEU OF DIMENSIONAL LUMBER, IF DESIRED, FOR ONE OR TWO-LAYER LOADS; PLYWOOD SEPARATOR GATES FOR A THREE-LAYER LOAD ARE NOT ECONOMICALLY FEASIBLE. CONSTRUCT EACH SEPARATOR GATE FOR ONE OR TWO-LAYER LOADS FROM 42" WIDE PLYWOOD OF AN APPROPRIATE LENGTH.
- CENTER GATES "V" AND "W" MAY BE PARTIALLY FORMED FROM 1/2" OR
 THICKER PLYWOOD, IF DESIRED. PLYWOOD MAY BE USED IN LIEU OF THE
 2" X 6" HORIZONTAL PIECES. SEE THE "PLYWOOD CENTER GATE ALTERNATIVE"
 DETAIL ON PAGE 123 FOR GUIDANCE.
- DOORWAY PROTECTION IS REQUIRED FOR ALL PALLET UNIT STACKS WHICH ARE COMPLETELY WITHIN THE DOORWAY AREA OR WHICH EXTEND INTO THE DOORWAY AREA BY ONE-HALF OR MORE OF THE STACK WIDTH OR LENGTH. THE WOODEN GATE TYPE OF DOORWAY PROTECTION, SHOWN AS PIECES MAKED (1) IN THE LOAD ON PAGE 76, IS APPLICABLE FOR BOX CARS EQUIPPED WITH CONVENTIONAL SLIDING DOORS AND NAILBEL DOOR POSTS. REFER TO PAGES 126 THRU 128 FOR ALTERNATIVE DOORWAY PROTECTION FOR CARS EQUIPPED WITH CONVENTIONAL SLIDING DOORS. IF THE CAR BEING LOADED IS EQUIPPED WITH FULG TYPE DOORS, NAILED FLOORLINE BLOCKING AND LOAD-BUNDLING STRAPS MUST BE USED. SEE THE "ALTERNATIVE DOORWAY PROTECTION F" DETAILS ON PAGE 128 FOR GUIDANCE; A COMBINATION OF THE TWO METHODS MUST BE USED. NAILED SIDE BLOCKING WILL BE USED UNDER THE CRIB FILL SHOWN IN THE DOORWAY AREA OF THE LOAD. POSITION DOUBLED 2" X 4" X 8"-0" PIECES AGAINST THE LENGTHWISE STACKS NUMBERED 6 AND 7, AND PREPOSITION DOUBLED 2" X 4" X 7"-0" PIECES (APPROXIMATELY 52" FROM THE NEAR SIDE CAR WALL) SO AS TO BE AGAINST THE CROSSWISE STACKS NUMBERED 8 AND 9. THESE PIECES WILL BE USED IN LIEU OF THE 40" AND 48" LONG PIECES SHOWN BY THE ALTERNATIVE DOORWAY PROTECTION F" DETAIL, MUST BE MODIFIED FOR USE BY CHANGING THE END WHICH EXTENDS OVER THE CROSSWISE CONTAINMENS TO BE LIKE THE NEAR END OF THE STRAPPING BOARD SHOWN IN THE "ALTERNATIVE DOORWAY PROTECTION F" DETAIL, MUST BE MODIFIED FOR USE BY CHANGING THE END WHICH EXTENDS OVER THE CROSSWISE CONTAINMENS TO BE LIKE THE NEAR END OF THE STRAPPING BOARD SHOWN IN THE "ALTERNATIVE DOORWAY PROTECTION F" DETAIL, MUST BE MODIFIED FOR USE BY CHANGING THE END WHICH EXTENDS OVER THE CROSSWISE CONTAINERS TO BE LIKE THE NEAR END OF THE STRAPPING BOARD SHOWN IN THE "ALTERNATIVE DOORWAY PROTECTION F" DETAIL, A 2" X 4" X 4" DOUBLED BATTEN AS SHOWN IN THAT VIEW IS ALSO REQUIRED. NOTE THAT THE VERTICAL PIECES OF THE CRIB FILL, PIECES MARKED (3), MUST HAVE THREE INCHES (3") CUT OFF THE BOTTOM END OF ONE SIDE SO THE CRIB WILL REST EVENLY ON THE MAILED SIDE BLOCKING WHICH IS ADJACENT

(CONTINUED AT LEFT)

LOAD AS SHOWN

ITEM	QUANTITY	WE	IGHT (APPROX)
	UNIT 84		
	TOTAL WEIGHT	138,529	LBS

ROUTED DUNNAGE METHOD UNIT (DECREASED HEIGHT)
84- UNIT LOAD IN A 60'-8" LONG BY 9'-2" WIDE CONVENTIONAL BOX CAR



(SPECIAL NOTES CONTINUED)

- 13. IF THE "ALTERNATIVE DOORWAY PROTECTION F" PROCEDURES SHOWN ON PAGE 128
 ARE USED IN LIEU OF THE WOODEN DOORWAY PROTECTION, PIECES MARKED (3),
 THE CENTER GATES MUST BE RESTRAINED FROM LATERAL MOVEMENT, THIS CAN BE
 ACCOMPLISHED BY NAILING TO THE CAR FLOOR A DOUBLED 2" X 4" X 18" PIECE
 POSITIONED LONGITUDINALLY SO AS TO BE CENTERED AGAINST THE FILL PIECE
 OF A CENTER GATE, TWO (2) PIECES WILL BE REQUIRED FOR EACH CENTER GATE
 WHICH IS IN THE DOOR OPENING OR WITHIN SIX INCHES (6") OF BEING IN THE
 OPPNING.
- 14. THE DEPICTED LOAD CAN BE REDUCED TO SUIT THE QUANTITY TO BE SHIPPED. A 3-TIER LOAD CAN BE REDUCED BY A MULTIPLE OF SIX (6) PALLET UNITS, OR A 2-TIER LOAD CAN BE REDUCED BY A MULTIPLE OF FOUR (4) UNITS, OR A 1-TIER LOAD CAN BE REDUCED BY A MULTIPLE OF TWO (2) UNITS BY OMITTING ONE OR MORE LOAD UNITS FROM THE CENTER PORTION OF THE LOAD. OR, THE ENTIRE ONE OR TWO TOP TIERS CAN BE OMITTED. FOR OTHER METHODS OF REDUCING A LOAD, AND FOR TYPICAL LCL PROCEDURES, REFER TO PAGES 92 THRU 120 FOR CHIDANCE.
- 15. IF PALLETIZED UNITS WHICH DO NOT CONTAIN A FULL QUANTITY OF CONTAINERS ARE TO BE TRANSPORTED, REFER TO PAGE 117 FOR SHIPPING GUIDANCE.
- 16. FOR SHIPMENT OF CNE OR MORE LEFTOVER CONTAINERS, SEE THE "PROCEDURES FOR SHIPMENT OF LEFTOVER CONTAINERS" ON PAGE 119 FOR GUIDANCE.

BILL OF MATERIAL		
LUMBER	LINEAR FEET	BOARD FEET
1" X 4"	183	61
1" X 6"	500	250
2" X 2"	110	37
2" X 3"	36	18
2" X 4"	515	344
2" X 6"	217 .	217
4" X 4"	100	134
NAILS	NC. REQD	POUNDS
6d (2")	312	2
10d (3")	820	12-3/4
12d (3-1/4")	36	3/4
16d (3-1/2")	96	2-1/4
WIRE, NO. 14 GAGE -	60' REQD	1 L

SPECIAL NOTES:


- A 60'-8" LONG BY 9'-2" WIDE WOOD-LINED CONVENTIONAL TYPE BOX CAR EQUIPPED WITH 10'-0" WIDE DOOR OPENINGS IS SHOWN. CARS OF OTHER DIMENSIONS AND CARS HAVING WIDER OR NARROWER DOOR OPENINGS CAN BE USED. SEE GENERAL NOTE "D" ON PAGE 2 AND SPECIAL NOTE 3 BELOW.
- 2. THE PALLET UNIT SHOWN IN THE TYPICAL LOAD ON PAGE 78 IS THE ROUTED DUNNAGE METHOD UNIT (DECREASED HEIGHT). A MAXIMUM OF SIXTY (60) OF THESE UNITS, FOR AN APPROXIMATE LADING WEIGHT OF 96,960 POUNDS, CAN BE PLACED IN A 50'-6" LONG CAR WHEN USING THE DEPICTED PROCEDURES; FORTY-EIGHT (48) UNITS, FOR AN APPROXIMATE LADING WEIGHT OF 77,568 POUNDS, CAN BE OUTLOADED IN A 40'-6" LONG CAR.
- 3. THE DEPICTED LOADING PATTERN IS ADEQUATE FOR CARS HAVING ANY SIZE DOORS. HOWEVER, IF THE CAR TO BE LOADED HAS DOOR OPENINGS AT LEAST 8'-0" WIDE AND OF SUFFICIENT HEIGHT TO ALLOW PERSONNEL TO EXIT THE CAR OVER THE TOP OF THE LOAD, WHEN NECESSARY, LOADING AND UNICADING WILL BE EASIER IF THE PALLETS ARE POSITIONED SO THERE ARE SEVEN (7) LOAD UNITS IN ONE END OF THE CAR AND FIVE (5) LOAD UNITS IN THE OPPOSITE.
- 4. IF THE "ALTERNATIVE DOORWAY PROTECTION F" PROCEDURES AS SHOWN ON PAGE 128 ARE USED IN LIEU OF THE WOODEN DOOR GATE TYPE PROTECTION, PIECE MARKED (a), NAILED FLOORLINE BLOCKING MUST BE USED IN LIEU OF EACH LOWER ANTI-SWAY BRACE IN THE DOORWAY AREA. NAILED BLOCKING IS REQUIRED FOR ALL PALLET STACKS WHICH ARE COMPLETELY WITHIN THE DOORWAY AREA OR WHICH EXTEND INTO THE DOORWAY AREA BY ONE-HALF OR MORE OF THE STACK WIDTH ON EITHER SIDE OF THE CAR.
- 5. TOP-OF-LOAD ANTI-SWAY BRACES, SHOWN AS PIECES MARKED ② IN THE LOAD ON PAGE 78, MUST BE INSTALLED IN EACH END OF THE CAR AND WIRE TIED TO A STRAPPING BOARD WITH NO. 14 GAGE WIRE AS SHOWN. THREE (3) BRACES ARE REQUIRED IN EACH END OF A LOAD REGARDLESS OF THE CAR LENGTH.
- 6. TO FACILITATE POSITIONING OF THE PALLET UNITS AS LOADING PROGRESSES, WHEN LOADING THE BOX CAR, POSITION PALLET UNIT STACKS AGAINST THE END WALL, THEN POSITION A SEPARATOR GATE, SHOWN AS PIECE MARKED ③, SO THE 1" X 4" TIE PIECES ARE LOCATED UNDER THE "OVERHANG" OF THE BOTTOM AND TOP PALLET UNITS. REPEAT THIS PROCEDURE FOR THE REMAINING STACKS.
- 7. SEPARATOR GATES IN THE DOORWAY MUST BE PREVENTED FROM SHIFTING INTO A DOOR OPENING BY THE APPLICATION OF STOP PIECES, A 7'-0" LONG STOP PIECE IS REQUIRED FOR A 3-LAYER LOAD AND 48" LONG STOP PIECES ARE REQUIRED FOR 1 AND 2-LAYER LOADS, SEE PIECE MARKED (A) ON PAGE 64 FOR A TYPICAL INSTALLATION, IN CARS EQUIPPED WITH STAGGERED DOORS, STOP PIECES MAY BE REQUIRED ON UP TO FOUR SEPARATOR GATES
- 8. SEPARATOR GATES MAY BE FORMED FROM 3/8" OR THICKER PLYWOOD IN LIEU OF DIMENSIONAL LUMBER, IF DESIRED, FOR ONE OR TWO-LAYER LOADS, PLYWOOD SEPARATOR GATES FOR 3-HIGH LOADS ARE NOT ECONOMICALLY FEASIBLE. SEE THE "ALTERNATIVE SEPARATOR GATE" DETAIL ON PAGE 122 FOR CONSTRUCTION GUIDANCE.
- CENTER GATE "X" MAY BE PARTIALLY FORMED FROM 1/2" OR THICKER PLYWOOD, IF DESIRED, PLYWOOD MAY BE USED IN LIEU OF THE 2" X 6" HORIZONTAL PIECES. SEE THE "PLYWOOD CENTER GATE ALTER-NATIVE" DETAIL ON PAGE 123 FOR GUIDANCE.
- 10. FOR EASE OF HANDLING, SPLIT CENTER GATES, WHICH ARE NOT DEPENDENT UPON THE WIDTH OF THE CAR, MAY BE USED AS AN ALTERNATIVE TO THE CAR-WIDTH GATES. IN LIEU OF EACH "CENTER GATE X", SHOWN AS PIECE MARKED (4) IN THE LOAD ON PAGE 78, INSTALL TWO (2) "CENTER GATES V" AS SHOWN ON PAGE 86. AFTER THE SPLIT GATES AND STRUTS HAVE BEEN INSTALLED, THE SPLIT GATES MUST BE TIED TOGETHER AS DEPICTED BY THE "TIE PIECE APPLICATION" DETAIL ON PAGE 123. OMIT THE STOP PIECES FROM "CENTER GATE V".
- 11. DOOR SPANNER TYPE GATE HOLD DOWN MAY BE USED IN LIEU OF THE DOUBLED 2" X 4" MATERIAL NAILED TO CENTER GATE"L, PROVIDING THE CAR BEING LOADED HAS NAILABLE SIDEWALLS. SEE THE DETAILS ON PAGE 125 FOR GUIDANCE
- 12. DOORWAY PROTECTION IS REQUIRED FOR ALL PALLET UNIT STACKS WHICH ARE COMPLETELY WITHIN THE DOORWAY AREA OR WHICH EXTEND INTO THE DOORWAY AREA BY ONE-HALF OR MORE OF THE STACK WIDTH. THE WOODEN GATE TYPE OF DOORWAY PROTECTION, SHOWN AS PIECES MARKED (3) IN THE LOAD ON PAGE 78, IS APPLICABLE FOR BOX CARS EQUIPPED WITH CONVENTIONAL SLIDING DOCRS AND NAILABLE DOOR POSTS. REFER TO PAGES 126 THRU 128 FOR ALTERNATIVE DOCRWAY PROTECTION FOR CARS EQUIPPED WITH CONVENTIONAL SLIDING DOCRS, IF THE CAR BEING LOADED IS EQUIPPED WITH PLUG TYPE DOCRS, NAILED FLOORLINE BLOCKING A ND LOAD BUNDLING STRAPS MUST BE USED. SEE THE "ALTERNATIVE DOORWAY PROTECTION F" DETAIL ON PAGE 128 FOR GUIDANCE"

(CONTINUED AT LEFT)

LOAD AS SHOWN

ITEM	QUANTITY	WEIGHT (APPROX	.)
PALLET UN DUNNAGE	NIT 72	116,352 LBS 2,141 LBS	
	TOTAL WEIGHT	118,493 LBS	

ROUTED DUNNAGE METHOD UNIT (DECREASED HEIGHT)
72-UNIT LOAD IN A 60'-8" LONG BY 9'-2" WIDE CONVENTIONAL BOX CAR



BILL OF MATERIAL LUMBER LINEAR FEET BOARD FEET 2" X 2" 117 39 2" X 3" 36 18 2" X 4" 70 201 201 108 144 NAILS NO. REQD POUNDS 6d (2") 10d (3") 5-1/4 336 12d (3-1/4") 16d (3-1/2") 96 2-1/4


SPECIAL NOTES:

- A 50'-6" LONG BY 9'-4" WIDE WOOD-LINED CONVENTIONAL TYPE BOX CAR EQUIPPED WITH 8"-0" WIDE DOOR OPENINGS IS SHOWN, WIDER CARS OF OTHER LENGTHS AND CARS HAVING WIDER OR NARROWER DOOR OPENINGS CAN BE USED. SEE GENERAL NOTE "D" ON PAGE 2.
- 2. THE PALLETIZED UNIT SHOWN IN THE TYPICAL LOAD ON PAGE 80 IS THE ROUTED DUNNAGE METHOD UNIT (DECREASED HEIGHT). A MAXIMUM OF SIXTY (60) OF THESE UNITS, FOR AN APPROXIMATE LADING WEIGHT OF 96,960 POUNDS, CAN BE PLACED IN A 40"-4" LONG CAR WHEN USING THE DEPICTED PROCEDURES. IF A 60"-8" LONG BY 9"-4" OR WIDER CAR IS AVAILABLE, NINETY-SIX (96) PALLET UNITS, FOR AN APPROXIMATE LADING WEIGHT OF 155,136 POUNDS, CAN BE LOADED. SEE SPECIAL NOTE 9 FOR CENTER GATE MODIFICATIONS WHICH MUST BE MADE IF 60' LONG CARS ARE TO BE USED.
- B. ANTI-SWAY BRACING BETWEEN LATERALLY ADJACENT ROWS OF PALLET UNITS IS REQUIRED IF A CAR WHICH IS WIDER THAN 9'-4" IS FURNISHED FOR LOADING. SEE THE "ANTI-SWAY BRACE B" DETAIL ON PAGE 74 FOR CONSTRUCTION GUIDANCE. TO PREVENT LONGITUDINAL DISPLACEMENT OF THE ANTI-SWAY BRACE BETWEEN THE UPPER UNITS, A STOP PIECE MUST BE NAILED TO EACH CENTER GATE "Y" AS SHOWN ON THE DETAIL ON PAGE 89. TO PREVENT DISPLACEMENT OF THE FLOOR LINE ANTI-SWAY BRACE (IF USED), POSITION A DOUBLED 2" X 4" X 12" PIECE LONGITUDINALLY BETWEEN THE FILL PIECES ON THE GATE SO AS TO BE IN CONTACT WITH THE ANTI-SWAY BRACE AND NAIL TO THE CAR FLOOR W3-124 NAILS EACH LAYER. IF DESIRED IN CARS HAVING NAILABLE SIDEWALLS, 1" X 6" OR 2" X 6" FILL MATERIAL MAY BE NAILED TO ONE OR BOTH SIDEWALLS AT HEIGHTS SPECIFIED FOR THE DOORWAY PROTECTION HORIZONTAL PIECES, IN LIEU OF USING THE ANTI-SWAY BRACES. NOTE THAT THE TOTAL ACCUMULATED SPACE ACROSS A CAR SHOULD NOT EXCEED TWO INCHES (2").
- 4. CENTER GATE "Y" MAY BE PARTIALLY FORMED FROM 1/2" OR THICKER PLYWOOD, IF DESIRED. PLYWOOD MAY BE USED IN LIEU OF THE 2" X 6" HORIZONTAL PIECES. SEE THE "PLYWOOD CENTER GATE ALTERNATIVE" DETAIL ON PAGE 123 FOR GUIDANCE.
- 5. FOR EASE OF HANDLING, SPLIT CENTER GATES, WHICH ARE NOT DEPENDENT UPON THE WIDTH OF THE CAR, MAY BE USED AS AN ALTERNATIVE TO THE CAR-WIDTH GATES. IN LIEU OF EACH "CENTER GATEY", SHOWN AS PIECE MARKED () IN THE LOAD ON PAGE 80, INSTALL TWO (2) "CENTER GATES W" AS SHOWN ON PAGE 87. AFTER THE SPLIT GATES AND STRUTS HAVE BEEN INSTALLED, THE SPLIT GATES MUST BE TIED TOGETHER AS DEPICTED BY THE "TIE PIECE APPLICATION" DETAIL ON PAGE 123.
- 6. AN ALTERNATIVE TO THE GATE HOLD DOWN SHOWN AS PIECE MARKED ③
 IN THE LOAD ON PAGE 80 MAY BE USED, IF DESIRED, WHEN THE CAR
 FURNISHED FOR LOADING IS EQUIPPED WITH B**-0** OR WIDER DOORS. NOTE
 THAT IN A CAR HAVING DOOR OPENINGS JUST 8*-0** WIDE IT MAY BE NECESSARY TO LAMINATE ONE OR TWO THICKNESSES OF 2-INCH MATERIAL TO THE
 ADJACENT CENTER GATE VERTICAL PIECES TO PROVIDE AN AREA FOR NAILING
 OF PIECES MARKED ③ AND ⑥. AN ALTERNATIVE MUST BE USED WHEN
 THE CAR FURNISHED HAS DOOR OPENINGS LESS THAN 8'-0** WIDE, DOOR
 SPANNER TYPE HOLD DOWN AS SHOWN ON PAGE 125 MAY BE USED IF THE
 CAR HAS NAILABLE SIDEWALLS, OR DOUBLED 2" X 3" HOLD DOWN PIECES
 MAY BE APPLIED TO THE CENTER GATES AS SHOWN BY THE CENTER GATE "Y"
 DETAIL ON PAGE 89.
- 7. DOORWAY PROTECTION IS REQUIRED FOR ALL PALLET UNIT STACKS WHICH ARE COMPLETELY WITHIN THE DOORWAY AREA OR WHICH EXTEND INTO THE DOORWAY AREA BY ONE-HALF OR MORE OF THE STACK LENGTH. THE WOODEN GATE TYPE OF DOORWAY PROTECTION, SHOWN AS PIECES MARKED (?) IN THE LOAD ON PAGE 80, IS APPLICABLE FOR BOX CARS EQUIPPED WITH CONVENTIONAL SLIDING DOORS AND NAILABLE DOOR POSTS. REFER TO PAGES 126 THRU 128 FOR ALTERNATIVE DOORWAY PROTECTION FOR CARS EQUIPPED WITH CONVENTIONAL SLIDING DOORS. IF THE CAR BEING LOADED IS EQUIPPED WITH CONVENTIONAL SLIDING DOORS. IF THE CAR BEING LOADED LOAD BUNDLING STRAPS MUST BE USED. SEE THE "ALTERNATIVE DOORWAY PROTECTION E" DETAIL ON PAGE 128 FOR GUIDANCE.
- 8. THE DEPICTED LOAD CAN BE REDUCED TO SUIT THE QUANTITY TO BE SHIPPED. A 3-TIER LOAD CAN BE REDUCED BY A MULTIPLE OF SIX (6) PALLET UNITS, A 2-TIER LOAD CAN BE REDUCED BY A MULTIPLE OF FOUR (4) UNITS, OR A 1-TIER LOAD CAN BE REDUCED BY A MULTIPLE OF TWO (2) UNITS BY OMITTING ONE OR MORE LOAD UNITS FROM THE CENTER PORTION OF THE LOAD. OX, THE ENTIRE ONE OR TWO TOP TIERS CAN BE OMITTED. FOR OTHER METHODS OF REDUCING A LOAD, AND FOR TYPICAL LCL PROCEDURES, REFER TO PAGES 92 THRU 120 FOR GUIDANCE.
- 9. IF A FULL LOAD IS TO BE SHIPPED IN A 60' LONG CAR, SIX (6) STRUTS ARE REQUIRED FOR EACH ROW/TIER. TO ACCOMMODATE THESE ADDITIONAL STRUTS, A VERTICAL PIECE MUST BE ADDED TO CENTER GATE "Y" FOR EACH ROW AS SHOWN BY THE PHANTOMED LINES ON THE DETAIL ON PAGE 89.
- IF PALLET UNITS WHICH DO NOT CONTAIN A FULL QUANTITY OF CON-TAINERS ARE TO BE TRANSPORTED, REFER TO PAGES 118 AND 120 FOR SHIPPING GUIDANCE.
- FOR SHIPMENT OF ONE OR MORE LEFTOVER CONTAINERS, SEE THE "PROCEDURES FOR SHIPMENT OF LEFTOVER CONTAINERS" ON PAGE 119 FOR GUIDANCE.

LOAD AS SHOWN

ITEM	QUANTITY	WEI	GHT	(APPRCX)
PALLET UN	T 78	126,048 1,049	LBS LBS	
,	TOTAL WEIGHT	127,097	LBS	

ROUTED DUNNAGE METHOD UNIT (DECREASED HEIGHT)
78-UNIT LOAD IN A 50'-6" LONG BY 9'-4" WIDE CONVENTIONAL BOX CAR




- A 50'-6" LONG BY 9'-0" WIDE (INSIDE CLEARANCE) BOX CAR EQUIPPED WITH ADJUSTABLE AND/OR FIXED WALL MEMBERS, AND WITH 10'-0" WIDE DOOR OPENINGS, IS SHOWN. CARS OF OTHER DIMENSIONS AND CARS HAVING WIDER OR NARROWER DOOR OPENINGS CAN BE USED.
- THE PALLETIZED UNIT SHOWN IN THE TYPICAL LOAD ON PAGE 82 IS THE ROUTED DUNNAGE METHOD UNIT (DECREASED HEIGHT). A MAXIMUM OF FORTY-FOUR (44) OF THESE UNITS, FOR AN APPROXIMATE LADING WEIGHT OF 71,104 POUNDS, CAN BE PLACED IN A 40'-6" LONG CAR.
- 3. IF A CAR HAS BOWED END WALLS WHICH ARE BOWED OUTWARD TWO INCHES (2") OR MORE EITHER FROM SIDE-TO-SIDE OR FROM FLOOR-TO-ROOF, CROSS MEMBERS CAN BE INSTALLED NEAR THE END WALL OF THE CAR TO PROVIDE A "SQUARED END" RATHER THAN INSTALLING DUNNAGE AS SPECIFIED IN GENERAL NOTE "G" ON PAGE 2. THESE CROSS MEMBERS SHOULD BE INSTALLED AT THE SAME HEIGHTS AS THE CROSS MEMBERS USED THROUGHOUT THE LOAD AS BLOCKING MEMBERS. A SEPARATOR GATE, SHOWN AS PIECE MARKED (4), MUST BE POSITIONED AGAINST THESE CROSS MEMBERS PRIOR TO LOADING.
- 4. TOP-OF-LOAD ANTI-SWAY BRACES, SHOWN AS PIECES MARKED ③ IN THE LOAD ON PAGE 82, MUST BE INSTALLED IN EACH END OF THE CAR AND WIRE TIED TO THE STRAPPING BOARDS WITH NO. 14 GAGE WIRE AS TYPICALLY SHOWN BY THE "TIE WIRE APPLICATION B" DETAIL ON PAGE 122. THREE (3) BRACES ARE REQUIRED IN EACH END OF A LOAD REGARDLESS OF THE CAR LENGTH
- 5. TO FACILITATE POSITIONING OF THE PALLET UNITS AS LOADING PROGRESSES, POSITION PALLET UNIT STACKS AGAINST THE END WALL, THEN POSITION A SEPARATOR GATE, SHOWN AS PIECE MARKED ④, SO THE 1" X 4" TIE PIECES ARE LOCATED UNDER THE "OVERHANG" OF THE BOTTOM AND TOP PALLET UNITS. REPEAT THIS PROCEDURE FOR THE REMAINING STACKS.
- 6. SEPARATOR GATES IN THE DOORWAY MUST BE PREVENTED FROM SHIFTING INTO A DOOR OPENING BY THE APPLICATION OF THE STOP PIECES, PIECES MARKED ②. IN CARS EQUIPPED WITH STAGGERED DOORS, STOP PIECES MAY BE REQUIRED ON UP TO FOUR SEPARATOR GATES.
- 7. SEPARATOR GATES MAY BE FORMED FROM 3/8" OR THICKER PLYWOOD IN LIEU OF DIMENSIONAL LUMBER, IF DESIRED, FOR ONE OR TWO-LAYER LOADS; PLYWOOD SEPARATOR GATES FOR A 3-LAYER LOAD ARE NOT ECONOMICALLY FEASIBLE. SEE THE "ALTERNATIVE SEPARATOR GATE" DETAIL ON PAGE 122 FOR CONSTRUCTION GUIDANCE.
- 8. IF THE CAR BEING LOADED IS EQUIPPED WITH AT LEAST TWELVE (12)
 DOORWAY MEMBERS, AN ADDITIONAL FOUR PALLET UNITS CAN BE LOADED
 IN THE DOORWAY AREA.
- 9. THE DEPICTED LOAD CAN BE REDUCED TO SUIT THE QUANTITY TO BE SHIPPED. A LOAD MAY BE REDUCED BY MULTIPLES OF TWO (2) PALLET UNITS BY OMITTING LATERALLY ADJACENT UNITS FROM THE TOP ONE OR TWO LAYERS OF ONE OR MORE LOAD UNITS, OR BY MULTIPLES OF SIX (6) PALLET UNITS BY OMITTING ONE OR MORE ENTIRE LOAD UNITS. TO REDUCE A LOAD BY ONE (1) PALLET UNIT, REFER TO THE LCL PROCEDURES ON PAGES 90 AND 91 FOR GUIDANCE.
- FOR SHIPMENT OF ONE OR MORE LEFTOVER CONTAINERS, SEE THE "PROCEDURES FOR SHIPMENT OF LEFTOVER CONTAINERS" ON PAGE 119 FOR GUIDANCE.

LUMBER	LINEAR FEET	BOARD FEET
1" X 4"	250	84
1" X 6"	261	131
2" X 4"	387	258
2" X 6"	19	19
NAILS	NO. REQD	POUNDS
6d (2")	336	2
10d (3")	420	6-1/2

LOAD AS SHOWN

ITEM	QUANTITY	WEIGHT (APPROX)
	T UNIT 56	90,496 LBS 994 LBS
	TOTAL WEIGHT	91,490 LBS

ROUTED DUNNAGE METHOD UNIT (DECREASED HEIGHT)
56-UNIT LOAD IN A 50'-6' LONG BY 9'-0' WIDE BOX CAR EQUIPPED WITH MECHANICAL BRACING DEVICES



(SPECIAL NOTES CONTINUED)

- 10. THE DEPICTED LOAD CAN BE REDUCED TO SUIT THE QUANTITY TO BE SHIPPED.
 A 3-TIER LOAD CAN BE REDUCED BY A MULTIPLE OF SIX (6) PALLET UNITS,
 OR A 2-TIER LOAD CAN BE REDUCED BY A MULTIPLE OF FOUR (4) UNITS, OR
 A 1-TIER LOAD CAN BE REDUCED BY A MULTIPLE OF TWO (2) UNITS BY
 OMITTING ONE OR MORE LOAD UNITS FROM THE CENTER PORTION OF THE
 LOAD. OR, THE ENTIRE ONE OR TWO TOP TIERS CAN BE OMITTED. FOR
 OTHER METHODS OF REDUCING A LOAD, AND FOR TYPICAL LCL PROCEDURES,
 REFER TO PAGES 94 THRU 105 AND GENERAL NOTE "FF" ON PAGE 3 FOR
 GUIDANCE.
- IF PALLET UNITS WHICH DO NOT CONTAIN A FULL QUANTITY OF CONTAINERS ARE TO BE TRANSPORTED, REFER TO PAGE 117 AND/OR PAGES 118 AND 120 FOR SHIPPING GUIDANCE.
- 12. FOR SHIPMENT OF ONE OR MORE LEFTOVER CONTAINERS, SEE THE "PROCEDURES FOR SHIPMENT OF LEFTOVER CONTAINERS" ON PAGE 119 FOR GUIDANCE.

SPECIAL NOTES:


- A 50'-6" LONG BY 9'-2" WIDE WOO'D-LINED CUSHIONED BOX CAR EQUIPPED WITH LOAD DIVIDER BULKHEADS AND WITH 10'-0" WIDE DOOR OPENINGS IS SHOWN. CARS OF OTHER DIMENSIONS AND CARS HAVING NARROWER OR WIDER DOOR OPENINGS CAN BE USED. SEE GENERAL NOTES "AA" THRU "EE" ON PAGE 3.
- 2. THE PALLET UNIT SHOWN IN THE TYPICAL LOAD ON PAGE 84 IS THE RCUTED DUNNAGE METHOD UNIT (DECREASED HEIGHT). A MAXIMUM OF SEVENTY-TWO (72) OF THESE UNITS, FOR AN APPROXIMATE LADING WEIGHT OF 116,352 POUNDS CAN BE PLACED IN A 60'-8" LONG CAR, OR A MAXIMUM OF FORTY-EIGHT (48) UNITS CAN BE LOADED IN A 40'-6" CAR FOR AN APPROXIMATE LADING WEIGHT OF 77,568 POUNDS, WHEN USING THE DEPICTED PROCEDURES. IF CARS 9'-4" OR WIDER ARE AVAILABLE, THE CROSSWISE LOADING PATTERN SHOWN ON PAGE 80 MAY BE EMPLOYED. THEN, NINETY-SIX (96) PALLET UNITS FOR AN APPROXIMATE LADING WEIGHT OF 155,136 POUNDS CAN BE PLACED IN A 60'-8" LONG CAR, SEVENTY-EIGHT (78) UNITS CAN BE LOADED IN A 50'-6" LONG CAR, FOR AN APPROXIMATE LADING WEIGHT OF 126,048 POUNDS, AND SIXTY (60) UNITS CAN BE LOADED IN A 40'-6" LONG CAR FOR AN APPROXIMATE LADING WEIGHT OF 126,048 POUNDS, AND SIXTY (60) UNITS CAN BE LOADED IN A 40'-6" LONG CAR FOR AN APPROXIMATE LADING WEIGHT OF 96,960 POUNDS.
- 3. IF THE "ALTERNATIVE DOORWAY PROTECTION F" PROCEDURES AS SHOWN ON PAGE 128 ARE USED IN LIEU OF THE WOODEN DOOR GATE TYPE PROTECTION, PIECE MARKED (3), NAILED FLOORLINE BLOCKIN'3 MUST BE USED IN LIEU OF THE LOWER ANTI-SWAY BRACE IN THE DOORWAY AREA. NAILED BLOCKING IS REQUIRED FOR ALL PALLET STACKS WHICH ARE COMPLETELY WITHIN THE DOORWAY AREA OR WHICH DXTEND INTO THE DOORWAY AREA BY ONE-HALF OR MORE OF THE STACK WIDTH ON EITHER SIDE OF THE CAR.
- 4. TOP-OF-LOAD ANTI-SWAY BRACES, SHOWN AS PIECES MARKED ② IN THE LOAD ON PAGE 84, MUST BE INSTALLED IN EACH END OF THE CAR AND WIRE TIED TO STRAPPING BOARDS WITH NO. 14 GAGE WIRE AS TYPICALLY SHOWN BY THE "TIE WIRE APPLICATION B" DETAIL ON PAGE 122. THREE (3) BRACES ARE REQUIRED IN EACH END OF A LOAD REGARDLESS OF THE CAR LENGTH.
- 5. TO FACILITATE POSITIONING OF THE PALLET UNITS AS LOADING PROGRESSES, POSITION PALLET UNIT STACKS AGAINST THE 'END WALL, THEN POSITION A SEPARATOR GATE SHOWN AS PIECE MARKED ③, SO THE 1" X 4" TIE PIECES ARE LOCATED UNDER THE "OVERHANG" OF THE BOTTOM AND TOP PALLET UNITS. REPEAT THIS PROCEDURE FOR THE REMAINING STACKS.
- 6. SEPARATOR GATES IN THE DOORWAY MUST BE PREVENTED FROM SHIFTING INTO A DOOR OPENING BY THE APPLICATION OF THE STOP PIECES, PIECES MARKED (4). IN CARS EQUIPPED WITH STAGGERED DOORS, STOP PIECES MAY BE REQUIRED ON UP TO FOUR SEPARATOR GATES.
- SEPARATOR GATES MAY BE FORMED FROM 3/8" OR THICKER PLYWOOD IN LIEU OF DIMENSIONAL LUMBER, IF DESIRED. SEE THE "ALTERNATIVE SEPARATOR GATE" DETAIL ON PAGE 122 FOR CONSTRUCTION GUIDANCE.
- 8. DOORWAY PROTECTION IS REQUIRED FOR ALL PALLET UNIT STACKS WHICH ARE COMPLETELY WITHIN THE DOORWAY AREA OR WHICH EXTEND INTO THE DOORWAY AREA BY ONE-HALF OR MORE OF THE STACK WIDTH. THE WOODEN GATE TYPE OF DOORWAY PROTECTION, SHOWN AS PIECES MARKED (3) IN THE LOAD ON PAGE 84, IS APPLICABLE FOR BOX CARS EQUIPPED WITH CONVENTIONAL SLIDING DOORS AND NAILABLE DOOR POSTS. REFER TO PAGES 125 THRU 128 FOR ALTERNATIVE DOORWAY PROTECTION FOR CARS EQUIPPED WITH CONVENTIONAL SLIDING DOORS. IF THE CAR BEING LOADED IS EQUIPPED WITH PLUG TYPE DOORS, NAILED FLOOR-LINE BLOCKING AND LOAD BUNDLING STRAPS MUST BE USED. SEE THE "ALTERNATIVE DOORWAY PROTECTION F" DETAIL ON PAGE 128 FOR GUIDANCE IF THE PALLET UNITS ARE POSITIONED AS SHOWN ON PAGE 84. SEE THE "ALTERNATIVE DOORWAY PROTECTION E" DETAIL ON THAT PAGE IF THE PALLET UNITS ARE POSITIONED CROSSWISE.
- 9. A STRUT ASSEMBLY, SHOWN AS PIECE MARKED (3) IN THE LOAD ON PAGE 42, IS REQUIRED BETWEEN THE LOAD DIVIDER BULKHEADS WHEN THE LOAD IN EITHER END OF THE CAR IS 50,000 POUNDS OR MORE. FOR THE DEPICTED PALLET UNIT, A STRUT ASSEMBLY WILL BE REQUIRED IF THE LOAD IN ONE END OF THE CAR CONSISTS OF MORE THAN FIVE (5) LOAD UNITS, WHICH WOULD BE THE CASE IF AN OFFSET LOADING PATTERN IS EMPLOYED. THE STRUT ASSEMBLY WILL ALWAYS BE REQUIRED FOR FULL LOADS IN 60' OR LONGER CARS.


('CONTINUED AT LEFT)


LUMBER	LINEAR FEET	BOARD FEET
1" X 4"	211	71
1" X 6"	500	250
2" X 3"	36	18
2" X 4"	424	283
NAILS	NO. REQD	POUNDS
6d (2")	336	2
10d (3")	444	7
12d (3-1/4")	36	3/4


LOAD AS SHOWN


ROUTED DUNNAGE METHOD UNIT (DECREASED HEIGHT)
60-UNIT LOAD IN A 50'-6' LONG BY 9'-2" WIDE BOX CAR EQUI PPED WITH LOAD DIVIDERS












- A 9'-0" WIDE (INSIDE CLEARANCE) WOOD-LINED BOX CAR EQUIPPED WITH ADJUSTABLE AND/OR FIXED WALL MEMBERS IS SHOWN, CARS OF OTHER WIDTHS CAN BE USED. SEE GENERAL NOTE "D" ON PAGE 2.
- THE PALLET UNIT SHOWN IN THE TYPICAL LCL LOAD IS THE ROUTED DUNNAGE METHOD UNIT (BASIC HEIGHT). THE DEPICTED PROCEDURES ARE ALSO APPLICABLE FOR THE OTHER UNITS COVERED BY THIS DOCUMENT.
- 3. FIVE (5) UNITS ARE SHOWN AS A TYPICAL LOAD QUANTITY. THE NUMBER OF UNITS CAN BE ADJUSTED TO SUIT THE QUANTITY TO BE SHIPPED.
- 4. TOP-OF-LOAD ANTI-SWAY BRACES, SHOWN AS PIECES MARKED (3), MUST BE INSTALLED IN EACH END OF THE CAR AND WIRE TIED TO A UNIT WITH NO. 14 GAGE WIRE. THREE (3) BRACES ARE REQUIRED IN EACH END OF A LOAD REGARDLESS OF THE CAR LENGTH.
- SEPARATOR GATES MAY BE FORMED FROM 3/8" OR THICKER PLYWOOD IN LIEU OF DIMENSIONAL LUMBER, IF DESIRED. CONSTRUCT EACH GATE TO BE CAR WIDTH MINUS 1/2" IN LENGTH BY UNIT HEIGHT, OR UNIT LENGTH IN WIDTH BY UNIT HEIGHT, AS APPLICABLE.
- 6. THE SPACER ASSEMBLIES, SHOWN AS PIECES MARKED (?), MAY ALSO BE USED IN AN UPPER LAYER OF A LOAD FOR THE OMISSION OF A PALLET UNIT. IF THE ASSEMBLIES ARE USED NEXT TO THE CAR END WALL IN EITHER A FIRST LAYER OR IN AN UPPER LAYER, AND THE END WALL IS WOOD—LINED, CUT THE ADJACENT ENDS OFF THE SUPPORT PIECES FLUSH WITH THE LATERAL PIECE. EACH ASSEMBLY CAN THEN BE SUPPORTED BY NAILING THE LATERAL PIECE TO THE CAR END WALL W/6-10d NAILS. IF THE END WALL IS NON-NAILABLE, CROSS MEMBERS MUST BE INSTALLED AT THE END OF THE LOAD TO SUPPORT THE SPACER ASSEMBLIES.


- (1) WALL MEMBER, ADJUSTABLE OR FIXED. MEMBERS MUST BE LOCATED AT THE SPECIFIED HEIGHTS ABOVE THE CAR FLOOR TO PROVIDE PROPER ALIGNMENT OF CROSS MEMBERS MARKED (3).
- (2) ANTI-SWAY BRACE (2 REQD). SEE THE "ANTI-SWAY BRACE A" DETAIL ON PAGE 18. INSTALL BETWEEN LATERALLY ADJACENT ROWS OF PALLET UNITS. SEE GENERAL NOTE "M" ON PAGE 2.
- 3 TOP-OF-LOAD ANTI-SWAY BRACE (2 REQD). SEE THE "TOP-OF-LOAD ANTI-SWAY BRACE A" DETAIL ON PAGE 19 FOR THE ALTERNATED CONTAINERS UNIT OR THE "TOP-OF-LOAD ANTI-SWAY BRACE B" DETAIL ON PAGE 46 FOR THE FLAT OR ROUTED DUNNAGE METHOD LOETS. WHEE TIE TO PALLET UNITS AS SHOWN BY THE APPLICABLE TIE WIRE APPLICATION DETAIL ON PAGE 122.
- 4 SEPARATOR GATE FOR 1-HIGH AND 2-WIDE (2 REQD). SEE THE APPLICABLE SEPARATOR GATE DETAIL FOR TWO UNITS WIDE ON PAGE 17, 31, 45, 59, 73, OR 87. POSITION WITH THE 1" X 4" HORIZONTAL PIECES AGAINST THE AIREADY-LOADED UNITS.
- (5) CROSS MEMBER (5 REQD). SEE GENERAL NOTE "W" ON PAGE 3.
- 6 SEPARATOR GATE FOR 1-HIGH AND 1-WIDE (2 REQD, 1 RIGHT HAND AND 1 LEFT HAND). SEE THE APPLICABLE SEPARATOR GATE DETAIL FOR ONE UNIT WIDE ON PAGE 17, 31, 45, 59, 73, OR 87. AS APPLICABLE, POSITION WITH THE 1" X 4" HORIZONTAL PIECES AGAINST THE ALREADY-LOADED UNITS.
- SPACER ASSEMBLY (2 REQD). SEE THE DETAIL ON PAGE 91 AND SPECIAL NOTE 6 AT LEFT. WIRE TIE TO CROSS MEMBER W/2 WRAPS OF NO. 14 GAGE WIRE AT EACH CORNER.

TYPICAL LCL (5-UNIT LOAD) IN A BOX CAR EQUIPPED WITH MECHANICAL BRACING DEVICES HAVING ADJUSTABLE OR FIXED WALL MEMBERS



SPACER ASSEMBLY

TYPICAL LCL (5-UNIT LOAD) IN A BOX CAR EQUIPPED WITH MECHANICAL BRACING DEVICES HAVING ADJUSTABLE OR FIXED WALL MEMBERS



ONLY THE CENTER PORTION OF A 9'-4" WIDE CONVENTIONAL TYPE BOX CAR
IS SHOWN TO PORTRAY THE STRUTTED GATE METHOD OF PARTIAL-LAYER BRACING.
WIDER CARS CAN ALSO BE USED.


ISOMETRIC VIEW

- THE PALLET UNIT SHOWN IS THE ROUTED DUNNAGE METHOD UNIT (BASIC HEIGHT).
 THE DEPICTED PROCEDURES ARE ALSO ADAPTABLE FOR THE OTHER UNITS COVERED
 BY THIS DOCUMENT.
- 3. THE PROCEDURES FOR THE ADJUSTMENT OF A LOAD QUANTITY BY THE OMISSION OF THE TOP LAYER FROM A 2-HIGH LOAD ARE SHOWN AS TYPICAL. THE PRINCIPLES MAY ALSO BE APPLIED FOR THE OMISSION OF THE TOP ONE OR TWO LAYERS FROM A 3-HIGH LOAD.
- 4. ONLY THE BLOCKING AND BRACING PIECES WHICH ARE NECESSARY TO PERMIT THE OMISSION OF THE UNITS FROM THE TOP LAYER ARE SHOWN.
- 5. THE CENTER GATE "U" USED IS ONLY APPLICABLE FOR THE ROUTED DUNNAGE METHOD UNIT DEPICTED. THE PROPER CENTER GATE TO BE USED WILL DEPEND UPON THE UNIT BEING SHIPPED. THE QUANTITY REQUIRED FOR DUNNAGE PIECES, SUCH AS THE NUMBER OF STRUTS OR THE NUMBER OF STRUTS OR THE NUMBER OF STRUT BRACING PIECES, WILL ALSO VARY DEPENDENT UPON THE UNIT BEING LOADED.

KEY NUMBERS

- CENTER GATE FOR 1-HIGH (2 REQD). SEE THE "CENTER GATE U" DETAIL ON PAGE 75. SEE GENERAL NOTE "M" ON PAGE 2 AND SPECIAL NOTE 5
- CENTER GATE FOR 2-HIGH (1 REQD). SEE THE "CENTER GATE U" DETAIL ON PAGE 75.
- 3 STRUT, 4" X 4" BY CUT TO FIT (AS REQD). POSITION BETWEEN THE CENTER GATES, PIECES MARKED (1) AND (2), IN THE FIRST LAYER AND TOENAIL W/2-16d NAILS AT EACH END. SEE GENERAL NOTES "L", "S", AND "T" ON PAGE 2.
- (4) GATE SUPPORT PIECE, 2" X 4" BY A LENGTH TO SUIT (1 REQD). NAIL TO THE VERTICAL PIECES OF THE CENTER GATE USED IN THE SECOND LAYER W/3-10d NAILS AT EACH JOINT.
- (5) STRUT, 4" X 4" BY CUT TO FIT (AS REQD). POSITION BETWEEN THE CENTER GATES, PIECES MARKED (1) AND (2), IN THE SECOND LAYER AND TOENAIL W/2-16d NAILS AT EACH END.
- 6 VERTICAL STRUT BRACING, 2" X 4" BY CUT TO EXTEND 3" ABOVE THE TOP STRUT (AS REQD). NAIL TO THE STRUTS W/3-10d NAILS AT EACH JOINT.
- (AS REQD). NAIL TO THE STRUTS W/3-10d NAILS AT EACH JOINT.


CROSSWISE-POSITIONED PALLET UNITS
TYPICAL LCL LOAD USING STRUTTED GATE METHOD OF PARTIAL-LAYER BRACING



- ONLY THE CENTER PORTION OF A 9'-2" WIDE CONVENTIONAL TYPE BOX CAR IS SHOWN TO PORTRAY THE STRUTTED GATE METHOD OF PARTIAL-LAYER BRACING, CARS OF OTHER WIDTHS CAN ALSO BE USED.
- THE PALLET UNIT SHOWN IS THE ALTERNATED CONTAINERS UNIT (BASIC HEIGHT).
 THE DEPICTED PROCEDURES ARE ALSO ADAPTABLE FOR THE OTHER UNITS COVERED BY THIS DOCUMENT.
- 3. THE PROCEDURES FOR THE ADJUSTMENT OF A LOAD QUANTITY BY THE OMISSION OF THE TOP LAYER FROM TWO (2) LOAD UNITS ARE SHOWN AS TYPICAL. THE PRINCIPLES MAY ALSO BE APPLIED FOR THE OMISSION OF THE TOP LAYER FROM JUST ONE (1) LOAD UNIT.
- 4. ONLY THE BLOCKING AND BRACING PIECES WHICH ARE NECESSARY TO PERMIT THE OMISSION OF THE UNITS FROM THE TOP LAYER ARE SHOWN.
- 5. THE CENTER GATE "C" USED IS ONLY APPLICABLE FOR THE ALTERNATED CONTAINERS UNIT DEPICTED. THE PROPER CENTER GATE TO BE USED WILL DEPEND UPON THE UNIT BEING SHIPPED. THE QUANTITY REQUIRED FOR DUNNAGE PIECES, SUCH AS THE NUMBER OF STRUTS OR THE NUMBER OF STRUTS OR PIECES, WILL ALSO VARY DEPENDENT UPON THE UNIT BEING LOADED.
- 6. TO PROTECT THE LADING FROM BEING PUNCTURED WHEN A SET OF VERTICAL STRUT BRACING IS INSTALLED ABOVE THE LOWER LAYER OF A LOAD, A SUITABLE LENGTH PAD OF 2" X 4" MATERIAL, SHOWN AS PIECE MARKED (9), MUST BE POSITIONED UNDER AND SECURED TO EACH APPLICABLE VERTICAL STRUT BRACING PIECE.

- (1) CENTER GATE FOR 2-HIGH (1 REQD). SEE THE "CENTER GATE C" DETAIL ON PAGE 18. SEE SPECIAL NOTE 5 AT LEFT.
- CENTER GATE FOR 3-HIGH (1 REQD). SEE THE "CENTER GATE C" DETAIL ON PAGE 18.
- 3 STRUT, 4" X 4" BY CUT TO FIT (16 REQD). TOENAIL TO PIECES MARKED (1) AND (2) W/2-16d NAILS AT EACH END. SEE GENERAL NOTES "L", "S", AND "T" ON PAGE 2.
- CENTER GATE FOR 1-HIGH (1 REQD). SEE THE "CENTER GATE C" DETAIL ON PAGE 18.
- SUPPORT PIECE, 2" X 4" BY CAR WIDTH MINUS 1/2" IN LENGTH (1 REQD).
 NAIL TO THE VERTICAL PIECES ON CENTER GATE "C", SHOWN AS PIECE
 MARKED .
- 6 STRUT, 4" X 4" BY CUT TO FIT (8 REQD). TOENAIL TO PIECES MARKED 2 AND 3W/2-16d NAILS AT EACH END.
- 7 VERTICAL STRUT BRACING, 2" X 4" BY CUT TO EXTEND 3" ABOVE THE TOP STRUT (4 REQD). NAIL TO THE STRUTS MARKED ③ AND ⑥ W/3-10d NAILS AT EACH JOINT.
- B VERTICAL STRUT BRACING, 2" X 4" BY CUT TO EXTEND 3" ABOVE THE TOP STRUT (8 REQD), NAIL TO THE STRUTS MARKED ® W/3-10d NAILS AT EACH JOINT. TOENAIL TO THE STRUT BRACING PAD, PIECE MARKED ®, W/1-10d NAIL AT EACH JOINT. SEE SPECIAL NOTE 6 AT LEFT.
- STRUT BRACING PAD, 2" X 4" BY LENGTH TO SUIT (2 REQD). POSITION UNDER THE VERTICAL STRUT BRACING AS SHOWN.
- (10) HORIZONTAL STRUT BRACING, 2" X 4" BY A LENGTH TO SUIT (10 REQD). NAIL TO THE STRUTS W/3-10d NAILS AT EACH JOINT.

LENGTHWISE-POSITIONED PALLET UNITS
TYPICAL LCL LOAD USING STRUTTED GATE METHOD OF PARTIAL-LAYER BRACING



TYPICAL COMBINATION LOAD PATTERN PLAN VIEW

A 10 LONG PLUS 2 WIDE LOAD IS SHOWN.

SPECIAL NOTES:

- 1. A 50'-6" LONG BY 9'-4" WIDE CONVENTIONAL TYPE BOX CAR IS SHOWN. WIDER CARS AND CARS OF OTHER LENGTHS CAN BE USED.
- THE PROCEDURES ON THIS PAGE AND ON PAGE 95 ARE PRESENTED TO PROVIDE A METHOD OF OBTAINING A LOAD QUANTITY WHICH MAY NOT BE READILY ATTAINABLE BY ANY OF THE OTHER METHODS OF ADJUSTING A LOAD QUANTITY SPECIFIED HEREIN, INCLUDING THE DEPICTED LCL PROCEDURES.
- 3. THE BLOCKING AND BRACING FOR THE COMBINATION LOAD, OTHER THAN SEPARATOR GATE "N", HAS NOT BEEN SHOWN. REFER TO THE APPLICABLE LOAD PAGES FOR BLOCKING AND BRACING SPECIFICATIONS. A SEPARATOR GATE "N" MUST BE INSTALLED AT EVERY LOCATION WHERE THE DIRECTION OF THE UNITS CHANGES. THE GATE MUST BE POSITIONED SO THAT THE VERTICAL PIECES ARE AGAINST THE CROSSWISE UNITS OF THE LOAD.
- 4. A CHART FOR EACH OF THE THREE TYPES OF PALLET UNITS IS SHOWN ON THIS PAGE. THE VARIOUS QUANTITIES (PER LAYER) WHICH CAN BE ATTAINED BY THE COMBINATION LOAD METHOD, AND THE PATTERNS REQUIRED TO PROVIDE THESE QUANTITIES, ARE SPECIFIED. FOR COMPARISON PURPOSES, THE OTHER TYPE LOADS WHICH CAN BE USED TO ATTAIN A LIKE QUANTITY, OR A QUANTITY WITHIN THE RANGE OF THE COMBINATION LOAD METHOD, AS WELL AS THE APPROXIMATE LENGTH OF THE STRUTS, ARE ALSO INCLUDED IN THE CHARTS.

FLAT DUNNAGE METHOD UNIT				
CAR LENGTH	UNITS PER LAYER	LOAD PATTERN	APPROX STRUT LENGTH	
40'-6"	20	CROSSWISE LOAD ON PAGE 38 OR 52	50"	
CAR	20	9LONG AT 43" PLUS 1 WIDE AT 55-3/8"	36"	
	18*	5 LONG AT 43" PLUS 4 WIDE AT 5543/8"	40"	
	18*	4 LONG AT 43" PLUS 5 WIDE AT 55-3/8"	28*	
	16	LENGTHWISE LOAD ON PAGE 36 OR 50.	37"	
50'-6" .	. 26	CROSSWISE LOAD ON PAGE 38 OR 52	41"	
CAR	26	12 LONG AT 43" PLUS 1 WIDE AT 55-3/8"	27"	
	24	9 LONG AT 43" PLUS 3 WIDE AT 55-3/8"	43"	
	24	8 LONG AT 43" PLUS 4 WIDE AT 55-3/8"	31"	
	23	COMBINATION LOAD ON PAGE 34 OR 48	46" & 41"	
	22	4 LONG AT 43" PLUS 7 WIDE AT 55-3/8"	37"	
	22	3 LONG AT 43" PLUS 8 WIDE AT 55-3/8"	25"	
	20	LENGTHWISE LOAD ON PAGE 36 OR 50	43"	
60'-8"	32	CROSSWISE LOAD ON PAGE 38 OR 52	34"	
CAR	30	12 LONG AT 43" PLUS 3 WIDE AT 55-3/8"	36"	
	30	11 LONG AT 43" PLUS 4 WIDE AT 55-3/8"	24"	
	28*	7 LONG AT 43" PLUS 7 WIDE AT 55-3/8"	30"	
	26	3 LONG AT 43" PLUS 10 WIDE AT 55-3/8"	36"	
	24	LENGTHWISE LOAD ON PAGE 36 OR 50	57"	

"THE COMBINATION LOAD ON PAGE 34 OR 48 MAY BE USED, IF DESIRED, STRUTS FOR THE COMBINATION LOAD WILL BE APPROXIMATELY 37" AND 50", AND 57" AND 34" IN 40' AND 60' CARS, RESPECTIVELY.


		ALTERNATED CONTAINERS UNIT	
CAR LENGTH	UNITS PER LAYER	LOAD PATTERN	APPROX STRUT LENGTH
40'-6" CAR	22 20 20 19 18 18	CROSSWISE LOAD ON PAGE 10 OR 24 8 LONG AT 40-3/4" PLUS 2 WIDE AT 55-3/8" 7 LONG AT 40-3/4" PLUS 3 WIDE AT 55-3/8" COMBINATION LOAD ON PAGE 6 OR 20 5 LONG AT 40-3/4" PLUS 4 WIDE AT 55-3/8" 4 LONG AT 40-3/4" PLUS 5 WIDE AT 55-3/4" LENGTHWISE LOAD ON PAGE 8 OR 22	31" 40" 25" 37"& 31" 51" 37" 37"
50'-6" CAR	28 26 26 24 22 22	CROSSWISE LOAD ON PAGE 10 OR 24 11 LONG AT 40-3/4" PLUS 2 WIDE AT 55-3/8" 10 LONG AT 40-3/4" PLUS 3 WIDE AT 55-3/8" 7 LONG AT 40-3/4" PLUS 5 WIDE AT 55-3/8" 3 LONG AT 40-3/4" PLUS 8 WIDE AT 55-3/8" LENGTHWISE LOAD ON PAGE 8 OR 22	29" 38" 23" 34" 31" 46"
60'-8" CAR	34 32 30 29 28 28 26 26 26	CROSSWISE LOAD ON PAGE 10 OR 24 14 LONG AT 40-3/4" PLUS 2 WIDE AT 55-3/8" 10 LONG AT 40 3/4" PLUS 5 WIDE AT 55-3/8" COMBINATION LOAD ON PAGE 6 OR 20 7 LONG AT 40-3/4" PLUS 7 WIDE AT 55-3/8" 6 LONG AT 40-3/4" PLUS 8 WIDE AT 55-3/8" 3 LONG AT 40-3/4" PLUS 10 WIDE AT 55-3/8" 2 LONG AT 40-3/4" PLUS 11 WIDE AT 55-3/8" LENGTHWISE LOAD ON PAGE 8 OR 22	29" 37" 34" 57" & 29" 46" 31" 43" 28" 57"

*THE COMBINATION LOAD ON PAGE 6 OR 20, MAY BE USED, IF DESIRED.
STRUTS FOR THE COMBINATION LOAD WILL BE APPROXIMATELY 46" AND 29" LONG.

RC	OUTED DUNN	AGE METHOD UNIT	
CAR LENGTH	UNITS PER	LOAD PATTERN	APPROX STRUT LENGTH
40'-6"	20	CROSSWISE LOAD ON PAGE 66 OR 80	60" 45"
CAR	20 20	9 LONG AT 42" PLUS 1 WIDE AT 55-3/8" 8 LONG AT 42" PLUS 2 WIDE AT 55-3/8"	45" 30"
	18*	5 LONG AT 42" PLUS 4 WIDE AT 55-3/8"	45"
	18*	4 LONG AT 42" PLUS 5 WIDE AT 55-3/8"	32"
	16	LENGTHWISE LOAD ON PAGE 64 OR 78	37"
50'-6"	26	CROSSWISE LOAD ON PAGE 66 OR 80	54"
CAR	26	12 LONG AT 42" PLUS 1 WIDE AT 55-3/8"	
]	26	11 LONG AT 42" PLUS 2 WIDE AT 55-3/8"	24"
	24	8 LONG AT 42" PLUS 4 WIDE AT 55-3/8"	39"
	24	7 LONG AT 42" PLUS 5 WIDE AT 55-3/8"	24"
	22	4 LONG AT 42" PLUS 7 WIDE AT 55-3/8"	39"
	20	LENGTHWISE LOAD ON PAGE 64 OR 78	47"
60'-8"	32	CROSSWISE LOAD ON PAGE 66 OR 80	50"
CAR	30	12 LONG AT 42" PLUS 3 WIDE AT 55-3/8"	48"
	30	11 LONG AT 42" PLUS 4 WIDE AT 55-3/8"	35"
	28*	7 LONG AT 42" PLUS 7 WIDE AT 55-3/8"	37"
	28*	6 LONG AT 42" PLUS 8 WIDE AT 55-3/8"	24"
1	26	3 LONG AT 42" PLUS 10 WIDE AT 55-3/8"	39"
1	26	2 LONG AT 42" PLUS 11 WIDE AT 55-3/8"	25"
1	24	LENGTHWISE LOAD ON PAGE 64 OR 78	57*

*THE COMBINATION LOAD ON PAGE 62 OR 76 MAY BE USED, IF DESIRED. STRUTS FOR THE COMBINATION LOAD WILL BE APPROXI-MATELY 37"- AND 60" LONG IN A 40"-6" LONG CAR, AND 57" AND 50" LONG IN A 60"-8" LONG CAR.

TYPICAL COMBINATION LOAD IN A 50'-6" LONG BY 9'-4" WIDE CONVENTIONAL BOX CAR



SEPARATOR GATE N


THIS VIEW DEPICTS A SEPARATOR GATE FOR A 2-HIGH LOAD, APPLICABLE TO ANY OF THE UNITS COVERED BY THIS DOCUMENT. SEE THE "END VIEW" BELOW FOR HEIGHT DIMENSIONS FOR THOSE UNITS WHICH CAN BE LOADED 3-HIGH.

HORIZONTAL PIECE, 1" X 6" BY CAR WIDTH MINUS 1/2" IN LENGTH (6 REQD). NAIL TO THE VERTICAL PIECES W/3-64 NAILS

AT EACH JOINT AND CLINCH .-

UNIT DIMENSIONS NUMBER 8 c D G н J 24-1/2" 44 -28* 54" 63-1/2" 8'-6' 8'-3 7'-2" 4-1/2" 24-1/2 44-19-37* 63-1/2 71-8 3-1/2 43 * 20" 40" 69 = 72" 3-1/2" 23 -20 * 43 " 68-1/2" 8'-11" 4-1/2" 24* 19" 40. 71-4-1/21 72" 4-1/2" 19" 29-1/2 57 67-1/2-9'-0" 7'-11"

PALLET UNIT IDENTIFICATION	SHOWN AS UNIT NUMBER
ALTERNATED CONTAINERS (BASIC HEIGHT)	1
ALTERNATED CONTAINERS (INCREASED HEIGHT)	2
FLAT DUNNAGE METHOD (BASIC HEIGHT)	3
FLAT DUNNAGE METHOD (DECREASED HEIGHT)	4
ROUTED DUNNAGE METHOD (BASIC HEIGHT)	5
ROUTED DUNNAGE METHOD (DECREASED HEIGHT)	6




END VIEW

THIS VIEW DEPICTS A SEPARATOR GATE FOR A 3-HIGH LOAD WHICH IS ONLY APPLICABLE FOR UNITS 1, 4, AND 6 AS IDENTIFIED AT THE LEFT.

TYPICAL COMBINATION LOAD IN A 50'-6" LONG BY 9'-4" WIDE CONVENTIONAL BOX CAR

PAGE 95


-VERTICAL PIECE, 1" X 6" BY DIMENSION "J" (6 REQD).



- A PARTIAL VIEW OF A 9'-2" WIDE CONVENTIONAL TYPE BOX CAR IS SHOWN. CARS OF OTHER WIDTHS CAN BE USED.
- THE PALLET UNIT SHOWN IS THE ALTERNATED CONTAINERS UNIT (INCREASED HEIGHT), THE DEPICTED PROCEDURES ARE ALSO APPLICABLE FOR THE OTHER UNITS COVERED BY THIS DOCUMENT.
- A UNIT OMITTED FROM THE TOP LAYER OF A 2-LAYER LOAD IS SHOWN AS TYPICAL. THE PROCEDURES ARE ALSO APPLICABLE FOR THE OMISSION OF A TOP-LAYER PALLET UNIT FROM A 3-LAYER LOAD.
- THE OMITTED-UNIT PROCEDURE SHOULD BE APPLIED NEAR THE CENTER OF THE CAR LENGTH, BUT NOT IN THE DOORWAY AREA. ALSO, THERE SHOULD BE AT LEAST ONE (1) LOAD UNIT BETWEEN THE OMITTED UNIT AND A CENTER GATE
- ONLY THE BLOCKING AND BRACING FOR THE OMITTED UNIT IS SHOWN; REFER TO THE APPLICABLE LOAD PAGE FOR THE BLOCKING AND BRACING REQUIRE-MENTS FOR THE BALANCE OF THE LOAD.
- 6. NOTE THAT THE TOP HORIZONTAL PIECE OF EACH SEPARATOR GATE WHICH IS A DJACENT TO THE OMITTED UNIT AREA MUST BE 1" X 2" MATERIAL IN LIEU OF 1" X 4" AND MAY NEED TO BE ADJUSTED IN HEIGHT SO AS TO PROVIDE CLEARANCE BETWEEN IT AND THE CONTAINERS ON THE UNIT BELOW AS TUBEL AS CLEARANCE BETWEEN IT AND THE LOAD BEARING GATE, PIECE MARKED (3).

KEY NUMBERS

- MODIFIED SEPARATOR GATE (2 REQD). SEE THE APPLICABLE SEPARATOR GATE DETAIL ON PAGE 17, 31, 45, 59, 73 OR 87 FOR POSITIONING OF THE VERTICAL PIECES. SEE SPECIAL NOTE 6 AT LEFT FOR GATE MODIFICATIONS. POSITION GATE SO THE HORIZONTAL PIECES ARE AWAY FROM THE OMITTED UNIT AREA.
- 2 SUPPORT PIECE, 2" X 6" X 55-3/8" (2 REQD), POSITION SO AS TO BE UNDER THE VERTICAL PIECES OF THE LOAD BEARING GATE, PIECE MARKED ③ (UNDER THE OUTWARD VERTICAL PIECES OF LOAD BEARING GATE "D").
- (3) LOAD BEARING GATE (2 REQD, 1 RIGHT HAND AND 1 LEFT HAND). SEE THE APPLICABLE DETAIL ON PAGE 99 OR 99. NAIL TO THE FILLER PIECE, PIECE MARKED (3), W/3-10d NAILS, TOENAIL TO THE SUPPORT PIECE, PIECE MARKED (2), W/2-10d NAILS AT EACH JOINT. CAUTION: USE CARE NOT TO TOENAIL INTO A CONTAINER.
- (4) ANTI-SWAY BEARING PIECE, 2" X 6" X 7'-0" (1 REQD).
- (1) FILLER PIECE, 2" X 6" X 54" (1 REQD). NAIL TO THE ANTI-SWAY BEARING PIECE, PIECE MARKED (4), W/5-10d NAILS.
- STRUT, 4" X 4" BY CUT TO FIT (REF: 51") (AS REQD). TOENAIL TO PIECES MARKED ③ W/2-16d NAILS AT EACH END.




- A PARTIAL VIEW OF A 9'-4" WIDE CONVENTIONAL TYPE BOX CAR IS SHOWN, WIDER CARS CAN BE USED.
- THE PALLET UNIT SHOWN IS THE ALTERNATED CONTAINERS UNIT (INCREASED HEIGHT). THE DEPICTED PROCEDURES ARE ALSO APPLICABLE FOR THE OTHER UNITS COVERED BY THIS DOCUMENT.
- A UNIT OMITTED FROM THE TOP LAYER OF A 2-LAYER LOAD IS SHOWN AS TYPIGAL. THE PROCEDURES ARE ALSO APPLICABLE FOR THE OMISSION OF A TOP-LAYER PALLET UNIT FROM A 3-LAYER LOAD.
- 4. THE OMITTED-UNIT PROCEDURES SHOULD BE APPLIED NEAR THE CENTER OF THE CAR LENGTH, BUT NOT IN THE DOORWAY AREA. ALSO, THERE SHOULD BE AT LEAST ONE (1) LOAD UNIT BETWEEN THE OMITTED UNIT AND A CENTER GATE.
- ONLY THE BLOCKING AND BRACING FOR THE OMITTED UNIT IS SHOWN, REFER TO THE APPLICABLE LOAD PAGE FOR THE BLOCKING AND BRACING REQUIREMENTS FOR THE BALANCE OF THE LOAD.

KEY NUMBERS

- 1) SUPPORT PIECE, 2" X 6" BY UNIT LENGTH (2 REQD). POSITION BENEATH THE OUTSIDE 2" X 6" VERTICAL PIECES OF THE LOAD BEARING GATE, PIECE MARKED 2.
- 2 LOAD BEARING GATE (2 REQD, 1 RIGHT HAND AND 1 LEFT HAND). SEL THE APPLICABLE DETAIL ON PAGE 100 OR 101. TOENAIL TO THE SUPPORT PIECE, PIECE MARKED (1) , W/2-10d NAILS AT EACH JOINT. CAUTION: USE CARE NOT TO TOENAIL INTO A CONTAINER.
- 3 STRUT, 4" X 4" BY CUT TO FIT (AS REQD). TOENAIL TO PIECES MARKED ② W/2-16d NAILS AT EACH END.


TYPICAL LCL-ONE PALLET UNIT OMITTED FROM THE TOP LAYER OF A CROSSWISE LOAD



THIS GATE IS FOR USE IN A LOAD OF ALTERNATED CONTAINERS UNITS 'BASIC HEIGHT), SEE SPECIAL NOTE 3 BELOW FOR NAILING GUIDANCE. CNE RIGHT HAND AND COME LEFT HAND GATE REQUIRED, A RIGHT HAND GATE IS SHOWN.

LOAD BEARING GATE B

THIS GATE IS FOR USE IN A LOAD OF FLAT DUNNAGE METHOD UNITS / BASIC HEIGHT), SEE SPECIAL NOTE 3
BELOW FOR NAILING GUIDANCE, ONE RIGHT HAND AND ONE LEFT HAND GATE REQUIRED. A RIGHT HAND GATE IS SHOWN.




SPECIAL NOTES:

- THE GATES SHOWN ON THIS PAGE ARE FOR USE WITH BASIC-HEIGHT UNITS IN THE LCL PROCEDURES SHOWN ON PAGE 96. THOSE PROCEDURES DEPICT THE OMISSION OF A PALLET UNIT FROM A LOAD OF LENGTHWISE-POSITIONED PALLET UNITS.
- THE REFERENCE DIMENSIONS GIVEN FOR THE CUT-TO-FIT PIECES ARE BASED ON AN INSIDE CAR WIDTH OF 9'-2". THESE DIMENSI WILL HAVE TO BE ADJUSTED WHEN LOADING CARS OF OTHER THESE DIMENSIONS
- THE NAILING OF THE VARIOUS PARTS OF THE GATES WILL BE AS FOLLOWS: NAIL THE 2" X 4" OR 2" X 6" HORIZONTAL PIECE (5) TO THE 2" X 6" VERTICAL PIECES W/3-10d NAILS AT EACH JOINT, NAIL THE DOUBLED 2" X 4" OR 2" X 3" GATE HOLD DOWN PIECES TO A 2" X 4" OR 2" X 6" HORIZONTAL PIECE, AS APPLICABLE, W/5-10d NAILS EACH LAYER, NAIL THE 2" X 2" STRUT LEDGERS TO THE VERTICAL PIECES W/2-10d NAILS AT EACH END,

LOAD BEARING GATE C


THIS GATE IF FOR USE IN A LOAD OF ROUTED DUNNAGE METHOD UNITS (BASIC HEIGHT). SEE SPECIAL NOTE 3 AT RIGHT FOR NAILING GUIDANCE. ONE RIGHT HAND AND CNE LEFT HAND GATE REQUIRED. A RIGHT HAND GATE IS

LOAD BEARING GATES FOR USE WITH BASIC-HEIGHT UNITS IN A LENGTHWISE LOAD



LOAD BEARING GATE D
THIS GATE IS FOR USE IN A LOAD OF ALTERNATED
CONTAINERS UNITS (INCREASED HEIGHT). SEE
SPECIAL NOTE 3 BELOW FOR NAILING GUIDANCE.
ONE RIGHT HAND AND ONE LEFT HAND GATE
REQUIRED. A RIGHT HAND GATE IS SHOWN.

THIS GATE IS FOR USE IN A LOAD OF FLAT DUNNAGE METHOD UNITS (DECREASED HEIGHT). SEE SPECIAL NOTE 3 BELOW FOR NAILING GUIDANCE. ONE RIGHT HAND AND ONE LEFT HAND GATE REQUIRED. A RIGHT HAND GATE IS SHOWN.




LOAD BEARING GATE F
THIS GATE IS FOR USE IN A LOAD OF ROUTED DUNNAGE
METHOD UNITS (DECREASED HEIGHT). SEE SPECIAL NOTE 3
AT RIGHT FOR NAILING GUIDANCE. ONE RIGHT HAND AND
ONE LEFT HAND GATE REQUIRED. A RIGHT HAND GATE IS
SHOWN.

SPECIAL NOTES:

- THE GATES SHOWN ON THIS PAGE ARE FOR USE WITH INCREASED AND/ OR DECREASED-HEIGHT UNITS IN THE LCL PROCEDURES SHOWN ON PAGE 96. THOSE PROCEDURES DEPICT THE OMISSION OF A PALLET UNIT FROM A LOAD OF LENGTHMISE-POSITIONED PALLET UNITS.
- THE REFERENCE DIMENSIONS GIVEN FOR THE CUT-TO-FIT PIECES ARE BASED ON AN INSIDE CAR WIDTH OF 9'-2". THESE DIMENSIONS WILL HAVE TO BE ADJUSTED WHEN LOADING CARS OF OTHER WIDTHS.
- 3. THE NAILING OF THE VARIOUS PARTS OF THE GATES WILL BE AS FOLLOWS: NAIL THE 2" X 4" OR 2" X 6" HORIZONTAL PIECE (5) TO THE VERTICAL PIECES W/3-100 NAILS AT EACH JOINT. NAIL THE DOUBLED 2" X 3" OR 2" X 4" GATE HOLD DOWN PIECES TO A 2" X 4" OR 2" X 6" HORIZONTAL PIECE, AS APPLICABLE, W/5-100 NAILS EACH LAYER. NAIL THE 2" X 2" STRUT LEDGERS TO THE VERTICAL PIECES W/2-100 NAILS AT EACH JOINT.

LOAD BEARING GATES FOR USE WITH INCREASED/DECREASED-HEIGHT UNITS IN A LENGTHWISE LOAD




LOAD BEARING GATE G

THIS GATE IS FOR USE IN A LOAD OF ALTERNATED CONTAINERS UNITS (INCREASED HEIGHT). SEE SPECIAL NOTE 3 BELOW FOR NAILING GUIDANCE, ONE RIGHT HAND AND ONE LEFT HAND GATE REQUIRED. A RIGHT HAND GATE IS SHOWN.

LOAD BEARING GATE H

THIS GATE IS FOR USE IN A LOAD OF FLAT DUNNAGE METHOD UNITS (DECREASED HEIGHT). SEE SPECIAL NOTE 3 BELOW FOR NAILING GUIDANCE. ONE RIGHT HAND AND ONE LEFT HAND GATE REQUIRED. A RIGHT HAND GATE IS SHOWN.




SPECIAL NOTES:

- THE GATES ON THIS PAGE ARE FOR USE WITH BASIC-HEIGHT UNITS IN THE LCL PROCEDURES SHOWN ON PAGE 97. THOSE PROCEDURES DEPICT THE OMISSION OF A PALLET UNIT FROM A LOAD OF CROSSWISE-POSITIONED PALLET UNITS.
- THE REFERENCE DIMENSION GIVEN FOR THE CUT-TO-FIT MECES IS BASED ON AN INSIDE CAR WIDTH OF 9'-4". THIS DIMENSION WILL HAVE TO BE INCREASED WHEN LOADING WIDER CARS.
- 3. THE NAILING OF THE VARIOUS PARTS OF THE GATES WILL BE AS FOLLOWS:
 NAIL THE 2" X 3", 2" X 4", OR 2" X 6" HORIZONTAL PIECE (S) TO THE
 VERTICAL PIECES W/3-104 NAILS AT EACH JOINT. NAIL THE DOUBLED 2" X 3"
 GATE HOLD DOWN PIECES TO A HORIZONTAL PIECE W/3-104 NAILS EACH
 LAYER, NAIL THE 2" X 2" STRUT LEDGERS TO THE VERTICAL PIECES W/2-104
 NAILS AT EACH JOINT.

LOAD BEARING GATE J
THIS GATE IS FOR USE IN A LOAD OF ROUTED DUNNAGE METHOD UNITS (DECREASED HEIGHT). SEE SPECIAL NOTE 3 AT RIGHT FOR NAILING GUIDANCE. ONE RIGHT HAND AND ONE LEFT HAND GATE REQUIRED. A RIGHT HAND GATE IS SHOWN.

LOAD BEARING GATES FOR USE WITH BASIC-HEIGHT UNITS IN A CROSSWISE LOAD




LOAD BEARING GATE K

THIS GATE IS FOR USE IN A LOAD OF ALTERNATED CONTAINERS UNITS (BASIC HEIGHT). SEE SPECIAL NOTE 3 BELOW FOR NAILING GUIDANCE. ONE RIGHT HAND AND ONE LEFT HAND GATE REQUIRED. A RIGHT HAND GATE IS SHOWN.

LOAD BEARING GATE L

THIS GATE IS FOR USE IN A LOAD OF FLAT DUNNAGE METHOD UNITS (DECREASED HEIGHT), SEE SPECIAL NOTE 3 BELOW FOR NAILING GUIDANCE, ONE RIGHT HAND AND ONE LEFT HAND GATE REQUIRED, A RIGHT HAND GATE IS SHOWN.




LOAD BEARING GATE M THIS GATE IS FOR USE IN A LOAD OF ROUTED DUNNAGE METHOD UNITS (DECURASE HEIGHT). SEE SPECIAL NOTE 3 AT RIGHT FOR NAILING GUIDANCE. ONE RIGHT HAND AND ONE LEFT HAND GATE REQUIRED. A RIGHT HAND GATE IS SHOWN.

SPECIAL NOTES:

- THE GATES ON THIS PAGE ARE FOR USE WITH INCREASED AND/OR DECREASED-HEIGHT UNITS IN THE LCL PROCEDURES SHOWN ON PAGE 97. THOSE PROCEDURES DEPICT THE OMISSION OF A PALLET UNIT. FROM A LOAD OF CROSS-POSITIONED PALLET UNITS.
- THE REFERENCE DIMENSION GIVEN FOR THE CUT-TO-FIT PIECES IS BASED ON AN INSIDE CAR WIDTH OF 9'-4". THIS DIMENSION WILL HAVE TO BE INCREASED WHEN LOADING WIDER CARS.
- 3. THE NAILING OF THE VARIOUS PARTS OF THE GATES WILL BE AS FOLLOWS: NAIL THE 2" X 3", 2" X 4", OR 2" X 6" HORIZONTAL PIECE (5) TO THE VERTICAL PIECES W/3-10d NAILS AT EACH JOINT. NAIL THE DOUBLED 2" X 3" GATE HOLD DOWN PIECES TO A HORIZONTAL PIECE W/3-10d NAILS EACH LAYER. NAIL THE 2" X 2" STRUT LEDGERS TO THE VERTICAL PIECES W/2-10d NAILS AT EACH LOUNT.

LOAD BEARING GATES FOR USE WITH INCREASED/DECREASED-HEIGHT UNITS IN A CROSSWISE LOAD






②
3
SECTION Z-Z
1

PAGE 102

- 1 ANTI-SWAY BRACE (7 REQD.). SEE THE "ANTI-SWAY BRACE A" DETAIL ON PAGE 18.
 INSTALL BETWEEN LATERALLY ADJACENT ROWS OF PALLET UNITS. SEE GENERAL NOTE "M" ON PAGE 2 AND SPECIAL NOTE 5 ON PAGE 103.
- TOP-OF-LOAD ANTI-SWAY BRACE (3 REQD). SEE THE "TOP-OF-LOAD ANTI-SWAY BRACE A" DETAIL ON PAGE 19 FOR THE ALTERNA TED CONTAINERS UNIT OR THE "TOP-OF-LOAD ANTI-SWAY BRACE B" DETAIL ON PAGE 46 FOR THE FLAT OR ROUTED DUNNAGE METHOD UNITS. (TOP-OF-LOAD ANTI-SWAY BRACE B" IS SHOWN). WIRE TIE TO PALLET UNITS AS SHOWN BY THE APPLICABLE TIE WIRE APPLICATION DETAIL ON PAGE 122.
- 3 STRAPPING BOARD, 2" X 6" X 36" (32 REQD/4 PER PALLET UNIT). POSITION AS SHOWN IN THE "METHOD A" DETAIL ON PAGE 104. SEE SPECIAL NOTE 6 ON PAGE 103.
- REINFORCING STRAP, 1-1/4" X .035" X 18'-0" LONG (REF) STEEL STRAPPING (16 REQD). INSTALL TO ENCIRCLE THE PALLET UNIT AND THE STRAPPING BOARDS. SECURE TO A STRAPPING BOARD W/3 STAPLES. SEE THE "METHOD A" DETAIL ON PAGE 104.
- (5) SEAL FOR 1-1/4" STRAPPING (32 REQD/2 PER STRAP), DOUBLE CRIMP EACH SEAL, SEE GENERAL NOTE "N" ON PAGE 2.
- 6 RISER ASSEMBLY (2 REQD). THE HEIGHT OF THESE RISER ASSEMBLIES WILL BE TWO-THIRDS OF THE PALLET UNIT HEIGHT. SEE THE "RISER ASSEMBLY" DETAIL ON PAGE 103.
- 7 RISER ASSEMBLY (2 REQD). THE HEIGHT OF THESE RISER ASSEMBLIES WILL BE ONE-THIRD OF THE PALLET UNIT HEIGHT. SEE THE "RISER ASSEMBLY" DETAIL ON PAGE 103.
- 8 STOP PIECE "A" (4 REQD). SEE THE "RISER ASSEMBLY" DETAIL ON PAGE 103 FOR LOCATION AND NAILING GUIDANCE.

TYPICAL LCL LOAD USING RISER METHOD OF PARTIAL-LAYER BRACING




SPECIAL NOTES FOR LOAD

- A 9'-2" WIDE CONVENTIONAL TYPE WOOD-LINED BOX CAR IS SHOWN. CARS OF OTHER WIDTHS CAN BE USED. SEE GENERAL NOTE "D" CN PAGE 2.
- THE PALLET UNIT SHOWN IN THE TYPICAL LOAD ON PAGE 102 IS THE FLAT DUNNAGE METHOD UNIT (BASIC HEIGHT). THE DEPICTED PR™CEDURES ARE ALSO APPLICABLE FOR THE OTHER UNITS COVERED BY THIS DOCUMENT.
- THE RISER METHOD OF PARTIAL-LAYER BRACING IS TYPICALLY SHOWN WITH THE PALLET UNITS POSITIONED LENGTHWISE IN THE CAR. WITH MODIFI-CATIONS, THE PROCEDURES ARE ALSO APPLICABLE FOR CROSSWISE POSITIONED UNITS. SEE SPECIAL NOTES 5 AND 6.
- CNLY THE BLOCKING AND BRACING FOR THE RISER METHOD OF PARTIAL-LAYER BRACING IS SHOWN, REFER TO THE APPLICABLE LOAD PAGE FOR THE BLOCKING AND BRACING REQUIREMENTS FOR THE BALANCE OF THE LOAD.
- 5. ANTI-SWAY BRACE "A" IS APPLICABLE FOR ALL THE LENGTHWISE POSITIONED UNITS. ANTI-SWAY BRACE "B", AS DETAILED ON PAGE 74, WILL BE USED FOR CROSSWISE POSITIONED ROUTED DUNNAGE METHOD UNITS IN CARS WIDER THAN 9'-4". ANTI-SWAY BRACING WILL NOT BE REQUIRED FOR THE OTHER UNITS, OR FOR THE ROUTED UNITS IN 9'-4" WIDE CARS.
- 6. FOR CROSSWISE POSITIONED UNITS, THE STRAPPING BOARDS SHOWN AS PIECES MARKED (3) WILL NOT BE REQUIRED. SEE THE "METHOD B", "METHOD C", AND "METHOD D" DETAILS ON PAGES 104 AND 105 FOR MODIFICATIONS TO BE ACCOMPLISHED IN LIEU OF USING STRAPPING BOARDS, WHEN THE PALLET UNITS ARE TO BE POSITIONED CROSSWISE IN THE CAR. ALSO, FOR LOADS OF CROSSWISE UNITS, STOP PIECE "B", AS SHOWN ON THE RISER DETAIL ABOVE, WILL BE USED IN LIEU OF STOP PIECE "A".

SPECIAL NOTES FOR RISER ASSEMBLY:

- 1. THE TYPICAL RISER ASSEMBLY SHOWN ABOVE IS FOR THE FLAT DUNNAGE METHOD UNIT (BASIC HEIGHT). THE HEIGHT OF THE BASIC UNIT IS 49". A TWO-THIRDS UNIT HEIGHT RISER IS SHOWN ABOVE AND AS KEY NUMBER (3) IN THE LOAD ON PAGE 102. EACH CROSS BRACE AND EACH LATERAL PIECE OF THE RISER IS FABRICATED FROM FIVE (5) PIECES OF 2" X 6" MATERIAL AND ONE (1) PIECE OF 2" X 4" MATERIAL TO PROVIDE FOR A TOTAL HEIGHT OF 32-1/2" AFTER THE DECKING IS IN PLACE. A ONE-THIRD HEIGHT RISER, SHOWN AS KEY NUMBER (7) IN THE LOAD ON PAGE 102, WILL BE FABRICATED FROM: TWO (2) PIECES OF 2" X 6" AND ONE PIECE OF 2" X 4" MATERIAL FCR EACH CROSS BRACE AND EACH LATERAL PIECE, TO PROVIDE FOR A TOTAL HEIGHT OF 16" AFTER THE DECKING IS IN PLACE.
- SELECT THE PROPER WIDTH COMBINATIONS FOR THE LATERAL/CROSS BRACE PIECES PRIOR TO CONSTRUCTING A RISER ASSEMBLY, TO ASSURE THAT THE TOTAL HEIGHT OF THE RISER ASSEMBLY IS ONE-THIRD OR TWO-THIRDS OF THE PALLET UNIT HEIGHT, BASED ON THE PALLET UNIT BEING LOADED AND THE LOCATION OF THE RISER ASSEMBLY WITHIN THE LOAD. NOTE: A PLUS OR MINUS 1" TOLERANCE IS PERMISSIBLE ON THE RISER HEIGHT.
- 3. THE STOP PIECE "A" SHOWN ON THE RISER ASSEMBLY ABOVE IS ONLY FOR USE WHEN THE PALLET UNITS ARE POSITIONED LENGTHMISE IN THE CAR, AS SHOWN IN THE LCL LOAD ON PAGE 102. IF THE PALLET UNITS ARE POSITIONED CROSSWISE IN THE CAR, POSITION A 2" X 2" BY A LENGTH TO SUIT PIECE ACROSS THE DECKING, ON THE END WHICH IS AGAINST THE CAR SIDEWALL, AND NAIL TO THE DECKING W/2-104 NAILS AT EACH JOINT. SEE STOP PIECE "B" ON THE RISER ASSEMBLY ABOVE FOR LOCATION GUIDANCE.


TYPICAL LCL LOAD USING RISER METHOD OF PARTIAL-LAYER BRACING




NOTE:
THE "METHOD A" DETAIL AT LEFT SHOWS THE MODIFICATION REQUIRED FOR PALLET THE "METHOD A" DETAIL AT LEFT SHOWS THE MODIFICATION REQUIRED FOR PALLET UNITS WHICH ARE TO BE POSITIONED LENGTHWISE IN A CAR WHEN USING THE RISER METHOD OF PARTIAL-LAYER BRACING SHOWN ON PAGE 102. THE BASIC HEIGHT ROUTED DUNNAGE METHOD UNIT IS SHOWN. THE PROCEDURES ARE APPLICABLE FOR ALL THE UNITS COVERED BY THIS DOCUMENT. FOR MODIFICATION OF UNITS TO BE POSITIONED CROSSWISE IN A CAR, REFER TO THE "METHOD B" DETAIL BELOW AND/OR THE "METHOD C" OR "METHOD D" DETAIL ON PAGE 105.

STRAPPING BOARD, 2" X 6" X 36" FOR 4-LAYER UNITS, 2" X 6" X 25-1/2" FOR 3-LAYER UNITS (4 REQD). POSITION SO AS TO CENTER ON THE JOINTS OF CONTAINERS.

METHOD A FOR ALL PALLET UNITS. THE ROUTED DUNNAGE METHOD UNIT (BASIC HEIGHT) IS SHOWN.







NOTE:
THE "METHOD B" DETAIL AT LEFT SHOWS THE MCDIFICATION REQUIRED FOR THE ROUTED DUNNAGE METHOD UNITS WHICH ARE TO BE POSITIONED CROSSWISE IN A CAR WHEN USING THE RISER METHOD OF PARTIAL-LAYER BRACING SHOWN ON PAGE 102. THE BASIC HEIGHT UNIT IS SHOWN, HOWEVER, THE PROCEDURE IS ALSO APPLICABLE FOR THE DECREASED HEIGHT UNIT. FOR MODIFICATION OF ROUTED DUNNAGE METHOD UNITS, TO BE POSITIONED LENGTHWISE IN A CAR, REFER TO THE "METHOD A" DETAIL ABOVE.

FOR ROUTED DUNNAGE METHOD UNITS. THE BASIC HEIGHT UNIT IS SHOWN.

TYPICAL LCL LOAD USING RISER METHOD OF PARTIAL-LAYER BRACING





ISOMETRIC VIEW

SPECIAL NOTES:

PAGE 106

- A 9'-4" WIDE ALL-METAL BOX CAR EQUIPPED WITH STRAP ANCHOR DEVICES AND HAVING AN AAR MECHANICAL DESIGNATION CLASS OF XL IS SHOWN, CARS OF CITHER WIDTHS CAN BE USED.
- THE PALLET UNIT SHOWN IN THE TYPICAL LCL LOAD IS THE ROUTED DUNNAGE METHOD UNIT (BASIC HEIGHT). THE DEPICTED PROCEDURES ARE ALSO APPLI-CABLE FOR THE OTHER UNITS COVERED BY THIS DOCUMENT.
- 3. THE BULKHEAD GATE METHOD OF PARTIAL-LAYER BRACING IS ONLY APPLICABLE FOR USE IN LOADS OF LENGTHWISE POSITIONED PALLET UNITS AS SHOWN IN THE VIEW ABOVE. PARTIAL LAYERS OF CROSSWISE POSITIONED PALLET UNITS WILL NOT BE RETAINED BY THE BULKHEAD GATE METHOD.
- 4. A BULKHEAD GATE USED IN CONJUNCTION WITH THREE (3) BULKHEAD STRAPS WILL RETAIN UP TO 18,000 POUNDS OF LADING; A BULKHEAD GATE WITH TWO (2) STRAPS WILL RETAIN NOT MORE THAN 12,000 POUNDS. IF ONLY TWO STRAPS ARE USED, THEY MUST BE APPLIED OVER THE UPPER AND LOWER STRAPPING BOARDS.
- 5. THE ANCHOR DEVICES TO BE USED FOR THE ATTACHMENT OF THE BULKHEAD STRAPS MUST BE LOCATED AT LEAST SIX INCHES (6") TOWARD THE CAR END WALL FROM THE OPPOSITE-THE-LOAD SIDE OF THE BULKHEAD GATE.
- 6. BULKHEAD STRAPS WILL BE TWO INCH (2") WIDE STEEL STRAPPING; 1-1/4" STRAPPING MUST NOT BE USED. A BULKHEAD STRAP WILL BE CF A LENGTH TO SUIT AND WILL BE THEADED THRU THE ANCHOR DEVICE (PRIOR TO POSITIONING THE ADJACENT UNITS) FAR ENOUGH TO PROVIDE FOR ONE LEG BEING APPROXIMATELY 48" LONGER THAN THE OTHER. THE STRAP ATTACHED TO THE MATING ANCHOR DEVICE WILL HAVE THE OPPOSITE LEG EXTENDING 48". THE TWO LEGS OF EACH HALF OF A STRAP WILL BE SECURED NEAR THE ANCHOR DEVICE WITH ONE DOUBLE CRIMPED SEAL, NOTE THAT THIS SEAL MUST BE POSITIONED EITHER CLOSE ENOUGH TO CR FAR ENOUGH AWAY FROM THE ANCHOR DEVICE SO AS NOT TO BE AT THE POINT WHERE THE STRAP BENDS AROUND THE END OF THE BULKHEAD GATE OR AROUND THE CORNER OF THE ADJACENT UNIT. THE STRAP ENDS OF EACH PAIR OF LONG AND SHORT LEGS WILL BE SECURED WITH TWO (2) SEALS BUTTED TOGETHER AND DOUBLE CRIMPED.

(CONTINUED ON PAGE 107)


KEY NUMBERS

- 1 END-WALL LINING (1 REQD). SEE THE DETAIL ON PAGE 121. SEE GENERAL NOTE "D" ON PAGE 2. NOTE THAT IF AN END-OF-CAR BULKHEAD, AS DETAILED ON PAGE 122 IS USED, THE END-WALL LINING IS NOT REQUIRED.
- 2 ANTI-SWAY BRACE (7 REQD). SEE THE "ANTI-SWAY BRACE A" DETAIL ON PAGE 18. INSTALL BETWEEN THE LATERALLY ADJACENT ROWS OF PALLET UNITS. SEE GENERAL NOTE "M" ON PAGE 2.
- TOP-OF-LOAD ANTI-SWAY BRACE (2 REQD). SEE THE TOF-OF-LOAD ANTI-SWAY BRACE A" DETAIL ON PAGE 19 FOR THE ALTERNATED CONTAINERS UNIT OR THE "TOP-OF-LOAD ANTI-SWAY BRACE B" DETAIL ON PAGE 46 FOR THE FLAT OR ROUTED DUNNAGE METHOD UNITS. WIRE TIE TO PALLET UNITS AS SHOWN BY THE APPLICABLE TIE WIRE APPLICATION DETAIL ON PAGE 122.
- SEPARATOR GATE FOR 2-HIGH LOAD (2 REQD). SEE THE APPLICABLE DETAIL ON PAGE 17, 31, 45, 59, 73, OR 87 AND/OR THE "ALTERNATIVE SEPARATOR GATE" DETAIL ON PAGE 122. POSITION WITH THE HORIZONTAL PIECES AGAINST THE ALREADY-LOADED UNITS.
- SEPARATOR GATE FOR 1-HIGH LOAD (1 REQD). SEE THE APPLICABLE DETAIL ON THE AFOREMENTIONED PAGES.
- 6 BULKHEAD STRAP, 2" X .050" X 23"-0" LONG (REF) STEEL STRAPPING (3 REQD), INSTALL FROM 2 EQUAL LENGTH PIECES, SEE THE "STRAP APPLICATION PLAN VIEW" ON PAGE 107 FOR INSTALLATION GUIDANCE, SEE SPECIAL NOTES 4. THELL 6 AT LEFT.
- SEAL FOR 2" STRAPPING (18 REQD, 6 PER STRAP), DOUBLE CRIMP EACH SEAL. SEE GENERAL NOTE "N" ON PAGE 2.
- 8 STRAPPING BOARD (2 REQD), SEE THE DETAIL ON PAGE 107.
- BUNDLING STRAP, 1-1/4" X .035" X 19'-0" LONG (REF) STEEL STRAPPING
 (2 REQD). ENCIRCLE THE PALLET UNIT, THE HORIZONTAL PIECES OF THE
 BULKHEAD GATE, AND A STRAPPING BOARD, PIECE MARKED ⑥. TENSION
 AND SEAL AFTER TENSIONING THE BULKHEAD STRAPS, PIECES MARKED ⑥.
- (1) BULKHEAD GATE (1 REQD). SEE THE DETAIL ON PAGE 107. SEE SPECIAL NOTE 3 AT LEFT.
- STRAP RETAINER, 2" X 4" BY A LENGTH TC SUIT (2 REQD), NAIL TO THE BULKHEAD GATE W/2-12d NAILS ABOVE AND BELOW EACH BULKHEAD STRAP.
- (2) SEAL FOR 1-1/4" STEEL STRAPPING (2 REQD, 1 PER STRAP). DOUBLE CRIMP EACH SEAL.


TYPICAL LCL LOAD USING BULKHEAD GATE METHOD OF PARTIAL-LAYER BRACING

(SPECIAL NOTES CONTINUED)

7. THE STRAPPING BOARDS ON A BULKHEAD GATE ARE TO BE ALIGNED AS NEARLY AS POSSIBLE WITH THE ANCHOR DEVICES IN THE CAR TO WHICH THE BULKHEAD STRAPS ARE ATTACHED. TOLERANCES ARE SPECIFIED ON THE END VIEW OF THE BULKHEAD GATE BELOW FOR THE LOCATION OF THE STRAPPING BOARDS. THE STRAPPING BOARDS/HORIZONTAL PIECES SHOULD BE LOCATED WITHIN THESE TOLERANCES. IF THIS IS NOT POSSIBLE, ADDITIONAL HORIZONTAL PIECES MUST BE APPLIED, AS NECESSARY TO PROVIDE PROPER BEARING AGAINST THE CONTAINERS.



HORIZONTAL PIECE LOCATION					
UNIT	3-ніG	3-нібн		4-HIGH	
	DIM A	DIM 8	DIM A	DIM B	
ALTERNATED CONTAINERS	13" ± 5"	22" ± 5"	17" ± 1"	32" ± 5"	
FLAT DUNNAGE	12-1/2" ± 5"	23" ± 5"	18" * 1"	34" ± 5"	
ROUTED DUNNAGE	12-1/2" ± 5"	23" ± 5"	18" ± 1"	34" ± 5"	



(SPECIAL NOTES CONTINUED)

ADJACENT PIECE MARKED ① MUST BE DOUBLED AND EXTENDED ACROSS AND FAR ENOUGH PAST THE DOOR OPENING (REF: 60"), TO PROVIDE FOR THE SPECIFIED NAILING OF EACH PIECE. LAMINATE THE SECOND PIECE OF THE DOUBLED PIECE MARKED ② TO THE FIRST W/16-16c NAILS. CLINCH THOSE NAILS WHICH PROTRUDE THRU THE HORIZONTAL WALL CLEAT WITHIN THE DOOR OPENING. NOTE THAT THE DIAGONAL BRACE WILL BE 49-1/8" LONG IN LIEU OF 50-1/4" WHEN PIECE MARKED ② IS DOUBLED.

THE CENTER CLEAT, SHOWN AS PIECE MARKED ② , WILL 28" LONG FOR AN 8"-6" WIDE CAR, 36" LONG FOR A 9"-2" , AND 38" LONG FOR A 9"-4"WIDE CAR. ADJUST THE LENGTH PROPORTIONATELY FOR CARS OF OTHER WIDTHS.

IF THE CAR HAS A BOWED END WALL, A BULKHEAD MUST BE INSTALLED. SEE THE "END-OF-CAR BULKHEAD" DETAIL ON PAGE 122.

EXCEPT FOR THE ALTERNATED CONTAINERS UNIT, DIRECTION OF ARROW INDICATES BASE END OF CONTAINER. SEE GENERAL NOTE "E" ON PAGE 2.

KEY NUMBERS

ANTI-SWAY BRACE (2 REQD), SEE THE "ANTI-SWAY BRACE A" DETAIL ON PAGE 18. INSTALL BETWEEN LATERALLY ADJACENT ROWS OF PALLET UNITS. SEE GENERAL NOTE "M" ON PAGE 2 AND SPECIAL NOTE 3 AT LEFT.

- 2) TOP-CF-LOAD ANTI-SWAY BRACE (1 REQD). SEE THE "TCP-CF-LOAD ANTI-SWAY BRACE A" DETAIL ON PAGE 19 FOR THE ALTERNATED CONTAINERS UNIT OR THE "TCP-CF-LOAD ANTI-SWAY BRACE B" DETAIL ON PAGE 46 FOR THE FLAT OR RCUTED DUNNAGE METHOD UNITS. WIRE TIE TO PALLET UNITS AS SHOWN BY THE APPLICABLE TIE WIRE APPLICATION DETAIL ON PAGE 122. NOTE THAT THE QUANTITY IS ONLY FOR THE PARTIAL-TIER UNITS.
- 3 SEPARATOR GATE (2 REQD). SEE THE APPLICABLE DETAIL ON PAGE 17, 31, 45, 59, 73, OR 87 AND/OR THE "ALTERNATIVE SEPARATOR GATE" DETAIL ON PAGE 122.
- 4 SUPPORT CLEAT, 2" X 4" X 12" (2 REQD). NAIL TO THE CAR SIDEWALL W/4-12d NAILS. POSITION SO AS TO CENTER PIECES MARKED (3) AND (6) ON THE JOINT BETWEEN THE BOTTOM TWO LAYERS OF CONTAINERS ON THE UNITS. SEE SPECIAL NOTE 5 AT LEFT.
- (3) HORIZONTAL PIECE, 2" X 6" BY CAR WIDTH IN LENGTH (CUT TO FIT)
 (2 REQD). NAIL TO THE CROSS CAR BRACE, PIECE MARKED (6), W/1-12d
 NAIL EVERY 6". SEE SPECIAL NOTE 3 AT LEFT.
- 6 CROSS CAR BRACE, 4" X 4" BY CAR WIDTH IN LENGTH (CUT TO FIT) (2 REQD)
- (7) CENTER CLEAT, 2" X 4" X 36" (2 REQD). NAIL TO THE CROSS CAR BRACE, PIECE MARKED (6), W/7-16d NAILS. SEE SPECIAL NOTE 6 ABOVE.
- 8 SPACER CLEAT, 2" X 4" X 14-3/4" FOR 4-LAYER UNITS, 10" FOR 3-LAYER UNITS (2 REQD). NAIL TO THE CAR SIDEWALL W/4-12d NAILS.
- O HORIZONTAL WALL CLEAT, 2" X 6" X 72" (4 REQD). NAIL TO THE CAR SIDEWALL W/16-12d NAILS.
- (D) POCKET CLEAT, 2" X 6" X 12" (2 REQD). NAIL TO THE HORIZONTAL WALL CLEAT, PIECE MARKED (9), W/4-16d NAILS.
- DIAGONAL BRACE, 2" X 4" X 50-1/4" (4 REQD). SEE THE DETAIL AT LEFT FOR BEVEL CUTS REQUIRED. TOENAIL TO THE CROSS CAR BRACE, PIECE MARKED ③, AND TO THE HORIZONTAL WALL CLEAT, PIECE MARKED ④, W/2-164 NAILS AT EACH END.
- (2) BACK -UP CLEAT, 2" X 6" X 24" (4 REQD). NAIL TO THE HORIZONTAL WALL CLEAT, PIECE MARKED (9), W/8-16d NAILS.
- (3) HOLD-DOWN CLEAT, 2" X 4" X 18" (2 REQD). NAIL TO THE CAR SIDEWALL W/5-12d NAILS.

A DIACENT FI
ACROSS AND
TO PROVIDE
THE SECOND
W/16-16c NM
HORIZONFAL
HAT THE DU
50-1/4" WHEI
OR AN 8"-6
FOR A 9"-4"V
CARS OF OTI

ANTI-SWAY BRACE (2 R
PAGE 18. INSTALL BET
SEE GENERAL NOTE "M

SPECIAL NOTES


PAGE 108

 A 9'-2" WIDE CONVENTIONAL WOOD-LINED BOX CAR IS SHOWN. WOOD-LINED CARS OF OTHER WIDTHS CAN BE USED.

ISOMETRIC VIEW


- 2. THE PALLET UNIT SHOWN IN THE TYPICAL LCL LOAD IS THE ROUTED DUNNAGE METHOD UNIT (BASIC HEIGHT). THE DEPICTED PROCEDURES ARE ALSO APPLICABLE FOR THE OTHER UNITS COVERED BY THIS DOCUMENT.
- 3. PARTIAL-LAYER BRACING MAY BE APPLIED FOR ANY OF THE CONVENTIONAL CARLOADS DEPICTED HEREIN EXCEPT THE COMBINATION LOADS (1 ROW LENGTH-WISE AND 1 ROW CROSSWISE). A LENGTH-WISE LOAD IS SHOWN AS TYPICAL. THE BLCCKING AND BRACING WILL VARY FOR ROSSWISE LOADS. NOTE THAT FOR A CROSSWISE PARTIAL TIER, THE PIECES MARKED (3) SHOULD BE LOCATED SO AS TO BEAR AGAINST THE PALLET UNITS IN THE SAME LOCATION AS THE HOPIZONIAL PIECES OF A CEPTIER GATE.
- 4. THE K-BRACE METHOD OF PARTIAL-LAYER (TIER) BRACING SHOWN MAY BE USED IN WCOD-LINED CARS FOR THE SECUREMENT OF A PARTIAL TOP TIER, BE IT A SECOND TIER, THIRD TIER, OR FIRST. THE TYPE "A" K-BRACE SHOWN IS ADEQUATE FOR RETAINING A PARTIAL TIER OF NOT MORE THAN 8,000 POUNDS. IF IT IS NECESSARY TO BLOCK A HEAVIER LOAD, REFER TO THE DETAILS ON PAGES 109, 110, AND 111 FOR SELECTION OF THE APPLICABLY SIZED K-BRACE TO USE AND THE DESIGN SPECIFICATIONS FOR THE BRACE.
- 5. CAUTION: SOME CARS ARE NOT SUITED FOR THE APPLICATION OF "PARTIAL-LAYER BRACING" BECAUSE THE LENGTH OF THE PARTIAL TIER TO BE SHIPPED AND/OR THE SIZE OR CONFIGURATION OF THE CAR DOCRS WILL NOT PERMIT PROPER INSTALLATION OF THE SPECIFIED K-BRACE DUNNAGE. PIECES MARKED (3), (3), (4), AND (3) MUST BE SUPPORTED AT THE SIDES OF A CAR BY A CAR SIDEWALL. IT IS ALRIGHT FOR THE ENDS OF THE DIAGONAL BRACES MARKED (1) TO BEAR IN FRONT OF A DOOR OPENING, HOWEVER, THE

(CONTINUED AT RIGHT ABOVE)



TYPICAL LCL LOAD USING K-BRACE METHOD OF PARTIAL-LAYER BRACING

- 1. THE TYPE "B" K-BRACE SHOWN IS ADEQUATE FOR RETAINING A PARTIAL TIER OF NOT MORE THAN 14,000 POUNDS. THIS WILL BE NOT MORE THAN EIGHT (8) 3-LAYER UNITS OR SIX (6) 4-LAYER UNITS. IF IT IS NECESSARY TO BLOCK A HEAVIER LOAD, REFER TO THE DETAILS ON PAGES 110 AND 111 FOR SELECTION OF THE APPLICABLY SIZED K-BRACE TO USE AND THE DESIGN SPECIFICATIONS FOR THE BRACE. IF THE PARTIAL TIER TO BE BRACED WEIGHS 8,000 POUNDS OR LESS, THE TYPE "A" K-BRACE DEPICTED ON PAGE 108 MAY BE USED.
- 2. CAUTION: SOME CARS ARE NOT SUITED FOR THE APPLICATION OF "PARTIAL-LAYER BRACING" BECAUSE THE LENGTH OF THE PARTIAL TIER TO BE SHIPPED AND/OR THE SIZE OR CONFIGURATION OF THE CAR DOORS WILL NOT PERMIT PROPER INSTALLATION OF THE SPECIFIED K-BRACE DUNNAGE. MECES MARKED ①, ②, ③, ⑥, ②), ①, AND ① MUST BE SUPPORTED AT THE SIDES OF A CAR BY A CAR SIDEWALL. IT IS ALRIGHT FOR THE ENDS OF THE DIAGONAL "BRACES MARKED ② TO BEAR IN PRONT OF A DOOR OPENING, HOWEVER, THE ADJACENT MECE MARKED ⑤ MUST BE DOUBLED AND EXTENDED ACROSS AND FAR ENOUGH PAST THE DOOR OPENING (REF 54") TO PROVIDE FOR THE SPECIFIED NAILING OF EACH PIECE. LAMINATE THE SECOND PIECE OF THE DOUBLED PIECE MARKED ③ TO THE FIRST W/16-16d NAILS. CLINCH THOSE NAILS WHICH PROTRUDE TIRKU THE HORIZONTAL WALL CLEAT WITHIN THE DOOR OPENING. NOTE THAT THE DIAGONAL BRACE WILL BE 49-1/8" LONG IN LIEU OF 50-1/4" WHEN PIECE MARKED ⑤ IS DOUBLED.
- 3. THE CENTER CLEAT, SHOWN AS MECE MARKED ♠, WILL BE 28*
 LONG FOR AN 8*-6* WIDE CAR, 36* LONG FOR A 9*-2*, AND
 38* LONG FOR A 9*-4* WIDE CAR. ADJUST THE LENGTH
 PROPORTIONATELY FOR CARS OF OTHER WIDTHS.
- 4. REFER TO PAGE 108 FOR A TYPICAL INSTALLATION OF A K-BRACE.





KEY NUMBERS

- SUPPORT CLEAT, 2" X 4" X 7" (2 REQD). NAIL TO THE CAR SIDEWALL W/2-12d NAILS. POSITION SO AS TO CENTER PIECES MARKED ② AND ③ ON THE JOINT BETWEEN THE BOTTOM TWO LAYERS OF CONTAINERS ON THE UNITS. SEE SPECIAL NOTE 2 AT LEFT.
- 2 LOAD BEARING PIECE, 2" X 6" BY CAR WIDTH (CUT TO FIT) (2 REQD).
 NAIL TO THE CROSS CAR BRACE, PIECE MARKED (3), W/1-12d NAIL EVERY 6".
 SEE GENERAL NOTE "M" ON PAGE 2.
- 3 CROSS CAR BRACE, 4" X 4" BY CAR WIDTH (CUT TO FIT) (2 REQD).
- CENTER CLEAT, 2" X 4" X 36" (2 REQD), NAIL TO THE CROSS CAR BRACE, MECE MARKED ③, W/7-16d NAILS. SEE SPECIAL NOTE 3 AT LEFT.
- 5 HORIZONTAL WALL CLEAT, 2" X 6" X 72" (4 REQD). NAIL TO THE CAR SIDEWALL W/16-12d NAILS.
- 6 POCKET CLEAT, 2" X 6" X 18" (4 REQD). NAIL TO THE HORIZONTAL WALL CLEAT, PIECE MARKED (3), W/7-164 NAILS.
- 7 DIAGONAL BRACE, 4" X 4" X 50-1/4" (4 REQD). SEE THE DETAIL BELOW FOR BEVEL CUTS REQUIRED. TOENAIL TO THE CROSS CAR BRACE, PIECE MARKED

 (3), AND TO THE HORIZONTAL WALL CLEAT, PIECE MARKED (3), W/1-604

 NAIL AT EACH RAID.
- 8 BACK-UP CLEAT, 2" X 6" X 30" (4 REQD). NAIL TO THE HORIZONTAL WALL CLEAT, MECE MARKED (3), W/14-164 NAILS.
- 9 SPACER CLEAT, 2" X 4" X 14-3/4" FOR 4-LAYER UNITS, 10" FOR 3-LAYER UNITS (2 REQD). NAIL TO THE CAR SIDEWALL W/4-12d NAILS.
- (1) HOLD-DOWN CLEAT, 2" X 4" X 18" (2 REQD). NAIL TO THE CAR SIDEWALL W/5-12d NAILS.






DIAGONAL BRACE
SEE SPECIAL NOTE 2 ABOVE.


THIS BEARING SURFACE MUST BE POSITIONED SO AS TO BE IN CONTACT WITH A CROSS CAR BRACE, PIECE MARKED (3), OR A HORIZONTAL WALL CLEAT, PIECE MARKED (3).

TYPE "B" K-BRACE



- THE TYPE "C" K-BRACE SHOWN IS ADEQUATE FOR RETAINING A PARTIAL TIER OF NOT MORE THAN 20,000 POUNDS. THIS WILL BE NOT MORE THAN TWELVE (12) 3-LAYER UNITS OR NINE (9) 4-LAYER UNITS, IF IT IS NECESSARY TO BLOCK A HEAVIER LOAD, REFER TO THE DETAIL ON PAGE 111 FOR THE APPLICABLY SIZED K-BRACE TO USE AND THE DESIGN SPECIFICATIONS FOR THE BRACE, IF THE PARTIAL TIER TO BE BRACED WEIGHS BETWEEN 8,000 POUNDS AND 14,000 POUNDS, THE TYPE "B" K-BRACE DEPICTED ON PAGE 109 MAY BE USED. IF THE PARTIAL TIER TO BE BRACED WEIGHS 8,000 POUNDS OR LESS, THE TYPE "A" K-BRACE DEPICTED ON PAGE 108 WILL BE ADEQUATE. PAGE 108 WILL BE ADEQUATE.
- CAUTION: SOME CARS ARE NOT SUITED FOR THE APPLICATION OF "PARTIAL-LAYER BRACING" BECAUSE THE LENGTH OF THE PARTIAL TIER TO BE SHIPPED AND/OR THE SIZE OR CONFIGURATION OF THE CAR DOORS WILL NOT PERMIT PROPER INSTALLATION OF THE SPECIFIED K-BRACE DUNNIAGE. PIECES MARKED ①, ②, ③, ⑥, ⑥, ♠, P, AND ① MILL BE SUPPORTED AT THE SIDES OF A CAR BY A CAR SIDEWALL. IT IS ALRIGHT FOR THE ENDS OF THE DIAGONAL BRACES MARKED ② TO BEAR IN FRONT OF A DOOR OPENING, HOWEVER, THE ADJACENT PIECE MARKED ③ MUST BE DOUBLED. LAMINATE THE SECOND PIECE TO THE FIRST W/40-164 NAILS. CLINCH THOSE NAILS WHICH PROTRUDE THRU THE HORIZONTAL WALL CLEAT WITHIN THE DOOR OPENING. NOTE THAT THE DIAGONAL BRACE WILL BE 49-1/8" LONG IN LIEU OF 50-1/4" WHEN PIECE MARKED ⑤ DOUBLED. PIECE MARKED (5) IS DOUBLED.

(CONTINUED AT RIGHT)




- SUPPORT CLEAT, 2" X 4" X 7" (2 REQD). NAIL TO THE CAR SIDEWALL W/2-12d NAILS. POSITION SO AS TO CENTER PIECES MARKED ② AND ③ ON THE JOINT BETWEEN THE BOTTOM TWO LAYERS OF CONTAINERS ON THE UNITS. SEE SPECIAL NOTE 2 AT LEFT.
- LOAD BEARING PIECE, 2" X 6" BY CAR WIDTH (CUT TO FIT) (2 REQD). NAIL TO THE CROSS CAR BRACE, PIECE MARKED (3), W/1-12d NAIL EVERY 6". SEE GENERAL NOTE "M" ON PAGE 2.
- 3 CROSS CAR BRACE, 4" X 4" BY CAR WIDTH (CUT TO FIT) (2 REQD).
- CENTER CLEAT, 2" X 4" X 36" (2 REQD). NAIL TO THE CROSS CAR BRACE, PIECE MARKED 3, W/7-16d NAILS. SEE SPECIAL NOTE 3 BELOW.
- HORIZONTAL WALL CLEAT, 2" X 6" BY CUT 10 FIT (4 REQD). A CLEAT WILL BE OF A LENGTH AS NECESSARY TO EXTEND ACROSS AND FAR ENOUGH PAST THE DOOR OPENINGS TO CONTACT PIECE MARKED ③ OF THE K-BBACE IN THE OPPOSITE END OF THE CAR. NAIL TO THE CAR SIDEWALL W/40-12d NAILS.
- POCKET CLEAT, 2" X 6" X 18" (DOUBLED) (4 REQD). NAIL THE FIRST PIECE TO THE HORIZONTAL WALL CLEAT, PIECE MARKED (3), W/7-16d NAILS. NAIL THE SECOND PIECE TO THE FIRST IN A LIKE MANNER. POCKET CLEAT, 2" X 6" X 18" (DOUBLED) (4 REQD).
- DIAGONAL BRACE, 4" X 4" X 50-1/4" (4 REQD). SEE THE DETAIL BELOW FOR BEVEL CUTS REQUIRED. TOENAIL TO THE CROSS CAR BRACE, PIECE MARKED (3), AND TO THE HORIZONTAL WALL CLEAT, PIECE MARKED (3), W/1-60d NAIL AT EACH END.
- BACK-UP CLEAT, 2" X 6" X 30" (4 REQD). NAIL TO THE HORIZONTAL WALL CLEAT, PIECE MARKED 3, W/14-164 NAILS. (8)
- SPACER CLEAT, 2" X 4" X 14-3/4" FOR 4-LAYER UNITS, 10" FOR 3-LAYER • UNITS (2 REQD). NAIL TO THE CAR SIDEWALL W/4-12d NAILS.
- **⑩** HOLD-DOWN CLEAT, 2" X 4" X 18" (2 REQD). NAIL TO THE CAR SIDEWALL W/5-12d NAILS.

(SPECIAL NOTES CONTINUED)


- 3. THE CENTER CLEAT, SHOWN AS PIECE MARKED 4), WILL BE 28" LONG FOR AN 8"-4" WIDE CAR, 36" LONG FOR A 9"-2", AND 38" LONG FOR A 9"-4" WIDE CAR. ADJUST THE LENGTH PROPORTIONATELY FOR CARS OF OTHER
- CAUTION: A TYPE "C" K-BRACE MUST BE USED IN BOTH ENDS OF THE CAR; THE BRACE IS NOT DESIGNED FOR USE IN ONLY ONE END. NOTE THAT EXCEPT FOR PIECES MARKED (3), THE QUANTITIES SPECIFIED ARE APPLICABLE ONLY FOR THE BRACE IN ONE END.

- THIS BEARING SURFACE MUST BE POSITIONED SO AS TO BE IN CONTACT WITH A CROSS CAR BRACE, PIECE MARKED ③, OR A HORIZONTAL WALL CLEAT, PIECE MARKED ⑤.


TYPE "C" K-BRACE



- THE TYPE "D" K-BRACE SHOWN IS ADEQUATE FOR RETAINING A PARTIAL TIER OF NOT MORE THAN 25,000 POUNDS. THIS WILL BE NOT MORE THAN FIFTEEN (15) 3-LAYER UNITS OR ELEVEN (11) 4-LAYER UNITS. IF THE PARTIAL TIER TO BE BRACED WEIGHS BETWEEN 14,000 POUNDS AND 20,000 POUNDS, THE TYPE "C" K-BRACE DEPICTED ON PAGE 110 MAY BE USED. FOR A PARTIAL TIER OF 8,000 POUNDS TO 14,000 POUNDS, THE TYPE "B" K-BRACE DEPICTED ON PAGE 100 MAY BE RESED. USED. FOR A PARTIAL TIER OF 8,000 POUNDS TO 14,000 POUNDS, THE TYPE "B" K-BRACE DEPICTED ON PAGE 109 MAY BE USED. IF THE PARTIAL TIER TO BE BRACED WEIGHS 8,000 POUNDS OR LESS, THE TYPE "A" K-BRACE DEPICTED ON PAGE 108 WILL BE ADEQUATE.
- SOME CARS ARE NOT SUITED FOR THE APPLICATION OF "PARTIAL-LAYER BRACING" CAUTION: SOME CARS ARE NOT SUITED FOR THE APPLICATION OF "PARTIAL-LAYER BRACING BECAUSE THE LENGTH OF THE PARTIAL TIER TO BE SHIPPED AND/OR THE SIZE OR CONFIGURATION OF THE CAR DOORS WILL NOT PERMIT PROPER INSTALLATION OF THE SPECIFIED K-BRACE DUNNAGE. MECES MARKED (1), (2), (3), (4), (7), (8), (11) AND (12) MUST BE SUPPORTED AT THE SIDES OF A CAR BY A CAR SIDEWALL. IT IS ALRIGHT FOR THE ENDS OF THE DIAGONAL BRACES MARKED (9) TO BEAR IN FRONT OF A DOOR OPENING, HOWEVER, THE ADJACENT PIECE MARKED (6) MUST BE DOUBLED. LAMINATE THE SECOND PIECE TO THE FIRST W/40-164 NAILS. CLINCH THOSE NAILS WHICH PROTEUDE THRU THE HORIZONTAL WALL CLEAT WITHIN THE DOOR OPENING. NOTE THAT THE DIAGONAL BRACE WILL BE 70-1/4" LONG IN LIEU OF 71" LONG WHEN MECE MARKED (6) IS DOUBLED.
- THE CENTER CLEAT, SHOWN AS PIECE MARKED (3), WILL BE 28" LONG FOR AN 8'-6" WIDE CAR, 36" LONG FOR A 9'-2", AND 38" LONG FOR A 9'-4" WIDE CAR, ADJUST THE LENGTH PROPORTIONATELY FOR CARS OF OTHER WIDTHS.
- CAUTION: A TYPE "D" K-BRACE MUST BE USED IN BOTH ENDS OF THE CAR; THE BRACE IS NOT DESIGNED FOR USE IN ONLY ONE END. NOTE THAT EXCEPT FOR PIECES MARKED (a) AND (a), THE QUANTITIES SPECIFIED ARE APPLICABLE ONLY FOR THE BRACE IN ONE END.




- SUPPORT CLEAT, 2" X 4" X 7" (2 REQD). NAIL TO THE CAR SIDE-WALL W/2-12d NAILS. POSITION SO AS TO CENTER PIECES MARKED ② AND ③ ON THE JOINT BETWEEN THE BOTTOM TWO LAYERS OF CONTAINERS ON THE UNITS. SEE SPECIAL NOTE 2
- (2) LOAD BEARING PIECE, 2" X 6" BY CAR WIDTH (CUT TO FIT)
 (2 REQD). NAIL TO THE CROSS CAR BRACE, PIECE MARKED (3), W/1-12d NAIL EVERY 6". SEE GENERAL NOTE "M" ON PAGE 2.
- CROSS CAR BRACE, 4" X 4" BY CAR WIDTH (CUT TO FIT) (2 REQD)
- HORIZONTAL PIECE, 2" X 6" BY CAR WIDTH (CUT TO FIT) (2 REQD) NAIL TO THE CROSS CAR BRACE, PIECE MARKED 3, W/1-12d NAIL
- CENTER CLEAT, 2" X 4" X 36" (2 REQD). NAIL TO THE HORIZONTAL PIECE, PIECE MARKED (4), W/7-16d NAILS. SEE SPECIAL NOTE 3 AT LEFT.
- HORIZONTAL WALL CLEAT, 2" X 6" BY CUT TO FIT (4 REQD). A CLEAT WILL BE OF A LENGTH AS NECESSARY TO EXTEND ACROSS AND FAR ENOUGH PAST THE DOOR OPENING TO CONTACT PIECE MARKED ⓐ OF THE K-BRACE IN THE OPPOSITE END OF THE CAR. NAIL TO THE CAR SIDEWALL W/40-12d NAILS.
- POCKET CLEAT, 2" X 6" X 36" (4 REQD). NAIL TO THE HORIZONTAL WALL CLEAT, PIECE MARKED 6, W/10-16d NAILS.
- POCKET CLEAT, 2" X 6" X 24" (4 REQD). NAIL TO THE POCKET CLEAT, PIECE MARKED \bigcirc , W/7-16d NAILS. (8)
- DIAGONAL BRACE, 4" X 4" X 71" (4 REQD). SEE THE DETAIL BELOW FOR BEVEL CUTS REQUIRED. TOENAIL TO THE HORIZONTAL PIECE, PIECE MARKED (4), AND TO THE HORIZONTAL WALL CLEAT, PIECE MARKED (6), W/1-60d NAIL AT EACH END. 9
 - BACK-UP CLEAT, 2" X 6" BY CUT TO FIT (4 REQD). BE OF A LENGTH AS NECESSARY TO EXTEND TO CONTACT THE
 DIAGONAL BRACE, PIECE MARKED (9), IN THE OPPOSITE END OF
 THE CAR. NAIL TO THE HORIZONTAL WALL CLEAT, PIECE MARKED
 (6), W/18-164 NAILS. CLINCH THOSE NAILS WHICH PROTRUDE THRU THE HORIZONTAL WALL CLEAT WITHIN THE DOCK OPENING, IF APPLICABLE.
 - SPACER CLEAT, 2" X 4" X 14-3/4" FOR 4-LAYER UNITS, 10" FOR 3-LAYER UNITS (2 REQD). NAIL TO THE CAR SIDEWALL W/4-12d
 - HOLD-DOWN CLEAT, 2" X 4" X 18" (2 REQD). NAIL TO THE CAR SIDEWALL W/5-12d NAILS.



- A 9'-2" WIDE WOOD-LINED CONVENTIONAL TYPE BOX CAR HAVING A WOOD OR NAILABLE METAL FLOOR IS SHOWN. CARS OF OTHER WIDTHS AND CARS HAVING METAL LININGS CAN BE USED.
- THE PALLET UNIT SHOWN IS THE ROUTED DUNNAGE METHOD UNIT (BASIC HEIGHT). THE DEPICTED PROCEDURES ARE ALSO APPLICABLE FOR THE OTHER UNITS COVERED BY THIS DOCUMENT.
- 3. THE LOAD SHOWN DEPICTING THE KNEE BRACE METHOD OF PARTIAL-LAYER BRACING IS TYPICAL. THE QUANTITY MAY BE ADJUSTED TO SUIT, PROVIDED THE LIMITATIONS OF THE KNEE BRACE AS SET FORTH IN SPECIAL NOTE 4 ARE NOT EXCEEDED. ALSO, THE LOAD MAY CONSIST OF TWO LENGTHWISE ROWS, OR TWO CROSSWISE ROWS IN LIEU OF ONE OF EACH AS DEPICTED.
- 4. A KNEE BRACE ASSEMBLY WILL BE USED FOR EACH ROW OF PALLET UNITS. ONE
 (1) KNEE BRACE ASSEMBLY IS ADEQUATE FOR RETAINING A MAXIMUM LCL LOAD
 OF NOT MORE THAN 8,500 POUNDS.
- 5. HOLD-DOWN CLEATS (GATE HOLD DOWN) MUST BE APPLIED TO THE BOTTOM HORIZONTAL PIECE OF A KNEE BRACE ASSEMBLY. THE PROPER MATERIAL SIZE AND PLACEMENT WILL BE AS DEPICTED BY THE CENTER GATE DETAILS FOR ONE ROW SPECIFIED ELSEWHERE. FOR HOLD DOWN PIECES TO BE APPLIED TO THE KNEE BRACE ASSEMBLY WHICH IS USED AGAINST THE LENGTHWISE ROW, REFER TO THE "CENTER GATE A" DETAIL ON PAGE 16 FOR THE ALTERNATED CONTAINERS UNITS, THE "CENTER GATE R" DETAIL ON PAGE 44 FOR THE FLAT DUNNAGE METHOD UNITS, OR THE "CENTER GATE R" DETAIL ON PAGE 72 FOR THE ROUTED DUNNAGE METHOD UNITS. FOR HOLD DOWN PIECES TO BE APPLIED TO THE KNEE BRACE ASSEMBLY WHICH IS USED AGAINST THE CROSSWISE ROW, REFER TO THE "CENTER B" DETAIL ON PAGE 17 FOR THE ALTERNATED CONTAINERS UNITS, THE "CENTER GATE K" DETAIL ON PAGE 45 FOR THE FLAT DUNNAGE METHOD UNITS, OR THE "CENTER GATE S" DETAIL ON PAGE 73 FOR THE FOUTED DUNNAGE METHOD UNITS,

KEY NUMBERS

- CRIB FILL (2 REQD). SEE THE APPLICABLE CRIB FILL DETAIL ON PAGE 16, 30, 44, 58, 72, OR 86. SEE GENERAL NOTE "M" ON PAGE 2.
- 2) SEPARATOR GATE (1 REQD). SEE THE APPLICABLE SEPARATOR GATE DETAIL ON PAGE 17, 31, 45, 59, 73, OR 87. POSITION WITH THE HORIZONTAL PIECES AGAINST THE ALREADY-LOADED UNIT.
- 3 KNEE BRACE ASSEMBLY (2 REQD). SEE THE DETAIL ON PAGE 113 FOR CON-STRUCTION SPECIFICATIONS AND NAILING REQUIREMENTS.



	VERTICAL PIECE PLACEMENT FOR CROSSWISE UNITS		
UNIT	DIM A	DIM B	
ALTERNATED CONTAINERS	7-1/2*	47-1/2*	
FLAT DUNNAGE	4"	52*	
ROUTED DUNNAGE	4-	52*	


	VERTICAL PIECE PLACEMENT FOR LENGTHWISE UNITS	
UNIT	DIM A	DIM B
ALTERNATED CONTAINERS	7-1/2"	32-1/2"
FLAT DUNNAGE	8-1/2"	34-1/2"
ROUTED DUNNAGE	7-3/4"	34-1/4*

(KNEE BRACE ASSEMBLY HEIGHT MINUS 132") X 2 THE BRACE MUST BE INSTALLED SO THAT THIS BEARING BRACE SURFACE WILL BE 4" X 4" MATERIAL IN CONTACT WITH THE VERTICAL PIECE

TYPICAL LCL LOAD USING KNEE BRACE METHOD OF PARTIAL-LAYER BRACING

KEY LETTERS


- VERTICAL PIECE, 2" X 6" BY UNIT HEIGHT MINUS 11" (2 REQD). SEE THE CHARTS AT LEFT FOR PLACEMENT DIMENSIONS.
- HORIZONTAL PIECE, 2" X 6" BY PALLET UNIT LENGTH, OR PALLET UNIT WIDTH PLUS 3", AS APPLICABLE, NAIL TO THE VERTICAL PIECES W/3-10d NAILS AT EACH JOINT. SEE GENERAL NOTE "M" ON PAGE 2. ➂
- ©
- HORIZONTAL PIECE, 1" X 6" BY PALLET UNIT WIDTH OR LENGTH (1 REQD FOR ROUTED DUNNAGE METHOD UNITS ONLY). NAIL TO THE BOTTOM HORIZONTAL PIECE MARKED ® W/1-64 NAIL EVERY 12".
 FLOOR CLEAT, 2" X 6" BY LENGTH TO SUIT (.87 OR 7/8 TIMES LENGTH OF PIECE MARKED © , PLUS 30") (2 REQD). ALIGN WITH A VERTICAL PIECE AND NAIL TO THE CAR FLOOR W/1-164 NAIL EVERY 8". SEE GENERAL NOTE "OR ON AGE 2" "Q" ON PAGE 2
- € HOLD-DOWN CLEAT, 2" X 6" X 12" (2 REQD). NAIL TO A VERTICAL PIECE W/5-10d NAILS.
- POCKET CLEAT, 2" X 6" X 12" (TRIPLED) (2 REQD). NAIL THE FIRST PIECE TO THE FLOOR CLEAT, PIECE MARKED 1, W/4-16d NAILS. NAIL THE SECOND AND THIRD PIECES IN A LIKE MANNER AND TOENAIL THE THIRD PIECE TO THE VERTICAL PIECE, PIECE MARKED 1, W/2-16d NAILS. €
- BRACE, 4" X 4" BY CUT TO FIT (KNEE BRACE ASSEMBLY HEIGHT MINUS 13-1/2", TIMES 2) (2 REQD). SEE THE DETAIL AT LEFT FOR BEVEL CUTS REQUIRED. TOENAIL TO THE VERTICAL PIECE AND TO THE FLOOR CLEAT, PIECES MARKED AND D , W/2-16d NAILS AT EACH JOINT. **©**
- BACK UP CLEAT, 2" X 6" X 30" (2 REQD). NAIL TO THE FLCOR CLEAT, PIECE MARKED 0 , W/6-40d NAILS.
- HOLD-DOWN CLEAT (NOT SHOWN). SEE SPECIAL NOTE 5 ON PAGE 112.



VERTICAL PIECE, 1" X 4" BY UNIT HEIGHT PLUS 61 (2 REQD). UNIT LENGTH HORIZONTAL PIECE, 1" X 4" BY UNIT LENGTH (2 REQD). Ę NAIL TO THE VERTICAL PIECES W/3-6d NAILS AT EACH JOINT AND CLINCH. VERTICAL PIECE, 1" X 6" BY UNIT HEIGHT PLUS 6" UNIT HEIGHT PLUS 6" (1 REQD). UNIT HEIGHT PLUS I' SEPARATOR GATE O

SPECIAL NOTES:

- A 50'-6" LONG BY 9'-2" WIDE CONVENTIONAL TYPE BOX CAR IS SHOWN. CARS OF OTHER WIDTHS CAN BE USED, AND SHORTER BUT NOT LONGER CARS WILL BE USED.
- THE PALLET UNIT SHOWN IN THE TYPICAL 1-WIDE LOAD IS THE ROUTED DUNNAGE METHOD UNIT (BASIC HEIGHT). THE DEPICTED PROCEDURES ARE ALSO APPLICABLE FOR THE OTHER UNITS COVERED BY THIS DOCUMENT
- 3. A 1-WIDE LENGTHWISE LOAD IS SHOWN AS TYPICAL. A CHART IS GIVEN TO SPECIFY THE PROPER DIMENSIONS FOR THE LENGTH AND POSITIONING OF PIECES FOR THE CENTER GATES. THE DEPICTED PROCEDURES ARE ALSO A PHICABLE FOR 1-WIDE CROSSWISE LOADS FOR WHICH THERE IS ALSO A CHART WHICH SPECIFIES LENGTHS AND POSITIONING OF PIECES FOR THE CENTER GATES. NOTE THAT THE SEPARATOR GATES, PIECES MARKED ①, ARE NOT REQUIRED, AND THE QUANTITY OF LCL BRACES, PIECES MARKED ②, IS NOT CORRECT FOR CROSSWISE LOADS.
- 4. ONE (1) LCL BRACE WILL BE USED AT EACH SIDE OF EACH PALLET UNIT. FOR CROSSWISE PALLET UNITS, THE BRACES WILL BE CENTERED ON THE LENGTH OF THE UNIT. FOR THE LENGTHWISE UNITS, THE BRACES WILL BE LOCATED NEAR THE CENTER OF THE UNIT WIDTH, WITH SLIGHT ADJUSTMENTS AS NECESSARY TO ALIGN A BRACE WITH THE INTERMEDIATE DUNNAGE PIECES OF THE ROUTED DUNNAGE METHOD UNIT, OR THE CROSS PIECE OF AN INTERMEDIATE DUNNAGE ASSEMBLY OF THE FIAT DUNNAGE METHOD UNIT.
- 5. THE BILL OF MATERIAL AND LOAD AS SHOWN ARE BASED ON THE DEPICTED UNIT AND THEREFORE ARE ONLY TYPICAL.
- 6. IF DESIRED, GATE HOLD DOWN PIECES WITH THE ASSOCIATED FILL PIECES, AS SHOWN ELSEWHERE ON THE APPLICA BLE CENTER GATE FOR A SINGLE ROW, MAY BE USED IN LIEU OF PIECES MARKED (6).



CENTER GATE AA


THIS GATE IS FOR USE WITH CROSSWISE UNITS. REFER TO THE "CENTER GATE AA" CHART AT TOP OF PAGE 114 FOR FIGURES REPRESENTED BY LETTERS ON THE DETAIL ABOVE.

LOAD AS SHOWN (TYPICAL)


ITEM	QUANTITY	WEIGHT (APPROX)
PALLET UNIT-	10	21,220 LBS
DUNNAGE		679 LBS
1	TOTAL WEIGHT	21.899 LBS

BILL OF MATERIAL (TYPICAL)			
LUMBER	LINEAR FEET	BOARD FEET	
1" X 4"	56	19	
1" X 6"	334	167	
2" X 2"	9	3	
2" X 3"	12	6	
2" X 6"	121	121	
4" X 4"	14	19	
VAILS	NO, REQD	POUNDS	
6d (2")	264	1-3/4	
8d (2-1/2")	240	2-1/2	
104 (3")	72	1-1/4	
16d (3-1/2")	156	3-1/2	


TYPICAL LCL LOAD USING 1-WIDE LOADING METHOD



- AN 8'-6" WIDE WOOD-LINED CONVENTIONAL TYPE BOX CAR HAVING A WOOD OR NAILABLE METAL FLOOR IS SHOWN, CARS OF OTHER WIDTHS CAN BE USED, SEE GENERAL NOTES "Q" AND "D" ON PAGE 2.
- THE PALLET UNIT SHOWN IN THE TYPICAL LCL LOAD IS THE ROUTED DUNNAGE METHOD UNIT (BASIC HEIGHT). THE DEPICTED PROCE-DURES ARE ALSO APPLICABLE FOR THE OTHER UNITS COVERED BY THIS DOCUMENT.
- 3. THE LOAD SHOWN DEPICTING THE LCL BRACE METHOD OF PARTIAL-LAYER BRACING IS TYPICAL. A CROSSWISE UNIT IS SHOWN. HOWEVER, THE PROCEDURES ARE ALSO APPLICABLE FOR LENGTHWISE UNITS AND FOR OTHER QUANTITIES AS LONG AS THE CAPACITY OF THE BRACES IS NOT EXCEPTED. SEE SEPCIAL NOTE.
- EACH LCL BRACE AS APPLIED FOR LONGITUDINAL BRACING WILL RETAIN 2,000 POUNDS OF LADING. EACH LCL BRACE AS APPLIED FOR LATERAL BRACING WILL SUPPORT 8,000 POUNDS OF LADING. A MINIBRUM OF TWO (2) BRACES MUST BE USED FOR LONGITUDINAL BRACING.




TYPICAL LCL LOAD USING LCL BRACE METHOD OF PARTIAL-LAYER BRACING




- SHIPMENTS OF PROPELLING CHARGES SHOULD CONSIST OF FULL-HEIGHT AND FULL-LAYER UNITS TO THE MAXIMUM EXTENT POSSIBLE. HOWEVER, THE END OF A LOT, OR THE QUANTITY OF ITEMS NEEDED TO FILL A REQUISITION, MAY NECESSITATE THE SHIPMENT OF ONE OR MORE LESS-THAN-FULL PALLET UNITS WITHIN A LOAD. THE PROCEDURES ON THIS PAGE ARE PRESENTED AS GUIDANCE IN THE SHIPMENT OF A PARTIAL UNIT WITHIN A LENGTHWISE LOAD.
- THE PALLET UNIT SHOWN IN THE SHIPMENT OF PARTIAL UNITS VIEW IS THE ROUTED DUNNAGE METHOD UNIT (BASIC HEIGHT). THE DEPICTED PROCEDURES ARE ALSO APPLICABLE FOR THE OTHER UNITS COVERED BY THIS DOCUMENT.
- 3. A LESS-THAN-FULL HEIGHT PALLET UNIT OF LENGTHWISE-POSITIONED PRO-PELLING CHARGES WHICH IS TO BE SHIPPED WITHIN A LAYER OF A LOAD HAS NO LIMITATIONS AS TO THE NUMBER OF LAYERS OF CONTAINERS ON THE PARTIAL UNIT. THE DEPICTED PROCEDURES SHOW THE BRACING OF A 2-LAYEP UNIT WITHIN A 4-LAYER LOAD, THE PRINCIPLES CAN BE ADAPTED TO SUIT OTHER SIZE PARTIAL UNITS.
- A PARTIAL UNIT MUST CONSIST OF FULL LAYERS OF FOUR (4) CONTAINERS, OR AN APPROVED FILLER ASSEMBLY, AS DETAILED BY DRAWING 19-48-4042A/1-20PM1001, MUST BE INSTALLED IN THE PLACE OF OMITTED CONTAINERS.
- 5. THE FILLERS AS REFERENCED IN SPECIAL NOTE 4. AND THE DUNNAGE DEPICTED ABOVE FOR THE SHIPMENT OF THE PARTIAL UNIT MAY BE REMOVED WHEN A SHIPMENT REACHES DESTINATION. OR IF DESIRED, THE FILLERS MAY REMAIN WITH THE UNIT DURING STORAGE (IF APPLICABLE) FOR POSSIBLE USE IN A FUTURE SHIPMENT.
- THE "POSITIONING OF PARTIAL LENGTHWISE UNIT WITHIN A LAYER" VIEW ABOVE DEPICTS A PORTION OF A CONVENTIONAL BOX CAR LOAD, HOWEVER, THE PROCEDURES ARE ALSO APPLICABLE FOR LOADS IN CARS EQUIPPED WITH LOAD DIVIDER BULKHEADS.

KEY NUMBERS

- PARTIAL-UNIT GATE (2 REQD), SEE THE "PARTIAL-UNIT GATE A" DETAIL BELOW. SEE GENERAL NOTE "M" ON PAGE 2 AND SPECIAL NOTE 3 AT LEFT.
- 2 STRUT, 4" X 4" X 49-3/8" (4 REQD). TOENAIL TO THE VERTICAL PIECES
 OF THE PARTIAL-UNIT GATE, PIECE MARKED ① , W/2-16d NAILS AT
 EACH END.
- 3 STRUT SUPPORT PIECE, 2" X 4" X 12" (4 REQD). NAIL TO A VERTICAL PIECE OF THE PARTIAL-UNIT GATE W/3-10d NAILS.
- 4 STRAPPING BOARD, 2" X 4" X 24-1/2" (2 REQD). NAIL TO THE STRUTS, PIECES MARKED ③, W/3-10d NAILS AT EACH END.
- (5) UNITIZING STRAP, 1-1/4" X .031" X .035" BY A LENGTH TO SUIT STEEL STRAPPING (2 REQD), PRE-POSITION THRU THE FORKLIFT OPENINGS OF THE PALLET.
- 6 SEAL FOR 1-1/4" STEEL STRAPPING (4 REQD, 2 PER JOINT). SEE GENERAL NOTE "N" ON PAGE 2.
- 7 ANTI-CHAFING NEUTRAL BARRIER MATERIAL, POSITION BETWEEN CONTAINERS AND STRAPPING AT POINTS OF CONTACT.



PROCEDURES FOR SHIPMENT OF PARTIAL UNITS LENGTHWISE




POSITIONING OF PARTIAL CROSS-WISE UNIT IN A LAYER

SPECIAL NOTES:

- SHIPMENTS OF PROPELLING CHARGES SHOULD CONSIST OF FULL-HEIGHT AND FULL-LAYER UNITS TO THE MAXIMUM EXTENT POSSIBLE. HOWEVER, THE END OF A LOT, OR THE QUANTITY OF ITEMS NEEDED TO FILL A REQUISITION, MAY NECESSITATE THE SHIPMENT OF ONE OR MORE LESS-THANFULL PALLET UNITS WITHIN A LOAD. THE PROCEDURES ON THIS PAGE ARE PRESENTED AS GUIDANCE IN THE SHIPMENT OF A PARTIAL UNIT WITHIN A
- THE PALLET UNIT SHOWN IN THE SHIPMENT OF PARTIAL UNITS VIEW IS THE ROUTED DUNNAGE METHOD UNIT (BASIC HEIGHT). THE DEPICTED PROCEDURES ARE ALSO APPLICABLE FOR THE OTHER UNITS COVERED BY THIS DOCUMENT.
- A LESS-THAN-FULL HEIGHT PALLET UNIT OF CROSSWISE-POSITIONED PROPELLING CHARGES WHICH IS TO BE SHIPPED WITHIN A LAYER OF A LOAD HAS NO LIMITATIONS AS TO THE NUMBER OF LAYERS ON THE PARTIAL UNIT. THE DEPICTED PROCEDURES SHOW THE BRACING OF A 2-LAYER UNIT WITHIN A 4-LAYER LOAD. THE PRINCIPLES CAN BE ADAPTED TO SUIT OTHER SIZE PARTIAL LINITS
- A PARTIAL UNIT MUST CONSIST OF FULL LAYERS OF FOUR (4) CONTAINERS, CR AN APPROVED FILLER ASSEMBLY, AS DETAILED BY DRAWING 19-48-4042A/1-20PM1001, MUST BE INSTALLED IN THE PLACE OF OMITTED CONTAINERS.
- THE FILLERS AS REFERENCED IN SPECIAL NOTE 4 AND THE DUNNAGE DEPICTED ABOVE FOR THE SHIPMENT OF THE PARTIAL UNIT MAY BE REMOVED WHEN A SHIPMENT REACHES DESTINATION. OR IF DESIRED, THE FILLERS MAY REMAIN WITH THE UNIT DURING STORAGE (IF APPLICABLE) FOR POSSIBLE USE IN A FUTURE SHIPMENT.
- THE "POSITIONING OF PARTIAL CROSSWISE UNIT IN A LAYER" VIEW ABOVE DEPICTS A PORTION OF A CONVENTIONAL BOX CAR LOAD, HOWEVER, THE PROCEDURES ARE ALSO APPLICABLE FOR LOADS IN CARS EQUIPPED WITH LOAD DIVIDER BULK-
- FOR THE SHIPMENT OF A PARTIAL UNIT CONSISTING OF ONE OR TWO LAYERS, THE PROCEDURES SHOWN ON PAGE 120 MAY BE MORE ECONOMICAL.


- SUPPORT PIECE, 2" X 6" BY UNIT LENGTH (3 REQD). POSITION ON TOP OF THE STRAPPING BOARD OF A PALLET UNIT, OR THE CROSS PIECE OF THE TOP DUNNAGE ASSEMBLY, AS APPLICABLE.
- (2) RETAINER PIECE, 2" X 4" X 55" (2 REQD). NAIL TO THE SUPPORT PIECES, PIECES MARKED (1), W/2-10d NAILS AT EACH JOINT.
- PARTIAL-UNIT GATE (2 REQD.). SEE THE "PARTIAL-UNIT GATE 8" DETAIL BELOW. SEE GENERAL NOTE "M" ON PAGE 2 AND SPECIAL NOTE 3 AT LEFT.
- STRUT, 4" X 4" BY UNIT LENGTH MINUS 6" (3 REQD). TOENAIL TO THE PARTIAL-UNIT GATE, PIECE MARKED 3 , W/2-160 NAILS AT EACH END.
- STRAPPING BOARD, 2" X 4" BY A LENGTH TO SUIT (2 REQD). NAIL TO THE STRUTS, PIECES MARKED 4 , W/3-10d Nails at Each Joint.
- UNITIZING STRAP, 1-1/4" X ,031" OR ,035" BY A LENGTH TC SUIT STEEL STRAPPING ($2\ \text{REQD}$). PRE-POSITION.
- SEAL FOR 1-1/4" STRAPPING (4 REQD, 2 PER JOINT), SEE GENERAL NOTE "N" ON PAGE 2.



PARTIAL-UNIT GATE B


THE LOCATION OF THE VERTICAL PIECES MUST BE ADJUSTED TO MATCH THE VERTICAL PIECES OF THE APPLICABLE CENTER GATE, SO AS TO ALIGN WITH THE DUNNAGE PIECES OF A UNIT.

PROCEDURES FOR SHIPMENT OF PARTIAL UNITS CROSSWISE




SPECIAL NOTES .

- 1. SHIPMENTS OF PROPELLING CHARGES SHOULD CONSIST OF FULL-HEIGHT AND FULL-LAYER UNITS TO THE MAXIMUM EXTENT POSSIBLE. HOWEVER, THE END OF A LOT, OR THE QUANTITY OF ITEMS NEEDED TO FILL A REQUISITION, MAY NECESSITATE THE SHIPMENT OF ONE OR MORE LEFTOVER CONTAINERS, LEFTOVER CONTAINERS ARE DESCRIBED AS A QUANTITY OF CONTAINERS WHICH IS INSUFFICIENT TO FORM A FULL-LAYERED PARTIAL UNIT FOR SHIPMENT EITHER ON TOP OF A LOAD AS SHOWN ON PAGE 120 OR WITHIN A LAYER AS SHOWN ON PAGES 117 AND 118.
- 2. SHIPMENT OF LEFTOVER CONTAINERS IS APPLICABLE FOR CONUS AND OCONUS RAILROAD SHIPMENTS FROM DEPOT TO DEPOT OR FROM DEPOT TO POSTS, CAMPS, AND STATIONS, OR, UPON APPROVAL FROM HIGHER HEADQUARTERS, FOR SHIPMENTS FROM LOAD, ASSEMBLE, AND PACK PLANTS TO DEPOTS. CAUTION: A LOAD CONTAINING LEFTOVER CONTAINERS IN AN AMOUNT WHICH IS LESS THAN A FULL LAYER, AND SECURED TO THE TOP OF A FULL OR PARTIAL UNIT, MUST NOT BE DESTINED FOR SHIPMENT OVERSEAS BY WATER CARRIER.
- 3. THE PALLET UNIT SHOWN IS THE ROUTED DUNNAGE METHOD UNIT (BASIC HEIGHT). THE DEPICTED PROCEDURES ARE ALSO APPLICABLE FOR THE OTHER UNITS COVERED BY THIS DOCUMENT.
- 4. FOR THE ALTERNATED CONTAINERS UNITS AND FOR THE FLAT DUNNAGE METHOD UNITS THE UNITIZING STRAP MUST NOT GO AROUND THE INTERMEDIATE DUNNAGE ASSEMBLY. THE STRAP MUST BE THREADED BEHIND THE 2" X 2" PIECES OF THE ASSEMBLIES.
- OBVIOUSLY, A PALLET UNIT WITH ONE OR MORE CONTAINERS STRAPPED TO THE TOP MUST BE POSITIONED IN THE TOP LAYER OF A LOAD. THE PREFERRED LOCATION WOULD BE NEAR THE CENTER AREA OF A CAR IF A FULL LOAD IS BEING SHIPPED.
- 6. THE PROCEDURES ON THIS PAGE ARE APPLICABLE FOR THE SHIPMENT OF LEFTOVER CONTAINERS IN ANY OF THE LOADS DEPICTED HEREIN.




SECUREMENT OF THREE CONTAINERS



SECUREMENT OF PARTIAL UNIT ON TOP

THIS PROCEDURE IS APPLICABLE ONLY FOR USE IN A CROSSWISE LOAD. CAUTION: THE PARTIAL UNIT ON TOP IS LIMITED TO NOT MORE THAN TWO (2) LAYERS OF CONTAINERS. FOR SHIPMENT OF MORE THAN TWO LAYERS OF CONTAINERS, OR AN ALTERNATIVE METHOD FOR ONE OR TWO LAYERS, REFER TO THE PROCEDURES ON PAGE 118.

PROCEDURES FOR SHIPMENT OF PARTIAL UNITS



- 1/2" MINIMUM THICK PLYWOOD, UNIT LENGTH IN WIDTH (48" WIDE MAY BE USED) BY LOAD HEIGHT. NAIL TO THE TIE PIECES W/1-APPLI-CABLY SIZED NAIL EVERY 8" AND CLINCH. NOTE THAT THE APPLICABLE SEPARATOR GATE MAY BE USED IN LIEU OF PLYWOOD. POSI-TION WITH THE VERTICAL PIECES AGAINST THE CAR END WALL.

THIS VIEW DEPICTS LINING REQUIRED FOR A LENGTHWISE LOAD IN A CAR EQUIPPED WITH A STEEL END WALL.

TIE PIECE, 1" X 4" BY CAR WIDTH MINUS 1" (MINIMUM OF 2 REQD).


CAR SIDEWALL


THE PIECE, 1" X 4" BY RANDOM LENGTH. LOCATE SO AS TO BE UNDER THE "OVERHANG" OF THE PALLET UNITS. NOTE THAT THE UPPER 1" X 4" PIECE MAY BE POSITIONED ABOVE THE TOP OF THE LOAD.


1/4" MINIMUM PLYWOOD, 1/8" MINIMUM HARDBOARD, OR .060" MINIMUM THICH SOLID WALL FIBERBOARD. NAIL PLYWOOD OR HARDBOARD TO 1" X 4" W/1 A PPLICABLY SIZED NAIL EVERY 8". STAPLE FIBERBOARD TO 1" X 4" W/1 STAPLE PURPY 6". NOTE THAT SEPARATOR GATES, OR SIMILARLY POSITIONED VERTICAL 1" X 6" LUMBER, MAY BE USED PROVIDING THEY ARE TIED TOGETHER TO PREVENT DISLODGEMENT.

SIDEWALL LINING
THIS VIEW DEPICTS LINING REQUIRED FOR A CROSSWISE
SHIPMENT IN A CAR EQUIPPED WITH A STEEL SIDEWALL,
NOTE THAT IF THE CAR IS EQUIPPED WITH A STEEL-FACED
PLUG DOOR, THE SPECIAL LINING WILL ALSO BE REQUIRED IN
THE DOORWAY AREA IF THE SPECIFIED DOORWAY PROTECTION
DOES NOT SUFFICE.

DETAILS









BEVEL-CUT

BEVEL CUTTING THE STRUTS AS SPECIFIED WILL FACILITATE INSTALLING THE STRUTS WITH A "DRIVE FIT"; CAUTION: DO NOT BEVEL A CORNER MORE THAN ONE-HALF INCH (1/2").




STRUT INSTALLATION SEE GENERAL NOTE "T" ON PAGE 2 FOR ADDITIONAL STRUT INSTALLATION GUIDANCE.




TYPICAL STRUT BRACING
SEE GENERAL NOTE "S" ON PAGE 2.

DETAILS



ALTERNATIVE GATE HOLD-DOWN


THIS VIEW DEPICTS AN ALTERNATIVE METHOD OF CENTER GATE HOLD DOWN WHICH CAN BE USED IF DESIRED, PROVIDING THE CAR HAS MAILABLE SIDEWALLS. THIS METHOD MAY BE APPLIED IN LIEU OF USING THE GATE HOLD DOWN PIECES WHICH ARE PART OF A CENTER GATE, OR IN LIEU OF THE 2" X 4" GATE HOLD DOWN PIECES WHICH SPAN THE CENTER VOID AREA AND ARE NAILED TO THE CENTER GATES. NOTE: FOR A GATE NOT LOCATED IN OR NEAR THE DOCKWAY AREA, THE GATE HOLD-DOWN CLEAT MAY BE DOUBLED AND NAILED TO THE CAR SIDEWALL TO PROVIDE A HOLD-DOWN.





CENTER GATE MODIFICATION


THE MODIFICATION PROCEDURES SHOWN IN THIS VIEW ARE APPLICABLE FOR THE CENTER GATES WHICH HAVE THE VERTICAL PIECES INSET FROM THE END OF THE HORIZONTAL PIECES AS SHOWN ABOVE. THE RISER PIECE WILL PROVIDE A MEANS FOR CONTACTING THE GATE WITH THE GATE HOLD-DOWN AS SHOWN IN THE "ALTERNATIVE GATE HOLD-DOWN" DETAIL AT THE TOP OF THIS PAGE.

DETAILS











THIS VIEW SHOWS THE STRUT ASSEMBLY INSTALLED BETWEEN THE LOAD DIVIDER BULKHEADS. NOTE THE 1/2" TO 3/4" (TOTAL) SPACE INTENTIONALLY PROVIDED BETWEEN THE ASSEMBLY AND THE BULKHEADS.




STRUT ASSEMBLY FOR 2-PIECE BULKHEADS

A STRUT ASSEMBLY IS REQUIRED WHEN THE LOAD BEHIND EITHER LOAD DIVIDER BULKHEAD EXCEEDS 50,000 POUNDS OF CLASS A OR CLASS B EXFLOSIVES. A STRUT ASSEMBLY IS NOT REQUIRED FOR LOADS OF CLASS C EXPLOSIVES, REGARDLESS OF THE WEIGHT OF THE LOAD. NOTE: TWO 2) ASSEMBLIES AS SHOWN ARE REQUIRED FOR A 2-PIECE BULKHEAD IF NOT LATERALLY ALIGNED. SEE "NOTE CEED" BELOW.



PROVISIONS FOR BOX CARS EQUIPPED WITH LOAD DIVIDER BULKHEADS


PROJECT FSA 43B/1-63



THIS VIEW SHOWS THE INSTALLATION OF A "FILL PIECE" IN A CAR EQUIPPED WITH A STANDARD ADJUSTABLE SIDE FILLER.

NOTE 1:

NAILING OF "FILL MECES" IS NOT REQUIRED EXCEPT THAT EACH "FILL MECE" LOCATED NEAREST THE DOOR OPENINGS OF THE CAR WILL BE SECURED AGAINST LONGITUDINAL MOVEMENT W/1-64 NAIL DRIVEN THROUGH THE SIDE FILLER PANEL AND INTO THE "FILL MECE".



TYPICAL TYPE B

THIS VIEW SHOWS A TYPICAL SECTION OF A CAR EQUIPPED WITH HEAVY DUTY, STEEL REINFORCED, ADJUSTABLE SIDE FILLES. A "FILL PIECE", AS SHOWN IN THE "TYPICAL TYPE A" DETAIL ABOVE, IS NOT REQUIRED IN CARS SO EQUIPPED.