

# LOADING AND BRACING (CL & LCL) IN BOX CARS OF PALLETIZED COMPLETE ROUNDS PACKED IN CYLINDRICAL METAL CONTAINERS MI59 SERIES CONTAINER

#### INDEX

<u>ITEM</u>	PAG	<u>E</u> (S
GENERAL NOTES	- 2.	3
MATERIAL SPECIFICATIONS	,	2
PALLET UNIT DETAIL	_	2
TYPICAL FULL LOAD PROCEDURES	- 4-	.13
DETAILS	- 11-	.17
LCL PROCEDURES FOR CARS EQUIPPED WITH MECHANICAL BRACING DEVICES	-18	5.)
LCL PROCEDURES FOR CONVENTIONAL BOX CAR	- 2n-	<i>ω</i> Λ
GENERAL DETAILS	_ /5_	51
PROVISIONS FOR BOX CARS EQUIPPED WITH LOAD DIVIDER BULKHEADS	- 42- - 52-	53

THIS OUTLOADING PROCEDURE DRAWING INCLUDES PROCEDURES FOR CONVENTIONAL TYPE BOX CARS, BOX CARS EQUIPPED WITH MECHANICAL BRACING DEVICES OF VARIOUS DESIGN AND MANUFACTURE AND CUSHIONED BOX CARS EQUIPPED WITH LOAD DIVIDER BULKHEADS.

REVISIONS		pt/tcm	F	HNICIAN ENGINEER
DEV T	SMCAC - D	m w	SMCAC-DEO ! Freuele	WF Const
DED DE	APPROVED, Ú.	APPROVED, U.S. ARMY ARMAMENT, MUNITIONS AND CHEMICAL		
DEV	~)a	en	c Anag	WILL
D€O D€	MATERIEL COM	HMAND (AMC)	ONMANDING GENER	
DEV	wu		FENSE AMMUNITION	CENTER AND SCHOOL
DED DED	U.S. ARI	MY MA	TERIEL	COMMAND
DEV	FEBRUARY 1992			
DE DE	CLASS	DIVISION	DRAWING	FILE
OEV OEO	19	48	4212/3	5PM
D€				1003

#### GENERAL NOTES

- A. THIS DOCUMENT HAS BEEN PREPARED AND ISSUED IN ACCORDANCE WITH AR 740-1 AND AUGMENTS TM 743-200-1 (CHAPTER 5).
- THE OUTLOADING PROCEDURES SPECIFIED IN THIS DRAWING ARE APPLICABLE FOR THE M159 SERIES COMPLETE ROUND CONTAINER WHEN UNITIZED ON 35" X 45-1/2" FOUR WAY ENTRY PALLET. SEE THE PICTORIAL VIEW ON PAGE 3. REFER TO THE U.S. ARMY AMC (DARCOM) DRAWING 19-48-4079/3-20PM1002 FOR UNITIZATION PROCEDURES FOR THE M159 SERIES CONTAINER.
- C. THE OUTLOADING PROCEDURES DEPICTED WITHIN THIS DOCUMENT ARE APPLICABLE FOR SHIPMENTS IN CONVENTIONAL TYPE BOX CARS, FOR SHIPMENTS IN BOX CARS EQUIPPED WITH VARIOUS TYPES OF SELF-CONTAINED MECHANICAL BRACING DEVICES AND FOR SHIPMENTS IN CUSHIONED BOX CARS EQUIPPED WITH LOAD DIVIDER BULKHEADS.
- ALL THE LOADS SHOWN HEREIN ARE TYPICAL. BECAUSE OF THIS FACT, IT IS MOST LIKELY THAT THE ACTUAL QUANTITY TO BE SHIPPED WILL NOT BE DEPICTED IN ANY OF THE LOAD IN G PROCEDURES. A LOAD PLAN SHOULD BE DEVELOPED WHICH WILL BE THE MOST EFFICIENT AS TO THE AMOUNT OF DUNINAGE REQUIRED AND AS TO THE EASE OF LOAD IN G FOR THE QUANTITY TO BE SHIPPED. THE LOAD PLANN IN G CHART ON PAGE 21 MAY BE USED IN CONJUNCTION WITH THE DEPICTED LOADING PROCEDURES FOR GUIDANCE.
- THE SELECTION OF RAIL CARS FOR THE TRANSPORT OF PALLETIZED UNITS OF COMPLETE ROUNDS IS THE RESPONSIBILITY OF THE ORIGINATING CARRIER AND THE SHIPPER. ONLY CARS WHICH HAVE "SOUND" FLOORS AND ARE IN OTHERWISE PROPER CONDITION, IN ACCORDANCE WITH THE REQUIREMENTS OF THE APPLICABLE REGULATORY DOCUMENTS, WILL BE SELECTED ..
- WHEN SELECTING RAIL CARS, EVERY EFFORT SHOULD BE MADE TO OBTAIN BOX CARS THAT DO NOT HAVE BOWED END WALLS. CARS HAVING BOWED ENDS CAN BE USED, HOWEVER, IF AN END WALL IS BOWED OUTWARD MORE THAN TWO INCHES (2"), EITHER FROM SIDE TO SIDE OR FROM FLOOR TO ROOF, AN END OF-CAR BULKHEAD MUST BE INSTALLED TO PROVIDE A "SQUARED OFF" SURFACE FOR THE LOAD AT THE END OF THE CAR. REFER TO PAGE 45 FOR GUIDANCE.
- G. BOX CARS EQUIPPED WITH CONVENTIONAL SLIDING DOORS HAVE BEEN SHOWN, HOWEVER, THE DEPICTED OUTLOADING PROCEDURES ARE ALSO APPLICABLE FOR CARS EQUIPPED WITH PLUG DOORS. <u>CAUTION</u>: DUNNAGE MATERIAL MUST NOT BE NAILED TO ANY PLUG DOORS, WHETHER AUXILLARY OR MAIN. ALSO, AFTER THE PLUG DOORS ON A CAR ARE CLOSED AND READY FOR THE INSTALLATION OF CAR SEALS, A PIECE OF WIRE OF SUITABLE SIZE WILL BE USED IN ADDITION TO, AND IN CONJUNCTION WITH EACH CAR SEAL USED TO SEAL THE CAR. THE WIRE WILL BE THREADED THRU THE HOLES IN THE DOOR LATCH ASSEMBLY ONE OR MORE TIMES, AND THE WIRE ENDS WILL BE TWISTED TOGETHER. TWISTED TOGETHER.
- THE USE OF AN OFFSET LOADING PATTERN WILL FACILITATE LOADING AND UNLOADING OPERATIONS IN THE DOORWAY AREA OF THE CAR. WHEN POSSIBLE TO DO SO, A FULL LOAD SHOULD BE BUILT USING AN OFFSET LOADING PATTERN. FOR INSTANCE, A LOAD CONSISTING OF AN EVEN NUMBER OF LOAD UNITS AND HAVING TWO MORE LOAD UNITS IN ONE END OF THE CAR THAN IN THE OPPOSITE END, OR A LOAD CONSISTING OF AN ODD NUMBER OF LOAD UNITS AND HAVING ONE MORE LOAD UNIT IN ONE END THAN IN THE OTHER, IS CONSIDERED TO BE AN OFFSET LOAD.
- OTHER TYPES OF LADING ITEMS MAY BE LOADED IN CARS WHICH ARE PARTIALLY LOADED WITH PALLETIZED UNITS OF COMPLETE ROUNDS PROVIDING THE TO PROVIDING THE TOTAL LOADED WITH PALLETIZED UNITS OF COMPLETE ROUNDS — ROVIDING THE TOTAL LOAD IS COMPATIBLE, EXISTING DIRECTIVES ARE NOT VIOLATED, AND THE OTHER LADING ITEMS ARE BLOCKED AND BRACED TO EQUAL THE BLOCKING AND BRACING CRITERIA SPECIFIED HEREIN. MIXED ITEMS TO BE SHIPPED IN CARS EQUIPPED WITH MECHANICAL BRACING DEVICES MUST BE SEPARATELY BLOCKED, USING THE PROCEDURES SHOWN FOR THESE CARS AS GUIDANCE.

#### (CONTINUED AT RIGHT)

#### MATERIAL SPECIFICATIONS

LUMBER ----: FED SPEC MM-L-751; DUNNAGE LUMBER. SEE TM 743-200-1. ----- :FED SPEC FF-N-105; COMMON. STAPLES-----FED SPEC FF-N-105; SENCO QUALITY OR EQUAL. STRAPPING, STEEL---: ASTM D 3953; FLAT STRAPPING, TYPE 1 OR 2, HEAVY DUTY, COATED FINISH (ORGANIC), ZINC-COATED (GRADE 2), OR UNCOATED. ASTM D 3953; CLASS H, FINISH A, B ( GRADE 2 ), OR C, TYPE D, STRAP\_SEAL----:: STYLE I, II, OR IV.

STRAP STAPLE -----: COMMERCIAL GRADE.

PLYWOOD ----FED SPEC NN-P-530; GROUP B, CONSTRUCTION AND INDUSTRIAL PLYWOOD, INTERIOR WITH EXTERIOR GLUE, GRADE C-D. IF SPECIFIED GRADE IS NOT AVAILABLE, A BETTER INTERIOR OR AN EXTERIOR GRADE MAY BE SUBSTITUTED.

WIRE ----- :FED SPEC QQ-W-461

#### ( GENERAL NOTES CONTINUED )

- K. DUNNAGE LUMBER SPECIFIED THROUGHOUT THIS PROCEDURAL DRAWING IS OF DUNINAGE LUMBER SPECIFIED THROUGHOUT THIS PROCEDURAL DRAWING IS OF NOMINAL SIZE. FOR EXAMPLE, 2" X 4" MATERIAL IS ACTUALLY 1-1/2" THICK BY 3-1/2" WIDE AND 2" X 6" MATERIAL IS ACTUALLY 1-1/2" THICK BY 5-1/2" WIDE. IF THOSE MEMBERS SPECIFICALLY IDENTIFIED AS "STRUTS" WITHIN THE KEY NUMBERS OF A DEPICTED LOAD ARE SPECIFIED TO BE 4" X 4" MATERIAL, IT IS PERMISSIBLE TO USE TWO LAMINATED PRICES OF 2" X 6" MATERIAL IN LIEU OF EACH 4" X 4" STRUT. DOUBLED 2" X 6" STRUTS WILL BE LAMINATED W/1-10d NAIL EVERY 6".
- NOTICE: A STAGGERED NAILING PATTERN WILL BE USED WHEREVER POSSIBLE WHEN NAILS ARE DRIVEN INTO JOINTS OF DUNNAGE ASSEMBLIES. ALSO, A STAGGERED NAILING PATTERN WILL BE USED WHEN DUNNAGE IS NAILED TO THE FLOOR OR SIDEWALL OF THE TRANSPORTING VEHICLE, OR WHEN LAMINATING DUNNAGE. THE NAILING PATTERN WILL BE ADJUSTED AS REQUIRED SO THAT A NAIL DOES NOT PENETRATE INTO OR NEAR A CRACK BETWEEN FLOOR BOARDS OR SIDEWALL BOARDS. ADDITIONALLY, THE NAILING PATTERN FOR AN UPPER PIECE OF LAMINATED DUNNAGE WILL BE ADJUSTED AS REQUIRED SO THAT A NAIL FOR THAT PIECE WILL NOT BE DRIVEN THROUGH, ONTO, OR RIGHT BESIDE A NAIL IN A LOWER PIECE.
- M. POWER DRIVEN STAPLES MAY BE USED AS ALTERNATIVE FASTENERS FOR NAILS WHEN POWER DRIVEN STAPLES MAY BE USED AS ALTERNATIVE FASTENERS FOR NAILS WHEN CONSTRUCTING DUNNAGE ASSEMBLIES WHICH ARE TO BE USED IN THE DELINEATED CAR LOADS SHOWN THROUGHOUT THIS DRAWING. THE STAPLES TO BE USED MUST BE EQUAL IN LENGTH TO THE SPECIFIED NAIL SIZE AND MUST BE SUBSTITUTED ON A ONE STAPLE FOR ONE NAIL BASIS. STAPLES WHICH ARE 2" OR LESS IN LENGTH SHOULD BE IN ACCORDANCE WITH FEDERAL SPECIFICATION FF-N-105 AS NEARLY AS PRACTICABLE. STAPLES WHICH ARE LONGER THAN 2" WILL BE A COMMERCIAL GRADE, OF A QUALITY EQUIVALENT TO THOSE MANUFACTURED BY SENCO PRODUCTS INCORPORATED. NOTE: STAPLES WILL NOT BE SUBSTITUTED FOR NAILS IN ANY LOAD-RESTRAINING FLOOR DUNNAGE APPLICATION.
- N. WHEN STEEL STRAPPING IS SEALED AT AN END-OVER-END LAP JOINT, A MINIMUM OF ONE (1) SEAL WITH TWO (2) PAIR OF NOTCHES WILL BE USED TO SEAL THE JOINT WHEN A NOTCH-TYPE SEALER IS BEING USED. A MINIMUM OF TWO (2) SEALS, BUTTED TOGETHER, WITH TWO (2) PAIR OF CRIMPS FER SEAL WILL BE USED TO SEAL THE JOINT WHEN A CRIMP-TYPE SEALER IS BEING USED. REFER TO THE "STRAP JOINT A" AND "STRAP JOINT B" DETAILS ON PAGE 44 FOR GUIDANCE.
- O. THROUGHOUT THIS PROCEDURAL DRAWING, PORTIONS OF THE BLOCKING COMPONENTS AND OF THE DEPICTED CARS, SUCH AS A CAR SIDE WALL, HAVE BEEN OMITTED FROM THE LOAD VIEW FOR CLARITY PURPOSES.
- THE NUMBER OF LADING UNITS MAY BE ADJUSTED TO FIT THE SIZE OF THE BOX. CAR BEING LOADED OR THE QUANTITY TO BE SHIPPED, HOWEVER, THE APPROVED METHODS SPECIFIED HEREIN MUST BE FOLLOWED AS CLOSELY AS POSSIBLE FOR BLOCKING, BRACING, AND STAYING OF THE UNITS. NOTICE: A SHIPMENT WILL BE POSITIONED IN THE RAIL CAR IN COMPLIANCE WITH THE WEIGHT DISTRIBUTION REQUIREMENTS OF THE AAR.
- CONVERSION TO METRIC EQUIVALENTS: DIMENSIONS WITHIN THIS DOCUMENT ARE EXPRESSED IN INCHES, AND WEIGHTS ARE EXPRESSED IN POUNDS. WHEN NECESSARY, THE METRIC EQUIVALENTS MAY BE COMPUTED ON THE BASIS OF ONE INCH EQUALS 25.4MM AND ONE POUND EQUALS 0.454KG.

#### GENERAL NOTES

# (FOR CONVENTIONAL TYPE BOX CARS)

- IF THE CAR BEING USED FOR A SHIPMENT IS EQUIPPED WITH A NAILABLE METAL FLOOR AND A NAIL SIZE FOR FLOOR NAILING IS MARKED ON THE SIDEWALL OF THE CAR, THAT GUIDANCE SHOULD BE APPLIED TO THE NAILING OF THE "DOOR-WAY BLOCKING" PIECES IN THE FULL LOADS AND TO THE NAILING TO THE CAR FLOOR OF THE LCL BRACES AND KINEE BRACE ASSEMBLIES IN THE LESS-THAN-FULL LOADS, IF A NAIL SIZE IS NOT SPECIFIED IN THE CAR, 304 NAILS SHOULD BE USED IN LIEU OF THOSE SPECIFIED IN THE APPLICABLE KEY NUMBERS. SEE GENERAL NOTE "L" ABOVE. NOTE "L" ABOVE.
- NOTICE: WHEN POSITIONING PALLETIZED UNITS IN A CAR, THEY SHOULD BE PLACED TIGHTLY AGAINST A CAR SDEWALL AND ARE TO BE PRESSED TIGHTLY TOGETHER LENGTHWISE SO AS TO ACHIEVE A TIGHT LOAD. TO AD IN ACHIEVING TIGHTNESS LENGTHWISE IN A FULL LOAD, A LOAD-COMPRESSING JACK MAY BE EMPLOYED IN THE AREA OF THE CENTER GATES TO MOVE THE PALLETIZED UNITS INTO THEIR FINAL SHIPPING POSITION. A HYDRAULIC JACK IS RECOMMENDED FOR THIS OPERATION. CAUTION: WHEN USING A JACK TO COMPACT A LOAD, THE JACK MUST BE USED AGAINST STRONG POINTS OF THE PALLETIZED UNITS, SUCH AS THE JOINTS BETWEEN THE LAYERS OF CONTAINERS ON THE UNIT. PADDING, OF 2-INCH (2") THICK LUMBER OR ANY OTHER MATERIAL OF SIMILAR CONSISTENCY SHOULD BE PLACED BETWEEN THE JACK AND THE LADING. SHOULD BE PLACED BETWEEN THE JACK AND THE LADING.
- LOAD-BLOCKING STRUTS WHICH ARE 48" OR LONGER MUST BE STIFFENED BY THE APPLICATION OF HORIZONTAL AND VERTICAL STRUT BRACING AS SHOWN IN THE LOAD ON PAGE 4. BRACING IS NOT REQUIRED IF THE STRUTS FOR THE LOAD BEING SHIPPED ARE SHORTER THAN 48". THE LENGTH OF THE LOAD-BLOCKING STRUTS SHOULD BE KEPT AS SHORT AS POSSIBLE (APPROX 18" MINIMUM), BUT IN THE EVENT IT IS NECESSARY TO USE STRUTS WHICH ARE 8'-0" OR MORE IN LENGTH, IT WILL BE NECESSARY TO APPLY AN ADDITIONAL SET OF HORIZONTAL AND VERTICAL STRUT BRACING PIECES. STRUT BRACING SHOULD BE APPLIED SO AS TO PROVIDE NEARLY EQUAL SPACES BETWEEN THE BRACING PIECES AND THE CENTER GATES AND/OR BETWEEN ADJACENT STRUT BRACING PIECES. NOTE THAT HORIZONTAL STRUT BRACING PIECES FOR THE UPPER LEVEL OF STRUTS FOR ALL BUT THE UPPERMOST THER OF A LOAD MAY BE DIFFICULT TO APPLY TO THE TOP SURFACES OF THE STRUTS AS DEPICTED. STRUT BRACING WILL BE EQUALLY EFFECTIVE IF APPLIED TO THE UNDER SIDE OF THOSE STRUTS.

(CONTINUED ON PAGE 3)

#### (GENERAL NOTES CONTINUED)

- U. TO ACHIEVE A TIGHTLY BLOCKED LOAD, A STRUT WILL BE CUT SLIGHTLY LONGER THAN THE MEASURED DISTANCE BETWEEN THE STRUT BEARING AREAS ON THE TWO CENTER GATES. ONE END OF THE STRUT WILL BE POSITIONED AT ITS BEARING AREA JUST ABOVE THE STRUT LEDGER ON ONE GATE. THE OTHER END, WHICH CAN BE BEVELED ON THE LOWER CORNER, IF DESIRED, WILL THEN BE DRIVEN DOWNWARD UNTIL IT CONTACTS THE STRUT LEDGER ON THE OTHER GATE, EACH BND OF THE STRUT WILL BE TOENAILED TO THE ADJACENT CENTER GATE, AS SPECIFIED WITHIN THE KEY NUMBERS FOR A LOAD, IN SUCH A MANNER SO THAT AS NEARLY AS PRACTICAL FIECE OF THE CENTER GATE, SEE THE "BEVEL CUT" DETAIL ON PAGE 47 FOR BEVELING INSTRUCTIONS AND THE "STRUT INSTALLATION" DETAIL ON THAT PAGE FOR A PICTORIAL VIEW SHOWING THE "ROPER POSITIONING OF A BEVELED STRUT FOR INSTALLATION. NOTE THAT THE UPPER CORNER NEEDS TO BE BEVELED ONLY IF THE STRUTS ARE VERY SHORT. IF ONLY ONE BND IS BEVEL-CUT, THE BEVELED EDGE WILL BE PLACED IN THE DOWNWARD POSITION SO THAT IT WILL ALLOW THE STRUT BND TO SLIDE MORE FREELY DOWN THE FACE OF THE VERTICAL PIECE ON THE ADJACENT CENTER GATE AS THE STRUT IS DRIVEN DOWN INTO ITS FINAL BLOCKING POSITION.
- V. FOR ADDITIONAL GUIDANCE, ATTENTION IS DIRECTED TO THE "SPECIAL NOTES" SECTIONS WHICH ARE IMMEDIATELY ADJACENT TO THE DEPICTED OUTLOADING METHODS.

#### GENERAL NOTES

(FOR BOX CARS EQUIPPED WITH MECHANICAL BRACING DEVICES)

- W.. THE OUTLOADING PROCEDURES FOR BOX CARS EQUIPPED WITH MECHANICAL BRACING DEVICES MAY BE ADAPTED AS REQUIPED TO FACILITATE THE USE OF BOX CARS EQUIPPED WITH VARIOUS TYPES OF SELF-CONTAINED MECHANICAL BRACING DEVICES, HOWEVER, FIXED OR ADJUSTABLE WALL MEMBERS AND DOORWAY MEMBERS WITHIN THESE CARS MUST PROVIDE FOR THE INSTALLATION OF LOAD BLOCKING CROSS MEMBERS AT THE HEIGHTS SPECIFIED. CAUTION: BOX CARS EQUIPPED WITH MEMBERS WHICH DO NOT MEET THE LOCATION REQUIREMENTS MUST NOT BE USED.
  - 1. FOR BLOCKING THE LOADS WHICH ARE DEPICTED, A CROSS MEMBER WILL NOT BE RELIED UPON TO RETAIN MORE LADING ON EITHER SIDE THAN AS SHOWN. VOIDS LENGTHWISE WITHIN THE LOAD MUST BE HELD TO A MINIMUM AND CROSS MEMBERS MUST BE PLACED AGAINST THE LADING AS TIGHTLY AS THE SPACING OF THE LOCKING HOLES IN THE WALL MEMBERS PERMIT. LOCKING BARS (LEVER JACKS) SHOULD BE USED FOR THIS PURPOSE. AN ADDITIONAL 1/2" OF ADJUSTMENT CAN BE MADE BY TURNING A CROSS MEMBER END-FOR-END WHEN LOCKING PINS ON THE MEMBER ARE OFF-CENTER. NOTE: IT IS RECOMMENDED THAT EACH CROSS MEMBER BE INSTALLED WITH THE ENDS ATTACHED AS NEARLY AS POSSIBLE IN "MATED" POSITIONS (AT EQUAL) HEIGHTS AND AT EQUAL DISTANCES FROM THE END OF THE CAR).
  - 2. CAUTION: ALL BLOCKING AND BRACING COMPONENTS IN EMPTY CARS AND ALL UNUSED COMPONENTS IN LOADED CARS MUST BE "SECURED" FOR SHIPMENT--AD JUSTABLE WALL MEMBERS TO VERTICAL WALL ATTACHMENT RAID, AND CROSS MEMBERS TO AD JUSTABLE WALL MEMBERS, OR TO FIXED HORIZONTAL WALL MEMBERS OR TO DOORWAY MEMBERS, AND DOORWAY MEMBERS TO DOOR POSTS. COMPONENTS ASSIGNED TO EACH CAR MUST REMAIN THEREWITH EVEN THOUGH UNUSED DURING SOME SHIPMENTS.
- X. IN A CAR EQUIPPED WITH ADJUSTABLE WALL MEMBERS, PROVIDING THE FIXED WALL MEMBERS WHICH ARE PRESENT IN SOME "ADJUSTABLE" CARS ARE NOT PROPERLY POSITIONED TO PROVIDE SIDE BEARING SURFACES BETWEEN THE UNITS AND THE CAR SIDEWALLS, ADJUSTABLE WALL MEMBERS (AS REQUIRED) MUST BE INSTALLED TO PROVIDE A MINIMUM OF ONE SURFACE AREA FOR SIDE BEARING AT SOME LOCATION WITHONTHE UPPER HALF OF EACH UNIT.
- Y- FOR ADDITIONAL GUIDANCE, ATTENTION IS DIRECTED TO THE "SPECIAL NOTES"
  SECTIONS WHICH ARE IMMEDIATELY ADJACENT TO THE DEPICTED OUTLOADING METHODS.

#### GENERAL NOTES


(FOR CARS EQUIPPED WITH LOAD DIVIDER BULKHEADS)

- AÁ. CAUTION: FOR CUSHIONED BOX CARS EQUIPPED WITH LOAD DIVIDER BULKHEADS, ON LY CARS EQUIPPED WITH LOAD DIVIDERS MANUFACTURED BY EVANS, EQUIPCO, OR PRECO MAY BE USED. LOAD DIVIDERS MANUFACTURED BY TRANSCO ARE NOT ACCEPTABLE, WHETHER OF ALUMINUM OR STEEL CONSTRUCTION. THE DEPICTED PROCEDURES ARE APPLICABLE FOR CARS OF VARIOUS LENGTHS AND WIDTHS. THE AAR MECHANICAL DESIGNATION CLASS FOR THESE CARS, AS IDENTIFIED IN THE OFFICIAL RAILWAY EQUIPMENT REGISTER, WILL BE RBL, XL, OR XLI.
- BB. THE USE OF LOAD DIVIDER EQUIPPED CARS WILL ELIMINATE THE NEED FOR CENTER GATES AND STRUTS, AND GATE HOLD DOWNS (WHEN APPLICABLE) WHICH ARE REQUIRED IN CONVENTIONAL BOX CAR LOADS. THIS WILL ACCOUNT FOR A CONSIDERABLE SAVING IN MATERIAL AND LABOR COSTS. THEREFORE, EVERY EFFORT SHOULD BE MADE TO ACQUIRE CUSHIONED CARS EQUIPPED WITH LOAD DIVIDERS FOR SHIPMENT OF COMPLETE ROUNDS. NOTICE: ONLY CUSHIONED CARS THAT HAVE SLIDING CENTER SILL TYPE CUSHIONING DEVICES OR END-OF-CAR TYPE DEVICES WHICH HAVE AT LEAST FIFTEEN INCHES (15") OF TRAVEL ARE ACCEPTABLE.
- CC. IF NAILING TO A CAR SIDEWALL IS NOT REQUIRED, BOX CARS EQUIPPED WITH ADJUSTABLE SIDE FILLERS THAT HAVE 3/8" OR THICKER PANELS MAY BE USED, HOWEVER, THESE SIDE FILLERS MUST NOT BE USED FOR LATERAL BLOCKING; THEY MUST BE RETRACTED AND LOCKED AGAINST THE CAR SIDEWALL. A "FILL PIECE" MUST BE INSTALLED IN THE VOID BETWEEN THE CAR SIDEWALL AND THE SIDE FILLER PANEL. SEE THE "TYPICAL TYPE A" VIEW ON PAGE 33 FOR GUIDANCE. IF THE BACK OF THE SIDE FILLER PANELS ARE REINFORCED WITH VERTICAL AND HORIZONTAL STEEL MEMBERS AS SHOWN IN THE "TYPICAL TYPE B" VIEW ON PAGE 53, THE "FILL PIECE" MATERIAL IS NOT REQUIRED.
- DD. NOTICE: AFTER THE LOAD DIVIDER BULKHEADS ARE POSITIONED AGAINST THE LADING, AND THE LOCKING PINS ARE ENGAGED IN THE HOLES OF THE RAILS, THE LOWER LOCKING PINS MUST BE INSPECTED TO ENSURE THAT THE PINS ARE FULLY ENGAGED IN THE LOCKING HOLES. IF THE PINS ARE NOT FULLY SEATED IN THE LOCKING HOLES, IF THE PINS WILL BE ALJUSTED AS REQUIRED SO THAT THE PINS WILL BE FULLY SEATED INTO THE LOCKING HOLES OF THE LOWER RAILS. IF PRESENT, DEBRIS MUST BE REMOVED FROM BENEATH THE LOCKING HOLES WHICH HAVE BEEN SELECTED FOR SECURING A LOAD DIVIDER BULKHEAD.

(CONTINUED AT RIGHT)

#### ( GENERAL NOTES CONTINUED )

- EE. A "STRUT ASSEMBLY" MUST BE INSTALLED BETWEEN THE LOAD DIVIDER BULKHEADS IS THE CAR CONTAINS CLASS A OR CLASS B EXPLOSIVES AND THE LOAD IN EITHER END OF THE CAR WEIGHS 50,000 POUNDS OR MORE, A STRUT ASSEMBLY IS NOT REQUIRED FOR LOADS OF CLASS C EXPLOSIVES. NOTE THAT THE STRUT ASSEMBLY MAY BE OMITTED FROM LOADS OF CLASS A OR B EXPLOSIVES WEIGHING 50,000 POUNDS WHEN THE LADING AND ADEQUATE BLOCKING AND BRACING ARE POSITIONED TO COMPLETELY FILL THE SPACE BETWEEN THE INSTALLED BULKHEADS AS SPECIFIED IN GENERAL NOTE "FF-3" BELOW, DETAILS OF STRUT ASSEMBLES FOR USE BETWEEN 2-PRECE BULKHEADS AND BETWEEN 1-PIECE BULKHEADS ARE SHOWN ON PAGE 52.
- FF. THE NORMAL LOADING PATTERN IN CARS EQUIPPED WITH LOAD DIVIDER: BULK-HEADS IS TO POSITION THE LADING BETWEEN A CAR END WALLAND A LOAD DIVIDER BULK-HEAD IN FULL LAYERS. OBVIOUSLY, A LOAD QUANTITY MUST THEN BE A MULTIPLE OF THE NUMBER OF PALLETIZED UNITS WHICH ARE IN ONE LOAD UNIT, A LOAD UNIT IS DEFINED AS A STACK OF CONTAINERS WHICH IS FULL CAR WIDTH BY FULL LOAD HEIGHT BY ONE UNIT IN LENGTH, IF THE QUANTITY TO BE SHIPPED CANNOT BE ATTAINED BY ADJUSTING THE NUMBER OF TIERS IN ONE OR BOTH ENDS OF A CAR, ONE OF THE FOLLOWING PROCEDURES MUST BE USED IN ORDER TO OBTAIN THE DESIRED QUANTITY.
  - ONE OR MORE RISERS CAN BE POSITIONED WITHIN A LOAD TO INCREASE A LOAD QUANTITY, SEE THE RISER PROCEDURES AND DETAILS ON PAGE 26 THRU 28.
  - 2. THE "GATES" AND "STRUTS" METHOD OF OMITTING A PALLET UNIT MAY BE USED TO ADJUST A LOAD QUANTITY DOWNWARD BY OTHER THAN A MULTIPLE OF A LOAD UNIT. SEE THE PROCEDURES ON PAGES 23 THRU 25 FOR GUIDANCE.
  - 3. AT LOCATION (S) WHERE K-BRACES MIGHT NORMALLY BE USED IN A LOAD IN A CONVENTIONAL CAR, LOAD DIVIDER BULKHEADS CAN BE POSITIONED. LOAD ING CAN THEN CONTINUE TOWARD THE CENTER OF THE CAR FROM EACH INSTALLED LOAD DIVIDER BULKHEAD, IN EVEN LAYERS WHICH ARE ONE OR MORE LESS IN HEIGHT THAN THE LOAD IN THE ENDS OF THE CAR. INSTALL CENTER GATES, STRUTS, AND GATE HOLD DOWNS AS SHOWN IN THE APPLICABLE CONVENTIONAL BOX CAR DRAWING HEREIN, TO PROVIDE FOR A TIGHT LOAD BETWEEN THE BULKHEADS.
  - 4. ONE OR MORE UNITS CAN BE POSITIONED IN CONTACT WITH A LOAD DIVIDER BULKHEAD ON THE CENTER-OF-CAR SIDE, BLOCK AND BRACE WITH LCL BRACES AS SHOWN ON PAGE 40 OR WITH KNEE BRACE ASSEMBLIES, AS SHOWN ON PAGE 36.
- GG. FOR ADDITIONAL GUIDANCE, ATTENTION IS DIRECTED TO THE "SPECIAL NOTES" SECTIONS WHICH ARE IMMEDIATELY ADJACENT TO THE DEPICTED OUTLOADING METHODS.




#### PALLET UNIT

CONTAINER ------30 EACH @ 68 LBS (APPROX)

CUBE -----38,5 CUBIC FEET (APPROX)

GROSS WEIGHT------2,176 LBS (APPROX)




- A 60'-8" LONG BY 9'-2" WIDE WOOD-LINED CONVENTIONAL TYPE BOX CAR EQUIPPED WITH 10'-0" WIDE DOOR OPEN INGS IS SHOWN. CARS OF OTHER DIMENSIONS AND CARS HAVING WIDER OR NARROWER, DOOR! OPEN INGS CAN BE USED.
- 2. A MAXIMUM OF SIXTY (60) PALLET UNITS, FOR AN APPROXIMATE LADING WEIGHT OF 130,560 POUNDS, CAN BE PLACED IN A 50'-6" LONG CAR WHEN USING THE DEPICTED PROCEDURES; FORTY-EIGHT (48) UNITS, FOR AN APPROXIMATE LADING WEIGHT OF 104,448 POUNDS, CAN BE LOADED IN A 40'-6" LONG CAR.
- ANTI-SWAY BRACING IS REQUIRED BETWEEN LATERALLY ADJACENT PALLET UNITS.
  TO PREVENT DISPLACEMENT OF THE ANTI-SWAY BRACE BETWEEN THE UPPER UNITS,
  A STOP PIECE MUST BE NAILED TO EACH CENTER GATE "B" AS SHOWN ON THE
  DETAIL ON PAGE 15.
- 4. TOP-OF-LOAD ANTI-SWAY BRACES, SHOWN AS PIECES MARKED ② IN THE LOAD ON PAGE 4, MUST BE INSTALLED IN EACH END OF THE CAR. FIVE (5) BRACES ARE REQUIRED IN EACH END OF A 60' CAR. FOUR (4) BRACES ARE REQUIRED IN EACH END OF 40' AND 50' CARS.
- CENTER GATE "B" MAY BE PARTIALLY FORMED FROM 1/2" OR THICKER PLYWOOD, IF DESIRED. PLYWOOD MAY BE USED IN LIEU OF THE 2" X 6" HORIZONTAL PIECES. SEE THE "PLYWOOD CENTER GATE ALTERNATIVE" DETAIL ON PAGE 46 FOR GUIDANCE
- 6. FOR EASE OF HANDLING, SPLIT CENTER GATES, WHICH ARE NOT DEPENDENT ON THE WIDTH OF THE CAR, MAY BE USED AS AN ALTERNATIVE TO THE CAR WIDTH GATES. IN LIEU OF EACH "CENTER GATE B", SHOWN AS PIECE MARKED (3) IN THE LOAD ON PAGE 4, INSTALL TWO (2) "CENTER GATES A" AS SHOWN ON PAGE 14. AFTER THE SPLIT GATES AND STRUTS HAVE BEEN INSTALLED, THE SPLIT GATES MUST BE TIED TOGETHER AS DEPICTED BY THE "TIE PIECE APPLICATION"!!

  DETAIL ON PAGE 46.
- 7. DOOR SPANNER TYPE GATE HOLD DOWN MAY BE USED IN LIEU OF THE DOUBLED 2" X 3" HOLD DOWNS ON CENTER GATE "B", PROVIDING THE CAR HAS NAILABLE SIDEWALLS. SEE THE DETAILS ON PAGE 48 FOR GUIDANCE.
- 8. DOUBLED 2" X 6" MATERIAL IS USED FOR THE STRUTS IN THE LOAD ON PAGE 4. IF A 50'-6" OR 40'-6" LONG CAR IS USED, 4" X 4" MATERIAL MAY BE USED AS SHOWN IN THE LOAD ON PAGE 6.
- 9. DOORWAY PROTECTION IS REQUIRED FOR ALL PALLET UNIT STACKS WHICH ARE COMPLETELY WITHIN THE DOORWAY AREA OR WHICH EXTEND INTO IT BY ONE-HALF OR MORE OF THE STACK WIDTH OR LENGTH. THE WOODEN GATE TYPE OF DOORWAY PROTECTION, SHOWN AS PIECE MARKED (?) IN THE LOAD ON PAGE 4, IS APPLICABLE FOR BOX CARS EQUIPPED WITH CONVENTIONAL SLIDING DOORS AND NAILABLE DOOR POSTS; OR NAILED FLOORLINE BLOCKING AND DOORWAY PROTECTION STRAPS MAY BE USED. REFER TO PAGES 49 THRU 51 FOR ALTERNATIVE DOORWAY PROTECTION FOR CARS EQUIPPED WITH CONVENTIONAL SLIDING DOORS. IF THE CAR TO BE LOADED IS EQUIPPED WITH PLUG TYPE DOORS OR COMBINATION PLUG AND SLIDING DOORS, NAILED FLOORLINE BLOCKING AND DOORWAY PROTECTION STRAPS MUST BE USED. SEE SPECIAL NOTE 10 BELOW.
- 10. IF NAILED FLOORLINE BLOCKING AN: DOORWAY PROTECTION STRAPS ARE USED, OMIT EACH LOWER ANTI-SWAY BRACE IN THE DOORWAY AREA; IN LIEU OF PIECE MARKED (2) ON PAGE 4, USE PIECES MARKED (3) THRU (6) ON PAGE 12. SEE SPECIAL NOTES 5 AND 6 ON PAGE 13 FOR GUIDANCE.
- 11. THE DEPICTED LOAD CAN BE REDUCED TO SUIT THE QUANTITY TO BE SHIPPED. A 2-TIER LOAD CAN BE REDUCED BY A MULTIPLE OF FOUR (4) PALLET UNITS OR A 1-TIER LOAD CAN BE REDUCED BY A MULTIPLE OF TWO (2) UNITS BY OMITTING ONE OR MORE LOAD UNITS FROM THE CENTER PORTION OF THE LOAD, OR THE ENTIRE TOP TIER CAN BE OMITTED. FOR OTHER METHODS OF REDUCING A LOAD, AND FOR TYPICAL ICL PROCEDURES, REFER TO PAGES 20 THRU 40 FOR GUIDANCE.
- 12. IF PALLET UNITS WHICH DO NOT CONTAIN A FULL QUANTITY OF CONTAINERS ARE TO BE TRANSPORTED, REFER TO PAGES 41 AND 44 FOR SHIPPING GUIDANCE.
- 13. FOR SHIPMENT OF ONE OR MORE LEFTOVER CONTAINERS, SEE THE "PROCEDURES FOR SHIPMENT OF LEFTOVER CONTAINERS" ON PAGE 43 FOR GUIDANCE.

BILL OF MATERIAL		
LUMBER	LINEAR FEET	BOARD FEET
1" X 4"	135	45
1" X 6"	80	40
2" X 2"	308	103
2" X 3"	31	16
2" X 4"	253	169
2" X 6"	506	506
NAILS	NO. REQD	POUNDS
6d.(2")	500	3
10d (3")	866	13-1/2
124 (3-1/4")	122	2
16d (3-1/2")	96	2-1/4

#### LOAD AS SHOWN



- A 50'-6" LONG BY 9'-2" WIDE WOOD-LINED CONVENTIONAL TYPE BOX CAR EQUIPPED WITH 10'-0" WIDE DOOR OPEN IN GS IS SHOWN. CARS OF OTHER DIMENSIONS AND CARS HAVING WIDER OR NARROWER, DOOR OPEN IN GS CAN BE USED.
- 2. A MAXIMUM OF SIXTY-EIGHT (68) UNITS, FOR AN APPROXIMATE LADING WEIGHT OF 147,968 POUNDS CAN BE PLACED IN A 60'-8" LONG CAR WHEN USING THE DEPICTED PROCEDURES; FORTY-EIGHT (48) UNITS, FOR AN APPROXIMATE LADING WEIGHT OF 104,448 POUNDS CAN BE LOADED IN A 40'-6" LONG CAR.
- 3. ANTI-SWAY BRACING IS REQUIRED BETWEEN LATERALLY ADJACENT PALLET UNITS, TO PREVENT DISPLACEMENT OF THE ANTI-SWAY BRACE BETWEEN THE UPPER UNITS, A STOP PIECE MUST BE NAILED TO EACH CENTER GATE "B" AS SHOWN ON THE DETAIL ON PAGE 15,
- 4. TOP-OF-LOAD ANTI-SWAY BRACES, SHOWN AS PIECES MARKED (2) IN THE LOAD ON PAGE 6 MUST BE INSTALLED IN EACH END OF THE CAR. FIVE (5) BRACES ARE REQUIRED IN EACH END OF A 60° CAR. FOUR (4) BRACES ARE REQUIRED IN EACH END OF 40° AND 50° CARS.
- CENTER GATE "B" MAY BE PARTIALLY FORMED FROM 1/2" OR THICKER PLYWOOD
  IF DESIRED. PLYWOOD MAY BE USED IN LIEU OF THE 2" X 6" HORIZONTAL
  PIECES. SEE THE "PLYWOOD CENTER GATE ALTERNATIVE" DETAIL ON PAGE 46
  FOR GUIDANCE.
- 6. FOR EASE OF HANDLING, SPLIT CENTER GATES, WHICH ARE NOT DEPENDENT ON THE WIDTH OF THE CAR, MAY BE USED AS AN ALTERNATIVE TO THE CAR WIDTH GATES. IN LIEU OF EACH "CENTER GATE B" SHOWN AS PIECE MARKED (3) IN THE LOAD ON PAGE 6, INSTALL TWO (2) "CENTER GATES A" AS SHOWN ON PAGE 14. AFTER THE SPLIT GATES AND STRUTS HAVE BEEN INSTALLED, THE SPLIT GATES MUST BE TIED TOGETHER AS DEPICTED BY THE "TIE PIECE APPLICATION" DETAIL ON PAGE 46.
- 7. DOOR SPANNER TYPE GATE HOLD DOWN MAY BE USED IN LIEU OF THE DOUBLED 2" X 3" HOLD DOWNS ON CENTER GATE "B", PROVIDING THE CAR HAS NAILABLE SIDEWALLS, SEE THE DETAILS ON PAGE 48 FOR GUIDANCE.
- 8. DOORWAY PROTECTION IS REQUIRED FOR ALL PALLET UNIT STACKS WHICH ARE COMPLETELY WITHIN THE DOORWAY AREA OR WHICH EXTEND INTO IT BY ONE-HALF OR MORE OF THE STACK WIDTH OR LENGTH. THE WOODEN GATE TYPE OF DOORWAY PROTECTION, SHOWN AS PIECE MARKED (3) IN THE LOAD ON PAGE 6, IS APPLICABLE FOR BOX CARS EQUIPPED WITH CONVENTIONAL SLIDING DOORS AND NAILABLE DOOR POSTS; OR NAILED FLOORLINE BLOCKING AND DOORWAY PROTECTION STRAPS MAY BE USED. REFER TO PAGES 49 THEN 21 FOR ALTERNATIVE DOORWAY PROTECTION FOR CARS EQUIPPED WITH CONVENTIONAL SLIDING DOORS, IF THE CAR TO BE LOADED IS EQUIPPED WITH PLUG TYPE DOORS OR COMBINATION PLUG AND SLIDING DOORS, NAILED FLOORLINE BLOCKING AND DOORWAY PROTECTION STRAPS MUST BE USED. SEE SPECIAL NOTE 9 BELOW.
- 9. IF NAILED FLOORLINE BLOCKING AND DOORWAY PROTECTION STRAPS ARE USED, OMIT EACH LOWER ANTI-SWAY BRACE IN THE DOORWAY AREA; IN LIEU OF PIECE MARKED (§) ON PAGE 6, USE PIECES MARKED (§) THRU (§) ON PAGE 12. SEE SPECIAL NOTES 5 AND 6 ON PAGE 13 FOR GUIDANCE.
- 10. THE DEPICTED LOAD CAN BE REDUCED `) SUIT THE QUANTITY TO BE SHIPPED. A 2-TIER LOAD CAN BE REDUCED BY A MULTIPLE OF FOUR (4) PALLET 'UNITS OR A 1-TIER LOAD CAN BE REDUCED BY A MULTIPLE OF TWO (2) UNITS BY OMITTING ONE OR MORE LOAD UNITS FROM THE CENTER PORTION OF THE LOAD, OR THE ENTIRE TOP TIER CAN BE OMITTED. FOR OTHER METHODS OF REDUCING A LOAD AND FOR TYPICAL ICL PROCEDURES, REFER TO PAGES 20 THRU 40 FOR GUIDANCE.
- IF PALLET UNITS WHICH DO NOT CONTAIN A FULL QUANTITY OF CONTAINERS ARE TO BE TRANSPORTED, REFER TO PAGES 41 AND 44 FOR SHIPPING GUIDANCE.
- FOR SHIPMENT OF ONE OR MORE LEFTOVER CONTAINERS, SEE THE "PROCEDURES FOR SHIPMENT OF LEFTOVER CONTAINERS" ON PAGE 43 FOR GUIDANCE.

BILL OF MATERIAL			
LUMBER	LINEAR FEET	BOARD FEET	
1" X 4"	120	40	
1" X 6"	80	40	
2" X 2"	282	94	
2" X 3"	31	16	
2" X 4"	158	106	
2" X 6"	180	180	
4" X 4"	68	91	
NAILS	NO. REQD	POUNDS	
6d (2")	444	2-3/4	
10d (3")	418	6-1/2	
124 (3-1/4")	110	2 1/2	
16d (3-1/2")	96	2-1/4	
VIRE, NO. 14 GAGI	48 REQD	7.10	


LOAD AS SHOWN

QUAN TITY

ITEM

WEIGHT (APPROX)

TOTAL WEIGHT----- 131,709 LBS (APPROX)




- 1. A 50'-6" LONG BY 9'-2" WIDE WOOD-LINED CONVENTIONAL TYPE BOX CAR EQUIPPED WITH 10'-0" WIDE DOOR OPENINGS IS SHOWN. CARS OF OTHER DIMENSIONS AND CARS HAVING WIDER OR NARROWER, DOOR OPENINGS CAN BE USED. SEE SPECIAL NOTE 3 BELOW.
- 2. A MAXIMUM OF SIXTY (60) UNITS, FOR AN APPROXIMATE LADING WEIGHT OF 130,560 POUNDS CAN BE PLACED IN A 601-8" LONG CAR WHEN USING THE DEPICTED PROCEDURES; THIRTY-SIX (36) UNITS, FOR AN APPROXIMATE LADING WEIGHT OF 78,336 POUNDS, CAN BE LOADED IN A 401-6" LONG CAR.
- 3. THE DEPICTED LOADING PATTERN IS ADEQUATE FOR CARS HAVING DOOR OPENINGS B! THRU 10! OR WIDER. IF THE CAR TO BE LOADED HAS DOOR OPENINGS LESS THAN 8!-0! WIDE AND NOT OF SUPFICIENT HEIGHT TO ALLOW PERSONNEL TO EXIT THE CAR OVER THE TOP OF THE LOAD, THE PALLETS SHOULD BE POSITIONED SO THERE ARE SIX (6) LOAD UNITS IN EACH BIND. NOTE THAT ALTHOUGH CARS HAVING DOOR OPENINGS AS NARROW AS 6!-0! WIDE CAN BE USED FOR FULL LOADS, LOADING IS PROGRESSIVELY MORE DIFFICULT AS THE WIDTH OF THE DOOR OPENING DECREASES.
- 4. IF THE "DOORWAY PROTECTION E" PROCEDURES AS SHOWN ON PAGE 51 ARE USED IN LIEU OF THE WOODEN DOOR GATE TYPE PROTECTION, PIECE MARKED (\$\frac{1}{2}\), NAILED FLOORLINE BLOCKING MUST BE USED IN LIEU OF EACH LOWER ANTI-SWAY BRACE IN THE DOORWAY AREA, NAILED BLOCKING IS REQUIRED FOR ALL PALLET STACKS WHICH ARE COMPLETELY WITHIN THE DOORWAY AREA OR WHICH EXTEND INTO THE DOORWAY AREA BY ONE-HALF OR MORE OF THE STACK WIDTH ON EITHER SIDE OF THE CAR.
- 5. TOP-OF-LOAD ANTI-SWAY BRACES, SHOWN AS PIECES MARKED ② IN THE LOAD ON PAGE 8, MUST BE INSTALLED IN EACH END OF THE CAR. FOUR (4) BRACES ARE REQUIRED IN EACH END OF 40' AND 50' CARS.
- 6. CENTER GATE "D" MAY BE PARTIALLY FORMED FROM 1/2" OR THICKER PLYWOOD, IF DESIRED. PLYWOOD MAY BE USED IN LIEU OF THE 2" X 6" HORIZONTAL PIECES. SEE THE "PLYWOOD CENTER GATE ALTERNATIVE" DETAIL ON PAGE 46 FOR GUIDANCE.
- 7. FOR EASE OF HANDLING, SPLIT CENTER GATES, WHICH ARE NOT DEPENDENT ON THE WIDTH OF THE CAR, MAY BE USED AS AN ALTERNATIVE TO THE CAR WIDTH GATES. IN LIEU OF EACH "CENTER GATE D", SHOWN AS PIECE MARKED (3) IN THE LOAD ON PAGE 8, INSTALL TWO (2) "CENTER GATES C" AS SHOWN ON PAGE 16. AFTER THE SPLIT GATES AND STRUTS HAVE BEEN INSTALLED, THE SPLIT GATES MUST BE TIED TOGETHER AS DEPICTED BY THE "TIE PIECE APPLICATION" DETAIL ON PAGE 46.
- 8. DOOR SPANNER TYPE GATE HOLD DOWN MAY BE USED IN LIEU OF THE DOUBLED 2" X 4" HOLD DOWNS ON CENTER GATE "D", PROVIDING THE CAR HAS NAILABLE SIDEWALLS. SEE THE DETAILS ON PAGE 48 FOR GUIDANCE.
- 9. DOORWAY PROTECTION IS REQUIRED FOR ALL PALLET UNIT STACKS WHICH ARE COMPLETELY WITHIN THE DOORWAY AREA OR WHICH EXTEND INTO IT BY ONE-HALF OR MORE OF THE STACK WIDTH OR LENGTH. THE WOODEN GATE TYPE OF DOORWAY PROTECTION, SHOWN AS PIECE MARKED (3) IN THE LOAD ON PAGE 8, IS APPLICABLE FOR BOX CARS EQUIPPED WITH CONVENTIONAL SLIDING DOORS AND NAILABLE DOOR POSTS; OR NAILED FLOORINE BLOCKING AND DOORWAY PROTECTION STRAPS MAY BE USED. REFER TO PAGES 49 THRU 51 FOR ALTERNATIVE DOORWAY PROTECTION FOR CARS EQUIPPED WITH CONVENTIONAL SLIDING DOORS. IF THE CAR TO BE LOADED IS EQUIPPED WITH PLUG TYPE DOORS OR COMBINATION PLUG AND SLIDING DOORS, NAILED FLOORINE BLOCKING AT ILD DOORWAY PROTECTION STRAPS MUST BE USED. SEE THE "DOORWAY PROTECTIC." I E" DETAIL ON PAGE 51 FOR GUIDANCE.
- 10. THE DEPICTED LOAD CAN BE REDUCED TO SUIT THE QUANTITY TO BE SHIPPED. A 2-TIER LOAD CAN BE REDUCED BY A MULTIPLE OF FOUR (4) PALLET UNITS OR A 1-TIER LOAD CAN BE REDUCED BY A MULTIPLE OF TWO (2) LNITS BY OMITTING ONE OR MORE LOAD LNITS FROM THE CENTER PORTION OF THE LOAD, OR THE ENTIRE TOP TIER CAN BE OMITTED. FOR OTHER METHODS OF REDUCING A LOAD, AND FOR TYPICAL LCL PROCEDURES, REFER TO PAGES 20 THRU 40 FOR GUIDANCE.
- 11. IF PALLET UNITS WHICH DO NOT CONTAIN A FULL QUANTITY OF CONTAINERS ARE TO BE TRANSPORTED, REFER TO PAGE 42 FOR SHIPPING GUIDANCE.
- FOR SHIPMENT OF ONE OR MORE LEFTOVER CONTAINERS, SEE THE "PROCEDURES FOR SHIPMENT OF LEFTOVER CONTAINERS" ON PAGE 43 FOR GUIDANCE.

LUMBER	LINEAR FEET	BOARD FEET
1" X 6"		<del></del>
1 A 0 2" X 2"	80 124	40
2 ^ 2 2" X 3"	24	42
2" X 4"	401	12
2 ^ <del>4</del> 2" X 6"		268
4" X 4"	160 87	160
· ^ •	87	116
VAILS	NO. REQD	POUNDS
6d (2")	48	1/2
10d (3")	704	9-3/4
12d (3-1/4")	28	1/2
led (3-1/2")	96	2-1/4

#### LOAD AS SHOWN

TOTAL WEIGHT------ 105,737 LBS (APPROX)





- 1. A 50'-6" LONG BY 9'-0" WIDE (INSIDE CLEARANCE) WOOD-LINED BOX CAR EQUIPPED WITH ADJUSTABLE AND/OR FIXED WALL MEMBERS, AND WITH 10'-0' WIDE DOOR OPENINGS IS SHOWN. CARS OF OTHER DIMENSIONS AND CARS HAVING WIDER OR NARROWER DOOR OPENINGS CAN BE USED.
- A MAXIMUM OF FIFTY (50) UNITS FOR AN APPROXIMATE LADING WEIGHT OF 108,800 POUNDS, CAN BE PLACED IN A 40'-6" LONG CAR.
- 3. IF A CAR HAS BOWED END WALLS WHICH ARE BOWED OUTWARD TWO INCHES (2") OR MORE EITHER FROM SIDE-TO-SIDE OR FROM FLOOR-TO-ROOF, CROSS MEMBERS CAN BE INSTALLED NEAR THE END WALL OF THE CAR TO PROVIDE A "SQUARED END" RATHER THAN INSTALLING DUNNAGE AS SPECIFIED IN GENERAL NOTE "F" ON PAGE 2. THESE CROSS MEMBERS SHOULD BE INSTALLED AT THE SAME HEIGHTS AS THE CROSS MEMBERS USED THROUGHOUT THE LOAD AS BLOCKING MEMBERS.
- 4. TOP-OF-LOAD ANTI-SWAY BRACES SHOWN AS PIECES MARKED (3) IN THE LOAD ON PAGE 10, MUST BE INSTALLED IN EACH END OF THE CAR AND WIRE TIED TO THE STRAPPING BOARDS WITH NO. 14 GAGE WIRE AS TYPICALLY SHOWN BY THE "TIE WIRE APPLICATION B" DETAIL ON PAGE 47. THREE (3) BRACES ARE REQUIRED IN EACH END OF A LOAD.
- IF THE CAR BEING LOADED IS EQUIPPED WITH AT LEAST TWELVE (12) DOORWAY
  MEMBERS, AN ADDITIONAL EIGHT PALLET UNITS CAN BE LOADED IN THE DOORWAY
  AREA.
- 6. THE DEPICTED LOAD CAN BE REDUCED TO SUIT THE QUANTITY TO BE SHIPPED. A LOAD MAY BE REDUCED BY MULTIPLES OF TWO (2) PALLET UNITS BY OMITTING LATERALLY ADJACENT UNITS FROM THE TOP LAYER OF ONE OR MORE LOAD UNITS OR BY MULTIPLES OF FOUR (4) PALLET UNITS BY OMITTING ONE OR MORE ENTIRE LOAD UNITS. TO REDUCE A LOAD BY ONE (1) PALLET UNIT, REFER TO THE LCL PROCEDURES ON PAGES 18 AND 19 FOR GUIDANCE.
- 7. FOR SHIPMENT OF ONE OR MORE LEFTOVER CONTAINERS, SEE THE "PROCEDURES FOR SHIPMENT OF LEFTOVER CONTAINERS" ON PAGE 43 FOR GUIDANCE.

BILL OF MATERIAL		
LUMBER	LINEAR FEET	BOARD FEET
2" X 4"	432	288
NAILS	NO. RECD	POUNDS
10d (3")	396	6-1/4

LOAD AS SHOWN

56-UNIT LOAD IN A 50'-6" LONG BY 9'-0" WIDE BOX CAR EQUIPPED WITH MECHANICAL BRACING DEVICES





ISOMETRIC VIEW


- ANTI-SWAY BRACE (27 REQD). SEE THE "ANTI-SWAY BRACE A" DETAIL ON PAGE 14. INSTALL BETWEEN LATERALLY ADJACENT PALLET UNITS. SEE GENERAL NOTES "L" AND "M" ON PAGE 2, AND SPECIAL NOTE 3 ON PAGE 13.
- (2) TOP-OF-LOAD ANTI-SWAY BRACE (8 REQD), SEE THE "TOP-OF-LOAD ANTI-SWAY BRACE A" DETAIL ON PAGE 14. WIRE TIE TO STRAPPING BOARDS OF UNIT WITH NO. 14 GAGE WIRE AS TYPICALLY SHOWN BY THE "TIE WIRE APPLICATION A" DETAIL ON PAGE 47. SEE SPECIAL NOTE 4 ON PAGE 13.
- (3) FLOORLINE BLOCKING, 2" X 6" X 35" (DOUBLED) (6 REQD). NAIL THE FIRST PIECE TO THE CAR FLOOR W/4-164 NAILS. NAIL THE SECOND PIECE TO THE FIRST IN A LIKE MANNER. SEE SPECIAL NOTES 3 AND 6 ON PAGE 13 AND GENERAL NOTE "R" ON PAGE 2.
- 4 SPACER ASSEMBLY "A" (4 REQD). SEE THE DETAIL ON PAGE 17.
- (5) DOORWAY PROTECTION STRAP, 1-1/4" X .031" OR .035" X 32"-0" LONG STEEL STRAPPING (4 REOD). STAPLE TO THE SPACER ASSEMBLY W/3 STAPLES. SEE SPECIAL NOTE 6 ON PAGE 13.
- SEAL FOR 1-1/4" STRAPPING (  $8\ \text{REQD},\ 2\ \text{PER STRAP}$  ). DOUBLE CRIMP EACH SEAL. SEE GENERAL NOTE "N" ON PAGE 2.
- STRUT ASSEMBLY (1 REQD), SEE THE "STRUT ASSEMBLY FOR 1-PIECE BULKHEADS" DETAIL ON PAGE 52. INSTALL BETWEEN THE LOAD DIVIDER BULKHEADS. SEE SPECIAL NOTE 7 ON PAGE 13.

60-UNIT LOAD IN A 50'-6" LONG BY 9'-2" WIDE BOX CAR EQUIPPED WITH LOAD DIVIDERS


- A 50'-6" LONG BY 9'-2" WIDE WOOD-LINED CUSHIONED BOX CAR EQUIPPED WITH LOAD DIVIDER BULKHEADS AND WITH 10'-0" WIDE DOOR OPENINGS IS SHOWN. CARS OF OTHER DIMENSIONS AND CARS HAVING NARROWER OR WIDER DOOR OPENINGS CAN BE USED. SEE GENERAL NOTES "AA" THRU "EE" ON PAGE 3.
- 2. A MAXIMUM OF SIXTY-EIGHT (68) PALLET UNITS, FOR AN APPROXIMATE LADING WEIGHT OF 147,968 POUNDS CAN BE PLACED IN A 601-8" LONG CAR, OR A MAXIMUM OF FORTY-EIGHT (48) UNITS CAN BE LOADED IN A 401-6" LONG CAR FOR AN APPROXIMATE LADING WEIGHT OF 104,448 POUNDS, WHEN USING THE DEPICTED PROCEDURES. IF THE LENGTHMSE LOADING PATTERN SHOWN ON PAGE 8 IS EMPLOYED, SIXTY (60) PALLET UNITS FOR AN APPROXIMATE LADING WEIGHT OF 130,560 POUNDS CAN BE PLACED IN A 601-8" LONG CAR, FORTY-EIGHT (48) UNITS CAN BE PLACED IN A 501-6" LONG CAR FOR AN APPROXIMATE LADING WEIGHT OF 104,448 POUNDS, AND THIRTY-SIX (36) UNITS CAN BE LOADED IN A 401-6" LONG CAR FOR AN APPROXIMATE LADING WEIGHT OF 78,336 POUNDS.
- 3. IF THE WOODEN GATE TYPE DOORWAY PROTECTION, PIECE MARKED (3) ON PAGE 6, IS USED IN LIEU OF THE NAILED FLOORLINE BLOCKING AND DOORWAY PROTECTION STRAP PROCEDURE, THE LOWER ANTI-SWAY BRACES IN THE DOORWAY AREA ARE REQUIRED.
- 4. TOP-OF-LOAD ANTI-SWAY BRACES, SHOWN AS PIECES MARKED ② IN THE LOAD ON PAGE 12 MUST BE INSTALLED IN EACH END OF THE CAR. FIVE (5) BRACES ARE REQUIRED IN EACH END OF A 60° CAR. FOUR (4) BRACES ARE REQUIRED IN EACH END OF 40° AND 50° CARS.
- 5. DOORWAY PROTECTION IS REQUIRED FOR ALL PALLET UNIT STACKS WHICH ARE COMPLETELY WITHIN THE DOORWAY AREA OR WHICH EXTEND INTO THE DOORWAY AREA BY ONE-HALF OR MORE OF THE STACK LENGTH. THE WOODEN GATE TYPE OF DOORWAY PROTECTION, SHOWN AS PIECE MARKED (5) IN THE LOAD ON PAGE 6, IS APPLICABLE FOR BOX CARS EQUIPPED WITH CONVENTIONAL SLIDING DOORS AND NAILABLE DOOR POSTS. REFER TO PAGES 49 THRU 51 FOR ALTERNATIVE DOORWAY PROTECTION FOR CARS EQUIPPED WITH CONVENTIONAL SLIDING DOORS. IF THE CAR BEING LOADED IS EQUIPPED WITH CONVENTIONAL SLIDING DOORS. IF THE CAR BEING LOADED IS EQUIPPED WITH PLUG TYPE DOORS OR COMBINATION PLUG AND SLIDING DOORS, NAILED FLOORLINE BLOCKING AND DOORWAY PROTECTION STRAPS MUST BE USED.
- S. FLOORLINE BLOCKING SHOWN AS PIECE MARKED (3) IN THE LOAD ON PAGE 12, MUST BE USED IN LIEU OF THE LOWER ANTI-SWAY BRACE MARKED (1), FOR ALL UNITS REQUIRING DOORWAY PROTECTION STRAPS. TWO (2) DOORWAY PROTECTION STRAPS ARE REQUIRED FOR EACH PALLET STACK AND/OR LOAD UNIT WHICH IS COMPLETELY WITHIN THE DOORWAY AREA OR WHICH IS NOT RETAINED BY AT LEAST SIX INCHES (6") OF CAR SIDEWALL ON BOTH SDES OF THE CAR. ONE DOORWAY PROTECTION STRAP IS REQUIRED FOR EACH PALLET STACK AND/OR LOAD UNIT WHICH IS RETAINED BY FROM 6" TO ONE-HALF THE PALLET/LOAD UNIT LENGTH OR WIDTH. IF THE PALLET UNITS ARE POSITIONED LENGTHWISE, REFER TO THE "DOORWAY PROTECTION E" PROCEDURES SHOWN ON PAGE 51.
- 7. THE STRUT ASSEMBLY, SHOWN AS PIECE MARKED (7) IN THE LOAD ON PAGE 12, IS REQUIRED WHEN THE LOAD IN EITHER END OF A CAR IS 50,000 POUNDS OR MORE, A STRUT ASSEMBLY WILL ALWAYS BE REQUIRED IF ONE END OF THE LOAD CONTAINS MORE THAN FIVE (5) LOAD UNITS.
- THE DEPICTED LOAD CAN BE REDUCED TO SUIT THE QUANTITY TO BE SHIPPED. A 2-TIER LOAD CAN BE REDUCED BY A MULTIPLE OF FOUR (4) PALLET UNITS OR A 1-TIER LOAD CAN BE REDUCED BY A MULTIPLE OF TWO (2) UNITS BY OMITTING ONE OR MORE LOAD UNITS FROM THE CENTER PORTION OF THE LOAD. OR, THE ENTIRE TOP TIER CAN BE OMITTED. FOR OTHER METHODS OF REDUCING A LOAD AND FOR TYPICAL ICL PROCEDURES, REFER TO PAGES 21 THRU 28 AND GENERAL NOTE "FF" ON PAGE 3 FOR GUIDANCE.
- 9. IF PALLET UNITS WHICH DO NOT CONTAIN A FULL QUANTITY OF CONTAINERS ARE TO BE TRANSPORTED, REFER TO PAGE 41 AND/OR PAGES 42 AND 44 FOR SHIPPING
- 10. FOR SHIPMENT OF ONE OR MORE LEFTOVER CONTAINERS, SEE THE "PROCEDURES FOR SHIPMENT OF LEFTOVER CONTAINERS" ON PAGE 43 FOR GUIDANCE.


LUMBER	LINEAR FEET	BOARD FEET
1" × 4"	107	36
1" X 8"	16	11
2" X 2"	170	57
2" X 4"	170	114
2" X 6"	101	101
4" X 4"	8	11
NAILS	NO, REQD	POUNDS
6d (2")	396	2-1/2
10d (3")	126	2 "
12d (3-1/4")	154	2-1/2
16d (3-1/2")	48	l ī"-

## LOAD AS SHOWN



VERTICAL PIECE, 2" X 6" X 6"-4" FOR A 2-HIGH LOAD, 38" FOR A 1-HIGH LOAD (2 REQD). STRUT LEDGER, 2" X 2" OR 2" X 4" X 29-3/4" (6 REQD), NAIL TO THE VERTICAL PIECES W/2-10d NAILS AT EACH JOINT. 6' 0 1 HORIZONTAL PIECE, 2" X 6" X 46-1/4" (6 REQD). NAIL TO THE VERTICAL PIECES W/3-101 NAILS AT EACH JOINT. STOP PIECE, 2" X 4" X 46-1/4" (1 REQD)
NAIL TO THE VERTICAL PIECES W/2-10d
NAILS AT EACH JOINT. 6-4" 68" 21/2 GATE HOLD DOWN, 2" X 3" X 10"
(DOUBLED) (2 REQD). NAIL THE FIRST
PIECE TO THE FILL PIECE W/3-104
NAILS. LAMINATE THE SECOND
PIECE TO THE FIRST IN A LIKE 55" FILL PIECE, 2" X 4" X 46-1/4" (1 REQD). NAIL TO THE VERTICAL PIECES 30 W/3-10d NAILS AT MANNER . -9 1/2 END VIEW CENTER GATE A DETAILS PAGE 14






#### ANTI-SWAY BRACE B


IF DESIRED, THE ANTI-SWAY BRACE CAN BE PARTIALLY PRE-ASSEMBLED; ONE BUFFER PIECE CAN BE NAILED TO BOTH RETAINER PIECES. THE LONG ENDS OF THE ASSEMBLY CAN THEN BE INSTALLED INTO THE FORKLIFT OPENING OF A LOADED PALLET PRIOR TO POSITIONING THE LATERALLY ADJACENT PALLET.


GATE HOLD DOWN, 2" X 4" X 9" (DOUBLED) (2 REQD).
NAIL THE FIRST PIECE TO THE FILL PIECE W/2-10! NAILS,
LAMINATE THE SECOND PIECE TO THE FIRST IN A LIKE
MANNER.

FILL PIECE.



DETAILS







- A 9'-0" WIDE (INSIDE CLEARANCE) WOOD-LINED BOX CAR EQUIPPED WITH ADJUSTABLE AND/OR FIXED WALL MEMBERS IS SHOWN. CARS OF OTHER WIDTHS CAN BE USED.
- FIVE (5) UNITS ARE SHOWN AS A TYPICAL LOAD QUANTITY. THE NUMBER OF UNITS CAN BE ADJUSTED TO SUIT THE QUANTITY TO BE SHIPPED.
- 3. TOP-OF-LOAD ANTI-SWAY BRACES, SHOWN AS PIECES MARKED (3), MUST BE INSTALLED IN EACH END OF THE CAR AND WIRE TIED TO A UNIT WITH NO. 14 CAGE WIRE. THREE (3) BRACES ARE REQUIRED IN EACH END OF A 40' AND 50' CAR, FOUR (4) BRACES ARE REQUIRED IN 60' LONG CAR.
- 4. THE SPACER ASSEMBLIES, SHOWN AS PIECES MARKED (5), MAY ALSO BE USED IN AN UPPER LAYER OF A LOAD FOR THE OMISSION OF A PALLET UNIT. IF THE ASSEMBLIES ARE USED NEXT TO THE CAR END WALL IN EITHER A FIRST LAYER OR IN AN UPPER LAYER, AND THE END WALL IS WOOD-LINED, CUT THE AD JACENT ENDS OFF THE SUPPORT PIECES FLUSH WITH THE LATERAL PIECE. EACH ASSEMBLY CAN THEN BE SUPPORTED BY NAILIN G THE LATERAL PIECE TO THE CAR END WALL W/6-104 NAILS. IF THE END WALL IS NON-NAILABLE, CROSS MEMBERS MUST BE INSTALLED AT THE END OF THE LOAD TO SUPPORT THE SPACER ASSEMBLIES.

#### KEY NUMBERS

- WALL MEMBER, AD JUSTABLE OR FIXED. MEMBERS MUST BE LOCATED AT THE SPECIFIED HEIGHTS ABOVE THE CAR FLOOR TO PROVIDE PROPER ALIGNMENT OF CROSS MEMBERS MARKED (4).
- 2) ANTI-SWAY BRACE (2 REQD). SEE THE "ANTI-SWAY BRACE B" DETAIL ON PAGE 16. I INSTALL BETWEEN LATERALLY ADJACENT PALLET UNITS. SEE GENERAL NOTES "L" AND "M" ON PAGE 2.
- (3) TOP-OF-LOAD ANTI-SWAY BRACE (2 REQD), SEE THE "TOP-OF-LOAD ANTI-SWAY BRACE B" DETAIL ON PAGE 16. WIRE TIE TO PALLET UNITS AS SHOWN BY THE "TIE WIRE APPLICATION B" DETAIL ON PAGE 47.
- (4) CROSS MEMBER (5 REQD). SEE GENERAL NOTE "W" ON PAGE 3.
- (5) SPACER ASSEMBLY (2 REQD). SEE THE DETAIL ON PAGE 19 AND SPECIAL NOTE 4 AT LEFT. WIRE TIE TO CROSS MEMBER W/2 WRAPS OF NO. 14 GAGE WIRE AT EACH CORNER.

TYPICAL LCL (5-UNIT LOAD) IN A BOX CAR EQUIPPED WITH MECHANICAL BRACING DEVICES HAVING ADJUSTABLE OR FIXED WALL MEMBERS.






- ONLY THE CENTER PORTION OF A 9'-2" WIDE CONVENTIONAL TYPE BOX CAR IS SHOWN TO PORTRAY THE STRUTTED GATE METHOD OF PARTIAL LAYER BRACING, CARS OF OTHER WIDTHS CAN ALSO BE USED.
- THE PROCEDURES FOR THE ADJUSTMENT OF A LOAD QUANTITY BY THE OMISSION OF THE TOP LAYER FROM ONE (1) LOAD UNIT IS SHOWN AS TYPICAL. THE PRINCIPLES MAY ALSO BE APPLIED FOR THE OMISSION OF THE TOP LAYER FROM TWO (2) LOAD UNITS.
- ONLY THE BLOCKING AND BRACING PIECES WHICH ARE NECESSARY TO PERMIT THE OMISSION OF THE UNITS FROM THE TOP LAYER ARE SHOWN.
- 4. THE CENTER GATE "B" IS ONLY APPLICABLE FOR CROSSWISE POSITIONED CONTAINERS. USE CENTER GATE "D" FOR A LOAD OF LENGTHMISE. : | POSITIONED CONTAINERS. THE QUANTITY REQUIRED FOR DUNNAGE PIECES, SUCH AS THE NUMBER OF STRUTS OR THE NUMBER OF STRUT BRACING PIECES, WILL VARY WITH THE POSITION OF THE PALLET UNITS AND THE LENGTH OF THE CAR BEING LOADED.

#### KEY NUMBERS

- (1) CENTER GATE FOR 1-HIGH (2 REQD). SEE THE "CENTER GATE B" DETAIL ON PAGE 15. SEE GENERAL NOTES "L" AND "M" ON PAGE 2 AND SPECIAL NOTE 4 AT THE LEFT.
- (2) CENTER GATE FOR 2-HIGH (1 REQD). SEE THE "CENTER GATE B" DETAIL ON PAGE 15.
- (3) STRUT, 4" X 4" BY CUT TO FIT (AS REQD). POSITION BETWEEN THE CENTER GATES, PIECES MARKED (1) AND (2), IN THE FIRST LAYER AND TOBNAIL W/2-164 NAILS AT EACH BND. SEE GENERAL NOTES "K" AND "T" ON PAGE 2, AND GENERAL NOTE "U" ON PAGE 3.
- (4) GATE SUPPORT, 2" X 4" BY A LENGTH TO SUIT († REQD). NAIL TO THE VERTICAL PIECES OF THE CENTER GATE USED IN THE SECOND LAYER W/2-100 NAILS AT EACH JOINT.
- 6 VERTICAL STRUT BRACING, 2" X 4" BY CUT TO EXTEND A MINIMUM OF 2" ABOVE THE TOP STRUT (AS REQD). NAIL TO THE STRUTS W/3-104 NAILS AT EACH JOINT.
- (7) HORIZONTAL STRUT BRACING, 2" X 4" BY LENGTH TO SUIT (AS REQD). NAIL TO THE STRUTS W/3-10d NAILS AT EACH JOINT.





9 LENGTHWISE PLUS 4 CROSSWISE LOAD UNITS ARE SHOWN

#### SPECIAL NOTES:

- A 50'-6" LONG BY 9'-2" WIDE CONVENTIONAL TYPE BOX CAR IS SHOWN. WIDER CARS AND CARS OF OTHER LENGTHS CAN BE USED.
- 2. THE PROCEDURES ON THIS PAGE AND ON PAGE 22 ARE PRESENTED TO PROVIDE A METHOD OF OBTAINING A LOAD QUANTITY WHICH MAY NOT BE READILY ATTAINABLE BY ANY OF THE OTHER METHODS OF ADJUSTING A LOAD QUANTITY SPECIFIED HEREIN, INCLUDING THE DEPICTED LCL PROCEDURES.
- 3. THE BLOCKING AND BRACING FOR THE COMBINATION LOAD, OTHER THAN THE SEPARATOR GATE HAS NOT BEEN SHOWN. REFER TO THE APPLICABLE LOAD PAGES FOR BLOCKING AND BRACING SPECIFICATIONS. A SEPARATOR GATE MUST BE INSTALLED AT EVERY LOCATION WHERE THE DIRECTION OF THE UNITS CHANGE. THE GATE MUST BE POSITIONED SO THAT THE VERTICAL PIECES ARE AGAINST THE CROSSWISE CONTAINERS OF THE LOAD.
- 4. THE CHART BELOW GIVES THE VARIOUS QUANTITIES ( PER LAYER ) WHICH CAN BE ATTAINED BY THE COMBINATION LOAD METHOD, AND THE PATTERNS REQUIRED TO PROVIDE THESE QUANTITIES, ARE SPECIFIED. FOR COMPARISON PURPOSES, THE OTHER TYPE LOADS WHICH CAN BE USED TO ATTAIN A LIKE QUANTITY, OR A QUANTITY WITHIN THE RANGE OF THE COMBINATION LOAD METHOD, AS WELL AS THE APPROXIMATE LENGTH OF THE STRUTS, ARE ALSO INCLUDED IN THE CHARTS.

CAR LENGTH	UNITS PER LAYER	LOAD PATTERN	APPROX STRUT LEN GTH
40'-6"	24 22 20 18	CROSSWISE LOAD ON PAGE 4 4 LONG-AT 46-3/8" PLUS 7 AT 37-3/4" 7 LONG AT 46-3/8" PLUS 3 AT 37-3/4" LENGTHWISE LOAD ON PAGE 8	27" 27" 39" 62"
50'-6"	30 28 26 24	CROSSWISE LOAD ON PAGE 6 4 LONG AT 46-3/8" PLUS 10 AT 37-3/4" 9 LONG AT 46-3/8" PLUS 4 AT 37-3/4" LENGTHWISE LOAD ON PAGE 8	33" 34" 28" 43"
60'-9"	36 34 32 30	CROSSWISE LOAD ON PAGE 4 6 LONG AT 46-3/8" PLUS 11 AT 37-3/4" 10 LONG AT 46-4/8" PLUS 6 AT 37-3/4" LENGTHWISE LOAD ON PAGE 8	42" 25" 29" 26"






ISOMETRIC VIEW

- 1. A PARTIAL VIEW OF A 91-2" WIDE CONVENTIONAL TYPE BOX CAR IS SHOWN. CARS OF OTHER WIDTHS CAN BE USED.
- THE OMITTED-UNIT PROCEDURE SHOULD BE APPLIED NEAR THE CENTER OF THE CAR LENGTH, BUTNOT IN THE DOORWAY AREA. ALSO, THERE SHOULD BE AT LEAST ONE (1) LOAD UNIT BETWEEN THE OMITTED UNIT AND A CENTER GATE.
- ONLY THE BLOCKING AND BRACING FOR THE OMITTED UNIT IS SHOWN.
  REFER TO THE LOAD ON PAGES 4 AND 6 FOR THE BLOCKING AND BRACING
  REQUIREMENTS FOR THE BALANCE OF THE LOAD.

#### KEY NUMBERS

- ① SUPPORT PIECE, 2" X 6" BY 37-3/4" (2 PF OD). POSITION SO AS TO BE UNDER THE VERTICAL PIECES OF THE LOAD BE  $\,$  NG GATE, PIECE MARKED 2 .
- (2) LOAD BEARING GATE (2 REQD, I'RIGHT HAND AND I'LEFT HAND). SEE THE "LOAD BEARING GATE A" DETAIL ON PAGE 25. NAIL TO THE FILLER PIECE, PIECE MARKED (4), W/3-10d NAILS. TOENAIL TO THE SUPPORT PIECE, PIECE MARKED (1), W/2-10d NAILS AT EACH JOINT. CAUTION: USE CARE NOT TO TOENAIL INTO A CONTAINER.
- 3 ANTI-SWAY BEARING PIECE, 2" X 6" X 60" (1 REQD).
- $\P$  FILLER PIECE , 2" X 6" X 34-3/4" (1 REQD). NAIL TO THE ANTI-SWAY BEARING PIECE , PIECE MARKED (3) , W/4-104 NAILS.
- (5) STRUT, 4" X 4" BY CUT TO FIT (REF: 31-3/4") (AS REQD).. TOENAIL TO PIECES MARKED (2) W/2-164 NAILS AT EACH END.




# ISOMETRIC VIEW

#### SPECIAL NOTES:

- 1. A PARTIAL VIEW OF A 9'-2" WIDE CONVENTIONAL TYPE BOXCAR IS SHOWN. CARS OF OTHER WIDTHS CAN BE USED.
- THE OMITTED-UNIT PROCEDURE SHOULD BE APPLIED NEAR THE CENTER OF THE CAR LENGTH, BUT NOT IN THE DOORWAY AREA. ALSO THERE SHOULD BE AT LEAST ONE (1) LOAD UNIT BETWEEN THE OMITTED UNIT AND A CENTER GATE.
- 3. ONLY BLOCKING AND BRACING FOR THE OMITTED UNIT IS SHOWN; REFER TO THE LOAD ON PAGE 8 FOR THE BLOCKING AND BRACING REQUIREMENTS FOR THE BALANCE OF THE LOAD.


# KEY NUMBERS

- ① SUPPORT PIECE, 2" X 6 X 46-3/8" (2 REQD). POSITION SO AS TO BE UNDER THE VERTICAL PIECES OF THE LOAD BEARING GATE, PIECE MARKED ②.
- (2) LOAD BEARING GATE (2 REQD,) RIGHT HAND AND 1 LEFT HAND). SEE THE PLOAD BEARING GATE B" DETAIL ON PAGE 25. NAIL TO THE FILLER PIECE, PIECE MARKED (4), W/3-104 NAILS. TOENAIL TO THE SUPPORT PIECE, PIECE MARKED (1), W/2-104 NAILS AT EACH JOINT. CAUTION: USE CARE NOT TO TOENAIL NTO A CONTAINER.
- (3) ANTI-SWAY BEARING PIECE, 2" X 6" X 72" (1 REQD).
- 4 FILLER PIECE , 2" X 6" X 43-3/8" (1 REQD). NAIL TO THE ANTI-SWAY BEARING PIECE , PIECE MARKED 3 , W/5-10d NAILS.
- (5) STRUT, 4" X 4" BY CUT TO FIT (REF: 40-3/8") (AS REQD). TOENAIL TO PIECES MARKED (2) W/2-16d NAILS AT EACH END.



#### LOAD BEARING GATE A


THIS GATE IS FOR USE IN A LOAD OF CROSSWISE POSITIONED CONTAINERS, SEE SPECIAL NOTE 2 BELOW FOR NAILING GUIDANCE, ONE RIGHT HAND AND ONE LEFT HAND GATE ARE REQUIRED.



END VIEW


#### SPECIAL NOTES:

- THE GATES ON THIS PAGE ARE FOR USE IN THE LCL PROCEDURES SHOWN ON PAGES 23 AND 24. THE REFERENCED DIMENSIONS GIVEN FOR THE CUT-TO-FIT PRECES ARE BASED ON AN INSIDE CAR WIDTH OF 9'-2". THIS DIMENSION WILL HAVE TO BE INCREASED WHEN LOAD-ING WIDER CARS.
- 2. THE NAILING OF THE VARIOUS PARTS OF LOAD BEARING GATE "A" WILL BE AS FOLLOWS: NAIL THE 2" X 4" OR 2" X 6" HORIZONTAL PIECE (S) TO THE VERTICAL PIECES W/3-10d NAILS AT EACH JOINT, NAIL THE DOUBLED 2" X 3" GATE HOLD DOWN PIECES TO A HORIZONTAL PIECE W/3-10d NAILS AT EACH LAYER, NAIL THE 2" X 2" STRUT LEDGERS TO THE VERTICAL PIECES W/2-10d NAILS AT EACH END.
- 3. THE NAILING OF THE VARIOUS PARTS OF LOAD BEARING GATE "B".
  FOLLOWS: NAIL THE 2" X 3" OR 2" X 6" HORIZONTAL PIECE (5')TO
  THE VERTICAL PIECES W/3-100 NAILS AT EACH JONT. NAIL THE
  DOUBLED 2" X 2" GATE HOLD DOWN PIECES TO A HORIZONTAL PIECE
  W/5-101 NAILS AT EACH LAYER. NAIL THE 2" X 2" STRUT LEDGERS
  TO THE VERTICAL PIECES W/2-101 NAILS AT EACH END.




# LOAD BEARING GATE B


THIS GATE IS FOR USE IN A LOAD OF LENGTHWISE POSITIONED CONTAINERS. SEE SPECIAL NOTE 3 ABOVE FOR NAILING GUIDANCE. ONE RIGHT HAND AND ONE LEFT HAND GATE ARE REQUIRED.



LOAD BEARING GATE DETAILS



## ISOMETRIC VIEW




SECTION F-F

# KEY NUMBERS

- (1) ANTI-SWAY BRACE (7 REQD). SEE THE "ANTI-SWAY BRACE B" DETAIL ON PAGE 16. INSTALL BETWEEN LATERALLY ADJACENT PALLET UNITS. SEE GENERAL NOTES NOTES "L" AND "M" ON PAGE 2 AND SPECIAL NOTE 4 ON PAGE 27.
- (2) TOP-OF-LOAD ANTI-SWAY BRACE (\$ REOD). SEE THE "TOP-OF-LOAD ANTI-SWAY BRACE B" DETAIL ON PAGE 16. WIRE TIE TO PALLET UNITS AS SHOWN BY THE "TIE WIRE APPLICATION B" DETAIL ON PAGE 47.
- (3) STRAPPING BOARD, 2" X 6" X 32-1/2" (32 REQD/4 PER PALLET UNIT). POSITION AS SHOWN IN THE "METHOD A" DETAIL ON PAGE 28 SEE SPECIAL NOTE 5 ON PAGE 27.
- (4) REINFORCING STRAP, 1-1/4" X.035" X 15'-0" LONG (REF) STEEL STRAPPING (16 RECD). INSTALL TO ENCIRCLE THE PALLET UNIT AND THE STRAPPING BORADS. SECURE TO A STRAPPING BOARD W/3 STAPLES. SEE THE "METHOD A" DETAIL ON PAGE 28.
- (3) SEAL FOR 1-1/4" STRAPPING (32 REQD/2 PER STRAP). DOUBLE CRIMP EACH SEAL. SEE GENERAL NOTE "N" ON PAGE 2.
- (6) RISER ASSEMBLY (2 REQD). THE HEIGHT OF THESE RISER ASSEMBLIES WILL BE TWO-THIRDS OF THE PALLET UNIT HEIGHT. SEE THE "RISER ASSEMBLY" DETAIL ON PAGE 27.
- (7) RISER ASSEMBLY (2 REQD). THE HEIGHT OF THESE RISER ASSEMBLIES WILL BE ONE-THIRD OF THE PALLET UNIT HEIGHT. SEE THE "RISER ASSEMBLY" DETAIL ON PAGE 27.
- (8) STOP PIECE (4 REQD). SEE THE "RISER ASSEMBLY" DETAIL ON PAGE 27 FOR LOCATION AND NATURE GUIDANCE.

TYPICAL LCL LOAD USING RISER METHOD OF PARTIAL LAYER BRACING




#### RISER ASSEMBLY


#### SPECIAL NOTES FOR LOAD:


- A 9'-2" WIDE CONVENTIONAL TYPE WOOD-LINED BOXCAR IS SHOWN. CARS OF OTHER WIDTHS CAN BE USED.
- THE RISER METHOD OF PARTIAL-LAYER BRACING IS TYPICALLY SHOWN WITH THE PALLET UNITS POSITIONED LENGTHWISE IN THE CAR. WITH MODIFI-CATIONS, THE PROCEDURES ARE ALSO APPLICABLE FOR CROSSWISE POSITIONED UNITS. SEE SPECIAL NOTES 4 AND 5.
- ONLY THE BLOCKING AND BRACING FOR THE RISER METHOD OF PARTIAL-LAYER BRACING IS SHOWN. REFER TO THE APPLICABLE LOAD PAGE FOR THE BLOCKING AND BRACING REQUIREMENTS FOR THE BALANCE OF THE LOAD.
- 4. ANTI-SWAY BRACE "B" IS APPLICABLE FOR THE LENGTHMSE POSITIONED CONTAINERS. ANTI-SWAY BRACE "A", AS DETAILED ON PAGE 14, WILL BE USED FOR CROSSWISE POSITIONED CONTAINER PALLET UNITS.
- 5. WHEN THE CONTAINERS ARE POSITIONED CROSSWISE IN THE LOAD, SEE THE "METHOD B" DETAIL ON PAGE 28, TO BE USED IN LIEU OF STRAPPING BOARDS. FLOORLINE BLOCKING WILL BE USED IN PLACE OF THE STOP PIECE SHOWN ON THE RISER ASSEMBLY DETAIL.

#### SPECIAL NOTES FOR RISER ASSEMBLY:

- 1. A TWO-THIRDS UNIT HEIGHT RISER IS SHOWN ABOVE AND AS KEY NUMBER (6) IN THE LOAD ON PAGE 26, EACH CROSS BRACE AND EACH LATERAL PIECE OF THE RISER IS FABRICATED FROM THREE (3) PIECES OF 2" X 6" MATERIAL AND TWO (2) PIECES OF 2" X 4" MATERIAL TO PROVIDE FOR A TOTAL HEIGHT OF 25" AFTER THE DECKING IS IN PLACE. A CNE-THIRD HEIGHT RISER, SHOWN AS KEY NUMBER (7) IN THE LOAD ON PAGE 26, WILL BE FABRICATED RROW TWO (2) PIECES OF 2" X 6" MATERIAL FOR EACH CROSS BRACE AND EACH LATERAL PIECE, TO PROVIDE FOR A TOTAL HEIGHT OF 12-1/2"AFTER THE DECKING IS IN PLACE.
- 2. THE STOP PIECE SHOWN ON THE RISER ASSEMBLY ABOVE IS USED WHEN THE CONTAINERS ARE POSITIONED LENGTHWISE IN THE CAR AS SHOWN IN THE LCL LOAD ON PAGE 26, SIDE BLOCKING IS REQUIRED WHEN THE CONTAINERS ARE POSITIONED CROSSWISE IN THE CAR. CENTER A 2" X 6" X 18" DOUBLED) AGAINST THE CROSS BRACE OF EACH RISER ASSEMBLY, NAIL THE FIRST PIECE TO THE CAR FLOOR W/3-16d NAILS, LAMINATE THE SECOND PIECE TO THE FIRST IN A LIKE MANNER










- A 9'-4" WIDE ALL-METAL BOXCAR EQUIPPED WITH STRAP ANCHOR DEVICES AND HAVING AN AAR MECHANICAL DESIGNATION CLASS OF XL IS SHOWN. CARS OF OTHER WIDTHS CAN BE USED.
- THE BULKHEAD GATE METHOD OF PARTIAL-LAYER BRACING IS ONLY APPLICABLE FOR USE IN LOADS OF LENGTHWISE POSITIONED PALLET UNITS AS SHOWN IN THE VIEW ABOVE. PARTIAL LAYERS OF CROSSWISE POSITIONED PALLET UNITS WILL NOT BE RETAINED BY THE BULKHEAD GATE METHOD.
- 3. A BULKHEAD GATE USED IN CONJUNCTION WITH THREE (3) BULKHEAD STRAPS WILL RETAIN UP TO 7,500 POUNDS OF LADING (3 PALLET UNITS). A BULKHEAD GATE WITH TWO (2) STRAPS WILL RETAIN NOT MORE THAN 5,000 POUNDS (2 PALLET UNITS). IF ONLY TWO STRAPS ARE USED, THEY MUST BE APPLIED OVER THE UPPER AND LOWER STRAPPING BOARDS,
- 4. THE ANCHOR DEVICES TO BE USED FOR THE ATTACHMENT OF THE BULKHEAD STRAPS MUST BE LOCATED AT LEAST THIRTY-SIX INCHES (36") TOWARD THE CAR END WALL FROM THE OPPOSITE—THE-LOAD SIDE OF THE BULKHEAD GATE. IF THE ANCHOR DEVICES IN THE CAR BEING LOADED ARE NOT LOCATED NEAR ENOUGH TO THE END OF THE CAR SO THAT THE 36" REQUIREMENT CAN BE SATISFIED, IT WILL BE NECESSARY TO INSTALL GATES AND STRUTS AT THE END OF THE CAR. THESE GATES WILL BE INSTALLED SIMILAR TO THE STRUTTED GATE METHOD SHOWN ON PAGE 20 FOR AN EVEN QUANTITY OF UNITS, OR THE PALLET UNIT OMITTED PROCEDURES AS SHOWN ABOVE AND ON PAGE 24 FOR A SINGLE UNIT.
- 5. THE STRAPPING BOARDS ON A BULKHEAD GATE ARE TO BE ALIGNED AS NEARLY AS POSSIBLE WITH THE ANCHOR DEVICES IN THE CAR TO WHICH THE BULKHEAD STRAPS ARE ATTACHED. TOLERANCES ARE SPECIFED ON THE END VIEW OF THE BULKHEAD GATE ON PAGE 31 FOR THE LOCATION OF THE STRAPPING BOARDS IN RELATION TO THE LOCATION OF THE HORIZONTAL PIECES. THE STRAPPING BOARDS SHOULD BE LOCATED WITHIN THESE TOLERANCES, IF THIS IS NOT POSSIBLE, ADDITIONAL HORIZONTAL PIECES MUST BE APPLIED, AS NECESSARY TO PROVIDE PROPER BEARING AGAINST THE CONTAINERS.

- ANTI-SWAY BRACE (3 REQD). SEE THE "ANTI-SWAY BRACE B" DETAIL ON PAGE 16. INSTALL BETWEEN LATERALLY ADJACENT PALLET UNITS. SEE GENERAL NOTES "L" AND "M" ON PAGE 2.
- (2) SUPPORT PIECE, 2" X 6" X 46-3/8" (2 REQD), POSITION SO AS TO BE UNDER THE VERTICAL PIECES OF THE LOAD BEARING GATE, PIECE MARKED (3).
- 3 LOAD BEARING GATE (2 REQD, 1 RIGHT HAND AND 1 LEFT HAND). SEE THE "LOAD BEARING GATE B" DETAIL ON PAGE 25. NAIL TO THE FILLER PIECE, PIECE MARKED (3), W/3-104 NAILS, TOENAIL TO THE SUPPORT PIECE, PIECE MARKED (2), W/2-104 NAILS AT EACH JOINT. CAUTION: USE CARE NOT TO TOENAIL INTO A CONTAINER.
- ANTI-SWAY BEARING PIECE, 2" X 6" X 60" ( 1 REQD ).
- (5) FILLER PIECE, 2" X 6" X 43-3/8" (1 REQD), NAIL TO THE ANTI-SWAY BEARING PIECE, PIECE MARKED (4), W/5-10d NAILS.
- (6) STRUT, 4" X 4" BY CUT TO FIT (REF: 40-3/8") (AS REQD). TOENAIL TO PIECES MARKED (3) W/2-16d NAILS AT EACH END.
- BULKHEAD STRAP, 1-1/4" X .031" OR .035" BY A LENGTH TO SUIT STEEL STRAPPING (3 REQD). INSTALL FROM 2 EQUAL LENGTH PIECES, ATTACH TO AN ANCHOR WITH 1 SEAL, SEE THE "STRAP APPLICATION PLAN VIEW" ON PAGE 31 FOR INSTALLATION GUIDANCE. SEE SPECIAL NOTES 3 AND 4 AT LEFT.
- (B) BUNDLING STRAP, 1-1/4" X . 035" X 15'-6" LONG (REF) STEEL STRAPPING (2 REQD). ENCIRCLE THE PALLET UNIT, THE HORIZONTAL PIECES OF THE BULKHEAD GATE, PIECE MARKED Ø). TENSION AND SEAL AFTER TENSIONING THE BULKHEAD STRAPS, PIECES MARKED Ø).
- BULKHEAD GATE ( 1 REQD ). SEE THE DETAIL ON PAGE 31. SEE SPECIAL NOTE 2 AT LEFT.
- (1) SEAL FOR 1-1/4" STRAPPING (14 REQD, 4 PER BULKHEAD STRAP, PIECE MARKED (2), AND 1 PER BUNDLING STRAP, PIECE MARKED (8). DOUBLE CRIMP EACH SEAL. SEE GENERAL NOTE "N" ON PAGE 2.
- STRAP RETAINER, 2" X 4" BY A LENGTH TO SUIT (2 REQD). NAIL TO THE BULKHEAD GATE W/2-12d NAILS ABOVE AND BELOW EACH BULKHEAD STRAP.








- 9'-2" WIDE CONVENTIONAL WOOD-LINED BOXCAR IS SHOWN. WOOD-LINED CARS OF OTHER WIDTHS CAN BE USED.
- A LENGTHWISE LOAD IS SHOWN AS TYPICAL. THE BLOCKING AND BRACING WILL VARY FOR CROSSWISE LOADS. NOTE THAT FOR A CROSSWISE PARTIAL TIER, THE PIECES MARKED (4) SHOULD BE LOCATED SO AS TO BEAR AGAINST THE PALLET UNITS IN THE SAME LOCATION AS THE HORIZONTAL PIECES OF
- THE K-BRACE METHOD OF PARTIAL-LAYER (TIER) BRACING SHOWN MAY BE USED IN WOOD-LINED CARS FOR THE SECUREMENT OF A PARTIAL TOP TIER,
  BE IT A SECOND TIER OR FITST. THE TYPE "A" K-BRACE SHOWN IS ADEQUATE
  FOR RETAINING A PARTAIL TIER OF NOT MORE THAN 8,000 POUNDS. IF IT IS NECESSARY TO BLOCK A HEAVIER LOAD, REFER TO THE DETAILS ON PAGES 33, 34, AND 35 FOR SELECTION OF THE APPLICABLY SIZED K-BRACE TO USE AND THE DESIGN SPECIFICATIONS FOR THE BRACE
- CAUTION: SOME CARS ARE NOT SUITED FOR THE APPLICATION OF "PARTIAL-LAYER BRACING" BECAUSE THE LENGTH OF THE PARTIAL TIER TO BE SHIPPED AND/OR THE SIZE OR CONFIGURATION OF THE CAR DOORS WILL NOT FER-MIT PROPER INSTALLATION OF THE SPECIFIED K-BRACE DUNNAGE. PIECES MARKED (3), (4), (5), (7), (9), AND (19) MUST BE SUPPORTED AT THE SIDES OF A CARBY A CAR SIDEWALL. IT IS ALRIGHT FOR THE ENDS OF THE DIAGONAL BRACES MARKED 10 TO BEAR IN FRONT OF A DOOR OPENING, HOWEVER, THE

## (CONTINUED AT RIGHT ABOVE).



#### (SPECIAL NOTES CONTINUED)


ADJACENT PIECE MARKED (3) MUST BE DOUBLED AND EXTENDED ACROSS AND FAR ENOUGH PAST THE DOOR OPENING (REF: 60"), TO PROVIDE FOR THE SPECIFIED NAILING OF EACH PIECE. LAMINATE THE SECOND PIECE OF THE DOUBLED PIECE MARKED (8) TO THE FIRST W/16-164 NAILS. CLINCH THOSE NAILS WHICH PROTRUDE THRU THE HORIZONTAL WALL CLEAT WITHIN THE DOOR OPENING. NOTE THAT THE DIAGONAL BRACE WILL BE 49-1/8" OPENING. NOTE THAT THE DIAGONAL BRACE WILL BE 49-1/8" LONG IN LIEU OF 50-1/4" WHEN PIECE MARKED (3) IS DOUBLED.

- THE CENTER CLEAT, SHOWN AS PIECE MARKED (6), WILL 29" LONG FOR AN 9"-6" WIDE CAR, 36" LONG FOR A 9"-2", AND 38" LONG FOR A 9"-4" WIDE CAR. ADJUST THE LENGTH PROPORTIONATELY FOR CARS OF OTHER WIDTHS.
  - IF THE CAR HAS A BOWED END WALL A BULKHEAD MUST BE INSTALLED. SEE THE "END-OF-CAR BULKHEAD" DETAIL

- ANTI-SWAY BRACE (2 REQD), SEE THE "ANTI-SWAY BRACE B" DETAIL ON PAGE 16.
  INSTALL BETWEEN LATERALLY ADJACENT PALLET UNITS, SEE GENERAL NOTES "L"
  AND "M" ON PAGE 2 AND SPECIAL NOTE 2 AT LEFT.
- (2) TOP-OF-LOAD ANTI-SWAY BRACE (1 REQD), SEE THE "TOP-OF-LOAD ANTI-SWAY BRACE B" DETAIL ON PAGE 16, WIRE TIE TO PALLET UNITS AS SHOWN BY THE APPLICABLE TIE WIRE APPLICATION DETAIL ON PAGE 47, NOTE THAT THE QUANTITY IS ONLY FOR THE PARTIAL-TIER UNITS.
- 3 SUPPORT CLEAT, 2" X 4" X 12" (2 REQD). NAIL TO THE CAR SIDEWALL W/4-12d NAILS. POSITION HORIZONTALLY SO AS TO CENTER PIECES MARKED (4) AND (5) ON THE JOINT BETWEEN THE BOTTOM TWO LAYERS OF CONTAINERS ON THE UNITS. SEE SPECIAL NOTE 4 AT LEFT.
- (4) HORIZONTAL PIECE, 2" X 6" BY CAR WIDTH IN LENGTH (CUT TO FIT) (2 REQD). NAIL TO THE CROSS CAR BRACE, PIECE MARKED (5), W/1-124 NAIL EVERY 6".
- (5) CROSS CAR BRACE, 4" X 4" BY CAR WIDTH IN LENGTH (CUT TO FIT) (2 REQD).
- CENTER CLEAT, 2" X 4" X 36" (2 REQD). NAIL TO THE CROSS CAR BRACE, PIECE MARKED (5) W/7-16d NAILS. SEE SPECIAL NOTE 5 ABOVE.
- (7) SPACER CLEAT, 2" X 4" X 15" (2 REQD). NAIL TO THE CAR SIDEWALL W/4-12 NAILS.
- (8) HORIZONTAL WALL CLEAT, 2" X 6" X 72" (4 REQD). NAIL TO THE CAR SIDEWALL W/16-12d NAILS.
- DIAGONAL BRACE, 2" X 4" X 50-1/4" (4 REQD). SEE THE DETAIL AT LEFT FOR BEVEL CUTS REQUIRED. TOENAIL TO THE CROSS CAR BRACE, PIECE MARKED 3, AND TO THE HORIZONTAL WALL CLEAT, PIECE MARKED 3, W/2-16d NAILS AT EACH END.
- BACK-UP CLEAT, 2" X 6" X 24" (4 REQD). NAIL TO THE HORIZONTAL WALL CLEAT, PIECE MARKED (8) , W/8-16d NAILS.
- HOLD-DOWN CLEAT, 2" X 4" X 18" (2 REQD). NAIL TO THE CAR SIDEWALL W/5-12d NAILS.

TYPICAL LCL LOAD USING K-BRACE METHOD OF PARTIAL-LAYER BRACING


- 1. THE TYPE "B" K-BRACE SHOWN IS ADEQUATE FOR RETAINING A PARTIAL TIER OF NOT MORE THAN 14,000 POUNDS. THIS WILL BE NOT MORE THAN SIX (6) PALLET UNITS. IF IT IS NECESSARY TO BLOCK A HEAVIER LOAD, REFER TO THE DETAILS ON PAGES 34 AND 35 FOR SELECTION OF THE APPLICABLY SIZED K-BRACE TO USE AND THE DESIGN SPECIFICATIONS FOR THE BRACE. IF THE PARTIAL TIER TO BE BRACED WEIGHS 8,000 POUNDS OR LESS, THE TYPE "A" K-BRACE DEPICTED ON PAGE 32 MAY BE USED.
- 2. CAUTION: SOME CARS ARE NOT SUITED FOR THE APPLICATION OF "PARTIAL-LAYER BRACING" BECAUSE THE LENGTH OF THE PARTIAL TIER TO BE SHIPPED AND/OR THE SIZE OR CONFIGURATION OF THE CAR DOORS WILL NOT PERMIT PROPER INSTALLATION OF THE SPECEFED K-BRACE DUNNAGE. PECES MARKED (1), (2), (3), (6), (9), (10), AND (11) MUST BE SUPPORTED AT THE SIDES OF A CAR BY A CAR SIDEWALL. IT IS ALRIGHT FOR THE ENDS OF THE DIAGONAL BRACES MARKED (7) TO BEAR IN FRONT OF A DOOR OPENING, HOWEVER, THE ADJACENT PECE MARKED (3) MUST BE DOUBLED AND EXTENDED ACROSS AND FAR ENOUGH PAST THE DOOR OPENING (REF 54") TO PROVIDE FOR THE SPECIFIED NAILING OF EACH PIECE. LAMINATE THE SECOND PIECE OF THE DOUBLED PIECE MARKED (3) TO THE FIRST W/16-164 NAILS. CLINCH THOSE NAILS WHICH PROTRUDE THRU THE HORIZONTAL WALL CLEAT WITHIN THE DOOR OPENING, NOTE THAT THE DIAGONAL BRACE WILL BE 49-1/8" LONG IN LEU OF 50-1/4" WHEN PIECE MARKED (3) IS DOUBLED.
- 3. THE CENTER CLEAT, SHOWN AS PIECE MARKED (4), WILL BE 28" LONG FOR AN 8"-6" WIDE CAR, 36" LONG FOR A 9"-2", AND 38" LONG FOR A 9"-4" WIDE CAR. ADJUST THE LENGTH PROPORTIONATELY FOR CARS FOR CARS OF OTHER WIDTHS.
- 4. REFER TO PAGE 32 FOR A TYPICAL INSTALLATION OF A K-BRACE.



#### ISOMETRIC VIEW

#### KEY NUMBERS


- (1) SUPPORT CLEAT, 2" X 4" X 12" (2 REQD). NAIL TO THE CAR SIDEWALL W/2-124 NAILS. POSITION HORIZONTALLY SO AS TO CENTER PIECES MARKED (2) AND (3) ON THE JOINT BETWEEN THE BOTTOM TWO LAYERS OF CONTAINERS ON THE UNITS. SEE SPECIAL NOTE 2 AT LEFT.
- (2) LOAD BEARING PIECE, 2" X 6" BY CAR WIDTH (CUT TO FIT) (2 REQD).
  NAIL TO THE CROSS CAR BRACE, PIECE MARKED (3), W/1-12d NAILS
  EVERY 6". SEE GENERAL NOTES "L" AND "M" ON PAGE 2.
- (3) CROSS CAR BRACE, 4" X 4" BY CAR WIDTH (CUT TO FIT) (2 RE QD).
- (4) CENTER CLEAT, 2" X 4" X 36" (2 REQD). NAIL TO THE CROSS CAR BRACE, PIECE MARKED (3), W/7-164 NAILS. SEE SPECIAL NOTE 3
- 6 POCKET CLEAT, 2" X 6" X 18" (4 REQD). NAIL TO THE HORIZONTAL WALL CLEAT, PIECE MARKED (5), W/7-164 NAILS.
- 7) DIAGONAL BRACE, 4" X 4" X 50-1/4" (4 REQD). SEE THE DETAIL BELOW FOR BEVEL CUTS REQUIRED. TOENAIL TO THE CROSS CAR BRACE, PIECE MARKED (3), AND TO THE HORIZONAL WALL CLEAT, PIECE MARKED (5), W/1-694 NAIL AT EACH END.
- (8) BACK-UP CLEAT, 2" X 6" X 30" (4 REQD). NAIL TO THE HORIZONTAL WALL CLEAT, PIECE MARKED (§) , W/14-16d NAILS.
- SPACER CLEAT, 2" X 4" X 15" (2 REQD). NAIL TO THE CAR SIDEWALL W/4+12d NAILS.
- 10 HOLD-DOWN CLEAT, 2" X 4" X 18" (2 REQD). NAIL TO THE CAR SIDE-WALL W/5-12d NAILS.
- VERTICAL BACK-UP CLEAT, 2" X 6" BY UNIT HEIGHT (2 REQD), NAIL TO THE CAR SIDEWALL W/8-124 NAILS.



DIAGONAL BRACE
SEE SPECIAL NOTE 2 ABOVE.


-THIS BEARING SURFACE MUST BE POSITIONED SO AS TO BE IN CONTACT WITH A CROSS CAR BRACE PIECE MARKED ③, OR A HORIZONTAL WALL CLEAT, PIECE MARKED ⑤.

TYPE "B" K-BRACE



- 1. THE TYPE "C" K-BRACE SHOWN IS ADEQUATE FOR RETAINING A PARTIAL TER OF NOT MORE THAN 20,000 POUNDS. THIS WILL BE NOT MORE THAN NINE (9) PALLET UNITS. IF IT IS NECESSARY TO BLOCK A HEAVIER LOAD, REFER TO THE DETAIL ON PAGE 35 FOR THE APPLICABLY SIZED K-BRACE TO USE AND THE DESIGN SPECIFICATIONS FOR THE BRACE, IF THE PARTIAL TIER TO BE BRACED WEIGHS BETWEEN 8,000 POUNDS AND 14,000 POUNDS, THE TYPE "B" K-BRACE DEPICITED ON PAGE 33 MAY BE USED. IF THE PARTIAL TIER TO BE BRACED WEIGHS 8,000 POUNDS OR LESS, THE TYPE "A" K-BRACE DEPICITED ON PAGE 32 WILL BE ADEQUATE.
- 2. CAUTION: SOME CARS ARE NOT SUITED FOR THE APPLICATION OF "PARTIAL-LAYER BRACING" BECAUSE THE LENGTH OF THE PARTIAL TER TO BE SHIPPED AND/OR THE SIZE OR CONFIGURATION OF THE CAR DOORS WILL NOT PERMIT PROPER INSTALLATION OF THE SPECIFIED K-BRACE DUNNAGE... PIECES MARKED "), (2), (3), (6), (9), AND (10) MUST BE SUPPORTED AT THE SIDES OF A CAR BY A CAR SIDEWALL. IT IS ALRIGHT FOR THE ENDS OF THE DIAGONAL BRACES MARKED (7) TO BEAR IN FRONT OF A DOOR OPENING, HOWEVER, THE ADJACENT PIECE MARKED (3) MUST BE DOUBLED. LAMINATE THE SECOND PIECE TO THE FIRST W/40-164 NAILS. CLINCH THOSE NAILS WHICH PROTRUDE THAT THE HORIZONTAL WALL CLEAT WITHIN THE DOOR OPENING, NOTE THAT THE DIAGONAL BRACE WILL BE 49-1/8" LONG IN LIEU OF 50-1/4" WHEN PIECE MARKED(3) IS DOUBLED.

#### (CONTINUED AT RIGHT)



- (1) SUPPORT CLEAT, 2" X 4" X 12" (2 REQD). NAIL TO THE CAR SIDEWALL W/2-12d NAILS. POSITION HORIZON TALLY SO AS TO CENTER PIECES MARKED(2) AND (3) ON THE JOINT-BETWEEN THE BOTTOM TWO LAYERS OF CONTAINERS ON THE UNITS. SEE SPECIAL NOTE 2 AT LEFT.
- (2) LOAD BEARING PIECE, 2" X 6" BY CAR WIDTH (CUT TO FIT) (2 REQD).
  NAIL TO THE CROSS CAR BRACE, PIECE MARKED (3), W/1-12d NAIL EVERY
  6". SEE GENERAL NOTES "L" AND "M".ON PAGE 2.
- 3 CROSS CAR BRACE, 4" X 4" BY CAR WIDTH (CUT TO FIT) (2 REQD).
- (4) CENTER CLEAT, 2" X 4" X 36" (2 REQD). NAIL TO THE CROSS CAR BRACE, PIECE MARKED (3) , W /7-16d NAILS. SEE SPECIAL NOTE 3 BELOW.
- (5) HORIZONTAL WALL CLEAT, 2" X 6" BY CUT TO FIT (4 REQD). A CLEAT WILL BE OF A LENGTH AS NECESSARY TO EXTEND ACROSS AND FAR ENOUGH PAST THE DOOR OPENINGS TO CONTACT PIECE MARKED (3) OF THE K-BRACE IN THE OPPOSITE END OF THE CAR. NAIL TO THE CAR SIDEWALL W/40-12d NAILS.
- OPOCKET CLEAT, 2" X 6" X 18" (DOUBLED) (4 REQD). NAIL THE FIRST PIECE TO THE HORIZON TAL WALL CLEAT, PIECE MARKED (5), W/7-16d NAILS. NAIL THE SECOND PIECE TO THE FIRST IN A LIKE MANNER.
- 7 DIAGONAL BRACE, 4" X 4" X 50-1/4" (4 REQD). SEE THE DETAIL BELOW FOR BEVEL CUTS REQUIRED. TOENAIL TO THE CROSS CAR BRACE, PIECE MARKED (3), AND TO THE HORIZONTAL WALL CLEAT, PIECE MARKED (5), W/1-60d NAIL AT EACH END.
- (B) BACK-UP CLEAT, 2"X 6" X 30" (4 REQD). NAIL TO THE HORIZONTAL WALL CLEAT, PIECE MARKED (5),W/14-6d NAILS.
- 9 SPACER CLEAT, 2" X 4" X 15" (2 REQD). NAIL TO THE CAR SIDEWALL W/4-12d NAILS.
- (0) HOLD-DOWN CLEAT, 2" X 4" X 18" (2 REQD). NAIL TO THE CAR SIDEWALL W/5-12d NAILS.


#### (SPECIAL NOTES CONTINUED)

- THE CENTER CLEAT, SHOWN AS PIECE MARKED (4), WILL BE 28" LONG FOR AN 8"-6" WIDE CAR, 36" LONG FOR A 9"-2", AND 38" LONG FOR 9"-4" WIDE CAR. ADJUST THE LENGTH PROPORTIONATELY FOR CARS OF OTHER WIDTHS.
  - CAUTION: A TYPE "C" K-BRACE MUST BE USED IN BOTH ENDS OF THE CAR, THE BRACE IS NOT DESIGNED FOR USE IN ONLY ONE END. NOTE THAT EXCEPT FOR PIECES MARKED (\$), THE QUANTITIES SPECIFIED ARE APPLICABLE ONLY FOR THE BRACE IN ONE END.

- This bearing surface must be positioned as to be in contact with a cross car brace, piece marked 3 , or a horizontal wall cleat, piece marked 5.

PAGE 34

TYPE "C" K-BRACE



- THE TYPE "D" K-BRACE SHOWN IS ADEQUATE FOR RETAINING A PARTIAL TER OF NOT MORE THAN 25,000 POUNDS. THIS WILL NOT BE MORE THAN TEN (10) PALLET UNITS. IF THE PARTIAL TIER TO BE BRACED WEIGHS BETWEEN 14,000 POUNDS AND 20,000 POUNDS, THE TYPE "C" K-BRACE DEPICTED ON PAGE 34 MAY BE USED. FOR A PARTIAL TER OF 8,000 POUNDS TO 14,000 POUNDS, THE TYPE "B" K-BRACE DEPICTED ON PAGE 33 MAY BE USED. IF THE PARTIAL TIER TO BE BRACED WEIGHS 8,000 POUNDS OR LESS, THE TYPE "A" K-BRACE DEPICTED ON PAGE 32 WILL BE ADEQUATE.
- CAUTION: SOME CARS ARE NOT SUITED FOR THE APPLICATION OF "PARTIAL-LAYER BRACING" BECAUSE THE LENGTH OF THE PARTIAL TIER TO BE SHIPPED AND/OR THE SIZE OR CONFIGURATIONS OF THE CAR DOORS WILL NOT PERMIT PROPER INSTALLATION OF THE SPECIFIED K-BRACE DUNNAGE. PIECES MARKED (1), (2), (3), (4), (7), (8), (11), AND (12), MUST BE SUIPPORTED AT THE SIDES OF A CAR BY A CAR SIDEWALL. IT IS ALRIGHT FOR THE ENDS OF THE DIAGONAL BRACES MARKED (3) MUST BE DOUBLED. LAMINATE THE SECOND PIECE TO THE FIRST W/40-164 NAILS. CLINCH THOSE NAILS WHICH PROTRUDE THRU THE HORIZONTAL WALL CLEAT WITHIN THE DOOR OPENING. NOTE THAT THE DIAGONAL BRACE WILL BE 70-1/4" LONG IN LEU OF 71" LONG WHEN PIECE MARKED (4) IS DOUBLED.
- THE CENTER CLEAT, SHOWN AS PIECE MARKED (3), WILL BE 28" LONG FOR AN 8'-6" WIDE CAR, 36" LONG FOR A 9'-2", AND 38" LONG FOR A 9'-4" WIDE CAR, ADJUST THE LENGTH PROPORTIONATELY FOR CARS OF OTHER WIDTHS.
- CAUTION: A TYPE "D" K-BRACE MUST BE USED IN BOTH ENDS OF THE CAR; THE BRACE IS NOT DESIGNED FOR USE IN ONLY ONE END. NOTE THAT EXCEPT FOR PIECES MARKED (§) AND (10), THE QUANTITIES SPECIFIED ARE APPLICABLE ONLY FOR THE BRACE IN ONE END.


MARKED 6 .

# 1 1 " 23" 24 (11)12 3 3 DIAGONAL BRACE SEE SPECIAL NOTE 2 ABOVE. THIS BEARING SURFACE MUST BE POSITIONED SO AS TO BE IN CONTACT WITH A HORIZONTAL WALL CEBAT, PIECE

TYPE "D" K-BRACE

#### KEY NUMBERS

- (1) SUPPORT CLEAT, 2" X 4" X 12" (2 REQD). NAIL TO THE CAR SIDE WALL W/2-12d NAILS, POSITION HORIZ ON TALLY SO AS TO CENTER PIECES MARKED (2) AND (3) ON THE JOINT BETWEEN THE BOTTOM TWO LAYERS OF CONTAINERS ON THE UNITS. SEE SPECIAL NOTE 2 AT
- (2) LOAD BEARING PECE, 2" X 6" BY CAR WIDTH (CUT TO FIT) (2 REQD), NAIL TO THE CROSS CAR BRACE, PECE MARKED (3), W/1-12d NAIL EVERY 6". SEE GENERAL NOTES "L" AND "M" ON PAGE 2.
- (3) CROSS CAR BRACE, 4" X 4" BY CAR WIDTH (CUT TO FIT) (2 RE QD).
- HORIZON TAL PIECE, 2" X 6" BY CAR WIDTH (CUT TO FIT) (2 REQD).
  NAIL TO THE CROSS CAR BRACE, PIECE MARKED (3), W/1-12d NAIL
- (5) CENTER CLEAT, 2" X 4" X 36" (2 REQD). NAIL TO THE HORIZONTAL PIECE, PIECE MARKED (4), W/7-164 NAILS. SEE SPECIAL NOTE 3
- (6) HORIZONTAL WALL CLEAT, 2" X 6" BY CUT TO FIT (4 REQD). CLEAT WILL BE OF A LENGTH AS NECESSARY TO EXTEND ACROSS AND FAR ENOUGH PAST THE DOOR OPENING TO CONTACT PECE MARKED (4) OF THE K-BRACE IN THE OPPOSITE END OF THE CAR. NAIL TO THE CAR SIDEWALL W/40-12d NAILS.
- 7) POCKET CLEAT, 2" X 6" X 36" (4 REQD). NAIL TO THE HORIZONTAL WALL CLEAT, PIECE MARKED 6 , W/10-36d NAILS.
- $\ensuremath{ 8 }$  Pocket cleat, 2" x 6" x 24" (4 reqd). Nail to the pocket cleat, piece marked  $\ensuremath{ ? | }$  , w/2-16d Nails.
- (9) DIAGONAL BRACE, 4" X 4" X 71" (4 REQD). SEE THE DETAIL BELOW FOR BEVEL CUTS REQUIRED. TOENAIL TO THE HORIZONTAL PIECE, PIECE MARKED (4), AND TO THE HORIZONTAL WALL CLEAT, PIECE MARKED (3), W/1-400 NAIL AT EACH END.
  - BACK-UP CLEAT, 2" X 6" BY CUT TO FIT (4 REQD). BOALT-UF CLEAT, 2"A 0" BY CUI TO THE (4 REQD). A CLEAT WILL BE OF A LENGTH AS NECESSARY TO EXTEND TO CONTACT THE DIAGONAL BRACE, PIECE MARKED (9), IN THE OPPOSITE END OF THE CAR. NAIL TO THE HORIZONTAL WALL CLEAT, PIECE MARKED (6), W/19-16d NAILS. CLINCH THOSE NAILS WHICH PROTRUDE THRU THE HORIZONTAL WALL CLEAT WITHIN THE DOOR OPENING,
  - SPACER CLEAT, 2" X 4" X 15" (2 REQD). NAIL TO THE CAR SIDEWALL W/4-12d NAILS.
  - HOLD-DOWN CLEAT, 2"  $\times$  4"  $\times$  18" (2 REQD). NAIL TO THE CAR SIDEWALL W/5-12d NAILS.




#### ISOMETRIC VIEW

#### SPECIAL NOTES:

- A 9'-2" WIDE WOOD-LINED CONVENTIONAL TYPE BOXCAR HAVING A WOOD OR NAILABLE METAL FLOOR IS SHOWN. CARS OF OTHER WIDTHS AND CARS HAVING METAL LININGS CAN BE USED.
- 2. THE LOAD SHOWN DEPICTING THE KNEE BRACE METHOD OF PARTIAL-LAYER BRACING IS TYPICAL. THE QUANTITY MAY BE ADJUSTED TO SUIT, PROVIDED THE LIMITATIONS OF THE KNEE BRACE AS SET FORTH IN SPECIAL NOTE 3 AME NOT EXCEEDED. ALSO, THE LOAD MAY CONSIST OF CROSSWISE POSITIONED CONTAINERS, IN LIEU OF LENGTHWISE AS SHOWN. IF THE CONTAINERS ARE POSITIONED CROSSWISE IN THE CAR, "ANTI-SWAY BRACE A" AND TOP-OF-LOAD ANTI-SWAY BRACE A" DETAILED ON PAGE 14 WILL BE USED IN LIEU OF PIECES MARKED (1) AND (2).
- A KNEE BRACE ASSEMBLY WILL BE USED FOR EACH ROW OF PALLET UNITS.
   ONE (1) KNEE BRACE ASSEMBLY IS ADEQUATE FOR RETAINING A MAXIMUM LCL LOAD OF NOT MORE THAN 8,500 POUNDS.
- 4. HOLD-DOWN CLEATS (GATE HOLD DOWN) MUST BE APPLIED TO THE BOTTOM HORIZONTAL PIECE OF A KNEE BRACE ASSEMBLY. THE PROPER MATERIAL SIZE AND PLACEMENT WILL BE AS DEPICTED BY THE CENTER GATE DETAILS FOR ONE ROW AS SPECIFIED ELSEWHERE. FOR A CROSSWISE ROW REFER TO THE "CENTER GATE A" DETAIL ON PAGE 14. FOR A LENGTHWISE ROW. AS SHOWN ABOVE, REFER TO THE "CENTER GATE C" DETAIL ON PAGE 16.


#### KEY NUMBERS

- 1) ANTI-SWAY BRACE (2 REQD), SEE THE "ANTI-SWAY BRACE B" DET ALL ON PAGE 16. INSTALL BETWEEN LATERALLY ADJACENT PALLET UNITS, SEE GENERAL NOTES "L" AND "M" ON PAGE 2.
- (2) TOP-OF-LOAD ANTI-SWAY BRACE (2 REQD). SEE THE TOP-OF-LOAD ANTI-SWAY BRACE B" DETAIL ON PAGE 16. WIRE THE TO THE PALLET UNIT STRAPPING BOARDS AS TYPICALLY SHOWN BY THE TIE WIRE APPLICATION B" DETAIL ON PAGE 47.
- (3) KNEE BRACE ASSEMBLY (2 REQD), SEE THE DETAIL ON PAGE 37 FGR CONSTRUCTION SPECIFICATION AND NAILING REQUIREMENTS.




## KEY LETTERS .

- A VERTICAL PIECE, 2" X 6" X 36" (2 REQD).
- B HORIZONTAL PIECE, 2" X 6" BY PALLET UNIT LENGTH OR WIDTH AS APPLICABLE (3 REQD). NAIL TO THE VERTICAL PIECES W/3-10d NAILS AT EACH JOINT, SEE GENERAL NOTES "L" AND "M" ON PAGE 2 AND SPECIAL NOTE 4 ON PAGE 3
- (C) FILL PIECE, 2" X 4" X 37-3/4" (1 REQD), NAIL TO THE VERTICAL PIECES W/3-10d NAILS AT EACH JOINT. NOTE: IF THE CONTAINERS ARE POSITIONED CROSSWISE, OMIT PIECE MARKED (C) AND POSITION THE LOWER HORIZONTAL PIECE, PIECE MARKED (B), 1-1/2" FROM THE CAR FLOOR, SEE SPECIAL NOTE 4 ON PAGE 36.
- (D) FLOOR CLEAT, 2" X 6" X 6'-1-1/2" (2 REQD). ALIGN WITH A VERTICAL PIECE AND NAIL TO THE CAR FLOOR W/1-16d NAIL EVERY 8". SEE GENERAL NOTE "R" ON PAGE 2.
- (E) HOLD -DOWN CLEAT, 2" X 6" X 9-1/2" (2 REQD), NAIL TO A VERTICAL PIECE W/5-10d NAILS.
- POCKET CLEAT, 2" X 6" X 12" (TRIPLED) (2 REQD). NAIL THE FIRST PIECE TO THE FLOOR CLEAT, PIECE MARKED (D), W/4-161 NAILS, NAIL THE SECOND AND THIRD PIECES IN A LIKE MANNER AND TOENAIL THE THIRD PIECE TO THE VERTICAL PIECE, PIECE MARKED (A), W/2-161 NAILS.
- (G) BRACE, 4" X 4" X 50" (2 REQD), SEE THE DETAIL AT LEFT FOR BEVEL CUT REQUIRED. TOENAIL TO THE VERTICAL PIECE AND TO THE FLOOR CLEAT, PIECES MARKED (A) AND (D) ,W/2-16d NAILS AT EACH JOINT.
- (H) BACK UP CLEAT, 2" X 6" X 30" (2 REQD). NAIL TO THE FLOOR CLEAT, PIECE MARKED (D), W/6-40d NAILS.
- J HOLD-DOWN CLEAT (NOT SHOWN), SEE SPECIAL NOTE 4 ON PAGE 36.



THE BRACE MUST BE INSTALLED SO THAT THIS BEARING SURFACE WILL BE IN CONTACT WITH THE VERTICAL PIECE MARKED (A).



# HORIZONTAL PIECE, 2" X 6" BY A LENGTH TO SUIT (AS REQD), NAIL TO THE VERTICAL PIECES W/3-10d NAILS AT EACH JOINT, GATE RETAINER, 2" X 6" X 9" (4 REQD). NAIL TO THE HORIZONTAL PIECES W/3-10d NAILS. VERTICAL PIECE, 2" X 6" X 38" (2 REQD). 38 HEIGHT OF STRUT LEDGER TO BE 4-1/2" LESS THAN HEIGHT OF ADJACENT HORIZONTAL 215 PIECE . STRUT LEDGER, 2" X 2" X 29" (2 REQD). NAIL TO THE VERTICAL -PIECE MARKED (5) PIECES W/2-10d NAILS AT EACH END.

CENTER GATE E THIS GATE IS FOR USE WITH LENGTHWISE CONTAINERS.

HORIZONTAL PIECE, 2" X 6" BY A LENGTH TO SUIT (AS REQD). NAIL TO THE VERTICAL PIECES W/3-10d NAILS AT EACH JOINT.

HEIGHT OF STRUT

LEDGER TO BE
4-1/2" LESS THAN
HEIGHT OF ADJACENT
HORIZONTAL PIECE. —

#### SPECIAL NOTES:

- A 50'-6" LONG BY 9'-2" WIDE CONVENTIONAL TYPE BOXCAR IS SHOWN, CARS OF OTHER WIDTHS CAN BE USED, AND SHORTER BUT NOT LONGER CARS WILL BE USED.
- A 1-WIDE LENGT! WISE LOAD IS SHOWN AS TYPICAL. THE DEPICTED PROCEDURES
  ARE ALSO APPLICABLE FOR A 1-WIDE CROSSWISE POSITIONED LOAD OF FIFTEEN (15) PALLET UNITS.
- ONE (1) LCL BRACE WILL BE USED AT EACH SIDE OF EACH PALLET UNIT. CENTER THE BRACE ON THE WIDTH OR LENGTH OF THE UNIT AS APPLICABLE.
- THE BILL OF MATERIAL IS BASED ON THE LOAD AS SHOWN ONLY.
- IF DESIRED, GATE HOLD DOWN PIECES WITH THE ASSOCIATED FILL PIECE, AS SHOWN ELSEWHERE ON THE APPLICABLE CENTER GATE FOR A SINGLE ROW, MAY BE USED IN LIEU OF PIECES MARKED (5).

GATE RETAINER, 2" X 6" X 9" (DOUBLED) (4 REQD).
NAIL THE FIRST PIECE TO THE HORIZONTAL PIECE
W/3-10d NAILS. NAIL THE SECOND PIECE TO THE
FIRST IN A LIKE MANNER. VERTICAL PIECE, 2" X 6" X 38" (2 REQD). 40 늘 ì6<del>ż</del>. 38 345 215 10" LPIECE MARKED (5) STRUT LEDGER, 2"  $\times$  2"  $\times$  29-1/2" (AS REQD). NAIL TO THE VERTICAL PIECES W/2-10d NAILS AT EACH END.

CENTER GATE F
THIS GATE IS FOR USE WITH CROSSWISE CONTAINERS.


BILL OF MATERIAL (TYPICAL)					
LUMBER	LINEAR FEET	BOARD FEET			
1" × 6"	305	153			
2" X 2"	15	5			
2" X 3"	12	6			
2" X 5"	130	130			
4" × 4"	22	30			
NAILS	NO. REQD	POUNDS			
6d ('2")	144	T ,			
Bd ('2-1/2")	288	3-1/4			
TOd ('3")	92	1-1/2			
16d (3-1/2")	192	4-1/4			

#### LOAD AS SHOWN (TYPICAL)

	QUANTITY 12	
DUNNAGE	TOTAL WEIGHT	

TYPICAL LCL LOAD USING 1-WIDE LOADING METHOD

PAGE 39



#### SPECIAL NOTES:

- AN 8'-5" WIDE WOOD-LINED CONVENTIONAL TYPE BOXCAR HAVING A WOOD OR NAILABLE METAL FLOOR IS SHOWN. CARS OF OTHER WIDTHS CAN BE USED. SEE GENERAL NOTE "R" ON PAGE 2.
- THE LOAD SHOWN DEPICTING THE LCL BRACE METHOD OF PARTIAL-LAYER BRACING IS TYPICAL. A CROSSWISE UNIT IS SHOWN. THE PROCEDURES ARE ALSO APPLICABLE FOR LENGTHWISE UNITS AND FOR OTHER QUANTITIES AS LONG AS THE CAPACITY OF THE BRACES IS NOT EXCEEDED.
- LONG AS THE CAPACITY OF THE BRACES IS NOT EXCEEDED.

  SEACH LCL BRACE AS APPLIED FOR LONGITUDINAL BRACING WILL RETAIN 2,000 POUNDS OF LADING. EACH LCL BRACE AS APPLIED FOR LATERAL BRACING WILL SUPPORT 8,000 POUNDS OF LADING. A MINIMUM OF TWO (2) BRACES MUST BE USED FOR LONGITUDINAL BRACING.


  ANGLE BRACE, 1" X 5" BY CUT TO FIT (2 BCGD). NAIL TO THE BACK-UP CLEAT PECE AND TO THE BACK-UP CLEAT PECE AND TO THE BACK-UP CLEAT UP CLEAT W.9-80 NAILS AT EACH END.

  BACK-UP CLEAT W.9-80 NAILS AT EACH END.

  BACK-UP CLEAT 2" X 6" MATERAIL (1) RECO ).

  LCL BRACE

TYPICAL LCL LOAD USING LCL BRACE METHOD OF PARTIAL-LAYER BRACING




POSITIONING OF PARTIAL CROSSWISE UNIT IN A LAYER

#### SPECIAL NOTES:

- SHIPMENTS OF COMPLETE ROUNDS SHOULD CONSIST OF FULL-HEIGHT AND FULL-LAYER UNITS TO THE MAXIMUM EXTENT POSSIBLE. HOWEVER,
  THE END OF A LOT; OR THE QUANTITY OF ITEMS NEEDED TO FILL A REQUISITION, MAY NECESSITATE THE SHIPMENT OF ONE OR MORE LESS-THANFULL PALLET UNITS WITHIN A LOAD. THE PROCEDURES ON THIS PAGE ARE PRESENTED AS GUIDANCE IN THE SHIPMENT OF A PARTIAL UNIT WITHIN A CROSSWISE LOAD.
- A LESS-THAN-FULL HEIGHT PALLET UNIT OF CROSSWISE-POSITIONED CON-TAINERS WHICH IS TO BE A SHIPPED WITHIN A LAYER OF A LOAD HAS NO LIMITATIONS AS TO THE NUMBER OF LAYERS ON THE PARTIAL UNIT. THE DEPICTED PROCEDURES SHOW THE BRACING OF A 2-LAYER UNIT WITHIN A 5-LAYER LOAD. THE PRINCIPLES CAN BE ADAPTED TO SUIT OTHER SIZE
- A PARTIAL UNIT MUST CONSIST OF FULL LAYERS OF SIX (6) CONTAINERS, OR AN APPROVED FILLER ASSEMBLY, AS DETAILED BY DRAWING 19-4079/3-20PM 1002, MUST BE INSTALLED IN THE PLACE OF OMITTED CONTAINERS.
- THE FILLERS AS REFERENCED IN SPECIAL NOTE 3 AND THE DUNNAGE DEPICTED ABOVE FOR THE SHIPMENT OF THE PARTIAL UNIT MAY BE REMOVED WHEN A SHIPMENT REACHES DESTINATION. OR IF DESIRED, THE FILLERS MAY REMAIN WITH THE UNIT DURING STORAGE (IF APPLICABLE) FOR POSSIBLE USE IN A FUTURE SHIPMENT.
- THE "POSITIONING OF PARTIAL CROSSWISE UNIT IN A LAYER" VIEW ABOVE DEPICTS A PORTION OF A CONVENTIONAL BOX CAR-LOAD, HOWEVER, THE PROCEDURES ARE ALSO APPLICABLE FOR LOADS IN CARS EQUIPPED WITH LOAD DIVIDERS BULKHEADS.
- FOR THE SHIPMENT OF A PARTIAL UNIT CONSISTING OF ONE OR TWO LAYERS, THE PROCEDURES SHOWN ON PAGE 44 MAY BE MORE ECONOMICAL.
- THE PARTIAL-UNIT PROCEDURES SHOULD BE APPLIED NEAR THE CENTER OF THE CAR LENGTH BUT NOT IN THE DOORWAY. ALSO, THERE SHOULD BE AT LEAST ONE (1) LOAD UNIT BETWEEN THE PARTIAL UNIT AND A CENTER GATE.

# KEY NUMBERS


- 1) SUPPORT PIECE, 2" X 6" X 37-3/4" ( 2 REQD). POSITION ON TOP OF THE STRAPPING BOARD OF THE PALLET UNIT.
- RETAINER PIECE, 2"  $\times$  4"  $\times$  46" (2 REQD). NAIL TO THE SUPPORT PIECES, PIECES MARKED (1) , W/2-10d NAILS AT EACH JOINT.
- PARTIAL-UNIT GATE (2 REQD). SEE THE "PARTIAL-UNIT GATE A" DETAIL BELOW, SEE GENERAL NOTES "L" AND "M" ON PAGE 2 AND SPECIAL NOTE (3) 2 AT LEFT.
- STRUT, 4"  $\times$  4"  $\times$  32" (4 REQD). TOENAIL TO THE PARTIAL UNIT GATE, PIECE MARKED 3 , W/2-13d NAILS AT EACH END. **④**
- STRAPPING BOARD, 2"  $\times$  4"  $\times$  27" (2 REQD). NAIL TO THE STRUTS, PIECES MARKED 4 , w/2-10d NAILS AT EACH JO INT.
- UNITIZING STRAP, 1-1/4" X .031" OR .035" BY A LENGTH TO SUIT STEEL STRAPPING (2 REQD). PREPOSITION.
- SEAL FOR 1-1/4 STRAPPING (4 REQD, 2 PER JOINT). SEE GENERAL NOTE "N" ON PAGE 2.



STRUT LEDGER, 2" X 2" X 29-1/2"
(2 REQD). NAIL TO THE VERTICAL
PIECES W/2-10d NAILS AT EACH

JOINT. (HEIGHT OF STRUT LEDGERS WILL BE 4-1/2" LESS THAN HEIGHT OF ADJACENT HORIZONTAL PIECES).

PROCEDURES FOR SHIPMENT OF PARTIAL UNITS OF CROSSWISE POSITIONED CONTAINERS




POSITIONING OF PARTIAL LENGTHWISE UNIT WITHIN A LAYER

#### SPECIAL NOTES:


- 1. SHIPMENTS OF COMPLETE ROUNDS SHOULD CONSIST OF FULL-HEIGHT AND FULL-LAYER UNITS TO THE MAXIMUM EXTENT POSSIBLE. HOWEVER, THE END OF A LOT, OR THE QUANTITY OF ITEMS NEEDED TO FILL A REQUISITION, MAY NECESSITATE THE SHIPMENT OF ONE OR MORE LESS-THAN-FULL PALLET UNITS WITHIN A LOAD. THE PROCEDURES ON THIS PAGE ARE PRESENTED AS GUIDANCE IN THE SHIPMENT OF A PARTIAL UNIT WITHIN A LENGTHWISE LOAD.
- 2. A LESS-THAN-FULL HEIGHT PALLET UNIT OF LENGTHWISE-POSITIONED CONTAINERS WHICH IS TO BE SHIPPED WITHIN A LAYER OF A LOAD HAS NO LIMITATIONS AS TO THE NUMBER OF LAYERS OF CONTAINERS ON THE PARTIAL UNIT, THE DEPICTED PROCEDURES SHOW THE BRACING OF A 2-LAYER UNIT WITHIN A 5-LAYER LOAD, THE PRINCIPLES CAN BE ADAPTED TO SUIT OTHER SIZE PARTIAL UNITS.
- A PARTIAL UNIT MUST CONSIST OF FULL LAYERS OF SIX (6) CONTAINERS, OR AN APPROVED FILLER ASSEMBLY, AS DETAILED BY DRAWING 19-48-4079/3 -20PM 1002, MUST BE INSTALLED IN THE PLACE OF OMITTED CONTAINERS.
- 4. THE FILLERS AS REFERENCED IN SPECIAL NOTE 3 AND THE DUNNAGE DEPICTED ABOVE FOR THE SHIPMENT OF THE PARTIAL UNIT MAY BE REMOVED WHEN A SHIPMENT REACHES DESTRUATION. OR IF DESIRED, THE FILLERS MAY REMAIN WITH THE UNIT DURING STORAGE (IF APPLICABLE) FOR POSSIBLE USE IN A FUTURE SHIPMENT.
- THE "POSITIONING OF PARTIAL LENGTHWISE UNIT WITHIN A LAYER" VIEW ABOVE DEPICTS A PORTION OF A CONVENTIONAL BOXCAR LOAD, HOWEVER, THE PROCEDURES ARE ALSO APPLICABLE FOR LOADS IN CARS EQUIPPED WITH LOAD DIVIDER BULKHEADS.
- THE PARTIAL-UNIT PROCEDURES SHOULD BE APPLIED NEAR THE CENTER OF THE CAR LENGTH BUT NOT IN THE DOORWAY. ALSO, THERE SHOULD BE AT LEAST ONE (1) LOAD UNIT BETWEEN THE PARTIAL UNIT AND A CENTER CATE

#### **KEY NUMBERS**

- 1 PARTIAL-UNIT GATE (2 REQD), SEE THE "PARTIAL-UNIT GATE B" DETAIL BELOW, SEE GENERAL NOTES "L" AND "M" ON PAGE 2 AND SPECIAL NOTE 2 AT LEFT.
- 2 STRUT, 4" X 4" X 40-3/8" (4 REQD). TOENAIL TO THE VERTICAL PIECES OF THE PARTIAL-UNIT GATE, PIECE MARKED (1), W/2-14d NAILS AT EACH END.
- 3 STRUT SUPPORT PIECE, 2" X 4" X 8" (4 REQD). NAIL TO A VERTICAL PIECE OF THE PARTIAL-UNIT GATE W/2-104 NAILS.
- 4 STRAPPING BOARD, 2"  $\times$  4"  $\times$  29" (2 REQD). NAIL TO THE STRUTS, PIECES MARKED 3 , W/2-10d NAILS AT EACH END.
- (5) UNITIZING STRAP, 1-1/4" X .031" OR.035" BY A LENGTH TO SUIT STEEL STRAPPING (2 REQD). PRE-POSITION THRU THE FORKLIFT OPENING OF THE PALLET.
- 6 SEAL FOR 1-1/4" STEEL STRAPPING (4 REQD, 2 PER JOINT). SEE GENERAL NOTE "N" ON PAGE 2.
- 7) ANTI-CHAFING NEUTRAL BARRIER MATERIAL. POSITION BETWEEN CONTAINERS AND STRAPPING AT POINTS OF CONTACT.




PROCEDURES FOR SHIPMENT OF PARTIAL UNITS OF LENGTHWISE POSITIONED CONTAINERS



## SECUREMENT OF THREE CONTAINERS


#### SPECIAL NOTES:

- 1. SHIPMENTS OF COMPLETE ROUNDS SHOULD CONSIST OF FULL-HEIGHT AND FULL-LAYER UNITS TO THE MAXIMUM EXTENT POSSIBLE. HOWEVER, THE END OF A LOT, OR THE QUANTITY OF ITEMS NEEDED TO FILL A REQUISITION, MAY NECESSITATE THE SHIPMENT OF ONE OR MORE LEFTOVER CONTAINERS. LEFTOVER CONTAINERS ARE DESCRIBED AS QUANTITY OF CONTAINERS WHICH IS INSUFFICIENT TO FORM A FULL-LAYERED PARTIAL UNIT FOR SHIPMENT EITHER ON TOP OF A LOAD AS SHOWN ON PAGE 44 OR WITHIN A LAYER AS SHOWN ON PAGES 41 AND 42.
- 2. SHIPMENT OF LEFTOVER CONTAINERS IS APPLICABLE FOR CONUS AND OCONUS RAILROAD SHIPMENTS FROM DEPOT TO DEPOT OR FROM DEPOT TO POSTS, CAMPS, AND STATIONS, OR, UPON APPROVAL FROM HIGHER READQUARTERS, FOR SHIPMENTS FROM LOAD, ASSEMBLE, AND PACK PLANTS TO DEPOTS. <u>CAUTION</u>: A LOAD CONTAINING LEFTOVER CONTAINERS IN AN AMOUNT WHICH IS LESS THAN A FULL LAYER, AND SECURED TO THE TOP OF A FULL OR PARTIAL UNIT, MUST NOT BE DESTINED FOR SHIPMENT OVERSEAS BY WATER CARRIER.
- NOTE THAT THE UNITIZING STRAPS MUST NOT GO AROUND THE INTERNEDIATE DUNNAGE ASSEMBLY. THE STRAP MUST BE THREADED BEHIND THE 1" X 2" PIECES OF THE ASSEMBLIES.
- 4. OBVIOUSLY, A PALLET UNIT WITH ONE OR MORE CONTAINERS STRAPPED TO THE TOP MUST BE POSITIONED IN THE TOP LAYER OF A LOAD. THE PREFERRED LOCATION WOULD BE NEAR THE CENTER AREA OF A CAR IF A FULL LOAD IS BEING SHIPPED.
- THE PROCEDURES ON THIS PAGE ARE APPLICABLE FOR THE SHIPMENT OF LEFTOVER CONTAINERS IN ANY OF THE LOADS DEPICTED HEREIN.




# SECUREMENT OF PARTIAL UNIT ON TOP

THIS PROCEDURE IS APPLICABLE ONLY FOR USE IN A CROSSWISE LOAD. CAUTION: THE PARTIAL UNIT ON TOP IS LIMITED TO NOT MORE THAN TWO (2) LAYERS OF CONTAINERS. FOR SHIPMENT OF MORE THAN TWO LAYERS OF CONTAINERS, OR AN ALTERNATIVE METHOD FOR ONE OR TWO LAYERS, REFER TO THE PROCEDURES ON PAGE 41.





PROCEDURES FOR SHIPMENT OF PARTIAL UNITS



THESE 2" X 6" HORIZONTAL PIECES AND 2" X6" VERTICAL PIECES ARE PART OF THE MODIFIED CENTER GATE. SEE THE SPECIAL NOTE


ABOVE.






## BEVEL CUT


BEVEL CUTTING THE STRUTS AS SPECIFIED WILL FACILITATE INSTALLING THE STRUTS WITH A "DRIVE FIT". CAUTION: DO NOT BEVEL A CORNER MORE THAN ONE-HALF INCH (1/2").



## STRUT INSTALLATION


SEE GENERAL NOTE "T" ON PAGE 2 FOR ADDITIONAL STRUT INSTALLATION GUIDANCE.






## ALTERNATIVE GATE HOLD-DOWN

THIS VIEW DEPICTS AN ALTERNATIVE METHOD OF CENTER GATE HOLD DOWN WHICH CAN BE USED IF DESIRED, PROVIDING THE CAR HAS NAILABLE SIBEWALLS.. THIS METHOD MAY BE APPLIED IN LIEU OF USING THE GATE HOLD DOWN PIECES WHICH ARE PART OF A CENTER GATE. NOTE: FOR A GATE NOT LOCATED IN OR NEAR THE DOORWAY AREA, THE GATE HOLD-DOWN CLEAT MAY BE DOUBLED AND NAILED TO THE CAR SIDEWALL TO PROTVIDE A HOLD-DOWN.





THE MODIFICATION PROCEDURES SHOWN IN THIS VIEW ARE APPLICABLE FOR THE CENTER GATES WHEN THE VERTICAL PIECES ARE INSET FROM THE END OF THE HORIZONTAL PIECES AS SHOWN ABOVE. THE RISER PIECE WILL PROVIDE A MEANS FOR CONTACTING THE GATE WITH THE GATE HOLD-DOWN AS SHOWN IN THE "ALTERNATIVE GATE HOLD-DOWN" DETAIL AT THE TOP OF THIS PAGE.


PAGE 48




PAGE 49










# TYPICAL TYPE A

THIS VIEW SHOWS THE INSTALLATION OF A "FILL PIECE" IN A CAR EQUIPPED WITH A STANDARD ADJUSTABLE SIDE FILLER.

## NOTE 1:

NAILING OF "FILL PIECES" IS NOT REQUIRED EXCEPT THAT EACH "FILL PIECE" LOCATED NEAREST THE DOOR OPENINGS OF THE CAR WILL BE SECURED AGAINST LONGITUDINAL MOVEMENT W/1-64 NAIL DRIVEN THROUGH THE SIDE FILLER PANEL AND INTO THE "FILL PIECE".



# TYPICAL TYPE B

THIS VIEW SHOWS A TYPICAL SECTION OF A CAR EQUIPPED WITH HEAVY DUTY, STEEL REINFORCED, ADJUSTABLE SIDE FILLERS. A "FILL PIECE", AS SHOWN IN THE "TYPICAL TYPE A" DETAIL ABOVE, IS NOT REQUIRED IN CARS SO EQUIPPED.

1				
1				
		•		
1				
1				
1				
1				
1				
1				
1				
1				
1				
1				
ļ				
1				
i				
		•		
1				
1				
1				
1				
1				
!				
1				
1				
Ì				
i				
				•
i				
Į.				
l				
l				
f				
į.				
1				
1				
İ				
l				
l	•			
1				
I				
I				
I				
l				
I				
l				
l				
1				
1			/	
1				
1				
I				
1				
I				
!				
1				
l				
1				
]				
l				
[				
L				
PAGE 54				
I PAGE 5/1				