LOADING AND BRACING (TL & LTL) IN CLOSED OR OPEN TOP VAN TRAILERS OF COMPLETE ROUNDS PACKED IN CYLINDRICAL METAL CONTAINERS AND UNITIZED ON A 42" X 44-1/2" METAL PALLET

PAII7 SERIES CONTAINER

INDEX

<u>ITEM</u>	PAGE (S)
GENERAL NOTES AND MATERIAL SPECIFICATIONS	2
PALLET UNIT DETAIL	4-9
TYPICAL LTL PROCEDURESPROCEDURES FOR SHIPMENT OF LEFTOVER CONTAINERS	10-13 14
PROCEDURES FOR SHIPMENT OF A PARTIAL PALLET UNIT	15
PROCEDURES FOR CONVENTIONAL VAN TRAILERS	
EQUIPPED WITH ROLL-UP TYPE DOORS	20-21
EQUIPPED WITH LARGE-ANGLED FRONT CORNERS	22

THIS DOCUMENT INCLUDES OUTLOADING PROCEDURES FOR CONVENTIONAL TYPE TRAILERS AND FOR TRAILERS EQUIPPED WITH MECHANICAL BRACING DEVICES AS APPROVED BY THE BUREAU OF EXPLOSIVES, ASSOCIATION OF AMERICAN RAILROADS. CAUTION: THE PROCEDURES SHOWN HEREIN, FOR BOTH TYPES OF TRAILERS, ARE ONLY APPLICABLE FOR HIGHWAY MOVEMENTS: NOI FOR CONTAINER/TRAILER-ONFLAT-CAR MOVEMENTS.

	REVISIONS	DALY CHECKER	sd PB	WRF	
		GKG	120	ENT, SUMITIONS	
-	- 	APPOPLE OF COURT OF COMMANDES PERSON, U.S. ARMY			
				MMUNITION CENTER	
		U. S.	ARMY	AMC D	RAWING
		FEBRUARY 1988			
		- CLASS	DIVISION	DRAWING	FILE
		19	48	4213/ 9	11 PM 1003

DO NOT SCALE

GENERAL NOTES

- A. THIS DOCUMENT HAS BEEN PREPARED AND ISSUED IN ACCORDANCE WITH AR 740-1, AND AUGMENTS TM 743-200-1 (CHAPTER 5).
- 8. THE OUTLOADING PROCEDURES SPECIFIED IN THIS DRAWING ARE APPLICABLE FOR THE PA117 COMPLETE ROUND CONTAINER ASSEMBLED ON THE 42" X 44-1/2" 4-WAY ENTRY PALLET. SEE THE PHOTORIAL VIEW ON PAGE 3 FOR SIZE AND WEIGHT, REFER TO U.S. ARMY AMC DRAWING 19-48-4079/8-20PM 1002 FOR UNITIZATION PROCEDURES FOR THE PA117 METAL AMMUNITION CONTAINERS.
- C. THE OUTLOADING PROCEDURES DEPICTED WITHIN THIS DOCUMENT ARE APPLICABLE FOR SHIPMENTS IN CONVENTIONAL TYPE VAN TRAILERS AND FOR SHIPMENT IN VAN TRAILERS EQUIPPED WITH VARIOUS TYPES OF SELF-CONTAINED MECHANICAL BRACING DEVICES (CROSS MEMBERS AND WALL MEMBERS) AND APPLY TO TRAILERS HAVING WOOD, OR WOOD AND METAL, OR ALL METAL FLOORS. VAN TRAILERS WHICH ARE 40'-0" LONG BY 7'-6" TO 7'-8-1/2" WIDE (INSIDE DIMENSION) HAVE BEEN SHOWN. HOWEVER, THE PROCEDURES ABE ALSO APPLICABLE FOR TRAILERS WHICH ARE FIGHTY-NINE INCHES (89") THRU NINETY-NINE (99") IN WIDTH AND FOR TRAILERS OF OTHER LENGTHS FROM THE SHORTEST TO THE LONGEST AVAILABLE (REF. 24' TO 3') AND FOR STRAIGHT TRUCK VANS. THE LOADING AND BRACING PROCEDURES SPECIFIED HEREIN ARE ALSO ADEQUATE (CONFIGURATION WISE AND STRENGTH WISE) FOR LOADS IN SHORTER OR LONGER VANS AND IN NARROWER OR WIDER VANS THAN SHOWN. THE SPECIFIED BRACING IS ADEQUATE FOR LOADS WEIGHING UP TO AND INCLUDING THE MAXIMUM WEIGHTS PERMITTED BY LAW.
- D. THE OUTLOADING PROCEDURES DEPICTED WITHIN THIS DOCUMENT FOR TRAILERS EQUIPPED WITH VARIOUS TYPES OF SELF-CONTAINED MECHANICAL BRACING DEVICES ARE LIMITED TO HIGHWAY MOVEMENTS ONLY. THE HEIGHT REQUIREMENTS SPECIFIED WITHIN THIS DRAWING FOR THE INSTALLATION OF CROSS MEMBERS ARE IDENTICAL WITH THOSE RECOMMENDED BY THE BUREAU OF EXPLOSIVES PAMPHLET 6C AND APPENDICES THERETO, CAUTION: TRAILERS EQUIPPED WITH WALL MEMBERS WHICH DO NOT MEET THE LOCATION REQUIREMENTS MUST NOT BE USED.
 - PALLET UNITS SHOULD BE LOADED TIGHTLY AGAINST EACH OTHER AND/OR AGAINST INSTALLED CROSS MEMBERS. VOIDS LENGTHWISE WITHIN A LOAD SHOULD BE MINIMUM. CROSS MEMBERS MUST BE PLACED AGAINST THE LADING AS TIGHTLY AS THE WALL MEMBER LOCKING HOLE SPACING FERMITS. EACH CROSS MEMBER WILL BE INSTALLED WITH EACH END ATTACHED AS NEARLY AS POSSIBLE IN A "MATED" POSITION (AT EQUAL HEIGHTS, AND AT EQUAL DISTANCES FROM THE END OF THE TRAHLER).
 - CROSS MEMBERS IN EMPTY TRAILERS AND THOSE UNUSED IN LOADED TRAILERS MUST BE "SECURED" FOR SHIPMENT, COMPONENTS ASSIGNED TO EACH TRAILER MUST REMAIN THEREWITH EVEN THOUGH UNUSED DURING SOME SHIPMENTS,
 - ONE (1) CROSS MEMBER WILL SE REQUIRED FOR EACH 10,000 POUNDS OF LADING AND SHOULD NOT SE RELIED UPON TO RETAIN A GREATER WEIGHT. CROSS MEMBERS WILL NOT BE DOUBLED, THAT 15, TWO CROSS MEMBERS AT THE SAME HEIGHT LOCATION WILL NOT BE PLACED SIDE BY SIDE.
- E. SELECTION OF A VEHICLE TO BE USED TO TRANSPORT THE DESIGNATED ITEM MUST COMPLY WITH AR 55-355, CHAPTER 29 FOR EXPLOSIVES AND OTHER DANGEROUS ARTICLES, IN FULL.
- F. THE GROSS WEIGHT AND AXLE DISTRIBUTION OF WEIGHT FOR A LOAD WILL BE THE RESPONSIBILITY OF THE CARRIER, THE CARRIER WILL ADVISE THE SHIPPER OF THE APPLICABLE LOADING REQUIREMENTS, AND THE SHIPPER WILL LOAD ACCORDINGLY. THE TOTAL WEIGHT OF THE LADING, OF THE DUNNAGE, OF THE TRACTOR AND OF THE SEMI-TRAILER CARRYING THE LADING MUST NOT EXCEED THE MAXIMUM GROSS WEIGHT ALLOWED FOR THE STATE OR STATES THRU WHICH THE LOAD IS TO BE TRANSPORTED BY MOTOR CARRIER, LIKE-WISE, THE GROSS WEIGHT ON A SINGLE OR TANDEM AXLE MUST NOT EXCEED THE MAXIMUM ALLOWABLE WEIGHT. IF THERE IS ANY DOUBT AS TO WHETHER THE TOTAL GROSS WEIGHT OF AXLE WEIGHT EXCEEDS THE MAXIMUM ALLOWABLE WEIGHT.


(CONTINUED AT RIGHT)

MATERIAL SPECIFICATIONS


LUMBER	FED SPEC MM-L-751; DUNNAGE LUMBER, SEE TM 743-200-1.
<u>MAILS</u>	FED SPEC FF=N=105: COMMON.
	FED SPEC QQ-S-781: CLASS 1, TYPE I OR $\overline{\mathbf{IV}}$, HEAVY DUTY, FIN ISH A, 8 (GRADE 2), OR C.
	FED SPEC QQ-S-781; TYPE D, STYLE I, II, OR $\overline{\bf M}$, CLASS H, FINISH A, B (GRADE 2) OR C.
	GROUP B, CONSTRUCTION AND INDUSTRIAL PLYWOOD, INTERIOR WITH EXTERIOR GLUE, GRADE C-D, FED SPEC NN-P-530. IF SPECIFIED GRADE IS NOT AVAILLABLE, A BETTER INTERIOR OR AN EXTERIOR GRADE MAY BE SUBSTITUTED.
<u>WIRE</u>	FED SPEC QQ-W-461.
TYGARD:	POLYESTER YARN, 1,100 POUNDS/INCH OF WIDTH STRENGTH.
ADHESIVE	TYGARD ADHESIVE.

(GENERAL NOTES CONTINUED)

- G. NOTICE: A SHIPMENT WILL BE POSITIONED IN THE TRAILER CONSISTENT WITH STATE WEIGHT LAWS, THE NUMBER OF LADING UNITS MAY BE ADJUSTED TO FIT THE SIZE THE TRAILER TO BE LOADED OR THE QUANTITY TO BE SHIPPED. COMBINATIONS OF THE OUTLOADING PROCEDURES SPECIFIED MAY BE USED; HOWEVER, THE APPROVED METHODS SHOWN MUST BE FOLLOWED AS CLOSELY AS POSSIBLE FOR BLOCKING, BRACING AND STAYING OF THE DESIGNATED ITEMS.
- H. THE "LOAD AS SHOWN" FOR MOST OF THE FULL LOADS DEPICTED HEREIN IS BASED ON AN APPROXIMATE LADING WEIGHT OF 42,000 POUNDS. THE SPECIFED BLOCKING AND BRACING FOR THE FULL LOADS IS ADEQUATE FOR THE RETENTION OF HEAVIER LOADS, IF IT IS DESIRED TO INCREASE THE LADING WEIGHT.
- J. OTHER TYPES OF LADING ITEMS MAY BE LOADED INTO TRAILERS WHICH ARE PARTIALLY LOADED WITH PALLET UNITS OF COMPLETE ROUNDS, PROVIDING THE TOTAL LOAD IS COMPATIBLE, EXISTING DIRECTIVES ARE NOT VIOLATED AND THE OTHER LADING ITEMS ARE BLOCKED AND BRACED TO EQUAL THE BLOCKING AND BRACING CRITERIA SPECIFIED HEREIN.
- K. SOME LOADS ARE SHOWN IN TRAILERS HAVING ROUNDED CORNERS AT THE FORWARD END. IF THE CONVENTIONAL VAN TRAILER SEING USED IS EQUIPPED WITH A SQUARE FRONT OR WITH AN INSTALLED BULKHEAD, OMIT THE FORWARD BLOCKING ASSEMBLY, PIECE MARKED (1), AND POSITION THE PALLET UNITS DIRECTLY AGAINST THE FORWARD PORTION OF THE TRAILER: OMIT CROSS MEMBERS IN THE FORWARD END OF MECHAINCAL VAN TRAILERS HAVING A SQUARE FRONT.
- L. PALLET UNITS WHICH DO NOT CONTAIN A FULL QUANTITY OF ITEMS CAN BE TRANSPORTED. SEE THE "SHIPMENT OF A PARTIAL PALLET UNIT" DETAIL AND SPECIAL NOTES ON PAGE 15. FOR "SHIPMENT OF LEFTOVER CONTAINERS", SEE THE DETAILS AND SPECIAL NOTES ON PAGE 14.
- M. WHEN STEEL STRAPPING IS SEALED AT AN END-OVER-END LAP JOINT,
 A MINIMUM OF ONE (1) SEAL WITH TWO (2) PAIR OF NOTCHES WILL
 BE USED TO SEAL THE JOINT WHEN A NOTCH-TYPE SEALER IS BEING USED,
 A MINIMUM OF TWO (2) SEALS, BUTTED TOGETHER, WITH TWO (2)
 PAIR OF CRIMPS PER SEAL WILL BE USED TO SEAL THE JOINT WHEN A
 CRIMP-TYPE SEALER IS BEING USED. REFER TO THE "STRAP JOINT A"
 AND "STRAP JOINT B" DETAILS ON PAGE 3 FOR GUIDANCE.
- N. DUNNAGE LUMBER SPECIFIED THROUGHOUT THIS PROCEDURAL DRAWING IS OF NOMINAL SIZE, FOR EXAMPLE, 2" X 4" MATERIAL IS ACTUALLY 1-1/2" THICK BY 3-1/2" WIDE AND 2" X 6" MATERIAL IS ACTUALLY 1-1/2" THICK BY 5-1/2" WIDE.
- O. NOTICE: A STAGGERED NAILING PATTERN WILL BE USED WHEREVER POSSIBLE WHEN NAILS ARE DRIVEN INTO JOINTS OF DIFFINAGE ASSEMBLIES. ALSO, A STAGGERED NAILING PATTERN WILL BE USED WHEN DUNNAGE IS NAILED TO THE FLOOR OF THE TRANSPORTING VEHICLE, OR WHEN LAMINATING DUNNAGE, THE NAILING PATTERN WILL BE ADJUSTED AS REQUIRED SO THAT A NAIL DOES NOT PENETRATE INTO OR NEAR A CRACK BETWEEN FLOOR BOARDS. ADDITIONALLY, THE NAILING PATTERN FOR AN UPPER PIECE OF LAMINATED DUNNAGE WILL BE ADJUSTED AS REQUIRED SO THAT A NAIL FOR THAT PIECE WILL NOT BE DRIVEN THROUGH ONTO OR RIGHT BESIDE A NAIL IN A LOWER PIECE.
- P. POWER DRIVEN STAPLES MAY SE USED AS ALTERNATIVE FASTENERS FOR NAILS WHEN CONSTRUCTING DUNNAGE ASSEMBLIES WHICH ARE TO BE USED IN THE DELINEATED TRAILER LOADS SHOWN THROUGHOUT THIS DRAWING. THE STAPLES TO BE USED MUST BE EQUAL IN LENGTH TO THE SPECIFIED NAIL SIZE AND MUST BE SUBSTITUTED ON A ONE STAPLE FOR ONE NAIL BASIS, STAPLES WHICH ARE 2-1/2" OR LESS IN LENGTH SHOULD BE IN ACCORDANCE WITH FEDERAL SPECIFICATION FF-N-105 AS NEARLY AS PRACTICABLE, STAPLES WHICH ARE LONGER THAN 2-1/2" WILL BE A COMMERCIAL GRADE, OF A QUALITY EQUIVALENT TO THOSE MANUFACTURED BY SENCO PRODUCTS INCORPORATED, NOTE: STAPLES WILL NOT BE SUBSTITUTED FOR NAILS IN ANY LOAD RESTRAINING FLOOR DUNNAGE APPLICATION.
- Q. PORTIONS OF THE TRAILERS, SUCH AS SIDEWALLS, END WALLS, AND ROOFS, HAVE NOT SEEN SHOWN IN THE LOAD VIEWS FOR CLARITY PURPOSES.
- R. FOR ADDITIONAL GUIDANCE, ATTENTION IS DIRECTED TO THE "SPECIAL NOTES" SECTIONS WHICH ARE IMMEDIATELY ADJACENT TO THE DEPICTED OUTLOADING METHODS.
- CONVERSION TO METRIC EQUIVALENTS: DIMENSIONS WITHIN THIS DOCUMENT ARE EXPRESSED IN INCHES AND WEIGHTS ARE EXPRESSED IN POUNDS. WHEN NECESSARY, THE METRIC EQUIVALENTS MAY BE COMPUTED ON THE BASIS OF ONE INCH EQUALS 25,4 MM AND ONE POUND EQUALS 0.454 KG.
- T. LONGITUDINALLY ADJACENT PALLET UNITS IN A TRAILER WILL BE POSITIONED WITH THE BASE END AGAINST BASE END OR BELL END AGAINST BELL END. THE FRONT LOAD UNIT IN A TRAILER WILL BE POSITIONED WITH THE BASE ENDS OF THE CONTAINERS TOWARD THE-FRONT WALL OF THE TRAILER.



PALLET UNIT




STRAP JOINT A

METHOD OF SECURING A STRAP JOINT WHEN USING A NOTCH-TYPE SEALER.



STRAP JOINT B

METHOD OF SECURING A STRAP JOINT WHEN USING A CRIMP-TYPE SEALER,



- A 22-UNIT LOAD IS SHOWN IN A 40'-0" LONG 8Y 7'-8" WIDE (INSIDE DIMENSION) CONVENTIONAL TYPE VAN TRAILER. TRAILERS OF OTHER DIMEN-SIONS CAN RE USED.
- 2. ANTI-SWAY BRACES, SHOWN AS PIECES MARKED (2), IN THE LOAD ON PAGE 4 ARE TO BE POSITIONED BETWEEN ALL LATERALLY ADJACENT PALLET UNITS.
- 3. IF THE VOID AT THE REAR OF THE LOAD BETWEEN THE PALLET UNITS AND THE REAR DOOR MEASURES 1-1/2" OR LESS, REAR BLOCKING IS NOT REQUIRED. IF THE VOID AT THE REAR OF THE LOAD IS GREATER THAN 1-1/2" BUT LESS THAN 9", USE "REAR BLOCKING ASSEMBLY C" AS DETAILED ON PAGE 18. IF THE VOID AT THE REAR OF THE LOAD IS 9" OR GREATER, USE THE REAR BLOCKING ASSEMBLY, PIECE MARKED 4 ON PAGE 4. SEE SPECIAL NOTE 8.
- 4. THE STACK UNITIZING STRAPS, PIECES MARKED (5) IN THE LOAD ON PAGE 4, WILL BE INSTALLED TO SECURE AN UNSUPPORTED PALLET UNIT IN THE SECOND LAYER TO A CORRESPONDING UNIT IN THE FIRST LAYER, EXCEPT AT THE VERY REAR OF THE LOAD. PALLET UNITS MUST NOT BE POSITIONED ON TOP OF THE REARMOST LOAD UNIT.
- IF THE QUANTITY OF UNITS IS REDUCED FROM WHAT IS SHOWN, OR IF THE TRAILER TO BE LOADED IS LONGER THAN 40°, THE SPACER ASSEMBLY PROCEDURES SPECIFIED IN SPECIAL NOTE 3 ON PAGE 7 CAN ALSO BE USED FOR THE DEPICTED LOAD.
- 6. REFER TO PAGE 15 FOR GUIDANCE IN THE SHIPMENT OF PARTIAL PALLET UNITS.
- LEFTOVER CONTAINERS IN AN AMOUNT NOT TO EXCEED FIVE (5) MAY BE SECURED TO THE TOP OF A FULL PALLET UNIT FOR SHIPMENT, REFER TO THE "PROCEDURES FOR SHIPMENT OF LEFTOVER CONTAINERS" ON PAGE 14 FOR GUIDANCE.
- B. TRAILERS EQUIPPED WITH ROLL-UP TYPE DOORS MAY SE USED: HOWEVER, SPECIAL REAR BLOCKING MUST BE INSTALLED. SEE THE "PROCEDURES FOR CONVENTIONAL VAN TRAILERS EQUIPPED WITH ROLL-UP TYPE DOORS" ON PAGES 20 AND 21 FOR GUIDANCE. THE NAILED-HEADER METHOD IS SHOWN ON PAGE 21 AND THE TYGARD METHOD IS SHOWN ON PAGE 20. NOTE THAT THE SPECIAL REAR BLOCKING FOR TRAILERS EQUIPPED WITH ROLL-UP TYPE DOORS MAY ALSO BE USED IN TRAILERS EQUIPPED WITH HINGED DOORS.


LUMBER	LINEAR FEET	8OARD FEET
1" X 4"	15	. 5
2" X 3"] <u>Z</u>	· <u> </u>
2" X 4"	115	` 77
2" X 6"	63	63
NAILS	NO. REQD	POUNDS
6d (2")	16	NIL
104 (3")	234	3-3/4


LOAD AS SHOWN

TOTAL WEIGHT ----- 41,735 LBS

22-UNIT LOAD IN A 40'-0" LONG BY 7'-8" WIDE CONVENTIONAL VAN TRAILER

PAGE 5






TYPICAL REAR VIEW OF AN 8'-2" WIDE VAN

BILL OF MATERIAL			
LUMBER	LINEAR FEET	BOARD FEET	
1" × 4" 1" × 6" 2" × 4" 2" × 6"	8 8 36 51	3 4 24 51	
NAILS	NO. REQD	POUNDS	
10d (3")	80	1-1/4	

- A 22-UNIT LOAD IS SHOWN IN A 40'-0" LONG BY 7'-8" WIDE (INSIDE DIMENSION) CONVENTIONAL VAN TYPE TRAILER, TRAILERS OF OTHER DIMENSIONS CAN BE USED. SEE SPECIAL NOTES 2 AND 3.
- IF A TRAILER WHICH IS WIDER THAN 7'-11" IS TO BE LOADED, CRIB FILL
 WILL BE REQUIRED BETWEEN LATERALLY ADJACENT PALLET UNITS. SEE
 THE "TYPICAL REAR VIEW OF AN 8'-2" WIDE VAN" AT LEFT, AND THE
 "CRIB FILL" DETAIL ON PAGE 16."
- 3. IF THE QUANTITY OF UNITS IS REDUCED FROM WHAT IS SHOWN, OR IF THE TRAILER TO BE LOADED IS LONGER THAN 40', SPACER ASSEMBLY "C" DETAILED ON PAGE 19, AND/OR SPACER ASSEMBLY "A" DETAILED ON PAGE 18 CAN SE USED FOR THE PURPOSE OF PROVIDING FOR PROPER WEIGHT DISTRIBUTION, OR MAY BE USED IN LIEU OF ONE AND/OR TWO OMITTED UNITS. NOTE THAT THE SPACER ASSEMBLES MUST NOT BE POSITIONED ADJACENT TO THE FORWARD BLOCKING ASSEMBLY PIECE MARKED (1), AND THEY MUST BE POSITIONED WHERE THERE WILL BE A PALLET UNIT AT EACH END OF EACH ASSEMBLY.
- 4. IF PALLET UNITS ARE TO BE LOADED ON THE TOP LAYER OF THE DEPICTED LOAD, STACK UNITIZING STRAPS, 21'-5" LONG WILL BE INSTALLED TO SECURE AN UNSUPPORTED PALLET UNIT IN THE SECOND LAYER TO A CORRESPONDING UNIT IN THE FIRST LAYER, PALLET UNITS MUST NOT BE POSITIONED ON TOP OF THE REARMOST LOAD UNIT, SEE KEY NUMBER (5) ON PAGE 4 FOR A TYPICAL INSTALLATION.
- 5. IF THE SPACE AT THE REAR OF THE LOAD BETWEEN THE PALLET UNITS AND THE REAR DOOR IS GREATER THAN 1-1/2" BUT LESS THAN 9", USE REAR BLOCKING ASSEMBLY "C" AS SHOWN IN THE LOAD ON PAGE 6. IF THE VOID AT THE REAR OF THE LOAD IS 9" OR GREATER, USE THE REAR BLOCKING ASSEMBLY "B" SHOWN ON PAGE 17. IF THE VOID AT THE REAR OF THE LOAD MEASURES 1-1/2" OR LESS, REAR BLOCKING IS NOT REQUIRED. SEE SPECIAL NOTE 8.
- 6. REFER TO PAGE 15 FOR GUIDANCE. IN THE SHIPMENT OF PARTIAL PALLET UNITS.
- LEFTOVER CONTAINERS IN AN AMOUNT NOT TO EXCEED FIVE (5)
 MAY BE SECURED TO THE TOP OF A FULL PALLET UNIT FOR SHIPMENT.
 REFER TO THE "PROCEDURES FOR SHIPMENT OF LEFTOVER CONTAINERS"
 ON PAGE 14 FOR GUIDANCE.
- B. TRAILERS EQUIPPED WITH ROLL-UP TYPE DOORS MAY BE USED; HOWEVER, SPECIAL REAR BLOCKING MUST BE INSTALLED. SEE THE "PROCEDURES FOR CONVENTIONAL VAN TRAILERS EQUIPPED WITH ROLL-UP TYPE DOORS" ON PAGES 20 AND 21 FOR GUIDANCE. A NAILED-HEADER METHOD AND A TYGARD METHOD ARE SHOWN. FOR THE DEPICTED LOAD IN A 40'-0" LONG TRAILER WHEN USING THE NAILED-HEADER METHOD, IT WILL SE NECESSARY TO FORM TEN (10) LOAD UNITS INSTEAD OF ELEVEN (11) AS SHOWN. NOTE THAT THE SPECIAL REAR BLOCKING FOR TRAILERS EQUIPPED WITH ROLL-UP TYPE DOORS MAY ALSO BE USED IN CONVENTIONAL VAN TRAILERS EQUIPPED WITH HINGED DOORS.


LOAD AS SHOWN



- A 22-UNIT LOAD IS SHOWN IN A 40'-0" LONG BY 7'-8" WIDE (INSIDE DIMENSION)
 TRAILER EQUIPPED WITH MECHANICAL BRACING DEVICES. TRAILERS OF OTHER
 DIMENSIONS CAN BE USED."
- 2. CROSS MEMBERS ARE REQUIRED AT THE 4" HEIGHT LOCATION TO PREVENT DISPLACEMENT OF THE ANTI-SWAY BRACES SHOWN AS PIECE MARKED (2). THESE CROSS MEMBERS, EXCEPT FOR THE ONE POSITIONED AT THE REAR OF THE LOAD, CAN BE OMITTED IF PALLET UNITS ARE POSITIONED AGAINST THE FROWARD END OF THE TRAHLER, OR IF THE CROSS MEMBERS ARE OMITTED FROM THE CENTER PORTION OF THE LOAD AS SPECIFIED IN SPECIAL NOTE 8.
- IF A PALLET UNIT IS TO BE ADDED OR OMITTED FROM THE DEPICTED LOAD, THE SPACER ASSEMBLY PROCEDURES DEPICTED ON PAGE 13 MAY BE USED. NOTE THAT CROSS MEMBERS ARE REQUIRED AT BOTH ENDS OF THE ODD UNIT.
- 4. REFER TO PAGE 15 FOR GUIDANCE IN THE SHIPMENT OF PARTIAL PALLET UNITS.
- LEFTOVER CONTAINERS IN AN AMOUNT NOT TO EXCEED FIVE (5) MAY BE SECURED TO THE TOP OF A FULL PALLET UNIT FOR SHIPMENT, REFER TO THE "PROCEDURES FOR SHIPMENT OF LEFTOVER CONTAINERS." ON PAGE 14 FOR GUIDANCE.
- FOR SHIPMENT OF LESS THAN FULL LOADS, REFER TO THE APPLICABLE GUIDANCE. ON PAGE 13.
- A PALLET UNIT IN THE SECOND LAYER MUST BE UNITIZED TO A PALLET UNIT IN THE FIRST LAYER, WITH UNITIZING STRAPS, PRECES MARKED (4).
- 8. IF THE TRAILER BEING LOADED IS EQUIPPED ONLY WITH SHORT WALL MEMBERS AT THE REAR FOR ATTACHMENT OF THE CROSS MEMBERS, THE CROSS MEMBERS LOCATED AT THE FRONT OF THE TRAILER AND THOSE LOCATED NEAR THE CENTER PORTION OF THE LOAD LENGTH WILL BE OMITTED; TWO (2) PALLET UNITS MILL HAVE TO BE OMITTED, A 1/2" PLYWOOD GATE WHICH IS UNIT HEIGHT BY TRAILER WIDTH MINUS 1/2" MUST BE INSTALLED AT THE REAR OF THE LOAD, AND A CROSS MEMBER MUST BE INSTALLED AT THE 18" HEIGHT LOCATION. IF THE TRAILER BEING LOADED IS LONGER THAN 40"-9" AND/OR IF LESS THAN 20 UNITS ARE TO BE TRANSPORTED, A SPACER ASSEMBLY WILL BE REQUIRED TO PROVIDE FOR PROPER WEIGHT DISTRIBUTION. POSITION BETWEEN THE SECOND AND THIRD OR THIRD AND FOURTH LOAD UNITS, DEPENDING UPON THE LENGTH OF TRAILER, AND THE QUANTITY TO BE TRANSPORTED. SEE THE "SPACER ASSEMBLY C" DETAIL ON PAGE 19.

BILL OF MATERIAL			
LUMSER	LINEAR FEET	BOARD FEET	
1* × 4* 2* × 4* 2* × 6*	15 82 14	5 55 14	
NAILS	NO. REQD	POUNDS	
6d (2") 10d (3")	16 144	NIL 2-1/4	

LOAD AS SHOWN



ISOMETRIC VIEW

(KEY NUMBERS CONTINUED)

- (2) SPLICE PIECE, 2" X 6" X 24" (AS REQD), CENTER ON JOINT OF PIECES MARKED (9) AND NAIL TO SIDE STRUT MARKED (9) W/4-104 NAILS AT EACH END. SEE SPECIAL NOTE 4 ON PAGE 11.
- (3) CENTER CLEAT, 2" X 6" X 30" (I REQD). NAIL TO A HEADER, PIECE MARKED (6) , W/6-10d NAILS.
- (14) DIAGONAL BRACE, 2" X 6" BY CUT-TO-FIT (2 REQD). DOUBLE BEVEL EACH END WITH 45" CUTS. INSTALL AT A 45" ANGLE AS SHOWN AND TOENAIL TO THE ADJACENT HEADER AND SIDE STRUT, PIECES MARKED (6) AND (7) W/2-164 NAILS AT EACH END.
- (5) BACK-UP CLEAT, 2" X 6" X 24" (2 REQD). NAIL TO A SIDE STRUT, PIECE MARKED (9), W/8-104 NAILS.
- (6) STRUT BRACE RETAINING CLEAT, 2" X 4" X 12" (AS REOD), NAIL TO A SIDE STRUT, PIECE MARKED (9), W/3-101 NAILS. SEE SPECIAL NOTE 5 ON PAGE 11.
- (7) STRUT BRACE, 2" X 4" BY TRAILER WIDTH MINUS 3" IN LENGTH (MINIMUM OF ONE REQUIRED). NAIL TO THE POCKET CLEATS, PIECES MARKED (1), AND/OR TO THE STRUT BRACE RETAINING CLEATS, PIECES MARKED (16), W/2-12d NAILS AT EACH END. SEE SPECIAL NOTE 5 ON PAGE 11.

- FORWARD BLOCKING ASSEMBLY (1 REQD.), SEE THE DETAIL AND FORWARD BLOCKING CHART "A" ON PAGE 16. SEE GENERAL NOTE "K" ON PAGE 2.
- (2) ANTI-SWAY BRACE (3 REQD), POSITION ON THE FLOOR BETWEEN LATERALLY ADJACENT PALLET UNITS. SEE THE "ANTI-SWAY BRACE" DETAIL ON PAGE 16.
- (3) BUNDLING STRAP, 1-1/4" X .035" OR .031" X 24"-6" LONG STEEL STRAPPING (2 REQD), INSTALL SO AS TO ENCIRCLE TWO (2) PALLET UNITS, SEE SPECIAL NOTE 2 ON PAGE 11.
- SEAL FOR 1-1/4" STRAPPING (4 REQD, 2 PER STRAP). DOUBLE CRIMP EACH SEAL. SEE GENERAL NOTE "M" ON PAGE 2.
- (3) SPACER ASSEMBLY (1 REQD.). SEE THE "SPACER ASSEMBLY A" DETAIL ON PAGE 18. SEE SPECIAL NOTE 3 ON PAGE 11.
- HEADER, 2" X 6" BY TRAILER WIDTH MINUS 1/2" IN LENGTH (2 REQD). SEE SPECIAL NOTES 9 AND 10 ON PAGE 11.
- THEADER AND SIDE STRUT SUPPORT, 2" X 4" BY TRAILER WIDTH MINUS 1/2" IN LENGTH (2 REQD). NAIL TO THE BOTTOM EDGE OF A HEADER, PIECE MARKED


 (3) , W/1-10d NAILS EVERY 8".
- (8) RISER PIECE, 2" X 4" X 9" (4 REQD), POSITION UNDER EACH END OF HEADER AND SIDE STRUT SUPPORT PIECES MARKED (7). NAIL TO PIECE MARKED (7) W/Z-10Q NAILS.
- 9 SIDE STRUT, 2" \times 6" BY CUT-TO-FIT BETWEEN THE FORWARD AND REAR HEADERS, PIECES MARKED (6) (2 REQD.). SEE SPECIAL NOTE 4 ON PAGE 11.
- (18) RISER PIECE, 2" X 4" X 9" (DOUBLED) (AS REQD), LAMINATE W/2-104 NAILS CENTER UNDER THE JOINTS OF PIECES MARKED (19) AND (15) , (16) AND (17) AND UNDER THE SPLICE OF PIECES MARKED (19) IF APPLICABLE. NAIL TO SIDE STRUT MARKED (19) W/2-104 NAILS.
- 1) POCKET CLEAT, 2" X 6" X 12" (4 REQD). NAIL TO A SIDE STRUT, PIECE MARKED (9), W/3-104 NAILS. TOENAIL TO THE ADJACENT HEADER, PIECE MARKED (6), W/3-124 NAILS.

(CONTINUED AT LEFT)

TYPICAL LTL-7 PALLET UNITS IN A CONVENTIONAL TYPE VAN TRAILER

- A 7'-6" WIDE (INSIDE DIMENSION) CONVENTIONAL VAN TRAILER IS SHOWN, TRAILERS OF OTHER WIDTHS CAN BE USED, SEE SPECIAL NOTES 9 AND 10.
- A PALLET UNIT THAT DOES NOT HAVE A PALLET UNIT DIRECTLY OPPOSITE MUST BE SECURED BY INSTALLING BUNDLING STRAPS, SHOWN AS PIECES MARKED (3) IN THE LTL LOAD ON PAGE 10, AROUND THAT PALLET UNIT AND THE PALLET UNIT IMMEDIATELY ADJACENT.
- 3. THE SPACER ASSEMBLY, SHOWN AS PIECE MARKED (3) IN. THE LTL LOAD ON PAGE 10, IS ONLY SHOWN TO DEPICT A TYPICAL INSTALLATION. IF A PALLET UNIT IS LOADED IN PLACE OF THE SPACER ASSEMBLY, BUNDLING STRAPS, SHOWN AS PIECE MARKED (3), WILL NOT BE REQUIRED. NOTE THAT A SPACER ASSEMBLY MUST BE POSITIONED WHERE THERE WILL BE A PALLET UNIT AT EACH END. A SPACER ASSEMBLY MUST NOT BE POSITIONED ADJACENT TO THE FORWARD BLOCKING ASSEMBLY PIECE MARKED (1).
- 4. DEPENDING ON THE NUMBER OF UNITS BEING LOADED, EACH OF THE SIDE STRUTS, PIECES MARKED (9), MAY NEED TO BE FORMED FROM MORE THAN ONE PIECE OF MATERIAL, IF SUCH IS THE CASE, THE SIDE STRUTS MUST BE SPLICED. SPLICING CAN BE ACCOMPLISHED BY CENTERING A 2" X 6" X 24" PIECE ON THE JOINT OF THE SIDE STRUTS AND NAILING IT TO THE SIDE STRUTS WA-TOU NAILS AT EACH END. CAUTION; A RISER PIECE, PIECE MARKED (10), MUST BE POSITIONED UNDER EACH SPLICE JOINT. NOTE: IF DESIRED, THE STRUT BRACING PIECE (5), PIECE MARKED (17), MAY BE NAILED TO THE STRUT BRACING PIECE SIN LIEU OF USING ADDITIONAL STRUT BRACE RETAINING CLEATS, PIECES MARKED (16).
- 5. ALL LTL LOADS, REGARDLESS OF THEIR SIZE, REQUIRE ONE STRUT BRACE
 POSITIONED AT THE REAR OF THE TRAILER AND NAILED TO PIECE MARKED

 (1) IF THE SIDE STRUTS, PIECES MARKED (?), ARE LONGER THAN
 7'-3", AN ADDITIONAL STRUT BRACE, PIECE MARKED (T), AND TWO (2)
 STRUT BRACE RETAINING CLEATS, PIECES MARKED (8), AND TWO (2)
 RISER PIECES MARKED (10), MUST BE APPLIED FOR EVERY 7'-0" OF
 SIDE STRUT LENGTH,
- 6. THE "K-BRACE" BLOCKING, SHOWN AS PIECES MARKED (3) THRU (17) , IS ADEQUATE FOR RETAINING A MAXIMUM LTL LOAD OF 20,000 POUNDS.
- 7. REFER TO PAGE 15 FOR GUIDANCE IN THE SHIPMENT OF PARTIAL PALLET UNITS.
- LEFTOVER CONTAINERS, IN AN AMOUNT NOT TO EXCEED FIVE (5), MAY
 BE SECURED TO THE TOP OF A FULL PALLET UNIT FOR SHIPMENT. REFER TO
 THE "PROCEDURES FOR SHIPMENT OF LEFTOVER CONTAINERS" ON PAGE 14
 FOR GUIDANCE.
- 9. TRAILERS EQUIPPED WITH ROLL-UP TYPE DOORS MAY 8E USED; HOWEVER, SPECIAL REAR BLOCKING MUST BE INSTALLED. SEE THE "PROCEDURES FOR CONVENTIONAL VAN TRAILERS EQUIPPED WITH ROLL-UP TYPE DOORS" ON PAGES 20 AND 21 FOR GUIDANCE. THE NAILED-HEADER METHOD SHOWN ON PAGE 21 OR THE TYGARD METHOD SHOWN ON PAGE 20 SHOULD BE USED IF POSSIBLE IN LIEU OF PIECES MARKED (3) THRU (7) WHICH APPLY TO TRAILERS HAVING NON-NAILABLE FLOORS. NOTE THAT THE SPECIAL REAR BLOCKING FOR TRAILERS EQUIPPED WITH ROLL-UP TYPE DOORS MAY ALSO & USED IN TRAILERS EQUIPPED WITH HOLDED DOORS.
- 10. IF DESIRED, IN TRAILERS EQUIPPED WITH NAILABLE FLOORS, THE NAILED-HEADER METHOD OF REAR BLOCKING MAY BE USED IN LIEU OF THE K-BRACE BLOCKING SHOWN AS PIECES MARKED (3) THRU (7). REFER TO PAGE 21 FOR GUIDANCE. AS AN ALTERNATIVE IN NAILABLE FLOORS TRAILERS, OR IN TRAILERS HAVING NON-NAILABLE FLOORS, THE TYGARD METHOD DEPICTED ON PAGE 20 MAY BE USED.




ISOMETRIC VIEW

SPECIAL NOTES:


- A 7'-6" WIDE (INSIDE DIMENSION) TRAILER WHICH HAS A NAILABLE FLOOR IS SHOWN. TRAILERS OF OTHER WIDTHS CAN BE USED.
- 2. THE POSITIONING OF A SINGLE PALLET UNIT IS OPTIONAL. IF THE TRAILER HAS A SQUARE FRONT, THE TWO (2) FORWARD LTL BRACES MAY BE OMITTED AND THE UNIT POSITIONED AGAINST THE END WALL.
- 3. MORE THAN ONE PALLET UNIT CAN BE SHIPPED PROVIDING THE CAPACITY OF THE LTL BRACES IS NOT EXCEEDED. THE LOAD SHOULD BE FORRED IN ROWS, WITH THE UNITS POSITIONED AGAINST OPPOSITE SIDEWALLS. THE "AN TI-SWAY BRACE", DETAILED ON PAGE 16, MUST BE INSTALLED BETWEEN LATERALLY ADJACENT UNITS. A STOP PIECE, SHOWN BY DOTTED LINES ON THE DETAIL, WILL BE REQUIRED.
- 4. EACH LTL BRACE AS APPLIED FOR LONGITUDINAL BRACING WILL SUPPORT 2,000 POUNDS OF LADING, HOWEVER, NOT LESS THAN TWO (2) BRACES WILL BE USED AGAINST EACH PALLET UNIT ACROSS THE WIDTH OF THE TRAILER. ADDITIONAL BRACES MAY BE INSTALLED FOR THE RETENTION OF A HEAVIER LOAD.

KEY NUMBERS

- 1 LOAD BEARING PIECE, 1" X 6" X 42" (4 REQD), LOCATE AT THE HEIGHTS AS SPECIFIED IN THE "LTL BRACE" DETAIL BELOW, NAIL TO THE LTL BRACES W/4-64 NAILS AT EACH JOINT, SEE GENERAL NOTE "O" ON PAGE 2.
- (2) LOAD BEARING PIECE, 1" X 6" X 44" (2 REQD.), LOCATE AT THE HEIGHTS AS SPECIFED IN THE LITE BRACES DETAIL BELOW. NAIL TO THE LITE BRACES W/4-6d NAILS AT EACH JOINT.
- 3 LTL BRACE (6 REQD), SEE THE "LTL BRACE" DETAIL BELOW. NAIL TO THE TRAILER FLOOR W/ 10-104 NAILS.



TYPICAL LTL (1-UNIT LOAD) IN A CONVENTIONAL VAN TRAILER



ISOMETRIC VIEW


SPECIAL NOTES:


- 1. A 7'-6" WIDE (INSIDE DIMENSION) VAN TRAILER EQUIPPED WITH MECHANICAL BRACING DEVICES IS SHOWN. TRAILERS OF OTHER WIDTHS MAY BE USED.
- 2. A TYPICAL LIL LOAD OF ONE (1) PALLETIZED UNIT IS SHOWN. IF TWO (2) PALLETIZED UNITS ARE TO BE TRANSPORTED, POSITION THE UNITS TWO ACROSS THE WIDTH OF THE TRAILER. OMIT THE SPACER ASSEMBLIES AND THE TIE WIRES SHOWN AS PIECES MARKED (2) AND (3). NOTE: WHEN LOADING TWO (2) PALLETIZED UNITS ACROSS THE WIDTH OF THE TRAILER, POSITION THE UNITS AGAINST INF FORWARD END WALL (UNIESS THE TRAILER HAS ROUNDED CORNERS) AND OMIT THE TWO CROSS MEMBERS AT THE FORWARD END. POSITION ONE ANTI-SWAY BRACE, SHOWN AS PIECE MARKED (2) ON PAGE 4 SETWEEN THE UNITS. NOTE THAT CROSS MEMBERS MUST BE POSITIONED AT THE 4" HEIGHT LOCATION TO PREVENT DISPLACEMENT OF ANTI-SWAY BRACE.

KEY NUMBERS


- CROSS MEMBER (4 REQD). POSITION AT THE HEIGHTS AS SPECIFIED BY
 THE ISOMETRIC VIEW ABOVE. SEE GENERAL NOTES "D" AND "K" ON
 PAGE 2.
- SPACER ASSEMBLY (2 REQD), SEE THE SPACER ASSEMBLY "B" DETAIL ON PAGE 18.
- TIE WIRE, NO. 14 GAGE WIRE 30" LONG (8 REQD). INSTALL TO FORM A COMPLETE LOOP AROUND THE CROSS MEMBER AND THE SPACER ASSEMBLY. BRING ENDS: TOGETHER AND TWIST TAUT. SECURE TO THE SPACER ASSEMBLY WITH A PARTIALLY DRIVEN TOWN HALL BENT OVER THE WIRE, OR WITH A STRAP STAPLE.

- 1. SHIPMENTS OF COMPLETE ROUNDS SHOULD CONSIST OF FULL-HFIGHT AND FULL-LAYER UNITS TO THE MAXIMUM EXTENT POSSIBLE, HOWEVER, THE END OF A LOT, OR THE QUANTITY OF ITEMS NEEDED TO FILL A REQUISITION, MAY NECESSITATE THE SHIPMENT OF ONE OR MORE LEFTOVER CONTAINERS, LEFTOVER CONTAINERS ARE DESCRIBED AS A QUANTITY OF CONTAINERS WHICH IS INSUFFICIENT TO FORM A FULL-LAYERED PARTIAL UNIT FOR SECUREMENT ON TOP OF A FULL PALLET UNIT AS SHOWN ON PAGE 15.
- 2. SHIPMENT OF LEFTOVER CONTAINERS IS APPLICABLE FOR CONUS AND OCONUS MOTOR CARRIER SHIPMENTS FROM DEPOT TO DEPOT OR FROM DEPOT TO POSTS, CAMPS, AND STATIONS, OR UPON APPROVAL FROM HIGHER HEAD-QUARTERS, FOR SHIPMENTS FROM LOAD, ASSEMBLE, AND PACK PLANTS TO DEPOTS. CAUTON: A LOAD CONTAINING LEFTOVER CONTAINERS IN AN AMOUNT WHICH IS LESS THAN A FULL LAYER, AND SECURED TO THE TOP OF A FULL OR PARTIAL UNIT, MUST NOT BE DESTINED FOR SHIPMENT OVERSEAS BY WATER CARRIER.
- THE PROCEDURES ON THIS PAGE ARE APPLICABLE FOR THE SHIPMENT OF LEFTOVER CONTAINERS IN ANY OF THE LOADS DEPICTED HEREIN.







SECUREMENT OF TWO CONTAINERS



PROCEDURES FOR SHIPMENT OF LEFTOVER CONTAINERS



- THE VIEW SHOWN ABOVE DEPICTS A PARTIAL 2-LAYER PALLET UNIT POSITIONED ON TOP OF A FULL-HEIGHT PALLET UNIT AND UNITIZED WITH TWO VERTICAL UNITIZING STRAPS. PLACEMENT WITHIN THE LOAD IS OPTIONAL, EXCEPT THAT IT WILL NOT BE POSITIONED IN THE REAR LOAD UNIT, OR WITHIN A GROUP WHICH IS BUNDLED TOGETHER.
- SHIPMENTS OF PALLET UNITS SHOULD CONSIST OF FULL-HEIGHT AND FULL-LAYER
 UNITS TO THE MAXIMUM EXTENT POSSIBLE. HOWEVER, THE END OF A LOT,
 OR THE QUANTITY OF ITEMS NEEDED TO FILL A REQUISITION MAY NECESSITATE
 THE SHIPMENT OF ONE OR MORE LESS-THAN-FULL PALLET UNITS WITHIN A
 LOAD. THE PROCEDURES ON THIS PAGE AND ON PAGE 14 ARE PRESENTED AS
 GUIDANCE IN THE SHIPMENT OF THESE PARTIAL UNITS.
- 3. THE "SHIPMENT OF A PARTIAL PALLET UNIT" PROCEDURES ON THIS PAGE ARE APPLICABLE FOR LOADS IN CONVENTIONAL TYPE VAN TRAILERS AND IN TRAILERS EQUIPPED WITH MECHANICAL BRACING DEVICES."
- 4. FOR SHIPMENT OF ONE THRU FIVE "LEFTOVER" CONTAINERS, SEE THE PROCEDURES ON PAGE 14 OF THIS DRAWING.



FORWARD BLOCKING CHART A				
DIM	A	В	O	
	36 "	15*	36"	

FORWARD BLOCKING CHART "A" IS USED FOR LENGTHWISE POSITIONED CONTAINERS AS SHOWN IN THE LOAD ON PAGE 4.


FORWARD BLOCKING CHART B			
MIG	A .	8	c
	39"	9"	41"

FORWARD BLOCKING CHART "B" IS USED FOR CROSSWISE POSITIONED CONTAINERS AS SHOWN IN THE LOAD ON PAGE 6. OMIT THE STOP PIECE ON "FORWARD BLOCKING ASSEMBLY",

> FABRICATE TO FIT MINUS 1/2",


FORWARD BLOCKING ASSEMBLY

THIS ASSEMBLY IS DESIGNED FOR USE AT THE FRONT END OF A TRAILER HAVING ROUNDED CORNERS, AND IS APPLICABLE FOR A CORNER RADIUS OF NOT MORE THAN 6-1/2". IF THE RADIUS IS FROM 6-1/2" TO 8", 2" X 6" VERTICAL PIECES WILL BE USED IN LIEU OF THE 2" X 4" PIECES. IF THE TRAILER TO BE LOADED HAS LARGE-ANGLED CORNERS AT THE FORWARD END, REFER TO PAGE 22 FOR GUIDANCE.




PAGE 16


DETAILS




REAR BLOCKING ASSEMBLY A

THIS ASSEMBLY IS FOR USE AT THE REAR END OF LENGTHWISE POSITIONED CONTAINERS WHEN THE SPACE BETWEEN THE LADING AND THE TRAILER DOORS IS GREATER THAN 9". NOTE THAT THE ABOVE VIEW IS ROTATED 180° FROM THE POSITION IN WHICH IT WILL BE INSTALLED.







SPACER ASSEMBLY C

* THIS DIMENSION WILL BE 41" IF CONTAINERS ARE POSITIONED CROSSWISE IN THE TRAILER.

RECOMMENDED EQUIPMENT/INSTALLATION PROCEDURES

EQUIPMENT REQUIRED

PAINT ROLLER, LATEX
PAINT ROLLER PAN
TENSIONING ROD/TOOL
PRESSURE ROLLER
RATCHET WRENCH (12" TO 15" HANDLE)
OPEN END OR BOX WRENCH (12" TO 15" HANDLE)
SCISSORS OR KNIFE
TYGARD (15" WIDE ROLL)
TYGARD ADMESIVE

BASIC INSTALLATION GUIDANCE


CUT TO LENGTH THE REQUIRED NUMBER OF TYGARD PIECES (FROM 2 TO 8
DEPENDING UPON THE LOAD CONFIGURATION) FOR ATTACHMENT TO THE
TRAILER SIDEWALL, PIECES WILL BE OF A LENGTH AS REQUIRED TO PROVIDE
PROPER BONDING TO THE TRAILER SIDEWALL AND TO EXTEND 60" ACROSS
THE REAR OF THE LOAD. ALSO, CUIT 2" LONG "PATCH" PIECES OF TYGARD
MATERIAL, ONE FOR EACH SET OF TWO PIECES PREVIOUSLY CUIT.

PALLET UNITS.

- 2. PRIOR TO POSITIONING OF THE PALLETS IN THE REARMOST LOAD UNIT, APPLY TYGARD ADJESTIVE TO THE PROPER PORTIONS OF THE TRAILER SIDEWALLS AND TO THE CORD SIDE OF A CORRESPONDING LENGTH OF EACH OF THE TYGARD PIECES THAT ARE TO BE ATTACHED TO THE SIDEWALLS OF THE TRAILER. ALLOW TIME FOR THE ADJESTIVE TO "CURE" BEFORE PLACING A STRIP OF TYGARD ONTO A SIDEWALL (ADJESTIVE WILL FEEL ALMOST DRY WHEN TOUCHED). NOTE: APPLICATION OF TYGARD IS SIMILAR TO THE APPLICATION OF "FORMICA".
- 3. APPLY THE TYGARD PIECES TO EACH SIDEWALL OF THE TRAILER SO THAT THE PIECES ARE PARALLEL OR NEARLY PARALLEL TO THE FLOOR. ROLL THE TYGARD WITH THE PRESSURE ROLLER TO ENSURE PROPER BONDING IS ACHIEVED. TEMPORARILY SECURE THE LOOSE ENDS TO THE TRAILER SIDEWALL OR TO AN OPEN HINGED TYPE DOOR OR TO THE OUTSIDE WALL, AS APPLICABLE.
- POSITION THE PALLETS OF THE REARMOST LOAD UNIT INTO THE TRAILER AND INSTALL THE SPECIFIED ANTI-SWAY BRACES OR CRIB FILL, AS APPLICABLE.
- 5. UNDO THE PREVIOUSLY SECURED LOOSE ENDS AND BRING A SET OF TWO PIECES TOGETHER ACROSS THE REAR OF THE LOAD. POSITION THE TENSIONING ROD SO THAT THE LOOSE ENDS OF THE TYGARD MATERIAL EXTEND THRU THE SLOT IN ROD. USING THE TWO WRENCHES, ROLL UP THE TYGARD TO TENSION IT ACROSS REAR OF THE LOAD. POSITION A WRENCH SO AS TO MAINTAIN THE TENSION IN THE TYGARD PIECES. CUT OFF AND DISCARD EXCESS MATERIAL FROM ONE PIECE OF THE TYGARD.
- 6. APPLY TYGARD ADMESIVE TO THE TENSIONED TYGARD PIECES AND ALSO TO THE CORD SIDE OF THE PREVIOUSLY CUT "PATCH" PIECE. APPLY THE "PATCH" AND ROLL WITH THE PRESSURE ROLLER TO ENSURE PROPER BONDING.


SPECIAL NOTES:

- THE TYGARD METHOD OF REAR BLOCKING DEPICTED, CAN ONLY BE USED IN TRAILERS WHICH HAVE REASONABLY SMOOTH AND ADEQUATELY SECURED SIDEWALL PANELS IN THE AREA WHERE THE TYGARD MATERIAL IS TO BE APPLIED. NOTE THAT TYGARD MATERIAL MUST BE INSTALLED AT TWO LEVELS ON THE REAR LOAD UNIT.
- 2. A 48" HIGH PLYWOOD GATE MUST BE INSTALLED AT THE REAR OF THE LOAD TO PROVIDE A SMOOTH SURFACE FOR THE TYGARD MATERIAL TO EXTEND AROUND. IF THE REAR LOAD UNIT IS 2-WIDE INSTALL A GATE WHICH IS TRAILER WIDTH MINUS 1/2" IN LENGTH AS SHOWN BY THE "TYGARD METHOD A" DETAIL AT LEFT. IF THE REAR LOAD UNIT IS 1-WIDE, ROTATE THE PALLET, INSTALL ONE (1) PALLET WIDTH GATE, AND ONE (1) TRAILER WIDTH MINUS 1/2" IN LENGTH GATE, AS SHOWN BY THE "TYGARD METHOD B" DETAIL BELOW.
- 3. THE TYGARD MATERIAL AND THE ADHESIVE FOR ATTACHING IT ARE COMMERCIAL PRODUCTS, FOR A SOURCE OF SUPPLY, CONTACT WALNUT INDUSTRIES, INC., 1344 ADAMS ROAD, P.O. BOX "E", BENSALEM, PA 10720-0860, PHONE 1-800-923-6536. APPLICATION INSTRUCTIONS AND GUIDANCE CAN ALSO BE OBTAINED FROM THAT OPFICE.
- THE TYGARD METHOD, ALTHOUGH ESPECIALLY FOR TRAILERS HAVING ROLL-UP TYPE DOORS, MAY ALSO BE USED IN TRAILERS EQUIPPED WITH HINGED DOORS.
- 5. NOTICE: IF THE AREA OF A SIDEWALL WHERE THE TYGARD SHOULD BE ATTACHED IS ROUGH AND/OR BROKEN, THE APPLICABLE PIECE (S) OF TYGARD CAN BE LENGTHENED A SUITABLE AMOUNT AND ATTACHED TO THE SIDEWALL AHEAD OF THE INDICATED PREFERRED LOCATION.



TYGARD METHOD


PROCEDURES FOR CONVENTIONAL VAN TRAILERS EQUIPPED WITH ROLL-UP TYPE DOORS



NATIED-HEADER METHOD


SPECIAL NOTES:

- THE NAILED-HEADER METHOD OF REAR BLOCKING DEPICTED ABOVE CAN ONLY BE USED IN TRAILERS HAVING A NAILABLE FLOOR AREA RETWEEN THE LADING AND THE METAL THRESHOLD, OR A THRESHOLD PLATE IF THE TRAILER IS SO EQUIPPED, OF AT LEAST FOURTEEN INCHES (14").
- REAR BLOCKING ASSEMBLY "A" IS SHOWN FOR A TYPICAL INSTALLATION.
 CONSTRUCT THE ASSEMBLY USING 6" (MINIMUM) LONG STRUTS.
- 3. THE NAILED-HEADER METHOD OF REAR BLOCKING IS ADEQUATE FOR THE RETENTION OF THE MAXIMUM WEIGHT LOAD.
- THE NAILED-HEADER METHOD, ALTHOUGH DESIGNED ESPECIALLY FOR TRAILERS HAVING ROLL-UP TYPE DOORS, MAY ALSO BE USED IN TRAILERS EQUIPPED WITH HINGED DOORS.



ALTERNATIVE FORWARD LOADING PATTERN

THIS PROCEDURE IS APPLICABLE TO THE LOADING OF ONE (1) PALLET UNIT IN THE FORWARD END OF A CONVENTIONAL VAN TRAILER HAVING LARGE ANGLED FRONT CORNERS (REF. 18"). THE PROCEDURES MAY ALSO BE USED IN TRAILERS HAVING SQUARE CORNERS, OR ROUNDED FRONT CORNERS, OR ANGLED CORNERS OF ANOTHER SIZE.



SPACER ASSEMBLY D

THIS ASSEMBLY IS DESIGNED FOR LATERAL BRACING OF A SINGLE PALLET UNIT WHICH IS TURNED 90° FROM THE NORMAL LOADING ORIEN TATION AND POSITIONED IN THE FRONT OF AN ANGLED CORNER CONVENTIONAL VAN TRAILER AS SHOWN IN THE "ALTERNATIVE LOADING PATTERN" VIEW ABOVE, RIGHT HAND AND LEFT HAND SPACER ASSEMBLES ARE REQUIRED.

PROCEDURES FOR CONVENTIONAL VAN TRAILERS EQUIPPED WITH LARGE-ANGLED FRONT CORNERS