APPROVED BY	APPROVED BY		
U.S. COAST GUARD	BUREAU OF EXPLOSIVES		
I H Hilm	SUPERVISOR MILITARY & INTERMODAL SERVICES		
	SUPERVISOR, MILITARY & INTERMODAL SERVICES		
DATE 2/31/80	DATE 4/80		

LOADING AND BRACING WITH WOODEN DUNNAGE IN COMMERCIAL CONTAINERS OF PALLETIZED UNITS OF 8IMM AMMUNITION (30-BOX PALLET UNIT) (WOODEN BOX)

THE DEPICTED WOODEN DUNNAGE METHOD CAN BE APPLIED TO ANY COMMERCIAL INTERMODAL 20-FOOT CONTAINER, ALTHOUGH THE DUNNAGE DIMENSIONS HAVE BEEN GIVEN FOR A 92" WIDE BY 95" HIGH (INSIDE DIMENSIONS) CONTAINER. ALTHOUGH THE LOAD AS SHOWN IS BASED ON AN 8"-6" HIGH CONTAINER, AN 8"-0" HIGH CONTAINER IS PREFERRED FOR SHIPPING THE DEPICTED LOAD. WHEN AN 8"-0" HIGH CONTAINER IS USED, THE HEIGHT OF SOME DUNNAGE ASSEMBLIES WILL HAVE TO BE LOWERED BY REMOVING SOME MATERIAL FROM THE TOP OR BOTTOM OF SOME OF THE VERTICAL PIECES.

LOADING AND BRACING SPECIFICATIONS AS DELINEATED HEREIN ARE ADEQUATE FOR SHIPMENTS TO BE MOVED BY ANY SURFACE MODE OF TRANSPORT (MOTOR, RAIL, AND WATER).


REQUIREMENTS CITED WITHIN THE BUREAU OF EXPLOSIVES PAMPHLET 6C APPLY WHEN THE SHIPMENT MOVES BY TRAILER/CONTAINER-ON-FLAT-CAR (T/COFC). SPECIAL T/COFC NOTES FOLLOW.


- A. A LOADED CONTAINER MUST BE ON A CHASSIS EQUIPPED WITH TWO BOGIE ASSEMBLIES WHEN BEING MOVED IN TOFC SERVICE.
- B. THE LOAD LIMIT OF A T/COFC RAIL CAR MUST NOT BE EXCEEDED, NOR WILL A CAR BE LOADED SO THAT THE TRUCK UNDER ONE END OF THE CAR CARRIES MORE THAN ONE-HALF OF THE LOAD LIMIT FOR THAT CAR.

DURING INTRASTATE AND/OR INTERSTATE MOVES BY MOTOR CARRIER, A PROPER CHASSIS/MODIFIED FLAT BED TRAILER MUST BE USED TO PRECLUDE VIOLATION OF ONE OR MORE "WEIGHT LAWS" APPLICABLE TO THE STATE OR STATES INVOLVED.

REVISIONS	BB MULK WRFLES	
	RSA LUUSULIS	
	David Tille,	
	APPROVED BY ORDER OF COMMANDING SENERAL, U. S. ARMY MATERIEL DEVELOPMENT AND READINESS COMMAND (DARCOM)	
	U.S. ARMY DEFENSE AMMUNITION CENTER AND SCHOOL	
	U. S. ARMY DARCOM DRAWING	
	APRIL 1980	
	DEF AMMO CEN & SCH DWG NO.	
	D-SARAC-4437	

DO NOT SCALE





- (2) LOWER ANTI-SWAY BRACE (8 REQD). SEE THE "LOWER ANTI-SWAY BRACE" DETAIL ON PAGE 5.
- 3 TOP ANTI-SWAY BRACE (4 REQD). SEE THE "TOP ANTI-SWAY BRACE" DETAIL ON PAGE 5.
- TIE WIRE, NO. 14 GAGE WIRE 24" LONG (16 REQD). INSTALL THE WIRE TO FORM A COMPLETE LOOP AROUND THE LOAD STRAP OF THE UNIT AND THE RETAINER PIECE OF THE TOP ANTI-SWAY BRACE, BRING ENDS TOGETHER AND TWIST TAUT.
- (5) REAR BLOCKING ASSEMBLY (1 REQD), SEE THE "REAR BLOCKING ASSEMBLY" DETAIL ON PAGE 4 AND GENERAL NOTE "E" ON PAGE 3.
- 6 DOOR POST VERTICAL (2 REQD). SEE THE "DOOR POST VERTICAL" DETAIL AND "DETAIL B" ON PAGE 7.
- 7 DOOR POST VERTICAL RETAINER (2 REQD). SEE THE "DOOR POST VERTICAL RETAINER" DETAILS ON PAGE 6 AND "DETAIL A" ON PAGE 7. NAIL THROUGH THE HOLES INTO THE DOOR POST VERTICAL W/4-10d NAILS.
- B DOOR SPANNER, 4" X 4" MATERIAL, CUT TO A LENGTH THAT WILL PROVIDE FOR A DRIVE FIT BETWEEN DOOR POST VERTICALS (REF: 7"-1-3/8")(4 REQD). TOENAIL TO THE DOOR POST VERTICALS W.2-12d NAILS AT EACH END. SEE THE "BEVEL-CUT" DETAIL ON PAGE 7. AFTER INSTALLING THE BOTTOM AND THE TOP DOOR SPANNERS, THE FILL MATERIAL, PIECE MARKED (), IS TO BE INSTALLED.
- FILL MATERIAL, 6" WIDE BY 7'-0" LONG MATERIAL (AS REQD). NAIL EACH PIECE TO THE REAR BLOCKING ASSEMBLY AND/OR LAMINATE TOGETHER W/9 NAILS OF A SUITABLE SIZE (10d NAILS FOR 2" THICK MATERIAL). CAUTION: DO NOT NAIL TO THE DOOR POST VERTICALS, PIECES MARKED (a).

#### ( GENERAL NOTES CONTINUED )

- J. RECOMMENDED SEQUENTIAL LOADING PROCEDURES:
  - PREFABRICATE ONE FORWARD BLOCKING ASSEMBLY, FOUR TOP ANTI-SWAY BRACES, ONE REAR BLOCKING ASSEMBLY, AND NAIL A DOOR POST VERTICAL RETAINER TO EACH DOOR POST VERTICAL, ONE RIGHT HAND AND ONE LEFT HAND.
  - INSTALL FORWARD BLOCKING ASSEMBLY.
  - 3. LOAD 4 PALLET UNITS
  - 4. INSTALL ONE TOP ANTI-SWAY BRACE AND TIE WIRE.
  - INSTALL TWO LOWER ANTI-SWAY BRACES (THESE ASSEMBLIES MUST BE FABRICATED IN PLACE, BETWEEN THE PALLET UNITS).
  - REPEAT STEP 3.
  - 7. REPEAT STEP 4.
  - 8. REPEAT STEP 5.
  - 9. REPEAT STEP 3.
  - 10. REPEAT STEP 4.

  - 11. REPEAT STEP 5.
  - 12. REPEAT STEP 3.
  - 13. REPEAT STEP 4.
  - 14. REPEAT STEP 5.
  - 15. INSTALL REAR BLOCKING ASSEMBLY.
  - 16. INSTALL THE TWO DOOR POST VERTICAL ASSEMBLIES (ONE RIGHT HAND AND ONE LEFT HAND)
  - INSTALL TWO DOOR SPANNER PIECES (ONE AT THE LOWEST POSITION AND ONE AT THE UPPERMOST POSITION).
  - 18. INSTALL THE SOLID FILL TYPE LOAD-BLOCKING MATERIAL.
  - 19. INSTALL THE REMAINING TWO DOOR SPANNER PIECES.

# GENERAL NOTES

- A. THIS DOCUMENT HAS BEEN PREPARED AND ISSUED IN ACCORDANCE WITH AR 740-1, AND AUGMENTS TM 743-200-1 ( CHAPTER 5 ).
- B. THE SPECIFIED OUTLOADING PROCEDURE IS APPLICABLE TO A LOAD OF 30-BOX PALLET UNITS OF 81MM AMMUNITION PACKED IN WOODEN BOXES. SUBSEQUENT REFERENCE TO PALLET UNIT MEANS THE PALLET UNIT WITH AMMUNITION ITEMS. SEE PAGE 5 FOR THE DETAIL OF THE PALLET UNIT. CAUTION: REGARDLESS OF THE QUANTITY OF UNITS TO BE SHIPPED, THE "MAXIMUM GROSS WEIGHT" OF 44,800 POUNDS MUST NOT BE EXCEEDED.
- C. THE LOAD AS SHOWN IS BASED ON A 4,700 POUND 20' LONG BY 8' WIDE BY 8'-6" HIGH INTERMODAL COMMERCIAL CONTAINER WITH INSIDE DIMENSIONS OF 19'-4" LONG BY 92" WIDE BY 95" HIGH. THE LOAD IS DESIGNED FOR TRAILER/CONTAINER-ON-FLAT-CAR (T/COFC) SHIPMENT, HOWEVER, THE LOAD AS DESIGNED CAN ALSO BE MOVED BY OTHER SURFACE MODES OF TRANSPORT. NOTICE: OTHER CONTAINERS OF THE SAME DESIGN CONFIGURATION CAN BE USED.
- D. DUNNAGE LUMBER SPECIFIED IS OF A NOMINAL SIZE. FOR EXAMPLE, 2" X 4" MATERIAL IS ACTUALLY 1-1/2" THICK BY 3-1/2" WIDE AND 2" X 6" MATERIAL IS ACTUALLY 1-1/2" THICK BY 5-1/2" WIDE.
- E. A STAGGERED NAILING PATTERN WILL BE USED WHEREVER POSSIBLE WHEN NAILS ARE DRIVEN INTO JOINTS OF DUNNAGE ASSEMBLIES OR WHEN LAMINATING DUNNAGE. ADDITIONALLY, THE NAILING PATTERN FOR AN UPPER PIECE OF LAMINATED DUNNAGE WILL BE ADJUSTED AS REQUIRED SO THAT A NAIL FOR THAT PIECE WILL NOT BE DRIVEN THROUGH ONTO OR RIGHT BESIDE A NAIL IN A LOWER PIECE
- F. IN SOME CONTAINERS, SUCH AS SOME ALL STEEL CONTAINERS, THERE IS A SLOT AT THE CORNERS OF THE FORWARD WALL. A PIECE OF DUNNAGE MATERIAL MUST BE LAMINATED TO THE BUFFER PIECES ON THE FORWARD BLOCKING ASSEMBLY TO PROVIDE A FLAT SURFACE FOR THE 2" X 6" BUFFER PIECES. A PIECE OF 2" X 4", 2" X 3", OR A SPECIAL WIDTH PIECE CUT-TO-FIT CAN BE USED. THIS FILL PIECE WILL BE NAILED WITH ONE APPROPRIATELY SIZED NAIL EVERY 12". THIS PIECE NOT REQUIRED WHEN THE FRONT WALL OF THE CONTAINER IS SMOOTH AND FLAT.
- G.  $\underline{\text{CAUTION}}\colon$  DO NOT NAIL DUNNAGE MATERIAL TO THE CONTAINER WALLS OR FLOOR. ALL NAILING WILL BE WITHIN THE DUNNAGE.
- H. PORTIONS OF THE CONTAINER DEPICTED WITHIN THIS DRAWING, SUCH AS ONE OF THE SIDE WALLS, HAVE NOT BEEN SHOWN IN THE LOAD VIEWS FOR CLARITY PURPOSES.

( CONTINUED AT LEFT )

LUMBER LINEAR FEET		BOARD FEET	
2" X 4"	128	86	
2" X 6"	283	283	
4" X 4"	51	68	
NAILS	NO, REQD	POUNDS	
10d (3")	<b>498</b>	7-3/4	
12d (3-1/4")	16	1/2	

## MATERIAL SPECIFICATIONS


WIRE ----- : FED SPEC QQ-W-461.


# LUMBER -----: TM 743-200-1 (DUNNA GE LUMBER ) AND FED SPEC MM-L-751. NAILS -----: FED SPEC FF-N-105; COMMON. STEEL, STRUCTURAL ---: FED SPEC QQ-S-741; SQUARE STRUCTURAL TUBING AND HOT-ROLLED STRIP.

### LOAD AS SHOWN

ITEM	QUANTITY	WEIGH	T (APPROX)
DUNNAGE -	16	947	LBS
T	OTAL WEIGHT	31 535	LRS


PAGE 3






#### PALLET UNIT

UNIT WEIGHT ------ 1,618 POUNDS (APPROX )
CUBE ------ 48.2 CUBIC FEET





TOP ANTI-SWAY BRACE




LOWER ANTI-SWAY BRACE

THIS ASSEMBLY MUST BE FABRICATED IN PLACE, BETWEEN THE PALLET UNITS.







DOOR POST VERTICAL RETAINER



A PARTIAL PLAN VIEW OF THE LEFT REAR PORTION OF THE CONTAINER IS SHOWN DEPICTING THE PROPER POSTION OF THE DOOR POST VERTICAL AND ADJACENT DUNNAGE PIECES.




IF DESIRED, EACH END OF A DOOR SPANNER FICE MAY BE BEVEL-CUT AS SHOWN ABOVE TO FACILITATE THE ACHIEVEMENT OF A TIGHT DOOR-POST-TO-DOOR-POST-FIT.




## DOOR POST VERTICAL

THE STRUT LEDGERS CAN ONLY BE PRE-NAILED TO THE DOOR POST VERTICAL ON ONE SIDE OF THE CONTAINER. THE STRUT LEDGERS ON THE OTHER SIDE ARE TO BE NAILED AFTER A LOWER DOOR SPANNER IS INSTALLED.



DOOR SPANNERS AND STRUTS HAVE BEEN OMITTED FOR CLARITY PURPOSES.

PAGE 7



ALTERNATIVE FORWARD/REAR BLOCKING ASSEMBLY

#### SPECIAL NOTE:

WHEN THE UNIT WIDTH IS LESS THAN 52-1/4", THE FILL MATERIAL, PIECE MARKED ③ ON PAGE 2, MUST BE INCREASED TO PROVIDE A TIGHT FIT BETWEEN THE REAR BLOCKING ASSEMBLY AND THE DOOR POST VERTICALS. IF THE UNIT WIDTH IS GREATER THAN 52-1/4", IT WILL BE NECESSARY TO USE THE ALTERNATIVE FORWARD/REAR BLOCKING ASSEMBLY AS DEPICTED ABOVE, IN LIEU OF THE FORWARD BLOCKING ASSEMBLY AND/OR THE REAR BLOCKING ASSEMBLY, AS DEPICTED ON PAGE 4.