LOADING AND BRACING (TL & LTL) IN CLOSED OR OPEN TOP VAN TRAILERS OF PALLETIZED PROPELLING CHARGES PACKED IN CYLINDRICAL METAL CONTAINERS

PA96 SERIES CONTAINER

INDEX	
<u>——</u>	PAGE (S)
GENERAL NOTES, AND MATERIAL SPECIFICATIONS	3 4-17 18-21
PROCEDURES FOR SHIPMENT OF LEFTOVER CONTAINERS DETAILS	23 24-31
PROCEDURES FOR CONVENTIONAL VAN TRAILERS EQUIPPED WITH ROLL-UP TYPE DOORS PROCEDURES FOR CONVENTIONAL VAN TRAILERS	32,33
EQUIPPED WITH LARGE-ANGLED FRONT CORNERSITEMIZED INDEX	34 35

THIS DOCUMENT INCLUDES OUTLOADING PROCEDURES FOR CONVENTIONAL TYPE TRAILERS AND FOR TRAILERS EQUIPPED WITH MECHANICAL BRACING DEVICES AS APPROVED BY THE BUREAU OF EXPLOSIVES, ASSOCIATION OF AMERICAN RAIL-ROADS. CAUTION: THE PROCEDURES SHOWN HEREIN, FOR BOTH TYPES OF TRAILERS, ARE ONLY APPLICABLE FOR HIGHWAY MOVEMENTS; NOT FOR CONTAINER/TRAILER-ON-FLAT-CAR MOVEMENTS.

	REVI	SIONS	PASTSMAN	dh 🎉	WRF	
			CHECKER	100	HOMENT, MUNITIONS	AND CHEMICAL
			COMMAND) Head	
			actions.	OWNER OF CO	4 Eenst	U.S. ARMY
				THE PER PROPER	AMC DI	
					MBER IS	
			CLASS	DIVISION	DRAWING	FILE
			19	48	4042C/ 17	IIPM IOOO

DO NOT SCALE

GENERAL NOTES

- A. THIS DOCUMENT HAS BEEN PREPARED AND ISSUED IN ACCORDANCE WITH AR 740-1, AND AUGMENTS TM 743-200-1 (CHAPTER 5).
- B. THE OUTLOADING PROCEDURES SPECIFIED IN THIS DRAWING ARE APPLICABLE FOR THE PA96 SERIES PROPELLING CHARGE CONTAINER ASSEMBLED ON THE 35" X 45-1/2" 4-WAY ENTRY PALLET. SEE THE PICTORIAL VIEWS ON PAGE 3 FOR SIZES AND WEIGHTS. REFER TO U.S. ARMY AMC (DARCOM) DRAWING 19-48-4042A/18-20PM1001 FOR UNITIZATION PROCEDURES FOR THE PA96 SERIES CONTAINERS
- C. THE OUTLOADING PROCEDURES DEPICTED WITHIN THIS DOCUMENT ARE APPLICABLE FOR SHIPMENTS IN CONVENTIONAL TYPE VAN TRAILERS, AND FOR SHIPMENTS IN VAN TRAILERS EQUIPPED WITH VARIOUS TYPES OF SELF-CONTAINED MECHANICAL BRACING DEVICES (CROSS MEMBERS AND WALL MEMBERS) AND APPLY TO TRAILERS HAVING WOOD, OR WOOD AND METAL, OR ALL METAL FLOORS. VAN TRAILERS WHICH ARE 40'-0" LONG BY 7'-8" TO 7'-8-1/2" WIDE (INSIDE DIMENSION) HAVE BEEN SHOWN. HOWEVER, THE PROCEDURES ARE ALSO APPLICABLE FOR TRAILERS WHICH ARE EIGHTY-NINE INCHES (89") THRU NINETY-NINE INCHES (99") IN WIDTH AND FOR TRAILERS OF OTHER LENGTHS FROM THE SHORTEST TO THE LONGEST AVAILABLE (REF. 24' TO 53'), AND FOR STRAIGHT TRUCK VANS. THE LOADING AND BRACING PROCEDURES SPECIFIED HEREIN ARE ALSO ADEQUATE (CONFIGURATION WISE AND STRENGTH WISE) FOR LOADS IN SHORTER OR LONGER VANS AND IN NARROWER OR WIDER VANS THAN SHOWN. THE SPECIFIED BRACING IS ADEQUATE FOR LOADS WEIGHING UP TO AND INCLUDING THE MAXIMUM WEIGHTS PERMITTED BY LAW.
- D. THE OUTLOADING PROCEDURES DEPICTED WITHIN THIS DOCUMENT FOR TRAILERS EQUIPPED WITH VARIOUS TYPES OF SELF-CONTAINED MECHANICAL BRACING DEVICES ARE LIMITED TO HIGHWAY MOVEMENTS ONLY. THE HEIGHT REQUIREMENTS SPECIFIED WITHIN THIS DRAWING FOR THE INSTALLATION OF CROSS MEMBERS ARE IDENTICAL WITH THOSE RECOMMENDED BY THE BUREAU OF EXPLOSIVES PAMPHLET 6C, AND APPENDICES THERETO. CAUTION: TRAILERS EQUIPPED WITH WALL MEMBERS WHICH DO NOT MEET THE LOCATION REQUIREMENTS MUST NOT BE USED.
 - 1. PALLET UNITS SHOULD BE LOADED TIGHTLY AGAINST EACH OTHER AND/OR AGAINST INSTALLED CROSS MEMBERS, VOIDS LENGTHWISE WITHIN A LOAD SHOULD BE MINIMUM, CROSS MEMBERS MUST BE PLACED AGAINST THE LADING AS TIGHTLY AS THE WALL MEMBER LOCKING HOLE SPACING PERMITS, EACH CROSS MEMBER WILL BE INSTALLED WITH EACH END ATTACHED AS NEARLY AS POSSIBLE IN A "MATED" POSITION (AT EQUAL HEIGHTS, AND AT EQUAL DISTANCES FROM THE END OF THE TRAILER).
 - CROSS MEMBERS IN EMPTY TRAILERS AND THOSE UNUSED IN LOADED TRAILERS MUST BE "SECURED" FOR SHIPMENT. COMPONENTS ASSIGNED TO EACH TRAILER MUST REMAIN THEREWITH EVEN THOUGH UNUSED DURING SOME SHIPMENTS.
 - ONE (1) CROSS MEMBER WILL BE REQUIRED FOR EACH 10,000 POUNDS OF LADING AND SHOULD NOT BE RELIED UPON TO RETAIN A GREATER WEIGHT, CROSS MEMBERS WILL NOT BE DOUBLED, THAT IS, TWO CROSS MEMBERS AT THE SAME HEIGHT LOCATION WILL NOT BE PLACED SIDE BY SIDE
- E. SELECTION OF A VEHICLE TO BE USED TO TRANSPORT THE DESIGNATED ITEM MUST COMPLY WITH AR 55-355, CHAPTER 213, FOR EXPLOSIVES AND OTHER DANGEROUS ARTICLES, IN FULL.
- F. THE GROSS WEIGHT AND AXLE DISTRIBUTION OF WEIGHT FOR A LOAD WILL
 BE THE RESPONSIBILITY OF THE CARRIER. THE CARRIER WILL ADVISE THE SHIPPER
 OF THE APPLICABLE LOADING REQUIREMENTS, AND THE SHIPPER WILL LOAD
 ACCORDINGLY. THE TOTAL WEIGHT OF THE LADING, OF THE DUNNAGE, OF
 THE TRACTOR AND OF THE SEMI-TRAILER CARRYING THE LADING MUST NOT
 EXCEED THE MAXIMUM GROSS WEIGHT ALLOWED FOR THE STATE OR STATES
 THRU WHICH THE LOAD IS TO BE TRANSPORTED BY MOTOR CARRIER. LIKEWISE, THE GROSS WEIGHT ON A SINGLE OR TANDEM AXLE MUST NOT EXCEED
 THE MAXIMUM ALLOWABLE WEIGHT. IF THERE IS ANY DOUBT AS TO WHETHER
 THE TOTAL GROSS WEIGHT OF AXLE WEIGHT EXCEEDS THE MAXIMUM ALLOWED,
 WEIGHT SHOULD BE VERIFIED BY ACTUALLY WEIGHING THE LOADED VEHICLE.


(CONTINUED AT RIGHT)

MATERIAL SPECIFICATIONS

(GENERAL NOTES CONTINUED)


- G. NOTICE: A SHIPMENT WILL BE POSITIONED IN THE TRAILER CONSISTENT WITH STATE WEIGHT LAWS. THE NUMBER OF LADING UNITS MAY BE ADJUSTED TO FIT THE SIZE OF THE TRAILER TO BE LOADED OR THE QUANTITY TO BE SHIPPED COMBINATIONS OF THE OUTLOADING PROCEDURES SPECIFIED MAY BE USED; HOWEVER, THE APPROVED METHODS SHOWN MUST BE FOLLOWED AS CLOSELY AS POSSIBLE FOR BLOCKING, BRACING, AND STAYING OF THE DESIGNATED ITEMS.
- H. THE "LOAD AS SHOWN" FOR MOST OF THE FULL LOADS DEPICTED HEREIN IS BASED ON AN APPROXIMATE LADING WEIGHT OF 42,000 POUNDS. THE SPECIFIED BLOCKING AND BRACING FOR THE FULL LOADS IS ADEQUATE FOR THE RETENTION OF HEAVIER LOADS, IF IT IS DESIRED TO INCREASE THE LADING WEIGHT.
- J. OTHER TYPES OF LADING ITEMS MAY BE LOADED INTO TRAILERS WHICH ARE PARTIALLY LOADED WITH PALLET UNITS OF PROPELLING CHARGES, PROVIDING THE TOTAL LOAD IS COMPATIBLE, EXISTING DIRECTIVES ARE NOT VIOLATED, AND THE OTHER LADING ITEMS ARE BLOCKED AND BRACED TO EQUAL THE BLOCKING AND BRACING CRITERIA SPECIFIED HEREIN.
- K. ALL LOADS ARE SHOWN IN TRAILERS HAVING ROUNDED CORNERS AT THE FOR-WARD END. IF THE CONVENTIONAL VAN TRAILER BEING USED IS EQUIPPED WITH A SQUARE FRONT OR WITH AN INSTALLED BULKHEAD, OMIT THE FOR-WARD BLOCKING ASSEMBLY, PIECE MARKED (1), AND POSITION THE PALLET UNITS DIRECTLY AGAINST THE FORWARD PORTION OF THE TRAILER; OMIT CROSS MEMBERS IN THE FORWARD END OF MECHANICAL VAN TRAILERS HAVING A SQUARE FRONT.
- L. PALLET UNITS WHICH DO NOT CONTAIN A FULL QUANTITY OF ITEMS CAN BE TRANSPORTED. SEE THE "SHIPMENT OF A PARTIAL PALLET UNIT" DETAIL AND SPECIAL NOTES ON PAGE 22. FOR "SHIPMENT OF LEFTOVER CONTAINERS", SEE THE DETAILS AND SPECIAL NOTES ON PAGE 23.
- M. WHEN STEEL STRAPPING IS SEALED AT AN END-OVER-END LAP JOINT, A MINIMUM OF ONE (1) SEAL WITH TWO (2) PAIR OF NOTCHES WILL BE USED TO
 SEAL THE JOINT WHEN A NOTCH-TYPE SEALER IS BEING USED. A MINIMUM
 OF TWO (2) SEALS, BUTTED TOGETHER, WITH TWO (2) PAIR OF CRIMPS PER
 SEAL WILL BE USED TO SEAL THE JOINT WHEN A CRIMP-TYPE SEALER IS BEING
 USED. REFER TO THE "STRAP JOINT A" AND "STRAP JOINT B" DETAILS ON
 PAGE 31 FOR GUIDANCE,
- N. DUNNAGE LUMBER SPECIFIED THROUGHOUT THIS PROCEDURAL DRAWING IS OF NOMINAL SIZE. FOR EXAMPLE, 2" X 4" MATERIAL IS ACTUALLY 1-1/2" THICK BY 3-1/2" WIDE AND 2" X 6" MATERIAL IS ACTUALLY 1-1/2" THICK BY 5-1/2" WIDE.
- O. NOTICE: A STAGGERED NAILING PATTERN WILL BE USED WHEREVER POSSIBLE WHEN NAILS ARE DRIVEN INTO JOINTS OF DUNNAGE ASSEMBLIES. ALSO, A STAGGERED NAILING PATTERN WILL BE USED WHEN DUNNAGE IS NAILED TO THE FLOOR OF THE TRANSPORTING VEHICLE, OR WHEN LAMINATING DUNNAGE. THE NAILING PATTERN WILL BE ADJUSTED AS REQUIRED SO THAT A NAIL DOES NOT PENETRATE INTO OR NEAR A CRACK BETWEEN FLOOR BOARDS. ADDITIONALLY, THE NAILING PATTERN FOR AN UPPER PIECE OF LAMINATED DUNNAGE WILL BE ADJUSTED AS REQUIRED SO THAT A NAIL FOR THAT PIECE WILL NOT BE DRIVEN THROUGH ONTO OR RIGHT BESIDE A NAIL IN A LOWER PIECE
- P. POWER DRIVEN STAPLES MAY BE USED AS ALTERNATIVE FASTENERS FOR NAILS WHEN CONSTRUCTING DUNNAGE ASSEMBLIES WHICH ARE TO BE USED IN THE DELINE ATED TRAILER LOADS SHOWN THROUGHOUT THIS DRAMING. THE STAPLES TO BE USED MUST BE EQUAL IN LENGTH TO THE SPECIFIED NAIL SIZE AND MUST BE SUBSTITUTED ON A ONE STAPLE FOR ONE NAIL BASIS. STAPLES WHICH ARE 2-1/2" OR LESS IN LENGTH SHOULD BE IN ACCORDANCE WITH FEDERAL SPECIFICATION FF-N-105 AS NEARLY AS PRACTICABLE. STAPLES WHICH ARE LONGER THAN 2-1/2" WILL BE A COMMERCIAL GRADE, OF A QUALITY EQUIVALENT TO THOSE MANUFACTURED BY SENCO PRODUCTS INCORPORATED. NOTE: STAPLES WILL NOT BE SUBSTITUTED FOR NAILS IN ANY LOAD RESTRICTION.
- Q. PORTIONS OF THE TRAILERS, SUCH AS SIDEWALLS, END WALLS, AND ROOFS, HAVE NOT BEEN SHOWN IN THE LOAD VIEWS FOR CLARITY PURPOSES.
- R. FOR ADDITIONAL GUIDANCE, ATTENTION IS DIRECTED TO THE "SPECIAL NOTES' SECTIONS WHICH ARE IMMEDIATELY ADJACENT TO THE DEPICTED OUTLOADING METHODS.
- CONVERSION TO METRIC EQUIVALENTS: DIMENSIONS WITHIN THIS DOCUMENT ARE EXPRESSED IN INCHES, AND WEIGHTS ARE EXPRESSED IN POUNDS. WHEN NECESSARY, THE METRIC EQUIVALENTS MAY BE COMPUTED ON THE BASIS OF ONE INCH EQUALS 25.4MM AND ONE POUND EQUALS 0.454KG.
- T. THE PALLET UNITS DEPICTED ON PAGE 3 MAY BE LOADED AS A MIXED LOAD IN THE SAME TRAILER. FOR MIXED-HEIGHT LOADS, POSITION ALL PALLET UNITS OF ONE HEIGHT IN ONE LAYER, WITH THE BASIC HEIGHT UNITS BEING IN THE BOTTOM LAYER. IF FULL LAYERS OF ONE HEIGHT UNITS ARE NOT POSSIBLE FOR THE QUANTITY OF EACH SIZE TO BE SHIPPED, THE BASIC HEIGHT UNITS WILL BE LOADED IN THE FORWARD PORTION OF THE TRAILER WITH THE DECREASED HEIGHT UNITS IN THE REAR PORTION. CARE MUST BE EXERCISED WHEN SHIPPING MIXED HEIGHT UNITS IN TRAILERS EQUIPPED WITH MECHANICAL BRACING DEVICES TO ENSURE THAT THE CROSS MEMBERS CONTACT THE PALLET DUNNAGE AND/OR INTERMEDIATE DUNNAGE ASSEMBLY OF A UNIT BY AT LEAST ONE-HALF THE SURFACE OF THE HEIGHT OF THE CROSS MEMBER, LOAD BEARING GATES MUST BE INSTALLED BETWEEN THE CROSS MEMBER, AND THE PALLET UNITS IF THE CROSS MEMBERS DO NOT ALIGN PROPERLY.

ADHESIVE----- TYGARD ADHESIVE.



PALLET UNIT (BASIC HEIGHT)

REFER TO PAGES 4 THRU 9 AND PAGES 16 AND 17 FOR OUTLOADING PROCEDURES.




CONTAINER ----- 30 EACH @ 44 LBS (APPROX)

CUBE ----- 43.8 CUBIC FEET (APPROX)

GROSS WEIGHT ---- 1,498 LBS (APPROX)

REFER TO PAGES 10 THRU 17 FOR OUTLOADING PROCEDURES.

PALLET UNIT DETAILS




- I. A 23-UNIT LOAD IS SHOWN IN A 40'-0" LONG BY 7'-8" WIDE (INSIDE DIM-ENSION) CONVENTIONAL VAN TYPE TRAILER, WIDER OR NARROWER TRAILERS MAY BE USED FOR SHIPMENT OF THE DEPICTED LOAD. IF THE TRAILER BEING LOADED DOES NOT HAVE A DOOR OPENING HEIGHT OF AT LEAST 8'-8" IT WILL BE NECESSARY TO LIMIT THE REARMOST LOAD UNIT TO ONE PALLET UNIT IN HEIGHT. IF A TRAILER WHICH IS 8'-2" OR WIDER IS FURNISHED FOR LOAD-ING, THE LOADING PATTERN DEPICTED ON PAGE 6 MAY BE USED IN LIEU OF THE PROCEDURES DEPICTED ON PAGE 4.
- THE PALLET UNIT SHOWN IN THE LOAD ON PAGE 4 IS THE BASIC HEIGHT UNIT HAVING OVERALL DIMENSIONS OF 36-1/8" LONG BY 48" WIDE BY 51-1/8" HIGH AND WEIGHING APPROXIMATELY 1,783 POUNDS.
- 3. TOP-OF-LOAD ANTI-SWAY BRACES, SHOWN AS PIECES MARKED (3) IN THE LOAD ON PAGE 4, ARE TO BE POSITIONED BETWEEN ALL LATERALLY ADJACENT TOP-LAYER PALLET UNITS; HOWEVER, IF THE PALLET UNIT IN THE SECOND LAYER IS UNITIZED TO THE CORRESPONDING PALLET UNIT IN THE FIRST LAYER, A TOP-OF-LOAD ANTI-SWAY BRACE WILL NOT BE REQUIRED.
- 4. THE TOP-OF-LOAD ANTI-SWAY BRACE "B", SHOWN IN THE LOAD AS PIECE MARKED (4), IS ONLY REQUIRED FOR THE BRACING OF AN ODD UNIT IN THE SECOND LAYER. IF ANOTHER PALLET UNIT IS POSITIONED OPPOSITE THE ODD UNIT, ANTI-SWAY BRACE "C" WILL BE INSTALLED IN LIEU OF PIECE MARKED (6); THEN, TWO (2) ADDITIONAL UNITIZING STRAPS MARKED (6) WILL BE REQUIRED.
- 5. IF THE SPACE BETWEEN THE LADING AND THE TRAILER DOORS IS LESS THAN 9" SOLID FILL REAR BLOCKING WILL BE USED IN LIEU OF THE DEPICTED REAR BLOCKING ASSEMBLY. SEE THE "REAR BLOCKING ASSEMBLY C" DETAIL ON PAGE 28. IF THE SPACE IS LESS THAN 1-1/2" REAR BLOCKING IS NOT REQUIRED. SEE SPECIAL NOTE 12.
- 6. THE STACK UNITIZING STRAPS, PIECES MARKED (3) IN THE LOAD ON PAGE 4, WILL BE INSTALLED TO SECURE AN UNSUPPORTED PALLET UNIT IN THE SECOND LAYER TO A CORRESPONDING UNIT IN THE FIRST LAYER, EXCEPT AT THE VERY REAR OF THE LOAD. SEE SPECIAL NOTE 7.
- IF A STACK AT THE REAR OF THE LOAD IS MORE THAN ONE UNIT HIGH, BUNDLING STRAPS MUST BE INSTALLED SO AS TO ENCIRCLE THE REARMOST TWO (2) STACKS IN EACH APPLICABLE ROW. SEE PIECE MARKED (3) ON PAGE 10 FOR A TYPICAL INSTALLATION.
- 8. IF ONLY ONE PALLET UNIT IS TO BE LOADED IN THE SECOND LAYER OF EITHER ROW, AS IN THE DEPICTED LOAD, IT MUST NOT BE POSITIONED ON TOP OF THE REARMOST PALLET UNIT IN THE FIRST LAYER.
- P. REFER TO PAGE 22 FOR GUIDANCE IN THE SHIPMENT OF PARTIAL PALLET UNITS.
- LEFTOVER CONTAINERS IN AN AMOUNT NOT TO EXCEED FOUR (4) MAY BE SECURED TO THE TOP OF A FULL PALLET UNIT FOR SHIPMENT, REFER TO THE "PROCEDURES FOR SHIPMENT OF LEFTOVER CONTAINERS" ON PAGE 23 FOR GUIDANCE.
- FOR SHIPMENT OF LESS THAN FULL LOADS, REFER TO THE APPLICABLE GUID-ANCE ON PAGES 18 THRU 20.
- 12. TRAILERS EQUIPPED WITH ROLL-UP TYPE DOORS MAY BE USED; HOWEVER, SPECIAL REAR BLOCKING MUST BE INSTALLED. SEE THE "PROCEDURES FOR CONVENTIONAL'VAN TRAILERS EQUIPPED WITH ROLL-UP TYPE DOORS" ON PAGES 32 AND 33 FOR GUIDANCE. THE NAILED-HEADER METHOD IS SHOWN ON PAGE 32 AND THE TYGARD METHOD IS SHOWN ON PAGE 33. NOTE THAT THE SPECIAL REAR BLOCKING FOR TRAILERS EQUIPPED WITH ROLL-UP TYPE DOORS MAY ALSO BE USED IN TRAILERS EQUIPPED WITH HINGED DOORS.

	BILL OF MATERIAL	
LUMBER	LINEAR FEET	BOARD FEET
2" X 4" 2" X 6"	218 82	146 82
NAILS	NO. REQD	POUNDS
10d (3")	292	4-1/2

STEEL STRAPPING, 1-1/4" X .035" OR .031"--265' REQD----38 LBS SEAL FOR 1-1/4" STRAPPING------20 REQD-----1 LB WIRE, NO. 14 GAGE ------1 LB

LOAD AS SHOWN

PALLET UNIT (BASIC HEIGHT)
23-UNIT LOAD IN A 40'-0" LONG BY 7'-8" WIDE HIGH-VOLUME VAN TYPE TRAILER



- A 25-UNIT LOAD IS SHOWN IN A 40'-0" LONG BY 8'-2" WIDE (INSIDE DIM-ENSION) CONVENTIONAL VAN TYPE TRAILER. WIDER OR NARROWER TRAILERS MAY BE USED. HOWEVER, IF THE TRAILER BEING LOADED DOES NOT HAVE A DOOR OPENING HEIGHT OF AT LEAST 8'-8" IT WILL BE INCESSARY TO LIMIT THE REARMOST LOAD UNIT TO ONE PALLET UNIT IN HEIGHT.
- THE PALLET UNIT SHOWN IN THE LOAD ON PAGE 6 IS THE BASIC HEIGHT UNIT, HAVING OVERALL DIMENSIONS OF 36-1/8" LONG BY 48" WIDE BY 51-1/8" HIGH AND WEIGHING APPROXIMATELY 1,783 POUNDS.
- 3. IF THE SPACE AT THE REAR OF THE LOAD, BETWEEN THE PALLET UNITS AND THE REAR DOORS MEASURES 1-1/2" OR LESS, REAR BLOCKING IS NOT REQUIRED. IF THE SPACE AT THE REAR OF THE LOAD IS GREATER THAN 1-1/2", BUT LESS THAN 9", USE REAR BLOCKING ASSEMBLY "C" DETAILED ON PAGE 28. IF THE SPACE AT THE REAR OF THE LOAD IS 9" OR GREATER, REAR BLOCKING ASSEMBLY "B" WILL BE USED AS SHOWN.
- 4. THE STACK UNITIZING STRAPS MARKED ③ IN THE LOAD ON PAGE 6, WILL BE INSTALLED TO SECURE AN UNSUPPORTED PALLET UNIT IN THE SECOND LAYER TO A CORRESPONDING UNIT IN THE FIRST LAYER, EXCEPT AT THE VERY REAR OF THE LOAD. SEE SPECIAL NOTE 5.
- 5. IF A STACK AT THE REAR OF THE LOAD IS MORE THAN ONE UNIT HIGH, BUNDLING STRAPS MUST BE INSTALLED SO AS TO ENCIRCLE THE REARMOST TWO (2) STACKS IN EACH APPLICABLE ROW. SEE KEY NUMBER ③ ON PAGE 12 AND DETAIL "A" ON PAGE 13 FOR A TYPICAL INSTALLATION.
- 6. IF ONLY ONE PALLET UNIT IS TO 8E LOADED IN THE SECOND LAYER OF EITHER ROW, AS IN THE DEPICTED LOAD, IT MUST NOT BE POSITIONED ON TOP OF THE REARMOST PALLET UNIT IN THE FIRST LAYER.
- REFER TO PAGE 22 FOR GUIDANCE IN THE SHIPMENT OF PARTIAL PALLET UNITS.
- LEFTOVER CONTAINERS IN AN AMOUNT NOT TO EXCEED FOUR (4) MAY BE SECURED TO THE TOP OF A FULL PALLET UNIT FOR SHIPMENT. REFER TO THE "PROCEDURES FOR SHIPMENT OF LEFTOVER CONTAINERS" ON PAGE 23 FOR GUIDANCE
- FOR SHIPMENT OF LESS THAN FULL LOADS, REFER TO THE APPLICABLE GUI-DANCE ON PAGES 18 THRU 20.
- 10. TRAILERS EQUIPPED WITH ROLL-UP TYPE DOORS MAY BE USED; HOWEVER, SPECIAL REAR BLOCKING MUST BE INSTALLED. SEE THE "PROCEDURES FOR CONVENTIONAL VAN TRAILERS EQUIPPED WITH ROLL-UP TYPE DOORS" ON PAGES 32 AND 33 FOR GUIDANCE. A NAILED-HEADER METHOD AND A TYGARD METHOD ARE SHOWN. NOTE THAT THE SPECIAL REAR BLOCKING FOR TRAILERS EQUIPPED WITH ROLL-UP TYPE DOORS MAY ALSO BE USED IN CONVENTIONAL VAN TRAILERS EQUIPPED WITH HINGED DOORS.


BILL OF MATERIAL			
LUMBER	LINEAR FEET	BOARD FEET	
2" X 3" 2" X 4" 2" X 6"	4 29 57	2 20 57	
NAILS	NO. REQD	POUNDS	
10d (3")	82	1-1/4	

STEEL STRAPPING, 1-1/4" X .035" OR .031"---48' REQD-----7 LBS
SEAL FOR 1-1/4" STRAPPING ------- NIL

LOAD AS SHOWN

PALLET UNIT (BASIC HEIGHT)

25-UNIT LOAD IN A 40'-0" LONG BY 8'-2" WIDE HIGH-VOLUME VAN TYPE TRAILER



- A 23-UNIT LOAD IS SHOWN IN A 40'-0" LONG BY 7'-8" WIDE (INSIDE DIM-ENSION) TRAILER EQUIPPED WITH MECHANICAL BRACING DEVICES (CROSS MEMBERS AND STATIONARY WALL MEMBERS) AND ROUNDED CORNERS. WIDER OR NARROWER TRAILERS MAY BE USED.
- THE PALLET UNIT SHOWN IN THE LOAD ON PAGE 8 IS THE BASIC HEIGHT UNIT HAVING OVERALL DIMENSIONS OF 36-1/8" LONG BY 48" WIDE BY 51-1/8" HIGH AND WEIGHING APPROXIMATELY 1,783 POUNDS.
- 3. IF PLYWOOD IS NOT AVAILABLE FOR THE CONSTRUCTION OF LOAD BEARING GATES, OR IF DESIRED, PIECES MARKED ② , ④ , AND ⑦ MAY BE CONSTRUCTED FROM 1" AND/OR 2" LUMBER. SEE THE ALTERNATIVE LOAD BEARING GATE "A", "B", AND "C" DETAILS ON PAGE 27.
- 4. TOP-OF-LOAD ANTI-SWAY BRACES, SHOWN AS PIECES MARKED (3) IN THE LOAD ON PAGE 8, ARE TO BE POSITIONED BETWEEN ALL LATERALLY ADJACENT TOP-LAYER PALLET UNITS; HOWEVER, IF THE PALLET UNIT IN THE SECOND LAYER IS UNITIZED TO THE CORRESPONDING PALLET UNIT IN THE FIRST LAYER A TOP-OF-LOAD ANTI-SWAY BRACE WILL NOT BE REQUIRED.
- IF ONLY ONE PALLET UNIT IS LOADED IN THE SECOND LAYER, SPACER ASSEM-BLY PROCEDURES AS SPECIFIED ON PAGE 21 MAY BE USED, OR THE TOP-OF-LOAD ANTI-SWAY BRACE "B" AND STACK UNITIZING STRAPS AS SHOWN ON PAGE 8 MAY BE USED.
- A STACK UNITIZING STRAP, PIECE MARKED (8) , WILL BE APPLIED AROUND THE REARMOST COMPLETE STACK AND AROUND THE MOST FORWARD COM-PLETE STACK IN EACH ROW WHERE THE NUMBER OF TIERS (LAYERS IN THE LOAD) CHANGES.
- REFER TO PAGE 22 FOR GUIDANCE IN THE SHIPMENT OF PARTIAL PALLET UNITS.
- 8. LEFTOVER CONTAINERS IN AN AMOUNT NOT TO EXCEED FOUR (4) MAY BE SECURED TO THE TOP OF A FULL PALLET UNIT FOR SHIPMENT, REFER TO THE "PROCEDURES FOR SHIPMENT OF LEFTOVER CONTAINERS" ON PAGE 23 FOR GUIDANCE.
- FOR SHIPMENT OF LESS THAN FULL LOADS, REFER TO THE APPLICABLE GUI-DANCE ON PAGE 21.
- 10. IF THE TRAILER BEING LOADED IS EQUIPPED ONLY WITH SHORT WALL MEMBERS AT THE REAR FOR ATTACHMENT OF THE CROSS MEMBERS, THE CROSS MEMBERS AND LOAD BEARING GATE "A" PIECES MARKED ① AND ② , WILL BE OMITTED FROM THE FRONT OF THE LOAD; UNILESS THE TRAILER HAS A SQUARE FRONT, A FORWARD BLOCKING ASSEMBLY WILL BE REQUIRED. SEE THE DETAIL AND THE FORWARD BLOCKING CHART "A" ON PAGE 24.


	BILL OF MATERIAL	
LUMBER	UNEAR FEET	BOARD FEET
1" X 4" 2" X 4"	31 191	11 128
NAILS	NO. REQD	POUNDS
6d (2") 10d (3")	78 178	1/2 2-3/4

STEEL STRAPPING, 1-1/4" X .035" OR .031"—265' REQD——38 LBS
SEAL FOR 1-1/4" STRAPPING ——20 REQD——1 LB
PLYWOOD, 1/2"——54 SQ FT REQD——75 LBS
WIRE, NO. 14 GAGE ——40' REQD——1 LB
CROSS MEMBER ——12 REQD

LOAD AS SHOWN

PALLET UNIT (BASIC HEIGHT)

23-UNIT LOAD' IN A 40'-0" LONG BY 7'-8" WIDE HIGH-VOLUME TRAILER EQUIPPED WITH MECHANICAL BRACING DEVICES




- A 28-UNIT LOAD IS SHOWN IN A 40'-0" LONG BY 7'-6" WIDE (INSIDE DIMENSION) CONVENTIONAL VAN TYPE TRAILER. WIDER OR NARROWER TRAILERS MAY BE USED.
- THE PALLET UNIT SHOWN IN THE LOAD ON PAGE 10 IS THE DECREASED HEIGHT UNIT HAVING OVERALL DIMENSIONS OF 36-1/8" LONG BY 48" WIDE BY 43-5/8" HIGH AND WEIGHING APPROXIMATELY 1,498 POUNDS.
- TOP-OF-LOAD ANTI-SWAY BRACES, SHOWN AS PIECES MARKED ③ IN THE LOAD ON PAGE 10, ARE TO BE POSITIONED BETWEEN ALL LATERALLY ADJACENT TOP-LAYER PALLET UNITS; HOWEVER, IF THE PALLET UNIT IN THE SECOND LAYER IS UNITIZED TO THE CORRESPONDING PALLET UNIT IN THE FIRST LAYER, -OF-LOAD ANTI-SWAY BRACE WILL NOT BE REQUIRED.
- IF THE SPACE BETWEEN THE LADING AND THE TRAILER DOORS IS LESS THAN 9", SOLID FILL REAR BLOCKING WILL BE USED IN LIEU OF THE DEPICTED REAR BLOCKING ASSEMBLY C" DETAIL ON PAGE 28. IF THE SPACE IS LESS THAN 1-1/2" REAR BLOCKING IS NOT RE-QUIRED. SEE SPECIAL NOTE 11.
- THE STACK UNITIZING STRAPS, PIECES MARKED ⑤ IN THE LOAD ON PAGE 10, WILL BE INSTALLED TO SECURE AN UNSUPPORTED PALLET UNIT IN THE SECOND LAYER TO A CORRESPONDING UNIT IN THE FIRST LAYER, EXCEPT AT THE VERY REAR OF THE LOAD.
- IF A STACK AT THE REAR OF THE LOAD IS MORE THAN ONE UNIT HIGH, AS IN THE DEPICTED LOAD, BUNDLING STRAPS, SHOWN AS PIECE MARKED 6, MUST BE INSTALLED SO AS TO ENCIRCLE THE REARMOST TWO (2) STACKS IN
- IF ONLY ONE PALLET UNIT IS TO BE LOADED IN THE SECOND LAYER OF EITHER ROW, IT MUST NOT BE POSITIONED ON TOP OF THE REARMOST PALLET UNIT IN THE FIRST LAYER, PROVIDE LONGITUDINAL BRACING BY INSTALLING UNITIZING STRAPS, PIECE MARKED ③. PROVIDE LATERAL BRACING BY INSTALLING A TOP-OF-LOAD ANTI-SWAY BRACE 18" AS DETAILED ON PAGE 25 AND SHOWN IN THE LOAD VIEW ON PAGE 8 AS PIECE MARKED ⑥. WIRE TIE AS SHOWN BY THE "TIE WIRE APPLICATION B" DETAIL ON PAGE 30.
- REFER TO PAGE 22 FOR GUIDANCE IN THE SHIPMENT OF PARTIAL PALLET UNITS.
- LEFTOVER CONTAINERS IN AN AMOUNT NOT TO EXCEED FOUR (4) MAY BE SECURED TO THE TOP OF A FULL PALLET UNIT FOR SHIPMENT. REFER TO THE "PROCEDURES FOR SHIPMENT OF LEFTOVER CONTAINERS" ON PAGE 23 FOR REFER TO THE
- FOR SHIPMENT OF LESS THAN FULL LOADS, REFER TO THE APPLICABLE GUI-DANCE ON PAGES 18 THRU 20,
- TRAILERS EQUIPPED WITH ROLL-UP TYPE DOORS MAY BE USED; HOWEVER SPECIAL REAR BLOCKING MUST BE INSTALLED. SEE THE "PROCEDURES FOR CONVENTIONAL VAN TRAILERS EQUIPPED WITH ROLL-UP TYPE DOORS" ON PAGES 32 AND 33 FOR GUIDANCE. THE NAILED-HEADER METHOD IS SHOWN ON PAGE 32 AND THE TYGARD METHOD IS SHOWN ON PAGE 33. NOTE THAT THE SPECIAL REAR BLOCKING FOR TRAILERS EQUIPPED WITH ROLL-UP TYPE DOORS MAY ALSO BE USED IN TRAILERS EQUIPPED WITH HINGED DOORS


BILL OF MATERIAL					
LUMBER	LINEAR FEET	BOARD FEET			
2" X 4" 2" X 6"	220 80	147 80			
NAILS	NO, REQD	POUNDS			
104 (3")	302	4-3/4			

LOAD AS SHOWN

ITEM QUANTITY WEIGHT (APPROX) DUNNAGE-------505 IRS TOTAL WEIGHT ----- 42,449 LBS

PALLET UNIT (DECREASED HEIGHT) 28-UNIT LOAD IN A 40'-0" LONG BY 7'-6" WIDE CONVENTIONAL VAN TYPE TRAILER





LUMBER	LINEAR FEET	BOARD FEET
2" X 3" 2" X 4" 2" X 6"	4 42 87	2 28 87
NAILS	NO. REQD	POUNDS
10d (3")	114	1-3/4


- 1. A 28-UNIT LOAD IS SHOWN IN A 40'-0" LONG BY 8'-2" WIDE (INSIDE DIM-ENSION) CONVENTIONAL VAN TYPE TRAILER, WIDER TRAILERS MAY BE USED. HOWEVER, IF THE TRAILER BEING LOADED DOES NOT HAVE A DOOR OPENING HEIGHT OF AT LEAST 7'-6" IT WILL BE NECESSARY TO LIMIT THE REARMOST LOAD UNIT TO ONE PALLET UNIT IN HEIGHT.
- THE PALLET UNIT SHOWN IN THE LOAD ON PAGE 12 IS THE DECREASED HEIGHT UNIT, HAVING OVERALL DIMENSIONS OF 36-1/8" LONG BY 48" WIDE BY 43-5/8" HIGH AND WEIGHING APPROXIMATELY 1,498 POUNDS.
- 3. IF THE SPACE AT THE REAR OF THE LOAD, BETWEEN THE PALLET UNITS AND THE REAR DOORS MEASURES 1-1/2" OR LESS, REAR BLOCKING IS NOT REQUIRED. IF THE SPACE AT THE REAR OF THE LOAD IS GREATER THAN 1-1/2" BUT LESS THAN 9", USE REAR BLOCKING ASSEMBLY "C" DETAILED ON PAGE 28. IF THE SPACE AT THE REAR OF THE LOAD IS 9" OR GREATER, REAR BLOCKING ASSEMBLY "B" WILL BE USED AS SHOWN.
- 4. THE STACK UNITIZING STRAPS MARKED ③ IN THE LOAD ON PAGE 12, WILL BE INSTALLED TO SECURE AN UNSUPPORTED PALLET UNIT IN THE SECOND LAYER TO A CORRESPONDING UNIT IN THE FIRST LAYER, EXCEPT AT THE VERY REAR OF THE LOAD.
- 5. IF A STACK AT THE REAR OF THE LOAD IS MORE THAN ONE UNIT HIGH, BUNDLING STRAPS MUST BE INSTALLED SO AS TO ENCIRCLE THE REARMOST TWO (2) STACKS IN EACH APPLICABLE ROW, NOTE THAT PIECE MARKED (3) MAY NOT BE REQUIRED.
- IF ONLY ONE PALLET UNIT IS TO BE LOADED IN THE SECOND LAYER OF EITHER ROW, IT MUST NOT BE POSITIONED ON TOP OF THE REARMOST PALLET UNIT IN THE FIRST LAYER.
- 7. REFER TO PAGE 22 FOR GUIDANCE IN THE SHIPMENT OF PARTIAL PALLET UNITS.
- LEFTOVER CONTAINERS IN AN AMOUNT NOT TO EXCEED FOUR (4) MAY BE SECURED TO THE TOP OF A FULL PALLET UNIT FOR SHIPMENT. REFER TO THE "PROCEDURES FOR SHIPMENT OF LEFTOVER CONTAINERS" ON PAGE 23 FOR GUIDANCE.
- FOR SHIPMENT OF LESS THAN FULL LOADS, REFER TO THE APPLICABLE GUI-DANCE ON PAGES 18 THRU 20.
- 10. TRAILERS EQUIPPED WITH ROLL-UP TYPE DOORS MAY BE USED; HOWEVER, SPECIAL REAR BLOCKING MUST BE INSTALLED. SEE THE "PROCEDURES FOR CONVENTIONAL VAN TRAILERS EQUIPPED WITH ROLL-UP TYPE DOORS" ON PAGES 32 AND 33 FOR GUIDANCE. A NAILED-HEADER METHOD AND A TYGARD METHOD ARE SHOWN. NOTE THAT THE SPECIAL REAR BLOCKING FOR TRAILERS EQUIPPED WITH ROLL-UP TYPE DOORS MAY ALSO BE USED IN CONVENTIONAL VAN TRAILERS EQUIPPED WITH HINGED DOORS.

LOAD AS SHOWN

| TOTAL WEIGHT -------42, 206 LBS | LBS |

PALLET UNIT (DECREASED HEIGHT)

28-UNIT LOAD IN A 40'-0" LONG BY 8'-2" WIDE CONVENTIONAL VAN TYPE TRAILER



- A 28-UNIT LOAD IS SHOWN IN A 40'-0" LONG BY 7'-6" WIDE (INSIDE DIM-ENSION) TRAILER EQUIPPED WITH MECHANICAL BRACING DEVICES (CROSS MEM-BERS AND STATIONARY WALL MEMBERS) AND ROUNDED CORNERS. WIDER OR NARROWER TRAILERS MAY BE USED.
- THE PALLET UNIT SHOWN IN THE LOAD ON PAGE 14 IS THE DECREASED HEIGHT UNIT HAVING OVERALL DIMENSIONS OF 36-1/8" LONG BY 48" WIDE BY 43-5/8" HIGH AND WEIGHING APPROXIMATELY 1,498 POUNDS.
- 3. IF PLYWOOD IS NOT AVAILABLE FOR THE CONSTRUCTION OF LOAD BEARING GATES, OR IF DESIRED, PIECES MARKED ② AND ③ MAY BE CONSTRUCTED FROM 1" AND/OR 2" LUMBER. SEE THE ALTERNATIVE LOAD BEARING GATE "A" AND "D" DETAILS ON PAGE 27.
- 4. TOP-OF-LOAD ANTI-SWAY BRACES, SHOWN AS PIECES MARKED ③ IN THE LOAD ON PAGE 14, ARE TO BE POSITIONED BETWEEN ALL LATERALLY ADJACENT TOP-LAYER PALLET UNITS; HOWEVER, IF THE PALLET UNIT IN THE SECOND LAYER IS UNITIZED TO THE CORRESPONDING PALLET UNIT IN THE FIRST LAYER, A TOP-OF-LOAD ANTI-SWAY BRACE WILL NOT BE REQUIRED.
- A STACK UNITIZING STRAP, PIECE MARKED (a), WILL BE APPLIED AROUND THE REARMOST COMPLETE STACK AND AROUND THE MOST FORWARD COMPLETE STACK IN EACH ROW WHERE THE NUMBER OF TIERS (LAYERS IN THE LOAD) CHANGES.
- IF ONLY ONE PALLET UNIT IS LOADED IN THE SECOND LAYER, SPACER ASSEMBLY PROCEDURES AS SPECIFED ON PAGE 21, MAY BE USED, OR THE TOP-OF-LOAD ANTI-SWAY BRACE "B" AND STACK UNITIZING STRAPS AS SHOWN ON PAGE 8 MAY BE USED.
- 7. REFER TO PAGE 22 FOR GUIDANCE IN THE SHIPMENT OF PARTIAL PALLET UNITS.
- LEFTOVER CONTAINERS IN AN AMOUNT NOT TO EXCEED FOUR (4) MAY BE SECURED TO THE TOP OF A FULL PALLET UNIT FOR SHIPMENT. REFER TO THE "PROCEDURES FOR SHIPMENT OF LEFTOVER CONTAINERS" ON PAGE 23 FOR GUIDANCE.
- FOR SHIPMENT OF LESS THAN FULL LOADS, REFER TO THE APPLICABLE GUI-DANCE ON PAGE 21.
- IF THE TRAILER BEING LOADED IS EQUIPPED ONLY WITH SHORT WALL MEMBERS AT THE REAR FOR ATTACHMENT OF THE CROSS MEMBERS, THE CROSS MEMBERS AND LOAD BEARING GATE "A" PIECES MARKED () AND (2) WILL BE OMITTED FROM THE FRONT OF THE LOAD; THEN, A FORWARD BLOCKING ASSEMBLY WILL BE REQUIRED. SEE THE DETAIL AND THE FORWARD BLOCKING CHART "A" ON PAGE 24.

LUMBER	LINEAR FEET	BOARD FEET
1" X 4" 2" X 4"	30 197	10 132
NAILS	NO. REQD	POUNDS
6d (2") 10d (3")	72 192	1/2


LOAD AS SHOWN

PALLET UNIT -----28------41,944 LBS
DUNNAGE ------171 LBS

TOTAL WEIGHT -----42,361 LBS

PALLET UNIT (DECREASED HEIGHT)

28-UNIT LOAD IN A 40'-0" LONG BY 7'-6" WIDE TRAILER EQUIPPED WITH MECHANICAL BRACING DEVICES



- A 23-UNIT LOAD IS SHOWN IN A 40'-0" LONG BY 7'-8" WIDE (INSIDE DIM-ENSION) CONVENTIONAL VAN TYPE TRAILER, WIDER OR NARROWER TRAILERS MAY BE USED, HIGH VOLUME-TRAILERS MAY BE REQUIRED.
- THE PALLET UNIT SHOWN IN THE LOAD ON PAGE 16 IS THE BASIC HEIGHT UNIT, HAVING OVERALL DIMENSIONS OF 36-1/8" LONG BY 48" WIDE BY 51-1/8" HIGH AND WEIGHING APPROXIMATELY 1,783 POUNDS. THE PROCE-DURES ARE ALSO APPLICABLE FOR THE DECREASED HEIGHT UNIT.
- TOP-OF-LOAD ANTI-SWAY BRACES, SHOWN AS PIECE MARKED (3) IN THE LOAD ON PAGE 16, ARE TO BE POSITIONED BETWEEN ALL LATERALLY ADJACENT PALLET UNITS IN EACH LAYER.
- 4. THE SPACER ASSEMBLY, SHOWN IN THE LOAD VIEW AS PIECE MARKED (4), IS ONLY SHOWN TO DEPICT A TYPICAL INSTALLATION. IF A PALLET UNIT IS LOADED IN PLACE OF THE SPACER ASSEMBLY, THE BUNDLING STRAPS, SHOWN AS PIECE MARKED (2), WILL NOT BE REQUIRED. NOTE THAT A SPACER ASSEMBLY MUST BE POSITIONED WHERE THERE WILL BE A PALLET UNIT AT EACH END, A SPACER ASSEMBLY MUST NOT BE POSITIONED ADJACENT TO THE FORWARD BLOCKING ASSEMBLY OR A BULKHEAD GATE, PIECES MARKED (1) AND (5).
- 5. IF THE VOID AT THE REAR OF THE LOAD, BETWEEN THE PALLET UNITS AND THE REAR DOORS MEASURES 1-1/2" OR LESS, REAR BLOCKING IS NOT REQUIRED. IF THE VOID AT THE REAR OF THE LOAD IS GREATER THAN 1-1/2" BUT LESS THAN 9", USE REAR BLOCKING ASSEMBLY "C" DETAILED ON PAGE 28. IF THE VOID AT THE REAR OF THE LOAD IS 9" OR GREATER, REAR BLOCKING ASSEMBLY "A" WILL BE USED AS SHOWN.
- 6. TRAILERS EQUIPPED WITH ROLL-UP TYPE DOORS MAY BE USED; HOWEVER, SPE-CIAL REAR BLOCKING MUST BE INSTALLED. SEE THE "PROCEDURES FOR CONVENTIONAL VAN TRAILERS EQUIPPED WITH ROLL-UP TYPE DOORS" ON PAGES 32 AND 33 FOR GUIDANCE. THE NAILED-HEADER METHOD IS SHOWN ON PAGE 33. NOTE THAT THE SPECIAL REAR BLOCKING FOR TRAILERS EQUIPPED WITH ROLL-UP TYPE DOORS MAY ALSO BE USED IN TRAILERS EQUIPPED WITH HINGED DOORS.
- 7. A PALLET UNIT THAT DOES NOT HAVE A PALLET UNIT DIRECTLY OPPOSITE MUST BE SECURED BY INSTALLING BUNDLING STRAPS, SHOWN AS PIECE MARKED (?) IN THE LOAD ON PAGE 16, AROUND THAT PALLET UNIT AND THE PALLET UNIT IMMEDIATELY ADJACENT; A PALLET UNIT WILL NOT BE OMITTED FROM THE SECOND LAYER PORTION OF THE LOAD.
- 8. THE SECOND LAYER PORTION OF THE LOAD IS LIMITED TO NOT MORE THAN TEN (10) BASIC HEIGHT UNITS OR TWELVE (12) DECREASED HEIGHT UNITS. THE LOWER BUNDLING STRAP, PIECE MARKED (3), MAY BE OMITTED IF THE SECOND LAYER CONTAINS TWO OR FOUR PALLET UNITS.
- 9. REFER TO PAGE 22 FOR GUIDANCE IN THE SHIPMENT OF PARTIAL PALLET UNITS.
- LEFTOVER CONTAINERS IN AN AMOUNT NOT TO EXCEED FOUR (4), MAY BE SECURED TO THE TOP OF A FULL PALLET UNIT FOR SHIPMENT, REFER TO THE "PROCEDURES FOR SHIPMENT OF LEFTOVER CONTAINERS" ON PAGE 23 FOR GUIDANCE.


BILL OF MATERIAL (TYPICAL)					
LUMBER	LINEAR FEET	BOARD FEET			
2" X 4" 2" X 6"	206 232	138 232			
NAILS	NO. REQD	POUNDS			
104 (3")	460	7-1/4			

40' REQD

WIRE, NO. 14 GAGE -

LOAD AS SHOWN (TYPICAL)

ALTERNATIVE LOADING PROCEDURES FOR ALL UNITS 23-UNIT LOAD IN A 40'-0" LONG BY 7'-8" WIDE HIGH-VOLUME VAN TYPE TRAILER




- SPACER ASSEMBLY (2 REQD). SEE THE "SPACER ASSEMBLY B" DETAIL ON PAGE 25. NAIL TO A HEADER, PIECE MARKED ③ , W/2-10d NAILS. SEE SPECIAL NOTE 4 ON PAGE 19.
- (5) HEADER, 2" X 6" BY TRAILER WIDTH MINUS 1/2" IN LENGTH (2 REQD). SEE SPECIAL NOTE 8 ON PAGE 19.
- (6) HEADER AND SIDE STRUT SUPPORT, 2" X 4" BY TRAILER WIDTH MINUS 1/2" IN LENGTH (2 REQD). NAIL TO THE BOTTOM EDGE OF A HEADER, PIECE MARKED (5), W/1-10d NAIL EVERY 8".
- 5 SIDE STRUT, 2" X 6" BY CUT-TO-FIT BETWEEN THE FORWARD AND REAR HEADERS, PIECES MARKED (\$) (2 REQD). SEE SPECIAL NOTE 5 ON PAGE 19.
- (8) RISER PIECE, 2" X 4" X 9" (AS REQD), CENTER UNDER THE JOINTS OF PIECES MARKED (7) AND (3) , (4) AND (5) , AND UNDER THE SPLICE OF PIECES MARKED (7) IF APPLICABLE. NAIL TO SIDE STRUT MARKED (7) W/2-104 NAILS.
- POCKET CLEAT, 2" X 6" X 12" (4 REQD). NAIL TO A SIDE STRUT, PIECE MARKED (3), W/3-104 NAILS. TOENAIL TO THE ADJACENT HEADER, PIECE MARKED (3), W/3-124 NAILS.
- (10) SPLICE PIECE, 2" X 6" X 24" (AS REQD). CENTER ON JOINT OF PIECES MARKED (2) AND NAIL TO SIDE STRUT MARKED (2) W/4-10d NAILS AT EACH END. SEE SPECIAL NOTE 5 ON PAGE 19.
- (1) CENTER CLEAT, 2" X 6" X 24" (1 REQD). NAIL TO A HEADER, PIECE MARKED (5) , W/6-10d NAILS.
- (12) DIAGONAL BRACE, 2" X 6" BY CUT-TO-FIT (2 REQD). DOUBLE BEVEL EACH END WITH 45° CUTS. INSTALL AT A 45° ANGLE AS SHOWN AND TOENAIL TO THE ADJACENT HEADER AND SIDE STRUT, PIECES MARKED (§) AND (?) , W/2-164 NAILS AT EACH END.
- (14) STRUT BRACE RETAINING CLEAT, 2" X 4" X 12" (AS REQD). NAIL TO A SIDE STRUT, PIECE MARKED ⑦, W/3-10d NAILS. SEE SPECIAL NOTE 6 ON PAGE 19.
- (15) STRUT BRACE, 2" X 4" BY TRAILER WIDTH MINUS 3" IN LENGTH (MINIMUM OF ONE REQUIRED). NAIL TO THE POCKET CLEATS, PIECES MARKED (9), AND/OR TO THE STRUT BRACE RETAINING CLEATS, PIECES MARKED (14), W/2-12d NAILS AT EACH END. SEE SPECIAL NOTE 6 ON PAGE 19.

TYPICAL LTL (5-UNIT LOAD) IN A CONVENTIONAL VAN TYPE TRAILER

- THESE OUTLOADING PROCEDURES COVER THE USE OF BOTH "K-BRACE" AND NAILED FLOOR LINE BLOCKING IN A 7'-8" WIDE (INSIDE DIMENSION) VAN TRAILER WHICH IS EQUIPPED WITH OR WITHOUT NAILABLE FLOORS AND REAR CORNER POSTS. WIDER OR NARROWER TRAILERS MAY BE USED. SEE SPECIAL NOTES 8 AND 9.
- THE PALLET UNIT SHOWN IS THE BASIC HEIGHT UNIT HAVING OVERALL DIMEN-SIONS OF 36-1/8" LONG BY 48" WIDE BY 51-1/8" HIGH AND WEIGHING APPROXIMATELY 1,783 POUNDS. THE PROCEDURES ARE ALSO APPLICABLE FOR THE DECREASED HEIGHT UNIT DEPICTED ON PAGE 3.
- TOP-OF-LOAD ANTI-SWAY BRACES WILL BE POSITIONED BETWEEN ALL LATERALLY ADJACENT BASIC HEIGHT PALLET UNITS. BRACES ARE NOT REQUIRED FOR THE DECREASED HEIGHT UNITS.
- 4. THE SPACER ASSEMBLIES, PIECE MARKED (1), ARE SHOWN ONLY TO DEPICT A TYPICAL INSTALLATION. SPACER ASSEMBLES WILL BE USED WHEN A PALLET UNIT IS OMITTED. THEY MAY OR MAY NOT BE REQUIRED, DEPENDING ON THE QUANTITY OF PALLET UNITS TO BE SHIPPED.
- 5. DEPENDING ON THE NUMBER OF UNITS BEING LOADED, EACH OF THE SIDE STRUTS, PIECES MARKED (?), MAY NEED TO BE FORMED FROM MORE THAN ONE PIECE OF MATERIAL. IF SUCH IS THE CASE, THE SIDE STRUTS MUST BE SPLICED. SPLICING CAN BE ACCOMPLISHED BY CENTERING A 2" X 6" X 24" PIECE ON THE JOINT OF THE SIDE STRUTS AND NAILING IT TO THE SIDE STRUTS W/4-104 NAILS AT EACH END. CAUTION: A RISER MECE, PIECE MARKED (B), MUST BE POSITIONED UNDER EACH SPLICE JOINT. NOTE: IF DESIRED, THE STURT BRACKING PIECE (S), PIECE MARKED (B), MAY BE NAILED TO THE SPLICE PIECES IN LIEU OF USING ADDITIONAL STRUT BRACE RETAINING CLEATS, PIECES MARKED (14).
- 6. ALL LTL LOADS, REGARDLESS OF THEIR SIZE, REQUIRE ONE STRUT BRACE POSITIONED AT THE REAR OF THE TRAILER AND NAILED TO PIECE MARKED ③ .


 IF THE SIDE STRUTS, PIECES MARKED ①, ARE LONGER THAN 7'-0", AN ADDITIONAL STRUT BRACE, PIECE MARKED ①, AND TWO (2) STRUT BRACE RETAINING CLEATS, PIECES MARKED ②, AND TWO (2) RISER PIECES MARKED ⑥, AND TWO (2) RISER PIECES MARKED ⑥, MUST BE APPLIED FOR EVERY 7'-0" OF SIDE STRUT LENGTH.
- 7. THE K-BRACE BLOCKING SHOWN AS PIECES MARKED (3) THRU (13) IS ADEQUATE FOR RETAINING A MAXIMUM LTL LOAD OF 20,000 POUNDS.
- 8. TRAILERS EQUIPPED WITH ROLL-UP TYPE DOORS MAY BE USED; HOWEVER, SPECIAL REAR BLOCKING MUST BE INSTALLED IN LIEU OF THE "K-BRACE" TYPE BLOCK-ING. SEE THE "PROCEDURES FOR CONVENTIONAL VAN TRAILERS EQUIPPED WITH ROLL-UP TYPE DOORS" ON PAGES 32 AND 33. THE NAILED-HEADER METHOD IS SHOWN ON PAGE 32 AND THE TYGARD METHOD IS SHOWN ON PAGE 33. NOTE THAT THE SPECIAL REAR BLOCKING FOR TRAILERS EQUIPPED WITH ROLL-UP TYPE DOORS MAY ALSO BE USED IN TRAILERS EQUIPPED WITH HINGED DOORS, AND MAY BE USED IN LIEU OF PIECES MARKED ③ THRU ⑤ WHICH APPLY TO TRAILERS HAVING NON-NAILABLE FLOORS. SEE SPECIAL NOTE 9.
- 9. WHEN THE NAILED-HEADER METHOD OF BRACING SHOWN ON PAGE 32 IS APPLIED FOR THE BRACING OF THE DEPICTED 5-UNIT LOAD OR ANY ODD NUM-BERED QUANTITY, ONLY THE DOUBLED 2" X 4" PIECES ARE REQUIRED. OMIT THE REAR BLOCKING ASSEMBLY; WHEN SHIPPING AN EVEN NUMBERED QUANTI-TY, THE NAILED-HEADER METHOD WILL APPLY AS SHOWN.




- 1. THESE OUTLOADING PROCEDURES DEPICT THE USE OF LTL BRACE BLOCKING IN A CONVENTIONAL TYPE VAN TRAILER EQUIPPED WITH A NAILABLE FLOOR.
- THE PALLET UNIT SHOWN IS THE BASIC HEIGHT UNIT HAVING OVERALL DIM-ENSIONS OF 36-1/8" LONG BY 48" WIDE BY 51-1/8" HIGH AND WEIGHING APPROXIMATELY 1,783 POUNDS. THE PROCEDURES ARE ALSO APPLICABLE FOR THE OTHER UNIT DEPICTED ON PAGE 3.
- THE POSITIONING OF A UNIT IS OPTIONAL. IF THE TRAILER HAS A SQUARE FRONT THE TWO (2) FORWARD LTL BRACES MAY BE OMITTED, AND THE UNIT MAY BE POSITIONED AGAINST THE END WALL.
- EACH LTL BRACE AS APPLIED FOR LONGITUDINAL BRACING WILL SUPPORT 2,000 POUNDS OF LADING; HOWEVER, NOT LESS THAN TWO (2) BRACES WILL BE USED AGAINST EACH PALLET UNIT ACROSS THE WIDTH OF THE TRAILER.
- MORE THAN ONE PALLET UNIT CAN BE SHIPPED PROVIDING THE CAPACITY
 OF THE LTL BRACE IS NOT EXCEEDED. THE LOAD SHOULD BE FORMED IN
 TWO ROWS, WITH THE UNITS POSITIONED AGAINST OPPOSITE SIDEWALLS.
 ANTI-SWAY BRACES WILL BE INSTALLED BETWEEN THE LATERALLY ADJACENT
 UNITS AND TOP-OF-LOAD ANTI-SWAY BRACES, IF APPLICABLE.

KEY NUMBER

1 LTL BRACE (6 REQD). SEE THE "LTL BRACE ASSEMBLY" DETAIL BELOW, NAIL EACH LTL BRACE TO TRAILER FLOOR W/7-10d NAILS. SEE SPECIAL NOTES 4 AND 5 AT LEFT.




TYPICAL LTL (1-UNIT LOAD) IN A CONVENTIONAL VAN TYPE TRAILER



- THESE OUTLOADING PROCEDURES DEPICT A VAN TRAILER EQUIPPED WITH MECH-ANICAL BRACING DEVICES.
- THE PALLET UNIT SHOWN IN THE TYPICAL LTL LOAD IS THE DECREASED HEIGHT UNIT HAVING OVERALL DIMENSIONS OF 36-1/8" LONG BY 48" WIDE BY 43-5/8" HIGH. THE PROCEDURES ARE ALSO APPLICABLE FOR THE BASIC HEIGHT UNIT DEPICTED ON PAGE 3.
- THE SPECIFIED CROSS MEMBER LOCATION DIMENSIONS ARE APPLICABLE FOR THE DECREASED HEIGHT PALLET UNITS DEPICTED HEREIN. THE UPPER LEVEL CROSS MEMBER FOR THE BASIC HEIGHT PALLET UNITS SHOULD BE LOCATED AT THE 38" HEIGHT, WITH A PLUS OR MINUS 3" BEING ACCEPTABLE.
- 4. A TYPICAL LIL LOAD OF ONE (1) PALLETIZED UNIT IS SHOWN, IF TWO (2) PALLETIZED UNITS ARE TO BE TRANSPORTED, POSITION THE UNITS TWO ACROSS THE WIDTH OF THE TRAILER, OMIT THE SPACER ASSEMBLIES AND TIE WIRES SHOWN AS PIECES MARKED (3) AND (4). NOTE: WHEN LOADING TWO (2) PALLETIZED UNITS ACROSS THE WIDTH OF THE TRAILER, POSITION THE UNITS AGAINST THE FORWARD END WALL (UNIESS TRAILER HAS ROUNDED CORNERS) AND OMIT THE TWO CROSS MEMBERS AT THE FORWARD END. POSITION ONE ANTI-SWAY BRACE ASSEMBLY, SHOWN AS PIECE MARKED (3) ON PAGE 14, BETWEEN THE TWO PALLETIZED UNITS, AND ALSO A TOP-OF-LOAD ANTI-SWAY BRACE IF APPLICABLE FOR THE UNIT BEING SHIPPED. REPLACE PIECE MARKED (2) WITH THE APPLICABLE LOAD BEARING GATE:
- TWO (2) SPACER ASSEMBLIES, PIECE MARKED ③, ARE REQUIRED WHEN LOAD-ING THE BASIC HEIGHT UNITS. WHEN LOADING THE DECREASED HEIGHT UNIT DEPICTED ON PAGE 3, A SPACER ASSEMBLY IS REQUIRED AT ONLY ONE LEVEL AS SHOWN ABOVE.

KEY NUMBERS


- CROSS MEMBER (4 REQD). POSITION AT THE HEIGHT AS SPECIFIED BY THE ISOMETRIC VIEW ABOVE. SEE GENERAL NOTES "D" AND "K" ON PAGE 2. SEE SPECIAL NOTE 3 ON THIS PAGE.
- 2 PLYWOOD, 1/2" X 36" X 31" (2 REQD). POSITION BETWEEN THE PALLET UNIT AND THE CROSS MEMBERS.
- 3 SPACER ASSEMBLY (1 REQD.). SEE THE "SPACER ASSEMBLY C" DETAIL ON PAGE 28. SEE SPECIAL NOTE 5 AT LEFT.
- 4 TIE WIRE, NO. 14 GAGE WIRE 24" LONG (4 REQD). INSTALL TO FORM A COM-PLETE LOOP AROUND THE CROSS MEMBER AND THE SPACER ASSEMBLY. BRING ENDS TOGETHER AND TWIST TAUT. SECURE TO THE SPACER ASSEMBLY WITH A PARTIALLY DRIVEN 104 NAIL BENT OVER THE WIRE, OR WITH A STRAP STAPLE.




SECUREMENT OF A PARTIAL PALLET UNIT
POSITIONED ON A FULL HEIGHT PALLET UNIT

SPECIAL NOTES:


- I. THE VIEW SHOWN ABOVE DEPICTS A PARTIAL 2-LAYER PALLET UNIT POSITIONED ON TOP OF A FULL-HEIGHT PALLET UNIT AND UNITIZED WITH TWO VERTICAL UNITIZING STRAPS. PLACEMENT WITHIN THE LOAD IS OPTIONAL, EXCEPT THAT IT WILL NOT BE POSITIONED WITHIN A GROUP WHICH IS BUNDLED TOGETHER OR WITHIN A STACK WHICH IS UNITIZED. THE PREFERRED LOCATION WOULD BE WITHIN A ONE-HIGH PORTION OF A LOAD (NOT IN THE REAR LOAD UNIT) IF AVAILABLE, OR WITHIN THE TOP LAYER OF A LOAD IF THE TRAILER HEIGHT PERMITS.
- SHIPMENTS OF PALLET UNITS SHOULD CONSIST OF FULL-HEIGHT AND FULL-LAYER UNITS TO THE MAXIMUM EXTENT POSSIBLE. HOWEVER, THE END OF A LOT, OR THE QUANTITY OF ITEMS NEEDED TO FILL A REQUISITION MAY NECESSITATE THE SHIPMENT OF ONE OR MORE LESS-THAN-FULL PALLET UNITS WITHIN A LOAD.
- THE "SHIPMENT OF A PARTIAL PALLET UNIT" PROCEDURES ON THIS PAGE ARE APPLICABLE FOR LOADS IN CONVENTIONTAL TYPE VAN TRAILERS AND TRAILERS EQUIPPED WITH MECHANICAL BRACING DEVICES.
- FOR SHIPMENT OF ONE THROUGH FOUR "LEFTOVER" CONTAINERS, SEE THE PROCEDURES ON PAGE 23 OF THIS DRAWING.



- 1. SHIPMENTS OF PROPELLING CHARGES SHOULD CONSIST OF FULL-HEIGHT AND FULL-LAYER UNITS TO THE MAXIMUM EXTENT POSSIBLE, HOWEVER, THE END OF A LOT, OR THE QUANTITY OF ITEMS NEEDED TO FILL A REQUISITION, MAY NECESSITATE THE SHIPMENT OF ONE OR MORE LEFTOVER CONTAINERS. LEFTOVER CONTAINERS ARE DESCRIBED AS A QUANTITY OF CONTAINERS WHICH IS INSUFFICIENT TO FORM A FULL-LAYERED PARTIAL UNIT FOR SECUREMENT ON TOP OF A FULL PALLET UNIT AS SHOWN ON PAGE 22.
- 2. SHIPMENT OF LEFTOVER CONTAINERS IS APPLICABLE FOR CONUS AND OCONUS MOTOR CARRIER SHIPMENTS FROM DEPOT TO DEPOT OR FROM DEPOTS TO POSTS, CAMPS AND STATIONS, OR, UPON APPROVAL FROM HIGHER HEADQUARTERS, FOR SHIPMENTS FROM LOAD, ASSEMBLE, AND PACK PLANTS TO DEPOTS. CAUTION: A LOAD CONTAINING LEFTOVER CONTAINERS IN AN AMOUNT WHICH IS LESS THAN A FULL LAYER, AND SECURED TO THE TOP OF A FULL OR PARTIAL UNIT, MUST NOT BE DESTINED FOR SHIPMENT OVERSEAS BY WATER CARRIER.
- 3. THE PROCEDURES ON THIS PAGE ARE PRESENTED AS GUIDANCE IN THE SECUREMENT OF LEFTOVER CONTAINERS FOR SHIPMENT. THE VIEW AT TOP LEFT DEPICTS ONE LEFTOVER CONTAINER SECURED TO A FULL-HEIGHT PALLET UNIT, THE VIEW BELOW DEPICTS FOUR LEFTOVER CONTAINERS SECURED TO A FULL-HEIGHT PALLET UNIT, WHEN THREE OR FOUR LEFTOVER CONTAINERS ARE BEING SHIPPED, A STRAPPING BOARD WILL BE NEEDED, LEFTOVER CONTAINERS MUST BE SECURED WITH A MINIMUM OF TWO (2) PIECES OF STEEL STRAPPING. NOTE THAT ONE (1) UNITIZING STRAP WILL GO OVER THE TOP DUNNAGE ASSEMBLY, AND THE OTHER WILL BE THREADED BEHIND THE 2" X 2" PIECE ON THE TOP DUNNAGE ASSEMBLY.
- 4. THE PREFERRED LOCATION FOR THE POSITIONING OF A PALLET UNIT HAVING ONE OR MORE CONTAINERS STRAPPED TO THE TOP WOULD BE WITHIN THE ONE-HIGH PORTION OF THE LOAD; IT MUST NOT HAVE A PALLET UNIT STACKED ON TOP.
- THE PROCEDURES ON THIS PAGE ARE APPLICABLE FOR THE SHIPMENT OF LEFTOVER CONTAINERS IN ANY OF THE LOADS DEPICTED HEREIN.



SECUREMENT OF ONE CONTAINER




FORWARD BL	OCKING	CHAR	* A T	
PALLET UNIT TYPE	A	В	С	D
BASIC HEIGHT DECREASED HEIGHT	8'-0" 6'-3"	61" 53"	46" 31"	30
BASIC W/DECREASED HEIGHT ON TOP	6'-10"	61"	46"	30'

FORWARD BLOCKING

THIS ASSEMBLY IS DESIGNED FOR USE AT THE FRONT END OF A TRAILER HAVING ROUNDED CORNERS, AND IS APPLICABLE FOR A CORNER RADIUS OF NOT MORE THAN 6-1/2". IF THE RADIUS IS FROM 6-1/2" TO 8", 2" X 6" VERTICAL PIECES WILL BE USED IN LIEU OF THE 2" X 4" PIECES.

* FORWARD BLOCKING CHART "A" IS USED FOR CROSSWISE POSITIONED PALLET UNITS AS SHOWN IN THE LOAD ON PAGE 4. IF THE UNITS ARE POSITIONED LENGTHWISE AS SHOWN IN THE LOAD ON PAGE 6, USE FORWARD BLOCKING CHART "B" BELOW.


FORWARD BLOCKING CHART B					
PALLET UNIT TYPE	A	В	С	D	
BASIC HEIGHT DECREASED HEIGHT	7'-5" 6'-3"	61" 53"	38" 31"	40" 40"	
BASIC W/DECREASED HEIGHT ON TOP	6'-10"	61"	38"	40"	




PAGE 24

DETAILS


PALLET UNIT, AS USED IN THE LOAD ON PAGE 16.




SPACER ASSEMBLY B




DETAILS







ALTERNATIVE LOAD BEARING GATE D



▲ THESE HEIGHTS MAY NEED TO BE ADJUSTED TO PROVIDE FOR CLEARANCE OF THE CROSS MEMBERS AT A MINUS TOLERANCE INSTALLATION.




ALTERNATIVE LOAD BEARING GATE A



DETAILS

SOLID FILL, 4" AND 6" WIDE MATERIAL BY TRAILER WIDTH MINUS 1/2"-IN LENGTH BY THE THICKNESS MIDIT MINUS 1/2 RECEIVED TO CONTACT REAR CORNER POSTS OR TO CONTACT REAR DOORS OF THE TRAILER WHEN THEY ARE CLOSED. POSITION PIECES ON EDGE, ONE ON TOP OF THE OTHER AS SHOWN, AND LAMINATE W/1-104 NAIL EVERY 12" .-

IF THE TRAILER IS EQUIPPED
WITH REAR CORNER POSTS, INSTALL
SOLID FILL, 4" AND 6" WIDE BY 48"
LONG BY THE THICKNESS REQUIRED TO
FILL THE EXCESS SPACE BETWEEN THE FILL I HE EXCESS SPACE BEIWEEN THE REAR BLOCKING AND THE REAR DOORS OF THE TRAILER WHEN THEY ARE CLOSED. POSITION PIECES ON EDGE, ONE ON TOP OF THE OTHER AS SHOWN, AND NAIL TO THE REAR BLOCKING W/4 APPLICABLY SIZED NAILS.



REAR BLOCKING ASSEMBLY C


TRAILER


WIDTH MINUS 1

THIS REAR BLOCKING IS DESIGNED FOR USE AT THE REAR OF A LOAD WHEN THE SPACE BETWEEN THE LADING AND THE TRAILER DOORS IS LESS THAN 9". NOTE THAT RETAINER PIECES MUST BE INSTALLED ON THE LOAD BEARING SIDE OF THE REAR BLOCKING ABOVE, REFER TO REAR BLOCKING ASSEMBLY "A" BELOW OR "B" ON PAGE 29 FOR LOCATION AND NAILING GUIDANCE.

SPACER ASSEMBLY C

THIS ASSEMBLY IS DESIGNED FOR USE AS LATERAL BRACING IN A TRAILER EQUIPPED WITH MECHANICAL BRACING DEVICES AS SHOWN IN THE TYPICAL LTL LOAD ON PAGE 21.







BULKHEAD GAT	E CHAF	RT .	
PALLET UNIT TYPE	DIMENSIONS		
	A	В	C _.
BASIC HEIGHT	6'-10"	61"	46"
DECREASED HEIGHT	6'-3"	53"	44'
BASIC HT W/DECKEASED HT UNIT ON TOP	6'-10"	61"	46"

BULKHEAD GATE


THIS GATE IS DESIGNED FOR USE IN THE ALTERNATIVE LOADING PROCEDURE LOAD ON PAGE 16.




NO. 14 GAGE WIRE BY A LENGTH TO SUIT. FORM A LOOP ACROSS TOP OF ANTI-SWAY BRACE, LOOP UNDER UNIT FUN DIINNAGE, BRING WIRE UP TO TOP OF BRACE, AND TWIST TO SELF AS SHOWN.





TIE WIRE APPLICATION A



DETAILS










METHOD OF SECURING A STRAP JOINT WHEN USING A CRIMP-TYPE SEALER.




NAILED-HEADER METHOD

SPECIAL NOTES:

- 1. THE NAILED-HEADER METHOD OF REAR BLOCKING DEPICTED ABOVE CAN ONLY BE USED IN TRAILERS HAVING A NAILABLE FLOOR AREA BETWEEN THE LADING AND THE METAL THRESHOLD, OR A THRESHOLD PLATE IF THE TRAILER IS SO EQUIPPED, OF AT LEAST FOURTEEN INCHES (14").
- REAR BLOCKING ASSEMBLY "A" IS SHOWN FOR A TYPICAL INSTALLATION. CON-STRUCT THE ASSEMBLY USING 6" (MINIMUM) LONG STRUTS.
- 3. THE NAILED-HEADER METHOD OF REAR BLOCKING IS ADEQUATE FOR THE RETENTION OF THE MAXIMUM WEIGHT LOAD.
- THE NAILED-HEADER METHOD, ALTHOUGH DESIGNED ESPECIALLY FOR TRAILERS HAVING ROLL-UP TYPE DOORS, MAY ALSO BE USED IN TRAILERS EQUIPPED WITH HINGED DOORS.

NAILED-HEADER METHOD
PROCEDURES FOR CONVENTIONAL VAN TRAILERS EQUI PPED WITH ROLL-UP TYPE DOORS



- THE TYGARD METHOD OF REAR BLOCKING CAN ONLY BE USED IN TRAILERS
 WHICH HAVE REASONABLY SMOOTH AND ADEQUATELY SECURED SIDEWALL
 PANELS IN THE AREA WHERE THE TYGARD MATERIAL IS TO BE APPLIED. TYGARD
 MATERIAL MUST BE INSTALLED AT TWO LEVELS FOR EACH LAYER OF THE REAR
 LOAD UNIT.
- 2. A PLYWOOD GATE MUST BE INSTALLED FOR EACH LAYER AT THE REAR OF THE LOAD TO PROVIDE A SMOOTH SURFACE FOR THE TYGARD MATERIAL TO EXTEND AROUND. IF THE REAR LOAD UNIT IS 2-MDE INSTALL A GATE WHICH IS TRAILER WIDTH MINUS 1/2" IN LENGTH. IF THE REAR LOAD UNIT IS 1-WIDE ROTATE THE PALLET, INSTALL ONE (1) PALLET WIDTH GATE, AND ONE (1) TRAILER WIDTH MINUS 1/2" IN LENGTH GATE, AS SHOWN BY THE TYGARD METHOD "A" AND "B" DETAILS; NOTE THAT PALLET ROTATION IS NOT REQUIRED IN METHOD "A".
- 3. THE TYGARD MATERIAL AND THE ADHESIVE FOR ATTACHING IT ARE COMMERCIAL PRODUCTS, FOR A SOURCE OF SUPPLY, CONTACT WALNUT INDUSTRIES, INC, 1344 ADAMS ROAD, PO BOX "E", BENSALEM, PA 19020-0060, PHONE 1-800-523-6536. APPLICATION INSTRUCTIONS AND GUIDANCE CAN ALSO BE OBTAINED FROM THAT OFFICE.
- THE TYGARD METHOD, ALTHOUGH ESPECIALLY FOR TRAILERS HAVING ROLL-UP TYPE DOORS, MAY ALSO BE USED IN TRAILERS EQUIPPED WITH HINGED DOORS.
- NOTICE: IF THE AREA OF A SIDEWALL WHERE THE TYGARD SHOULD BE AT-TACHED IS ROUGH AND/OR BROKEN, THE APPLICABLE PIECE (5) OF TYGARD CAN BE LENGTHENED A SUITABLE AMOUNT AND ATTACHED TO THE SIDEWALL AHEAD OF THE INDICATED PREFERRED LOCATION.
- 6. TYGARD MATERIAL MUST BE APPLIED TO THE WALL IN SUCH A LONGITUDINAL LOCATION THAT IT WILL HAVE A PALLET UNIT BEARING AGAINST IT. IF A SHIPMENT CONTAINS AN ODD NUMBER OF PALLET UNITS, THE ODD UNIT MUST BE TURNED 90° AND CENTERED ACROSS THE WIDTH OF THE TRAILER AS SHOWN IN THE LOAD ON PAGE 18, AND AS SHOWN BY THE TYGARD METHODS ON THIS PAGE. THE TYGARD MATERIAL WILL BE APPLIED TO DIRECTLY OPPOSITE PORTIONS OF THE TRAILER SIDEWALL; IT MUST BE APPLIED TO EXTEND AT LEAST 36" FORWARD OF THE LAST PALLET UNIT IN EACH LAYER ON EACH SIDE OF THE LOAD.


RECOMMENDED EQUIPMENT/INSTALLATION PROCEDURES

EQUIPMENT REQUIRED

PAINIT ROLLER, LATEX
PAINT ROLLER PAN
TENSIONING ROD/TOOL
PRESSURE ROLLER
RATCHET WRENCH (12" TO 15" HANDLE)
OPEN END OR BOX WRENCH (12" TO 15" HANDLE)
SCISSORS OR KNIFE
TYGARD (15" WIDE ROLL)
TYGARD ADHESIVE


BASIC INSTALLATION GUIDANCE

- CUT TO LENGTH THE REQUIRED NUMBER OF TYGARD PIECES (FROM 2 TO 8 DEPENDING UPON THE LOAD CONFIGURATION) FOR ATTACHMENT TO THE TRAILER SIDEWALL, PIECES WILL BE OF A LENGTH AS REQUIRED TO PROVIDE PROPER BONDING TO THE TRAILER SIDEWALL AND TO EXTEND 60" ACROSS THE REAR OF THE LOAD. ALSO, CUT 72" LONG "PATCH" PIECES OF TYGARD MATERIAL, ONE FOR EACH SET OF TWO PIECES PREVIOUSLY CUT.
- PRIOR TO POSITIONING OF THE PALLETS IN THE REARMOST LOAD UNIT, APPLY TYGARD ADHESINE TO THE PROPER PORTIONS OF THE TRAILER SIDEWALLS AND TO THE CORD SIDE OF A CORRESPONDING LENGTH OF EACH OF THE TYGARD PIECES THAT ARE TO BE ATTACHED TO THE SIDEWALLS OF THE TRAILER. ALLOW TIME FOR THE ADHESIVE TO "CURE" BEFORE PLACING A STRIP OF TYGARD ONTO A SIDEWALL ADHESIVE WILL FEEL ALMOST DRY WHEN TOUCHED). NOTE: APPLICATION OF TYGARD IS SIMILAR TO THE APPLICATION OF "FORMICA".
- 3. APPLY THE TYGARD PIECES TO EACH SIDEWALL OF THE TRAILER SO THAT THE PIECES ARE PARALLEL OR NEARLY PARALLEL TO THE FLOOR. ROLL THE TYGARD WITH PRESSURE ROLLER TO ENSURE PROPER BONDING IS ACHIEVED. TEMPORARILY SECURE THE LOOSE ENDS TO THE TRAILER SIDEWALL OR TO AN OPEN HINGED TYPE DOOR OR TO THE OUTSIDE WALL, AS APPLICABLE.
- POSITION THE PALLETS OF THE REARMOST LOAD UNIT INTO THE TRAILER AND INSTALL THE SPECIFIED ANTI-SWAY BRACES, AS APPLICABLE.
- 5. UNDO THE PREVIOUSLY SECURED LOOSE ENDS AND BRING A SET OF TWO PIECES TOGETHER ACROSS THE REAR OF THE LOAD. POSITION THE TENSIONING ROD SO THAT THE LOOSE ENDS OF THE TYGARD MATERIAL EXTEND THRU THE SLOT IN ROD. USING THE TWO WRENCHES, ROLL UP THE TYGARD TO TENSION IT ACROSS REAR OF THE LOAD. POSITION A WRENCH SO AS TO MAINTAIN THE TENSION IN THE TYGARD PIECES. CUT OFF AND DISCARD EXCESS MATERIAL FROM ONE PIECE OF THE TYGARD.
- APPLY TYGARD ADHESIVE TO THE TENSIONED TYGARD PIECES AND ALSO TO THE CORD SIDE OF THE PREVIOUSLY CUT "PATCH" PIECE. APPLY THE "PATCH" AND ROLL WITH THE PRESSURE ROLLER TO ENSURE PROPER BONDING.



TYGARD METHODS "A" OR "B" CAN BE USED IN A 1-LAYER LOAD CONTAINING AN ODD NUMBER OF UNITS, OR IN A 2-LAYER LOAD WHEN THE REAR LOAD UNIT IN EITHER LAYER IS CENTERED ACROSS THE WIDTH OF THE TRAILER AS SHOWN ON THE FIRST LAYER ABOVE.


TYGARD METHOD
PROCEDURES FOR CONVENTIONAL VAN TRAILERS EQUIPPED WITH ROLL-UP TYPE DOORS



ALTERNATIVE FORWARD LOADING PATTERN A

THIS PROCEDURE IS APPLICABLE TO THE LOADING OF ONE (1) PALLET UNIT IN THE FORWARD END OF A CONVENTIONAL'VAN TRAILER HAVING LARGE ANGIED FRONT CORNERS (REF: 18"). THE PROCEDURES MAY ALSO BE USED IN TRAILERS HAVING SQUARE CORNERS, OR ROUNDED FRONT CORNERS, OR ANGIED CORNERS OF ANOTHER SIZE. THE BASIC HEIGHT UNIT IS SHOWN. THE PROCEDURES ARE ALSO APPLICABLE FOR THE DECREASED HEIGHT UNIT DEPICTED ON PAGE 3.

THIS PROCEDURE IS APPLICABLE TO THE LOADING OF A STACK OF TWO (2) PALLET UNITS IN THE FORWARD END OF A CONVENTIONAL VAN TRAILER HAVING LARGE ANGLED FRONT CORNERS (REF: 18"). THE PROCEDURES MAY ALSO BE USED IN TRAILERS HAVING SQUARE CORNERS, OR ROUNDED FRONT CORNERS, OR ANGLED CORNERS OF ANOTHER SIZE. NOTE THAT IF THE LOAD UNIT BEHIND THE STACKED PALLET UNITS IN THE FRONT OF THE TRAILER IS ONLY ONE HIGH, TWO (2) STACK UNITIZING STRAPS MUST BE INSTALLED AROUND THOSE PALLET UNITS IN THE FRONT STACK.
THE BASIC HEIGHT UNIT IS SHOWN. THE PROCEDURES ARE ALSO APPLI-CABLE FOR THE DECREASED HEIGHT UNIT DEPICTED ON PAGE 3.



BASIC W/DECREASED ON TOP 6'-2"

SPACER ASSEMBLY E

THIS ASSEMBLY IS DESIGNED FOR LATERAL BRACING OF A 2-HIGH PALLET STACK WHICH IS TURNED 90° FROM THE NORMAL LOADING ORIENTATION AND POSITIONED IN THE FRONT OF AN ANGLED-CORNER CONVENTIONAL VAN TRAILER AS SHOWN IN THE "ALTERNATIVE FORWARD LOADING PATTERN YAN INAILE ASSAMLY NOTE THAT THIS VIEW DEPICTS THE ASSEMBLY POSITIONED 180° FROM THE POSITION IN WHICH IT WILL BE INSTALLED IN A LOAD. RIGHT HAND AND LEFT HAND SPACER ASSEMBLIES ARE REQUIRED.

PROCEDURES FOR CONVENTIONAL VAN TRAILERS EQUIPPED WITH LARGE-ANGLED FRONT CORNERS

ITEMIZED INDEX

<u>ITEM</u> P	AGE (S))
GENERAL NOTES, AND MATERIAL SPECIFICATIONS	2	
	3	
PALLET UNIT (BASIC HEIGHT):		
HIGH-VOLUME CONVENTIONAL VAN TRAILER	4- 7	
HIGH-VOLUME TRAILER EQUIPPED WITH MECHANICAL BRACING DEVICES	8, 9	
PALLET UNIT (DECREASED HEIGHT): CONVENTIONAL VAN TRAILER	10.10	
TRAILER EQUIPPED WITH MECHANICAL BRACING DEVICES	10-13	
ALTERNATIVE LOADING PROCEDURE FOR ALL UNITS: .:	14-15	
CONVENTIONAL VAN TRAILER	16 17	
TYPICAL ITI-5 PALLET UNITS IN A	•	
CONVENTIONAL VAN TRAILER	18 10	
TUDICAL ITE 1 DALLET HALF IN A	-	
CONVENTIONAL VAN TRAILER	20	
TYPICAL LTL-1 PALLET UNIT IN A TRAILER EQUIPPED WITH MECHANICAL BRACING DEVICES		
PROCEDURES FOR SHIPMENT OF A PARTIAL PALLET UNIT	22	
PROCEDURES FOR SHIPMENT OF LEFTOVER CONTAINERS		
PROCEDURES FOR CONVENTIONAL VAN TRAILERS EQUIPPED WITH ROLL-UP TYPE DOORS	32,33	
DETAILS:		
ALTERNATIVE LOAD BEARING GATE A		
ALTERNATIVE LOAD BEARING GATE B		
ALTERNATIVE LOAD BEARING GATE C		
ALTERNATIVE LOAD BEARING GATE D		
ANTI-SWAY BRACE C	25	
BULKHEAD GATEFORWARD BLOCKING ASSEMBLY		
LOAD BEARING GATE A	: ·	
LOAD BEARING GATE B		
LOAD BEARING GATE C		
LOAD BEARING GATE D		
LOAD BEARING GATE E	31	
LOAD BEARING GATE F	31	
LTL BRACE		
REAR BLOCKING ASSEMBLY A		
REAR BLOCKING ASSEMBLY B		
REAR BLOCKING ASSEMBLY C	28	
SPACER ASSEMBLY A	24	
SPACER ASSEMBLY B		
SPACER ASSEMBLY C		
STRAP JOINT DETAILS	31	
TIE WIRE APPLICATION	30	
TOP-OF-LOAD ANTI-SWAY BRACE A	25	
TOP-OF-LOAD ANTI-SWAY BRACE B	25	
PROCEDURES FOR CONVENTIONAL VAN TRAILERS EQUIPPED WITH LARGE-ANGLED FRONT CORNERS		
WITH LAKGE-ANGLED FRONT CORNERS	34	