

APPROVED BY
BUREAU OF EXPLOSIVES

J. A. Reshman

DATE 12/10/92

LOADING AND BRACING (CL & LCL) IN BOXCARS OF 40MM CARTRIDGES PACKED IN PA120 METAL BOX AND UNITIZED ON A 45-1/2" X 35" METAL PALLET

INDEX

ITEM	PAGE(S)
GENERAL NOTES - - - - -	2-4
MATERIAL SPECIFICATIONS - - - - -	2
INDEX, PALLET UNIT DETAIL - - - - -	5

⊙ THIS OUTLOADING PROCEDURE DRAWING INCLUDES PROCEDURES FOR CONVENTIONAL TYPE
BOXCARS, BOXCARS EQUIPPED WITH MECHANICAL BRACING DEVICES OF VARIOUS DESIGN
AND MANUFACTURE, AND CUSHIONED BOXCARS EQUIPPED WITH LOAD DIVIDER BULKHEADS.

U.S. ARMY MATERIEL COMMAND DRAWING

APPROVED, U.S. ARMY ARMAMENT, MUNITIONS AND
CHEMICAL COMMAND

Timothy R. Fore

APPROVED BY ORDER OF COMMANDING GENERAL, U.S.
ARMY MATERIEL COMMAND

William F Ernst

U.S. ARMY DEFENSE AMMUNITION CENTER AND SCHOOL

DRAFTSMAN	TECHNICIAN	ENGINEER
-----------	------------	----------

P. BELlich

P. BRIGHT

VALIDATION
ENGINEERING
DIVISION

TRANSPORTATION
ENGINEERING
DIVISION

LOGISTICS
ENGINEERING
OFFICE

JMK

W. Francis

W F Ernst

APRIL 1993

CLASS	DIVISION	DRAWING	FILE
-------	----------	---------	------

19

48

4246/21

SPM1005

DO NOT SCALE

GENERAL NOTES

- A. THIS DOCUMENT HAS BEEN PREPARED AND ISSUED IN ACCORDANCE WITH AR 740-1 AND AUGMENTS TM 743-200-1 (CHAPTER 5).
- B. THE OUTLOADING PROCEDURES SPECIFIED IN THIS DRAWING ARE APPLICABLE FOR 40MM CARTRIDGES PACKED IN THE PA120 METAL BOX AND UNITIZED ON A 45-1/2" X 35-1/2" METAL PALLET. SEE THE PICTORIAL VIEW ON PAGE 5 FOR SIZE AND WEIGHT. REFER TO AMC DRAWING 19-49-4232/21-20PM1002 FOR UNITIZATION PROCEDURES FOR THE PA120 SERIES CONTAINERS.
- C. THE OUTLOADING PROCEDURES DEPICTED WITHIN THIS DOCUMENT ARE APPLICABLE FOR SHIPMENTS IN CONVENTIONAL TYPE BOXCARS, FOR SHIPMENTS IN BOXCARS EQUIPPED WITH VARIOUS TYPES OF SELF-CONTAINED MECHANICAL BRACING DEVICES, AND FOR SHIPMENTS IN CUSHIONED BOXCARS EQUIPPED WITH LOAD DIVIDER BULKHEADS.
- D. CAUTION: METAL COMPONENTS THAT ARE FLUSH WITH OR OVERHANG THE PALLET END MUST NOT BE ALLOWED TO CONTACT STEEL SIDEWALLS OR ENDWALLS OF BOXCARS. THIS TYPE OF UNIT LOAD SHOULD BE SHIPPED IN BOXCARS HAVING WOOD SIDEWALLS AND/OR ENDWALLS. IF CARS WITH WOOD SIDEWALLS AND/OR ENDWALLS ARE NOT AVAILABLE, AND ALL-STEEL CARS ARE USED, THE SIDEWALLS AND/OR ENDWALLS MUST BE LINED WITH DIMENSIONAL LUMBER, PLYWOOD, HARDBOARD, OR SOLID FIBERBOARD. THE LINING SHOULD BE PROVIDED WHEREVER METAL-OF-CONTAINER TO METAL-OF-CAR CONTACT IS POSSIBLE. REFER TO PAGE 44 FOR GUIDANCE.
- E. ALL THE LOADS SHOWN HEREIN ARE TYPICAL. BECAUSE OF THIS FACT, IT IS MOST LIKELY THAT THE ACTUAL QUANTITY TO BE SHIPPED WILL NOT BE DEPICTED IN ANY OF THE LOADING PROCEDURES HEREIN. A LOAD PLAN SHOULD BE DEVELOPED WHICH WILL BE THE MOST EFFICIENT AS TO THE AMOUNT OF DUNNAGE REQUIRED AND THE EASE OF LOADING, FOR THE QUANTITY TO BE SHIPPED. THE LOAD PLANNING CHART ON PAGE 24 MAY BE USED IN CONJUNCTION WITH THE DEPICTED LOADING PROCEDURES FOR GUIDANCE.
- F. THE SELECTION OF RAIL CARS FOR THE TRANSPORT OF PALLET UNITS OF CARTRIDGES IS THE RESPONSIBILITY OF THE ORIGINATING CARRIER AND THE SHIPPER. ONLY CARS WHICH HAVE "SOUND" FLOORS AND ARE IN OTHERWISE PROPER CONDITION, IN ACCORDANCE WITH THE REQUIREMENTS OF THE APPLICABLE REGULATORY DOCUMENTS, WILL BE SELECTED.
- G. WHEN SELECTING RAILCARS, EVERY EFFORT SHOULD BE MADE TO OBTAIN BOXCARS THAT DO NOT HAVE BOWED ENDWALLS. CARS HAVING BOWED ENDS CAN BE USED, HOWEVER, IF AN ENDWALL IS BOWED OUTWARD MORE THAN TWO INCHES EITHER FROM SIDE TO SIDE OR FROM FLOOR TO ROOF, AN END-OF-CAR BULKHEAD MUST BE INSTALLED TO PROVIDE A "SQUARED OFF" SURFACE FOR THE LOAD AT THE END OF THE CAR. REFER TO PAGE 45 FOR GUIDANCE.

(CONTINUED AT RIGHT)

MATERIAL SPECIFICATIONS

LUMBER	FED SPEC MM-L-751. SEE TM 743-200-1 (DUNNAGE LUMBER).
NAILS	FED SPEC FF-N-105; COMMON.
STRAPPING, STEEL	ASTM D3953; FLAT STRAPPING, TYPE I OR 2, HEAVY DUTY, FINISH A, B (GRADE 2), OR C.
SEAL, STRAP	ASTM D3953; CLASS H, FINISH A, B (GRADE 2), OR C, DOUBLE NOTCH TYPE, STYLE I, II, OR IV.
STAPLE, STRAP	COMMERCIAL GRADE.
PLYWOOD	COMMERCIAL ITEM DESCRIPTION A-A-55057, TYPE A, CONSTRUCTION AND INDUSTRIAL PLYWOOD, INTERIOR WITH EXTERIOR GLUE, GRADE C-D. IF SPECIFIED GRADE IS NOT AVAILABLE, A BETTER INTERIOR OR AN EXTERIOR GRADE MAY BE SUBSTITUTED.
WIRE, CARBON STEEL	ASTM A853; ANNEALED AT FINISH, BLACK OXIDE FINISH, .0800" DIA, GRADE 1006 OR BETTER.
HARDBOARD	ANSI/AHA A135.4, CLASS 1.
SOLID FIBERBOARD	FED SPEC PP-F-320, TYPE SF, CLASS DOMESTIC, GRADE 175 OR STRONGER; OR TYPE SF, CLASS WEATHER-RESISTANT, GRADE W65 OR STRONGER.

(GENERAL NOTES CONTINUED)

- H. CONVENTIONAL BOXCARS EQUIPPED WITH SLIDING DOORS HAVE BEEN SHOWN, HOWEVER, THE DEPICTED OUTLOADING PROCEDURES ARE ALSO APPLICABLE FOR CONVENTIONAL CARS EQUIPPED WITH PLUG DOORS. CAUTION: DUNNAGE MATERIAL MUST NOT BE NAILED TO ANY PLUG DOOR, WHETHER AUXILIARY OR MAIN. ALSO, AFTER THE PLUG DOORS ON A CAR ARE CLOSED AND READY FOR THE INSTALLATION OF CAR SEALS, A PIECE OF WIRE OF SUITABLE SIZE WILL BE USED IN ADDITION TO AND IN CONJUNCTION WITH EACH CAR SEAL USED TO SEAL THE CAR. THE WIRE WILL BE THREADED THRU THE HOLES IN THE DOOR LATCH ASSEMBLY ONE OR MORE TIMES, AND THE WIRE ENDS WILL BE TWISTED TOGETHER.
- J. THE USE OF AN OFFSET LOADING PATTERN WILL FACILITATE LOADING AND UNLOADING OPERATIONS IN THE DOORWAY AREA OF THE CAR. UNLESS PROHIBITED WITHIN THE SPECIAL NOTES, A FULL LOAD SHOULD BE BUILT USING AN OFFSET LOADING PATTERN. FOR INSTANCE, A LOAD CONSISTING OF AN EVEN NUMBER OF LOAD UNITS AND HAVING TWO MORE LOAD UNITS IN ONE END OF THE CAR THAN IN THE OPPOSITE END, OR A LOAD CONSISTING OF AN ODD NUMBER OF LOAD UNITS AND HAVING ONE MORE LOAD UNIT IN ONE END THAN IN THE OTHER IS CONSIDERED TO BE AN OFFSET LOAD.
- K. OTHER TYPES OF LADING ITEMS MAY BE LOADED IN CARS WHICH ARE PARTIALLY LOADED WITH PALLET UNITS OF CARTRIDGES, PROVIDING THE TOTAL LOAD IS COMPATIBLE, EXISTING DIRECTIVES ARE NOT VIOLATED, AND THE OTHER LADING ITEMS ARE BLOCKED AND BRACED TO EQUAL THE BLOCKING AND BRACING CRITERIA SPECIFIED HEREIN. MIXED ITEMS TO BE SHIPPED IN CARS EQUIPPED WITH MECHANICAL BRACING DEVICES MUST BE SEPARATELY BLOCKED, USING THE PROCEDURES SHOWN FOR THESE CARS AS GUIDANCE.
- L. DUNNAGE LUMBER SPECIFIED THROUGHOUT THIS PROCEDURAL DRAWING IS OF NOMINAL SIZE. FOR EXAMPLE, 2" X 4" MATERIAL IS ACTUALLY 1-1/2" THICK BY 3-1/2" WIDE AND 2" X 6" MATERIAL IS ACTUALLY 1-1/2" THICK BY 5-1/2" WIDE. IF THOSE MEMBERS SPECIFICALLY IDENTIFIED AS "STRUTS" WITHIN THE KEY NUMBERS OF A DEPICTED LOAD ARE SPECIFIED TO BE 4" X 4" MATERIAL, IT IS PERMISSIBLE TO USE TWO LAMINATED PIECES OF 2" X 6" MATERIAL IN LIEU OF EACH 4" X 4" STRUT. DOUBLED 2" X 6" STRUTS WILL BE LAMINATED W/1-10d NAIL EVERY 6".
- M. NOTICE: A STAGGERED NAILING PATTERN WILL BE USED WHEREVER POSSIBLE WHEN NAILS ARE DRIVEN INTO JOINTS OF DUNNAGE ASSEMBLIES. ALSO, A STAGGERED NAILING PATTERN WILL BE USED WHEN DUNNAGE IS NAILED TO THE FLOOR OR SIDEWALL OF THE TRANSPORTING VEHICLE, OR WHEN LAMINATING DUNNAGE. THE NAILING PATTERN WILL BE ADJUSTED AS REQUIRED SO THAT A NAIL DOES NOT PENETRATE INTO OR NEAR A CRACK BETWEEN FLOOR BOARDS OR SIDEWALL BOARDS. ADDITIONALLY, THE NAILING PATTERN FOR AN UPPER PIECE OF LAMINATED DUNNAGE WILL BE ADJUSTED AS REQUIRED SO THAT A NAIL FOR THAT PIECE WILL NOT BE DRIVEN THROUGH ONTO, OR RIGHT BESIDE A NAIL IN A LOWER PIECE.
- N. POWER DRIVEN STAPLES MAY BE USED AS ALTERNATIVE FASTENERS FOR NAILS WHEN CONSTRUCTING DUNNAGE ASSEMBLIES WHICH ARE TO BE USED IN THE DELINEATED BOXCAR LOADS SHOWN THROUGHOUT THIS DRAWING. THE STAPLES TO BE USED MUST BE EQUAL IN LENGTH TO THE SPECIFIED NAIL SIZE AND MUST BE SUBSTITUTED ON A ONE STAPLE FOR ONE NAIL BASIS. STAPLES WHICH ARE 2-1/2" OR LESS IN LENGTH SHOULD BE IN ACCORDANCE WITH FEDERAL SPECIFICATION FF-N-105 AS NEARLY AS PRACTICABLE. STAPLES WHICH ARE LONGER THAN 2-1/2" WILL BE A COMMERCIAL GRADE, OF A QUALITY EQUIVALENT TO THOSE MANUFACTURED BY Senco PRODUCTS INCORPORATED. NOTE: STAPLES WILL NOT BE SUBSTITUTED FOR NAILS IN ANY LOAD RESTRAINING FLOOR DUNNAGE APPLICATION.
- O. WHEN STEEL STRAPPING IS SEALED AT AN END-OVER-END LAP JOINT, A MINIMUM OF ONE SEAL WITH TWO PAIR OF NOTCHES WILL BE USED TO SEAL THE JOINT WHEN A NOTCH-TYPE SEALER IS BEING USED. A MINIMUM OF TWO SEALS, BUTTED TOGETHER, WITH TWO PAIR OF CRIMPS PER SEAL WILL BE USED TO SEAL THE JOINT WHEN A CRIMP-TYPE SEALER IS BEING USED. REFER TO THE "STRAP JOINT A" AND "STRAP JOINT B" DETAILS ON PAGE 47 FOR GUIDANCE.
- P. THROUGHOUT THIS PROCEDURAL DRAWING, PORTIONS OF THE BLOCKING COMPONENTS AND OF THE DEPICTED CARS, SUCH AS A CAR SIDEWALL, HAVE BEEN OMITTED FROM THE LOAD VIEW FOR CLARITY PURPOSES.
- Q. THE NUMBER OF LADING UNITS MAY BE ADJUSTED TO FIT THE SIZE OF THE BOXCAR BEING LOADED OR THE QUANTITY TO BE SHIPPED, HOWEVER, THE APPROVED METHODS SPECIFIED HEREIN MUST BE FOLLOWED AS CLOSELY AS POSSIBLE FOR BLOCKING, BRACING, AND STAYING OF THE UNITS. NOTICE: A SHIPMENT WILL BE POSITIONED IN THE RAILCAR IN COMPLIANCE WITH THE WEIGHT DISTRIBUTION REQUIREMENTS OF THE AAR.

GENERAL NOTES

(FOR CONVENTIONAL TYPE BOXCARS)

- R. IF THE CAR BEING USED FOR A SHIPMENT IS EQUIPPED WITH A NAILABLE METAL FLOOR AND A NAIL SIZE FOR FLOOR NAILING IS MARKED ON THE SIDEWALL OF THE CAR, THAT GUIDANCE SHOULD BE APPLIED TO THE NAILING OF THE "DOORWAY BLOCKING" PIECES IN THE FULL LOADS AND TO THE NAILING TO THE CAR FLOOR OF THE LCL BRACES AND KNEE BRACE ASSEMBLIES IN THE LESS-THAN-FULL LOADS. IF A NAIL SIZE IS NOT SPECIFIED IN THE CAR, 30d NAILS SHOULD BE USED IN LIEU OF THOSE SPECIFIED IN THE APPLICABLE KEY NUMBERS. SEE GENERAL NOTE "M" ON PAGE 2.
- S. NOTICE: WHEN POSITIONING PALLET UNITS IN A CAR, THEY SHOULD BE PLACED TIGHTLY AGAINST A CAR SIDEWALL AND ARE TO BE PRESSED TIGHTLY TOGETHER LENGTHWISE TO ACHIEVE A TIGHT LOAD. TO AID IN ACHIEVING TIGHTNESS LENGTHWISE IN A FULL LOAD, A LOAD-COMPRESSING JACK MAY BE EMPLOYED IN THE AREA OF THE CENTER GATES TO MOVE THE PALLET UNITS INTO THEIR FINAL SHIPPING POSITION. A HYDRAULIC JACK IS RECOMMENDED FOR THIS OPERATION. CAUTION: WHEN USING A JACK TO COMPACT A LOAD, THE JACK MUST BE USED AGAINST STRONG POINTS OF THE PALLET UNITS, SUCH AS THE TOP AND BOTTOM PALLET ADAPTERS ON THE UNIT. PADDING, OF 2" THICK LUMBER OR ANY OTHER MATERIAL OF SIMILAR CONSISTENCY, SHOULD BE PLACED BETWEEN THE JACK AND THE LADING.
- T. LOAD-BLOCKING STRUTS WHICH ARE 48" OR LONGER MUST BE STIFFENED BY THE APPLICATION OF HORIZONTAL AND VERTICAL STRUT BRACING AS SHOWN BY KEY NUMBERS ⑤ AND ⑥ ON PAGE 8. BRACING IS NOT REQUIRED IF THE STRUTS FOR THE LOAD BEING SHIPPED ARE SHORTER THAN 48". THE LENGTH OF THE LOAD-BLOCKING STRUTS SHOULD BE KEPT AS SHORT AS POSSIBLE (APPROX 18" MINIMUM), BUT IN THE EVENT IT IS NECESSARY TO USE STRUTS WHICH ARE 8'-0" OR MORE IN LENGTH, IT WILL BE NECESSARY TO APPLY AN ADDITIONAL SET OF HORIZONTAL AND VERTICAL STRUT BRACING PIECES. STRUT BRACING SHOULD BE APPLIED SO AS TO PROVIDE NEARLY EQUAL SPACES BETWEEN THE BRACING PIECES AND THE CENTER GATES AND/OR BETWEEN ADJACENT STRUT BRACING PIECES. NOTE THAT HORIZONTAL STRUT BRACING PIECES FOR THE UPPER LEVEL OF STRUTS FOR ALL BUT THE UPPERMOST TIER OF A LOAD MAY BE DIFFICULT TO APPLY TO THE TOP SURFACES OF THE STRUT AS DEPICTED. STRUT BRACING WILL BE EQUALLY EFFECTIVE IF APPLIED TO THE UNDER SIDE OF THOSE STRUTS.
- U. TO ACHIEVE A TIGHTLY BLOCKED LOAD, A STRUT WILL BE CUT APPROXIMATELY 1/4" TO 3/8" LONGER THAN THE MEASURED DISTANCE BETWEEN THE STRUT BEARING AREAS ON THE TWO CENTER GATES. MEASUREMENTS FOR STRUT LENGTHS NEED TO BE ACCOMPLISHED AT SEVERAL PLACES DURING THE BLOCKING AND BRACING PROCESS. CARE MUST BE EXERCISED WHEN MEASURING FOR AND INSTALLING STRUTS. THE SPECIFIED APPROXIMATE DIMENSION FOR A STRUT LENGTH MAY BE ADJUSTED, AS NECESSARY, TO PROVIDE FOR A TIGHTLY BLOCKED LOAD WITHOUT DISTORTING, DENTING, OR OTHERWISE DAMAGING THE CONTAINERS. ONE END OF THE STRUT WILL BE POSITIONED AT ITS BEARING AREA JUST ABOVE THE STRUT LEDGER ON ONE GATE. THE OTHER END, WHICH CAN BE BEVELED ON THE LOWER CORNER IF DESIRED, WILL THEN BE DRIVEN DOWNWARD UNTIL IT CONTACTS THE STRUT LEDGER ON THE OTHER GATE. EACH END OF THE STRUT WILL BE TOE-NAILED TO THE ADJACENT CENTER GATE, AS SPECIFIED WITHIN THE KEY NUMBERS FOR A LOAD, IN SUCH A MANNER SO THAT AS NEARLY AS PRACTICAL EQUAL LENGTHS OF A NAIL ARE EMBEDDED IN THE STRUT AND IN THE VERTICAL PIECE OF THE CENTER GATE. SEE THE "BEVEL CUT" DETAIL ON PAGE 47 FOR BEVELING INSTRUCTIONS AND THE "STRUT INSTALLATION" DETAIL ON THAT PAGE FOR A PICTORIAL VIEW SHOWING THE PROPER POSITIONING OF A BEVELED STRUT FOR INSTALLATION. NOTE THAT THE UPPER CORNER NEEDS TO BE BEVELED ONLY IF THE STRUTS ARE VERY SHORT. IF ONLY ONE END IS BEVEL-CUT, THE BEVELED EDGE WILL BE PLACED IN THE DOWNWARD POSITION SO THAT IT WILL ALLOW THE STRUT END TO SLIDE MORE FREELY DOWN THE FACE OF THE VERTICAL PIECE ON THE ADJACENT CENTER GATE AS THE STRUT IS DRIVEN DOWN INTO ITS FINAL BLOCKING POSITION.
- V. WHERE 2" X 2" PIECES ARE SPECIFIED FOR STRUT LEDGERS, 2" X 4" MATERIAL MAY BE SUBSTITUTED, IF DESIRED.
- W. FOR ADDITIONAL GUIDANCE, ATTENTION IS DIRECTED TO THE "SPECIAL NOTES" SECTIONS WHICH ARE IMMEDIATELY ADJACENT TO THE DEPICTED OUTLOADING METHODS.

GENERAL NOTES

(FOR BOXCARS EQUIPPED WITH MECHANICAL BRACING DEVICES)

- X. THE OUTLOADING PROCEDURES FOR BOXCARS EQUIPPED WITH MECHANICAL BRACING DEVICES MAY BE ADAPTED AS REQUIRED TO FACILITATE THE USE OF BOXCARS EQUIPPED WITH VARIOUS TYPES OF SELF-CONTAINED MECHANICAL BRACING DEVICES, HOWEVER, FIXED OR ADJUSTABLE WALL MEMBERS AND DOORWAY MEMBERS WITHIN THESE CARS MUST PROVIDE FOR THE INSTALLATION OF LOAD BLOCKING CROSS MEMBERS AT THE HEIGHTS SPECIFIED. CAUTION: BOXCARS EQUIPPED WITH MEMBERS WHICH DO NOT MEET THE LOCATION REQUIREMENTS MUST NOT BE USED.
1. FOR BLOCKING THE LOAD WHICH IS DEPICTED, A CROSS MEMBER WILL NOT BE RELIED UPON TO RETAIN MORE LADING ON EITHER SIDE THAN AS SHOWN. VOIDS LENGTHWISE WITHIN THE LOAD MUST BE HELD TO A MINIMUM AND CROSS MEMBERS MUST BE PLACED AGAINST THE LADING AS TIGHTLY AS THE SPACING OF THE LOCKING HOLES IN THE WALL MEMBERS PERMIT. LOCKING BARS (LEVER JACKS) SHOULD BE USED FOR THIS PURPOSE. AN ADDITIONAL 1/2" OF ADJUSTMENT CAN BE MADE BY TURNING A CROSS MEMBER END-FOR-END WHEN LOCKING PINS ON THE MEMBER ARE OFF-CENTER. NOTE: IT IS RECOMMENDED THAT EACH CROSS MEMBER BE INSTALLED WITH THE ENDS ATTACHED AS NEARLY AS POSSIBLE IN "MATED" POSITIONS (AT EQUAL HEIGHTS AND AT EQUAL DISTANCES FROM THE END OF THE CAR).
 2. CAUTION: ALL BLOCKING AND BRACING COMPONENTS IN EMPTY CARS AND ALL UNUSED COMPONENTS IN LOADED CARS MUST BE "SECURED" FOR SHIPMENT -- ADJUSTABLE WALL MEMBERS TO VERTICAL WALL ATTACHMENT RAILS, AND CROSS MEMBERS TO ADJUSTABLE WALL MEMBERS OR TO FIXED HORIZONTAL WALL MEMBERS OR TO DOORWAY MEMBERS, AND DOORWAY MEMBERS TO DOOR POSTS. COMPONENTS ASSIGNED TO EACH CAR MUST REMAIN THEREWITH EVEN THOUGH UNUSED DURING SOME SHIPMENTS.
- Y. IN A CAR EQUIPPED WITH ADJUSTABLE WALL MEMBERS, PROVIDING THE FIXED WALL MEMBERS WHICH ARE PRESENT IN SOME "ADJUSTABLE" CARS ARE NOT PROPERLY POSITIONED TO PROVIDE SIDE BEARING SURFACES BETWEEN THE UNITS AND THE CAR SIDEWALLS, ADJUSTABLE WALL MEMBERS (AS REQUIRED) MUST BE INSTALLED TO PROVIDE A MINIMUM OF ONE SURFACE AREA FOR SIDE BEARING AT SOME LOCATION WITHIN THE UPPER HALF OF EACH UNIT.
- Z. FOR ADDITIONAL GUIDANCE, ATTENTION IS DIRECTED TO THE "SPECIAL NOTES" SECTION WHICH IS IMMEDIATELY ADJACENT TO THE DEPICTED OUTLOADING METHOD.

GENERAL NOTES


(FOR CARS EQUIPPED WITH LOAD DIVIDER BULKHEADS)

(GENERAL NOTES CONTINUED)

- AA. CAUTION: FOR CUSHIONED BOXCARS EQUIPPED WITH LOAD DIVIDER BULKHEADS, ONLY CARS EQUIPPED WITH LOAD DIVIDERS MANUFACTURED BY EVANS, EQUIPCO, OR PRECO MAY BE USED. LOAD DIVIDERS MANUFACTURED BY TRANSCO ARE NOT ACCEPTABLE WHETHER OF ALUMINUM OR STEEL CONSTRUCTION. THE DEPICTED PROCEDURES ARE APPLICABLE FOR CARS OF VARIOUS LENGTHS AND WIDTHS. THE AAR MECHANICAL DESIGNATION CLASS FOR THESE CARS, AS IDENTIFIED IN "THE OFFICIAL RAILWAY EQUIPMENT REGISTER", WILL BE RBL, XL, OR XLI.
- BB. THE USE OF LOAD DIVIDER EQUIPPED CARS WILL ELIMINATE THE NEED FOR CENTER GATES AND STRUTS, AND GATE HOLD DOWNS (WHEN APPLICABLE) WHICH ARE REQUIRED IN CONVENTIONAL BOXCAR LOADS. THIS WILL ACCOUNT FOR A CONSIDERABLE SAVING IN MATERIAL AND LABOR COSTS. THEREFORE, EVERY EFFORT SHOULD BE MADE TO ACQUIRE CUSHIONED CARS EQUIPPED WITH LOAD DIVIDERS FOR SHIPMENT OF CARTRIDGES. NOTICE: ONLY CUSHIONED CARS THAT HAVE SLIDING CENTER SILL TYPE CUSHIONED DEVICES OR END-OF-CAR TYPE DEVICES WHICH HAVE AT LEAST 15" OF TRAVEL ARE ACCEPTABLE.
- CC. IF NAILING TO A CAR SIDEWALL IS NOT REQUIRED, BOX CARS EQUIPPED WITH ADJUSTABLE SIDE FILLERS THAT HAVE 3/8" OR THICKER PANELS MAY BE USED, HOWEVER, THESE SIDE FILLERS MUST NOT BE USED FOR LATERAL BLOCKING; THEY MUST BE RETRACTED AND LOCKED AGAINST THE CAR SIDEWALL. A "FILL PIECE" MUST BE INSTALLED IN THE VOID BETWEEN THE CAR SIDEWALL AND THE SIDE FILLER PANEL. SEE THE "TYPICAL TYPE A" VIEW ON PAGE 53 FOR GUIDANCE. IF THE BACK OF THE SIDE FILLER PANELS ARE REINFORCED WITH VERTICAL AND HORIZONTAL STEEL MEMBERS AS SHOWN IN THE "TYPICAL TYPE B" VIEW ON PAGE 53, THE "FILL PIECE" MATERIAL IS NOT REQUIRED.
- DD. NOTICE: AFTER THE LOAD DIVIDER BULKHEADS ARE POSITIONED AGAINST THE LADING, AND THE LOCKING PINS ARE ENGAGED IN THE HOLES OF THE RAILS, THE LOWER LOCKING PINS MUST BE INSPECTED TO ENSURE THAT THE PINS ARE FULLY ENGAGED IN THE LOCKING HOLES. IF THE PINS ARE NOT FULLY SEATED IN THE LOCKING HOLES, THE LINKAGE MECHANISM WILL BE ADJUSTED AS REQUIRED SO THAT THE PINS WILL BE FULLY SEATED INTO THE LOCKING HOLES OF THE LOWER RAILS. IF PRESENT, DEBRIS MUST BE REMOVED FROM BENEATH THE LOCKING HOLES WHICH HAVE BEEN SELECTED FOR SECURING A LOAD DIVIDER BULKHEAD.
- EE. A "STRUT ASSEMBLY" MUST BE INSTALLED BETWEEN THE LOAD DIVIDER BULKHEADS IF THE CAR CONTAINS CLASS AND DIVISION 1.1, 1.2, OR 1.3 EXPLOSIVES AND THE LOAD IN EITHER END OF THE CAR WEIGHS 50,000 POUNDS OR MORE. A STRUT ASSEMBLY IS NOT REQUIRED FOR LOADS OF HAZARD CLASS AND DIVISION 1.4 EXPLOSIVES. NOTE THAT THE STRUT ASSEMBLY MAY BE OMITTED FROM LOADS OF CLASS AND DIVISION 1.1, 1.2, OR 1.3 EXPLOSIVES WEIGHING 50,000 POUNDS WHEN THE LADING AND ADEQUATE BLOCKING AND BRACING ARE POSITIONED TO COMPLETELY FILL THE SPACE BETWEEN THE INSTALLED BULKHEADS AS SPECIFIED IN GENERAL NOTE "FF-3" BELOW. DETAILS OF STRUT ASSEMBLIES FOR USE BETWEEN 2-PIECE BULKHEADS AND BETWEEN 1-PIECE BULKHEADS ARE SHOWN ON PAGE 52.
- FF. THE NORMAL LOADING PATTERN IN CARS EQUIPPED WITH LOAD DIVIDER BULKHEADS IS TO POSITION THE LADING BETWEEN A CAR END WALL AND A LOAD DIVIDER BULKHEAD IN FULL LAYERS. OBVIOUSLY, A LOAD QUANTITY MUST THEN BE A MULTIPLE OF THE NUMBER OF PALLET UNITS WHICH ARE IN ONE LOAD UNIT. A LOAD UNIT IS DEFINED AS A STACK OF PALLET UNITS WHICH IS FULL CAR WIDTH BY FULL LOAD HEIGHT BY ONE UNIT IN LENGTH. IF THE QUANTITY TO BE SHIPPED CANNOT BE ATTAINED BY ADJUSTING THE NUMBER OF TIERS IN ONE OR BOTH ENDS OF A CAR, OR BY ADJUSTING THE NUMBER OF LOAD UNITS IN EITHER END OF THE CAR, ONE OF THE FOLLOWING PROCEDURES MUST BE USED IN ORDER TO OBTAIN THE DESIRED QUANTITY.
1. ONE OR MORE RISERS CAN BE POSITIONED WITHIN A LOAD TO INCREASE A LOAD QUANTITY. SEE THE RISER PROCEDURES AND DETAILS ON PAGES 28 AND 29.
 2. THE "GATES AND STRUTS" METHOD OF OMITTING A PALLET UNIT MAY BE USED TO ADJUST A LOAD QUANTITY DOWNWARD BY OTHER THAN A MULTIPLE OF A LOAD UNIT. SEE THE PROCEDURES ON PAGES 26 AND 27 FOR GUIDANCE.
 3. AT LOCATIONS WHERE K-BRACES MIGHT NORMALLY BE USED IN A LOAD IN A CONVENTIONAL CAR, LOAD DIVIDER BULKHEADS CAN BE POSITIONED. LOADING CAN THEN CONTINUE TOWARD THE CENTER OF THE CAR FROM EACH INSTALLED LOAD DIVIDER BULKHEAD IN A ONE-HIGH LOADING PATTERN. INSTALL CENTER GATES AND STRUTS AS SHOWN ON PAGES 6, 8, OR 10 OF THE CONVENTIONAL BOXCAR DRAWING HEREIN TO PROVIDE FOR A TIGHT LOAD BETWEEN THE BULKHEADS.
 4. ONE OR MORE UNITS CAN BE POSITIONED IN CONTACT WITH A LOAD DIVIDER BULKHEAD ON THE CENTER-OF-CAR SIDE. BLOCK AND BRACE WITH NAILED FLOORLINE BLOCKING AS SHOWN ON PAGE 38 OR WITH KNEE BRACE ASSEMBLIES, AS SHOWN ON PAGE 36.
- GG. FOR ADDITIONAL GUIDANCE, ATTENTION IS DIRECTED TO THE "SPECIAL NOTES" SECTION WHICH IS IMMEDIATELY ADJACENT TO THE DEPICTED OUTLOADING METHOD.


ITEMIZED INDEX

<u>ITEM</u>	<u>PAGE(S)</u>
60-UNIT LOAD IN A 60'-8" LONG BY 9'-2" WIDE CONVENTIONAL BOXCAR - - -	6,7
48-UNIT LOAD IN A 50'-6" LONG BY 9'-2" WIDE CONVENTIONAL BOXCAR - - -	8,9
48-UNIT LOAD IN A 50'-6" LONG BY 9'-0" WIDE BOXCAR EQUIPPED WITH MECHANICAL BRACING DEVICES - - - - -	10-13
48-UNIT LOAD IN A 50'-6" LONG BY 9'-2" WIDE BOXCAR EQUIPPED WITH LOAD DIVIDER BULKHEADS - - - - -	14,15
DETAILS - - - - -	16-19
TYPICAL LCL LOAD IN A BOXCAR EQUIPPED WITH MECHANICAL- BRACING DEVICES - - - - -	20,21
TYPICAL LCL USING STRUTTED GATE METHOD - - - - -	22,23
TYPICAL LCL USING COMBINATION LOAD PATTERN - - - - -	24,25
TYPICAL LCL ONE PALLET UNIT OMITTED - - - - -	26,27
TYPICAL LCL USING RISER METHOD - - - - -	28,29
TYPICAL LCL USING BULKHEAD GATE METHOD - - - - -	30,31
TYPICAL LCL USING K-BRACE METHOD - - - - -	32-35
TYPICAL LCL USING KNEE BRACE METHOD - - - - -	36-37
TYPICAL LCL USING 1-WIDE LOADING METHOD - - - - -	38-39
TYPICAL LCL USING FLOORLINE BLOCKING METHOD - - - - -	40
PROCEDURES FOR SHIPMENT OF PARTIAL UNITS - - - - -	41-43
DETAILS FOR CONVENTIONAL BOXCARS - - - - -	44-51
DETAILS FOR BOXCARS EQUIPPED WITH LOAD DIVIDER BULKHEADS - - - - -	52,53




PALLET UNIT

BOX - - - - - 42 EACH @ 57 LBS (APPROX)
 UNIT WEIGHT - - - - - 2,200 LBS (APPROX)
 CUBE - - - - - 37.61 CU FT (APPROX)



SEE GENERAL NOTE "G" ON PAGE 2.

ISOMETRIC VIEW



SECTION A-A

KEY NUMBERS

- ① ANTI-SWAY BRACE (30 REQD). SEE THE "ANTI-SWAY BRACE" DETAIL ON PAGE 16. INSTALL BETWEEN LATERALLY ADJACENT PALLET UNITS. SEE GENERAL NOTE "M" ON PAGE 2 AND SPECIAL NOTE 3 ON PAGE 7.
- ② TOP-OF-LOAD ANTI-SWAY BRACE (8 REQD). SEE THE "TOP-OF-LOAD ANTI-SWAY BRACE" DETAIL ON PAGE 16. WIRE TIE TO THE LIFTING RINGS ON THE PALLET UNIT WITH NO. 14 GAGE WIRE AS TYPICALLY SHOWN BY THE "TIE WIRE APPLICATION" DETAIL ON PAGE 45. SEE SPECIAL NOTE 4 ON PAGE 7.
- ③ CENTER GATE (2 REQD). SEE THE "CENTER GATE A" DETAIL ON PAGE 16. SEE SPECIAL NOTES 5 THRU 7 ON PAGE 7.
- ④ STRUT, 4" X 4" BY CUT TO FIT (REF: 39") (24 REQD). TOENAIL TO PIECES MARKED ③ W/2-16d NAILS AT EACH END. SEE GENERAL NOTE "U" ON PAGE 3.
- ⑤ DOORWAY PROTECTION (2 REQD). SEE THE DETAIL ON PAGE 18. NAIL TO THE DOOR POSTS W/12d NAILS. SEE SPECIAL NOTES 8 AND 9 ON PAGE 7.

(SPECIAL NOTES CONTINUED)

10. THE DEPICTED LOAD CAN BE REDUCED TO SUIT THE QUANTITY TO BE SHIPPED. A 2-TIER LOAD CAN BE REDUCED BY A MULTIPLE OF FOUR UNITS, OR A 1-TIER LOAD CAN BE REDUCED BY A MULTIPLE OF TWO UNITS BY OMITTING ONE OR MORE LOAD UNITS FROM THE CENTER PORTION OF THE LOAD. OR, THE ENTIRE TOP TIER CAN BE OMITTED. FOR OTHER METHODS OF REDUCING A LOAD, AND FOR TYPICAL LCL PROCEDURES, REFER TO PAGES 24 THRU 40 FOR GUIDANCE.
11. IF PALLET UNITS WHICH DO NOT CONTAIN A FULL QUANTITY OF BOXES ARE TO TRANSPORTED, REFER TO U.S. ARMY MATERIEL COMMAND DRAWING 19-48-4232/21-20PM1007 FOR PROCEDURES TO BE USED.
12. FOR SHIPMENT OF A PARTIAL UNIT CONSISTING OF ONE OR TWO LAYERS, REFER TO THE PROCEDURES ON PAGES 41 AND 43 FOR GUIDANCE.

SPECIAL NOTES:

1. A 60'-8" LONG BY 9'-2" WIDE WOOD LINED CONVENTIONAL TYPE BOXCAR EQUIPPED WITH 10'-0" WIDE DOOR OPENINGS IS SHOWN. CARS OF OTHER DIMENSIONS AND CARS HAVING WIDER OR NARROWER DOOR OPENINGS CAN BE USED. SEE GENERAL NOTE "D" ON PAGE 2.
2. IF A 50'-6" OR 40'-6" LONG CAR IS FURNISHED FOR LOADING, REFER TO THE PROCEDURES ON PAGES 8 AND 9 FOR LOADING GUIDANCE.
3. IF THE DOORWAY PROTECTION PROCEDURES SHOWN ON PAGE 14 ARE USED IN LIEU OF THE WOODEN DOOR GATE TYPE PROTECTION, PIECE MARKED (5), NAILED FLOORLINE BLOCKING MUST BE USED IN LIEU OF EACH LOWER ANTI-SWAY BRACE IN THE DOORWAY AREA. NAILED BLOCKING IS REQUIRED FOR ALL PALLET STACKS WHICH ARE COMPLETELY WITHIN THE DOORWAY AREA OR WHICH EXTEND INTO THE DOORWAY AREA BY ONE HALF OR MORE OF THE STACK WIDTH ON EITHER SIDE OF THE CAR. SEE SPECIAL NOTES 8 AND 9 BELOW.
4. TOP-OF-LOAD ANTI-SWAY BRACES, SHOWN AS PIECES MARKED (2) IN THE LOAD ON PAGE 6, MUST BE INSTALLED IN EACH END OF THE CAR. FOUR BRACES ARE REQUIRED IN EACH END OF A 60' LONG CAR.
5. CENTER GATE "A" MAY BE PARTIALLY FORMED FROM 1/2" OR THICKER PLYWOOD, IF DESIRED. PLYWOOD MAY BE USED IN LIEU OF THE 2" X 6" HORIZONTAL PIECES. SEE THE "PLYWOOD CENTER GATE ALTERNATIVE" DETAIL ON PAGE 46 FOR GUIDANCE.
6. FOR EASE OF HANDLING, SPLIT CENTER GATES, WHICH ARE NOT DEPENDENT UPON THE WIDTH OF THE CAR, MAY BE USED AS AN ALTERNATIVE TO THE CAR WIDTH GATES. IN LIEU OF EACH "CENTER GATE A", SHOWN AS PIECE MARKED (3) IN THE LOAD ON PAGE 6, INSTALL TWO "CENTER GATES C" AS SHOWN ON PAGE 19. AFTER THE SPLIT GATES AND STRUTS HAVE BEEN INSTALLED, THE SPLIT GATES MUST BE TIED TOGETHER AS DEPICTED BY THE "TIE PIECE APPLICATION" DETAIL ON PAGE 48.
7. DOOR SPANNER TYPE GATE HOLD DOWN MAY BE USED IN LIEU OF THE DOUBLED 2" X 4" MATERIAL NAILED TO THE "CENTER GATE A", PROVIDING THE CAR BEING LOADED HAS AVAILABLE SIDEWALLS. SEE THE "ALTERNATIVE GATE HOLD DOWN" DETAIL ON PAGE 48 FOR GUIDANCE.
8. DOORWAY PROTECTION IS REQUIRED FOR ALL PALLET UNIT STACKS WHICH ARE COMPLETELY WITHIN THE DOORWAY AREA OR WHICH EXTEND INTO THE DOORWAY AREA BY ONE-HALF OR MORE OF THE STACK WIDTH. THE WOODEN GATE TYPE OF DOORWAY PROTECTION, SHOWN AS PIECES MARKED (5) IN THE LOAD ON PAGE 6, IS APPLICABLE FOR BOXCARS EQUIPPED WITH CONVENTIONAL SLIDING DOORS AND AVAILABLE DOOR POSTS. REFER TO PAGES 49 THRU 51 FOR ALTERNATIVE DOORWAY PROTECTION FOR CARS EQUIPPED WITH CONVENTIONAL SLIDING DOORS. IF THE CAR BEING LOADED IS EQUIPPED WITH PLUG TYPE DOORS OR COMBINATION PLUG AND SLIDING DOORS, NAILED FLOORLINE BLOCKING AND DOORWAY PROTECTION STRAPS MUST BE USED. SEE KEY NUMBERS (3) THRU (6) ON PAGE 14 AND SPECIAL NOTE 5 ON PAGE 15 FOR INSTALLATION GUIDANCE. SEE SPECIAL NOTE 9 BELOW.
9. IF NAILED FLOORLINE BLOCKING AND DOORWAY PROTECTION STRAPS SHOWN ON PAGE 14 ARE USED IN LIEU OF THE WOODEN DOORWAY PROTECTION, PIECES MARKED (5), THE CENTER GATES MUST BE RESTRAINED FROM LATERAL MOVEMENT. THIS CAN BE ACCOMPLISHED BY NAILING TO THE CAR FLOOR A DOUBLED 2" X 4" X 18" PIECE POSITIONED LONGITUDINALLY SO AS TO BE CENTERED AGAINST THE FILL PIECE OF THE CENTER GATE. TWO PIECES WILL BE REQUIRED FOR EACH CENTER GATE WHICH IS IN THE DOOR OPENING OR WITHIN SIX INCHES OF BEING IN THE OPENING.


(CONTINUED AT LEFT)

BILL OF MATERIAL		
LUMBER	LINEAR FEET	BOARD FEET
1" X 6"	80	40
2" X 2"	73	25
2" X 3"	27	14
2" X 4"	525	350
2" X 6"	153	153
4" X 4"	78	104
NAILS	NO. REQD	POUNDS
6d (2")	48	1/4
10d (3")	660	10-1/4
12d (3-1/4")	48	1
16d (3-1/2")	96	2-1/4
WIRE, NO. 14 GAGE	80' REQD	NIL


LOAD AS SHOWN

ITEM	QUANTITY	WEIGHT (APPROX)
PALLET UNIT	60	132,000 LBS
DUNNAGE		1,362 LBS

TOTAL WEIGHT - - - - - 133,362 LBS (APPROX)



ISOMETRIC VIEW



SECTION B-B

KEY NUMBERS

- ① ANTI-SWAY BRACE (24 REOD). SEE THE "ANTI-SWAY BRACE" DETAIL ON PAGE 16. INSTALL BETWEEN LATERALLY ADJACENT PALLET UNITS. SEE GENERAL NOTE "M" ON PAGE 2 AND SPECIAL NOTE 3 ON PAGE 9.
- ② TOP-OF-LOAD ANTI-SWAY BRACE (6 REOD). SEE THE "TOP-OF-LOAD ANTI-SWAY BRACE" DETAIL ON PAGE 16. WIRE TIE TO THE LIFTING RINGS ON THE PALLET UNIT WITH NO. 14 GAGE WIRE AS TYPICALLY SHOWN BY THE "TIE WIRE APPLICATION" DETAIL ON PAGE 45. SEE SPECIAL NOTE 4 ON PAGE 9.
- ③ CENTER GATE (2 REOD). SEE THE "CENTER GATE A" DETAIL ON PAGE 16. SEE SPECIAL NOTES 5 THRU 7 ON PAGE 9.
- ④ STRUT, 4" X 4" BY CUT TO FIT (REF: 54") (24 REOD). TOENAIL TO PIECES MARKED ③ W/2-16d NAILS AT EACH END. SEE GENERAL NOTE "L" ON PAGE 2 AND GENERAL NOTES "T" AND "U" ON PAGE 3.
- ⑤ VERTICAL STRUT BRACING, 2" X 4" 6'-6" (6 REOD). NAIL TO THE STRUTS W/3-10d NAILS AT EACH JOINT.
- ⑥ HORIZONTAL STRUT BRACING, 2" X 4" BY CAR WIDTH MINUS 2" IN LENGTH (4 REOD). NAIL TO THE STRUTS W/3-10d NAILS AT EACH JOINT.
- ⑦ DOORWAY PROTECTION (2 REOD). SEE THE DETAIL ON PAGE 16. NAIL TO THE DOOR POSTS W/12d NAILS. SEE SPECIAL NOTES 8 AND 9 ON PAGE 9.

(SPECIAL NOTES CONTINUED)

10. THE DEPICTED LOAD CAN BE REDUCED TO SUIT THE QUANTITY TO BE SHIPPED. A 2-TIER LOAD CAN BE REDUCED BY A MULTIPLE OF FOUR UNITS, OR A 1-TIER LOAD CAN BE REDUCED BY A MULTIPLE OF TWO UNITS BY OMITTING ONE OR MORE LOAD UNITS FROM THE CENTER PORTION OF THE LOAD. OR, THE ENTIRE TOP TIER CAN BE OMITTED. FOR OTHER METHODS OF REDUCING A LOAD, AND FOR TYPICAL LCL PROCEDURES, REFER TO PAGES 24 THRU 40 FOR GUIDANCE.
11. IF PALLET UNITS WHICH DO NOT CONTAIN A FULL QUANTITY OF BOXES ARE TO TRANSPORTED, REFER TO U.S. ARMY MATERIEL COMMAND DRAWING 19-48-4232/21-20PM1007 FOR PROCEDURES TO BE USED.
12. FOR SHIPMENT OF A PARTIAL UNIT CONSISTING OF ONE OR TWO LAYERS, REFER TO THE PROCEDURES ON PAGES 41 AND 43 FOR GUIDANCE.

SPECIAL NOTES:


1. A 50'-6" LONG BY 9'-2" WIDE WOOD-LINED CONVENTIONAL TYPE BOXCAR EQUIPPED WITH 10'-0" WIDE DOOR OPENINGS IS SHOWN. CARS OF OTHER DIMENSIONS AND CARS HAVING WIDER OR NARROWER DOOR OPENING CAN BE USED. SEE GENERAL NOTE "D" ON PAGE 2.
2. A MAXIMUM OF FORTY PALLET UNITS, FOR AN APPROXIMATE LADING WEIGHT OF 88,000 POUNDS, CAN BE PLACED IN A 40'-6" LONG CAR WHEN USING THE DEPICTED PROCEDURES.
3. IF THE DOORWAY PROTECTION PROCEDURES SHOWN ON PAGE 14 ARE USED IN LIEU OF THE WOODEN DOOR GATE TYPE PROTECTION, PIECE MARKED ⑦, NAILED FLOORLINE BLOCKING MUST BE USED IN LIEU OF EACH LOWER ANTI-SWAY BRACE IN THE DOORWAY AREA. NAILED BLOCKING IS REQUIRED FOR ALL PALLET STACKS WHICH ARE COMPLETELY WITHIN THE DOORWAY AREA OR WHICH EXTEND INTO THE DOORWAY AREA BY ONE HALF OR MORE OF THE STACK WIDTH ON EITHER SIDE OF THE CAR. SEE SPECIAL NOTES 8 AND 9 BELOW.
4. TOP-OF-LOAD ANTI-SWAY BRACES, SHOWN AS PIECES MARKED ② IN THE LOAD ON PAGE 8, MUST BE INSTALLED IN EACH END OF THE CAR. THREE BRACES ARE REQUIRED IN EACH END OF A 40' OR 50' LONG CAR.
5. CENTER GATE "A" MAY BE PARTIALLY FORMED FROM 1/2" OR THICKER PLYWOOD, IF DESIRED. PLYWOOD MAY BE USED IN LIEU OF THE 2" X 6" HORIZONTAL PIECES. SEE THE "PLYWOOD CENTER GATE ALTERNATIVE" DETAIL ON PAGE 46 FOR GUIDANCE.
6. FOR EASE OF HANDLING, SPLIT CENTER GATES, WHICH ARE NOT DEPENDENT UPON THE WIDTH OF THE CAR, MAY BE USED AS AN ALTERNATIVE TO THE CAR WIDTH GATES. IN LIEU OF EACH "CENTER GATE A", SHOWN AS PIECE MARKED ③ IN THE LOAD ON PAGE 8, INSTALL TWO "CENTER GATES C" AS SHOWN ON PAGE 19. AFTER THE SPLIT GATES AND STRUTS HAVE BEEN INSTALLED, THE SPLIT GATES MUST BE TIED TOGETHER AS DEPICTED BY THE "TIE PIECE APPLICATION" DETAIL ON PAGE 48.
7. DOOR SPANNER TYPE GATE HOLD DOWN MAY BE USED IN LIEU OF THE DOUBLED 2" X 4" MATERIAL NAILED TO THE "CENTER GATE A", PROVIDING THE CAR BEING LOADED HAS AVAILABLE SIDEWALLS. SEE THE "ALTERNATIVE GATE HOLD DOWN" DETAIL ON PAGE 48 FOR GUIDANCE.
8. DOORWAY PROTECTION IS REQUIRED FOR ALL PALLET UNIT STACKS WHICH ARE COMPLETELY WITHIN THE DOORWAY AREA OR WHICH EXTEND INTO THE DOORWAY AREA BY ONE-HALF OR MORE OF THE STACK WIDTH. THE WOODEN GATE TYPE OF DOORWAY PROTECTION, SHOWN AS PIECES MARKED ⑦ IN THE LOAD ON PAGE 8, IS APPLICABLE FOR BOXCARS EQUIPPED WITH CONVENTIONAL SLIDING DOORS AND AVAILABLE DOOR POSTS. REFER TO PAGES 49 THRU 51 FOR ALTERNATIVE DOORWAY PROTECTION FOR CARS EQUIPPED WITH CONVENTIONAL SLIDING DOORS. IF THE CAR BEING LOADED IS EQUIPPED WITH PLUG TYPE DOORS OR COMBINATION PLUG AND SLIDING DOORS, NAILED FLOORLINE BLOCKING AND DOORWAY PROTECTION STRAPS MUST BE USED. SEE KEY NUMBERS ③ THRU ⑥ ON PAGE 14 AND SPECIAL NOTE 5 ON PAGE 15 FOR GUIDANCE. SEE SPECIAL NOTE 9 BELOW.
9. IF NAILED FLOORLINE BLOCKING AND DOORWAY PROTECTION STRAPS SHOWN ON PAGE 14 ARE USED IN LIEU OF THE WOODEN DOORWAY PROTECTION, PIECES MARKED ⑦, THE CENTER GATES MUST BE RESTRAINED FROM LATERAL MOVEMENT. THIS CAN BE ACCOMPLISHED BY NAILING TO THE CAR FLOOR A DOUBLED 2" X 4" X 18" PIECE POSITIONED LONGITUDINALLY SO AS TO BE CENTERED AGAINST THE FILL PIECE OF A CENTER GATE. TWO PIECES WILL BE REQUIRED FOR EACH CENTER GATE WHICH IS IN THE DOOR OPENING OR WITHIN SIX INCHES OF BEING IN THE OPENING.

(CONTINUED AT LEFT)

LOAD AS SHOWN

ITEM	QUANTITY	WEIGHT (APPROX)
PALLET UNIT	48	105,600 LBS
DUNNAGE		1,430 LBS
TOTAL WEIGHT		107,030 LBS (APPROX)

BILL OF MATERIAL		
LUMBER	LINEAR FEET	BOARD FEET
1" X 6"	80	40
2" X 2"	73	25
2" X 3"	27	14
2" X 4"	497	331
2" X 6"	153	153
4" X 4"	108	144
NAILS	NO. REQD	POUNDS
6d (2")	48	1/2
10d (3")	732	11-1/4
12d (3-1/4")	42	1
16d (3-1/2")	96	2-1/4
WIRE, NO. 14 GAGE	60' REED	NIL



WIDTH OF PALLET UNIT (45-29/64")


ONE LOAD UNIT.

SEE GENERAL NOTES "D" AND "G" ON PAGE 2.

ISOMETRIC VIEW

KEY NUMBERS

- ① CRIB FILL (10 REOD). SEE THE "CRIB FILL A" DETAIL ON PAGE 17. SEE SPECIAL NOTE 3 ON PAGE 11. SEE GENERAL NOTES "M" AND "N" ON PAGE 2.
- ② CRIB FILL (8 REOD). SEE THE "CRIB FILL B" DETAIL ON PAGE 17.
- ③ CENTER GATE (2 REOD). SEE THE "CENTER GATE B" DETAIL ON PAGE 17. SEE SPECIAL NOTES 4, 5, AND 6 ON PAGE 11.
- ④ STRUT, 2" X 6" BY CUT TO FIT (REF: 44") (DOUBLED) (24 REOD). LAMINATE W/1-10d NAIL EVERY 6". TOENAIL TO PIECE MARKED ③ W/2-12d NAILS AT EACH END. SEE GENERAL NOTE "L" ON PAGE 2. SEE GENERAL NOTES "T" AND "U" ON PAGE 3, AND SPECIAL NOTE 7 ON PAGE 11.
- ⑤ DOORWAY PROTECTION (2 REOD). SEE THE "DOORWAY PROTECTION" DETAIL ON PAGE 18. NAIL TO THE DOOR POSTS W/12d NAILS. SEE SPECIAL NOTES 8 AND 9 ON PAGE 11.



SECTION C-C

(SPECIAL NOTES CONTINUED)

10. THE DEPICTED LOAD CAN BE REDUCED TO SUIT THE QUANTITY TO BE SHIPPED. A 2-TIER LOAD CAN BE REDUCED BY A MULTIPLE OF FOUR UNITS, OR A 1-TIER LOAD CAN BE REDUCED BY A MULTIPLE OF TWO UNITS BY OMITTING ONE OR MORE LOAD UNITS FROM THE CENTER PORTION OF THE LOAD. OR, THE ENTIRE TOP TIER CAN BE OMITTED. FOR OTHER METHODS OF REDUCING A LOAD, AND FOR TYPICAL LCL PROCEDURES, REFER TO PAGES 24 THRU 40 FOR GUIDANCE.
11. IF PALLET UNITS WHICH DO NOT CONTAIN A FULL QUANTITY OF BOXES ARE TO BE TRANSPORTED, REFER TO U.S. ARMY MATERIEL COMMAND DRAWING 19-48-4232/21-20PM1007 FOR PROCEDURES TO BE USED.
12. FOR SHIPMENT OF A PARTIAL UNIT CONSISTING OF ONE OR TWO LAYERS, REFER TO THE PROCEDURES ON PAGE 42 FOR GUIDANCE.

SPECIAL NOTES:

1. A 60'-8" LONG BY 9'-2" WIDE WOOD-LINED CONVENTIONAL TYPE BOXCAR EQUIPPED WITH 10'-0" WIDE DOOR OPENINGS IS SHOWN. CARS OF OTHER DIMENSIONS AND CARS HAVING WIDER OR NARROWER DOOR OPENINGS CAN BE USED.
2. A MAXIMUM OF SIXTY PALLET UNITS, FOR AN APPROXIMATE LADING WEIGHT OF 132,000 POUNDS, CAN BE PLACED IN A 50'-6" LONG CAR WHEN USING THE DEPICTED PROCEDURES; FORTY-EIGHT UNITS, FOR AN APPROXIMATE LADING WEIGHT OF 105,600 POUNDS, CAN BE OUTLOADED IN A 40'-6" LONG CAR.
3. THE "HIGH" CRIB FILL SHOWN AS PIECE MARKED ①, MUST BE INSTALLED IN EACH END OF THE LOAD. FOUR ASSEMBLIES ARE REQUIRED IN EACH END OF THE LOAD IN 40' AND 50' CARS. FIVE ASSEMBLIES ARE REQUIRED IN EACH END OF THE LOAD IN A 60' CAR.
4. CENTER GATE "B" MAY BE PARTIALLY FORMED FROM 1/2" OR THICKER PLYWOOD IF DESIRED. PLYWOOD MAY BE USED IN LIEU OF THE 2" X 6" HORIZONTAL PIECES. SEE THE "PLYWOOD CENTER GATE ALTERNATIVE" DETAIL ON PAGE 46 FOR GUIDANCE.
5. FOR EASE OF HANDLING, SPLIT CENTER GATES, WHICH ARE NOT DEPENDENT UPON THE WIDTH OF THE CAR, MAY BE USED AS AN ALTERNATIVE TO THE CAR-WIDTH GATES. IN LIEU OF EACH "CENTER GATE B" SHOWN AS PIECE MARKED ③ IN THE LOAD ON PAGE 10, INSTALL TWO "CENTER GATES D" AS SHOWN ON PAGE 19. AFTER THE SPLIT GATES AND STRUTS HAVE BEEN INSTALLED, THE SPLIT GATES MUST BE TIED TOGETHER AS DEPICTED BY THE "TIE PIECE APPLICATION" DETAIL ON PAGE 48.
6. DOOR SPANNER TYPE GATE HOLD DOWN MAY BE USED IN LIEU OF THE 2" X 4" MATERIAL NAILED TO "CENTER GATE B" PROVIDING THE CAR BEING LOADED HAS AVAILABLE SIDE-WALLS. SEE THE DETAILS ON PAGE 48 FOR GUIDANCE.
7. IF THE DEPICTED LOAD CONTAINS EIGHT LOAD UNITS OR LESS IN EACH END OF THE CAR, 4" X 4" STRUTS MAY BE USED IN LIEU OF PIECES MARKED ④. NAIL AS DESCRIBED BY KEY NUMBER ④ ON PAGE 8.
8. DOORWAY PROTECTION IS REQUIRED FOR ALL PALLET UNIT STACKS WHICH ARE COMPLETELY WITHIN THE DOORWAY AREA OR WHICH EXTEND INTO THE DOORWAY AREA BY ONE-HALF OR MORE OF THE STACK LENGTH. THE WOODEN GATE TYPE OF DOORWAY PROTECTION, SHOWN AS PIECES MARKED ⑤ IN THE LOAD ON PAGE 10, IS APPLICABLE FOR BOXCARS EQUIPPED WITH CONVENTIONAL SLIDING DOORS AND NAILABLE DOOR POSTS. REFER TO PAGES 49 THRU 51 FOR ALTERNATIVE DOORWAY PROTECTION FOR CARS EQUIPPED WITH CONVENTIONAL SLIDING DOORS. IF THE CAR BEING LOADED IS EQUIPPED WITH PLUG TYPE DOORS OR COMBINATION PLUG AND SLIDING DOORS, NAILED FLOORLINE BLOCKING AND DOORWAY PROTECTION STRAPS MUST BE USED. SEE KEY NUMBERS ③ THRU ⑥ ON PAGE 14 AND SPECIAL NOTE 5 ON PAGE 15 FOR GUIDANCE. SEE SPECIAL NOTE 9 BELOW.
9. IF NAILED FLOORLINE BLOCKING AND DOORWAY PROTECTION STRAPS SHOWN ON PAGE 14 ARE USED IN LIEU OF THE WOODEN DOORWAY PROTECTION, PIECES MARKED ⑤, THE CENTER GATES MUST BE RESTRAINED FROM LATERAL MOVEMENT. THIS CAN BE ACCOMPLISHED BY EXTENDING THE LENGTH OF THE FLOORLINE BLOCKING 9" BEYOND THE GATES TO PREVENT DISPLACEMENT.

(CONTINUED AT LEFT)

BILL OF MATERIAL		
LUMBER	LINEAR FEET	BOARD FEET
1" X 6"	80	40
2" X 2"	73	25
2" X 3"	27	14
2" X 4"	743	495
2" X 6"	329	329
NAILS	NO. REOD	POUNDS
6d (2")	48	1/4
10d (3")	1,500	23
12d (3-1/4")	120	2


LOAD AS SHOWN

ITEM	QUANTITY	WEIGHT (APPROX)
PALLET UNIT	72	158,400 LBS
DUNNAGE		1,832 LBS
TOTAL WEIGHT		160,232 LBS (APPROX)

CAR EQUIPMENT REQUIRED

ADJUSTABLE WALL MEMBER - - - -	64
(SEE "NOTE ▲" BELOW)	
CROSS MEMBERS - - - - -	42
DOORWAY MEMBERS - - - - -	6

NOTE ▲: FOR CARS EQUIPPED WITH FIXED WALL MEMBERS LOCATED AT THE HEIGHTS SPECIFIED IN "SECTION D-D" OMIT ALL REFERENCE TO "ADJUSTABLE WALL MEMBERS".




SEE GENERAL NOTES "D" AND "G" ON PAGE 2.

ISOMETRIC VIEW

EACH DIMENSIONED HEIGHT ABOVE THE CAR FLOOR TO AN ADJUSTABLE OR FIXED WALL MEMBER MARKED ① AND/OR A DOORWAY MEMBER MARKED ⑦ IS SPECIFIED TO LOCATE THE CENTER LINE OF A CROSS MEMBER, EXCEPT FOR THE BOTTOM CROSS MEMBER, PLUS OR MINUS 3" IS PERMITTED.

KEY NUMBERS

- ① WALL MEMBER, ADJUSTABLE OR FIXED. MEMBERS MUST BE LOCATED AT THE SPECIFIED HEIGHTS ABOVE THE CAR FLOOR TO PROVIDE PROPER ALIGNMENT OF CROSS MEMBERS MARKED ⑤. SEE THE "SECTION D-D" VIEW BELOW FOR LOCATION GUIDANCE.
- ② ANTI-SWAY BRACE (28 REOD). SEE THE "ANTI-SWAY BRACE" DETAIL ON PAGE 15. INSTALL BETWEEN LATERALLY ADJACENT PALLET UNITS. SEE GENERAL NOTES "M" AND "N" ON PAGE 2.
- ③ TOP-OF-LOAD ANTI-SWAY BRACE (6 REOD). SEE THE DETAIL ON PAGE 16. WIRE TIE TO THE LIFTING RINGS ON THE PALLET UNIT WITH NO. 14 GAGE WIRE AS SHOWN BY THE "TIE WIRE APPLICATION" DETAIL ON PAGE 45. SEE SPECIAL NOTE 3 ON PAGE 13.
- ④ LOAD BEARING GATE FOR 3-HIGH LOAD (6 REOD). SEE THE "LOAD BEARING GATE A" DETAIL ON PAGE 18. POSITION WITH THE VERTICAL PIECES AGAINST THE PALLET UNITS. SEE SPECIAL NOTE 4 ON PAGE 13.
- ⑤ CROSS MEMBER (42 REOD). SEE GENERAL NOTE "X" ON PAGE 3.
- ⑥ LOAD BEARING GATE FOR 1-HIGH LOAD (4 REOD). SEE THE "LOAD BEARING GATE A" DETAIL ON PAGE 18.
- ⑦ DOORWAY MEMBER (6 REOD). SEE THE "SECTION D-D" VIEW AT LEFT FOR LOCATION GUIDANCE. SEE SPECIAL NOTE 5 ON PAGE 13.



SECTION D-D

INDICATES CAR FLOOR.

56-UNIT LOAD

SPECIAL NOTES:


1. A 50'-6" LONG BY 9'-2" WIDE (INSIDE CLEARANCE) WOOD-LINED BOX CAR EQUIPPED WITH ADJUSTABLE AND/OR FIXED WALL MEMBERS, AND WITH 10'-0" WIDE DOOR OPENINGS IS SHOWN. CARS OF OTHER DIMENSIONS AND CARS HAVING WIDER OR NARROWER DOOR OPENINGS CAN BE USED.
2. A MAXIMUM OF FIFTY UNITS FOR AN APPROXIMATE LADING WEIGHT OF 110,000 POUNDS, CAN BE PLACED IN A 40'-6" LONG CAR WHEN USING THE DEPICTED PROCEDURES.
3. TOP-OF-LOAD ANTI-SWAY BRACES SHOWN AS PIECES MARKED ③ IN THE LOAD ON PAGE 12, MUST BE INSTALLED IN EACH END OF THE CAR. THREE BRACES ARE REQUIRED IN EACH END OF A LOAD.
4. IF A CAR HAS BOWED ENDWALLS WHICH ARE BOWED OUTWARD TWO INCHES OR MORE EITHER FROM SIDE-TO-SIDE OR FROM FLOOR-TO-ROOF, CROSS MEMBERS CAN BE INSTALLED NEAR THE ENDWALL OF THE CAR TO PROVIDE A "SQUARED END" RATHER THAN INSTALLING DUNNAGE AS SPECIFIED IN GENERAL NOTE "G" ON PAGE 2. THESE CROSS MEMBERS SHOULD BE INSTALLED AT THE SAME HEIGHTS AS THE CROSS MEMBERS USED THROUGHOUT THE LOAD AS BLOCKING MEMBERS. A LOAD BEARING GATE, SHOWN AS PIECE MARKED ④ MUST BE POSITIONED AGAINST THESE CROSS MEMBERS PRIOR TO LOADING.
5. IF THE CAR BEING LOADED IS EQUIPPED WITH AT LEAST TWELVE DOORWAY MEMBERS, AN ADDITIONAL EIGHT PALLET UNITS CAN BE LOADED IN THE DOORWAY AREA.
6. THE DEPICTED LOAD CAN BE REDUCED TO SUIT THE QUANTITY TO BE SHIPPED. A LOAD MAY BE REDUCED BY MULTIPLES OF TWO PALLET UNITS BY OMITTING LATERALLY ADJACENT PALLET UNITS FROM THE CENTER PORTION OF THE LOAD, OR BY OMITTING TWO UNITS FROM THE 3-HIGH PORTION OF THE LOAD. THE LOAD MAY BE REDUCED BY MULTIPLES OF SIX PALLET UNITS BY OMITTING ONE OR MORE ENTIRE LOAD UNITS. TO REDUCE A LOAD BY ONE PALLET UNIT, REFER TO THE LCL PROCEDURES ON PAGE 20 AND 21 FOR GUIDANCE.
7. IF PALLET UNITS WHICH DO NOT CONTAIN A FULL QUANTITY OF BOXES ARE TO BE TRANSPORTED, REFER TO U.S. ARMY MATERIEL COMMAND DRAWING 19-48-4232/21-20PM1007 FOR THE PROCEDURES TO BE USED.
8. FOR SHIPMENT OF A PARTIAL UNIT CONSISTING OF ONE OR TWO LAYERS, REFER TO PAGES 41 AND 43 FOR GUIDANCE.

BILL OF MATERIAL		
LUMBER	LINEAR FEET	BOARD FEET
2" X 4"	696	464
2" X 6"	286	286
NAILS	NO. REQD	POUNDS
10d (3")	648	10
12d (3-1/4")	24	1/2
WIRE, NO. 14 GAGE - - - - 60' REQD - - - - -		1 LB

LOAD AS SHOWN

ITEM	QUANTITY	WEIGHT (APPROX)
PALLET UNIT - - - - -	56 - - - - -	123,200 LBS
DUNNAGE - - - - -	- - - - -	1,511 LBS
TOTAL WEIGHT - - - - -		124,711 LBS (APPROX)


56-UNIT LOAD
IN A 50'-6" LONG BY 9'-2" WIDE BOXCAR EQUIPPED WITH MECHANICAL BRACING DEVICES



LENGTH OF PALLET UNIT (37-5/8").

SEE GENERAL NOTES "D" AND "G" ON PAGE 2.

ISOMETRIC VIEW



SECTION E-E

KEY NUMBERS

- ① ANTI-SWAY BRACE (22 REOD). SEE THE "ANTI-SWAY BRACE" DETAIL ON PAGE 16. INSTALL BETWEEN LATERALLY ADJACENT PALLET UNITS. SEE GENERAL NOTES "L" AND "M" ON PAGE 2, AND SPECIAL NOTE 5 ON PAGE 15.
- ② TOP-OF-LOAD ANTI-SWAY BRACE (6 REOD). SEE THE "TOP-OF-LOAD ANTI-SWAY BRACE" DETAIL ON PAGE 16. WIRE TIE TO LIFTING RINGS OF UNIT WITH NO.14 GAGE WIRE AS TYPICALLY SHOWN BY THE "TIE WIRE APPLICATION" DETAIL ON PAGE 45. SEE SPECIAL NOTE 3 ON PAGE 15.
- ③ FLOORLINE BLOCKING, 2" X 6" X 45" (DOUBLED) (4 REOD). NAIL THE FIRST PIECE TO THE CAR FLOOR W/5-16d NAILS. NAIL THE SECOND PIECE TO THE FIRST IN A LIKE MANNER. SEE SPECIAL NOTE 5 ON PAGE 15.
- ④ STRAPPING BOARD (3 REOD). SEE THE DETAIL ON PAGE 18.
- ⑤ DOORWAY PROTECTION STRAP, 1-1/4" X .031" DR .035" X 32'-6" LONG STEEL STRAPPING (3 REOD). STAPLE TO STRAPPING BOARD MARKED ④ W/3 STAPLES. SEE SPECIAL NOTE 5 ON PAGE 15.
- ⑥ SEAL FOR 1-1/4" STRAPPING (6 REOD, 2 PER STRAP). DOUBLE CRIMP EACH SEAL. SEE GENERAL NOTE "O" ON PAGE 2.
- ⑦ STRUT ASSEMBLY (1 REOD). SEE THE "STRUT ASSEMBLY FOR 1-PIECE BULKHEADS" DETAIL ON PAGE 52. INSTALL BETWEEN THE LOAD DIVIDER BULKHEADS. SEE SPECIAL NOTE 6 ON PAGE 15.

48-UNIT LOAD

IN A 50'-6" LONG BY 9'-2" WIDE BOXCAR EQUIPPED WITH LOAD DIVIDER BULKHEADS

(SPECIAL NOTES CONTINUED)

- 7. THE DEPICTED LOAD CAN BE REDUCED TO SUIT THE QUANTITY TO BE SHIPPED. A 2-TIER LOAD CAN BE REDUCED BY A MULTIPLE OF FOUR PALLET UNITS. A 1-TIER LOAD CAN BE REDUCED BY A MULTIPLE OF TWO UNITS BY OMITTING ONE OR MORE LOAD UNITS FROM THE CENTER PORTION OF THE LOAD. OR, THE ENTIRE TOP TIER CAN BE OMITTED. FOR OTHER METHODS OF REDUCING A LOAD, AND FOR TYPICAL LCL PROCEDURES, REFER TO PAGES 24 THRU 29 AND GENERAL NOTE "FF" ON PAGE 4 FOR GUIDANCE.
- 8. IF PALLET UNITS WHICH DO NOT CONTAIN A FULL QUANTITY OF BOXES ARE TO BE TRANSPORTED, REFER TO U.S. ARMY MATERIEL COMMAND DRAWING 19-48-4232/21-20PM1007 FOR PROCEDURES TO BE USED.

SPECIAL NOTES:

- 1. A 50'-6" LONG BY 9'-2" WIDE WOOD-LINED CUSHIONED BOXCAR EQUIPPED WITH LOAD DIVIDER BULKHEADS AND WITH 10'-0" WIDE DOOR OPENING IS SHOWN. CARS OF OTHER DIMENSIONS AND CARS HAVING NARROWER OR WIDER DOOR OPENINGS CAN BE USED. SEE GENERAL NOTES "AA" THRU "EE" ON PAGE 4.
- 2. THE PALLET UNITS SHOWN IN THE TYPICAL LOAD ON PAGE 14 ARE POSITIONED CROSSWISE IN THE CAR. A MAXIMUM OF SIXTY PALLET UNITS, FOR AN APPROXIMATE LADING WEIGHT OF 132,000 POUNDS CAN BE PLACED IN A 60'-8" LONG CAR, OR A MAXIMUM OF FORTY UNITS CAN BE LOADED IN A 40'-6" LONG CAR FOR AN APPROXIMATE LADING WEIGHT OF 88,000 POUNDS, WHEN USING THE DEPICTED PROCEDURES. IF THE LENGTHWISE LOADING PATTERN SHOWN ON PAGE 10 IS EMPLOYED, SEVENTY-TWO PALLET UNITS FOR AN APPROXIMATE LADING WEIGHT OF 158,400 POUNDS CAN BE PLACED IN A 60'-8" LONG CAR; SIXTY UNITS FOR AN APPROXIMATE LADING WEIGHT OF 132,000 POUNDS CAN BE PLACED IN A 50'-6" LONG CAR, OR A MAXIMUM OF FORTY-EIGHT UNITS FOR AN APPROXIMATE LADING WEIGHT OF 105,600 POUNDS CAN BE LOADED IN A 40'-6" LONG CAR.
- 3. TOP-OF-LOAD ANTI-SWAY BRACES, SHOWN AS PIECES MARKED ② IN THE LOAD ON PAGE 14 MUST BE INSTALLED IN EACH END OF THE CAR. FOUR BRACES ARE REQUIRED IN EACH END OF A 60' CAR. THREE BRACES ARE REQUIRED IN EACH END OF 40' AND 50' CARS.
- 4. DOORWAY PROTECTION IS REQUIRED FOR ALL PALLET UNIT STACKS WHICH ARE COMPLETELY WITHIN THE DOORWAY AREA OR WHICH EXTEND INTO IT BY ONE-HALF OR MORE OF THE STACK WIDTH. THE WOODEN GATE TYPE OF DOORWAY PROTECTION, SHOWN AS PIECES MARKED ⑦ IN THE LOAD ON PAGE 8, IS APPLICABLE FOR BOXCARS EQUIPPED WITH CONVENTIONAL SLIDING DOORS AND NAILABLE DOOR POSTS; OR NAILED FLOORLINE BLOCKING AND DOORWAY PROTECTION STRAPS MAY BE USED. REFER TO PAGES 49 THRU 51 FOR OTHER TYPES OF DOORWAY PROTECTION. NOTE: IF THE CAR BEING LOADED IS EQUIPPED WITH PLUG TYPE DOORS OR COMBINATION PLUG AND SLIDING DOORS NAILED FLOORLINE BLOCKING AND DOORWAY PROTECTIONS STRAPS MUST BE USED.
- 5. FLOORLINE BLOCKING SHOWN AS PIECE MARKED ③ IN THE LOAD ON PAGE 14, MUST BE USED IN LIEU OF THE LOWER ANTI-SWAY BRACE MARKED ①, FOR ALL UNITS REQUIRING DOORWAY PROTECTION STRAPS. TWO DOORWAY PROTECTION STRAPS ARE REQUIRED FOR EACH PALLET STACK AND/OR LOAD UNIT WHICH IS COMPLETELY WITHIN THE DOORWAY AREA OR WHICH IS NOT RETAINED BY A LEAST SIX INCHES OF THE SIDEWALL ON BOTH SIDES OF THE CAR. ONE DOORWAY PROTECTION STRAP IS REQUIRED FOR EACH PALLET STACK AND/OR LOAD UNIT WHICH IS RETAINED BY FROM 6" TO ONE-HALF THE PALLET/LOAD UNIT LENGTH OR WIDTH.
- 6. THE STRUT ASSEMBLY, SHOWN AS PIECE MARKED ⑧ IN THE LOAD ON PAGE 14, IS REQUIRED WHEN THE LOAD IN EITHER END OF A CAR IS 50,000 POUNDS OR MORE. FOR THE DEPICTED LOAD THE STRUT ASSEMBLY WOULD NOT BE REQUIRED IF THE LOAD CONSISTED OF FIVE LOAD UNITS IN EACH END OF THE CAR. THE STRUT ASSEMBLY WILL ALWAYS BE REQUIRED FOR FULL LOADS IN 50' OR LONGER CARS.

3-HIGH LOAD CHART		
LOAD UNITS	PALLET UNITS	LADING WEIGHT
* 8	48	105,600
9	50	118,800
10	60	132,000
11	66	145,202
12	72	158,400

(CONTINUED AT LEFT)

BILL OF MATERIAL		
LUMBER	LINEAR FEET	BOARD FEET
1" X 8"	17	12
2" X 4"	415	277
2" X 6"	58	58
4" X 4"	15	20
NAILS	NO. REQD	POUNDS
6d (2")	14	4-1/2
10d (3")	282	1
12d (3-1/4")	52	1
16d (3-1/2")	40	1
STEEL STRAPPING, 1-1/4"		
X .031" OR .035"	98' REQD	14 LBS
SEAL FOR 1-1/4" STRAPPING	6 REQD	NIL
WIRE, NO. 14 GAGE	48' REQD	3/4 LBS
STAPLE, STRAP	9 REQD	NIL

* PALLET UNITS CAN BE STACKED 3-HIGH AS SHOWN IN THE LOAD ON PAGE 12, IF DESIRED. SEE THE "3-HIGH LOAD CHART" ON THIS PAGE FOR THE QUANTITIES AND WEIGHTS THAT CAN BE ATTAINED FOR THE DEPICTED CAR. NOTE THAT PIECES MARKED ④, ⑤, AND ⑥ WILL NOT BE REQUIRED FOR 8 THRU 10 LOAD UNITS.

LOAD AS SHOWN

ITEM	QUANTITY	WEIGHT (APPROX)
PALLET UNIT	48	105,600 LBS *
DUNNAGE		756 LBS


TOTAL WEIGHT - - - - - 106,356 LBS (APPROX)

48-UNIT LOAD
 IN A 50'-6" LONG BY 9'-2" WIDE BOXCAR EQUIPPED WITH LOAD DIVIDER BULKHEADS

BUFFER PIECE, 2" X 4" X 39"
(2 REOD). NAIL TO THE
RETAINER PIECES W/3-10d
NAILS AT EACH JOINT.


RETAINER PIECE, 2" X 4" BY
A LENGTH TO SUIT (2 REOD).

FABRICATE TO FIT BETWEEN
THE POSTS OF LATERALLY
ADJACENT PALLETS.



SUPPORT PIECE, 2" X 4" BY A
LENGTH TO SUIT (1 REOD). NAIL
TO THE SPACER PIECE W/4-12d NAILS.

SPACER PIECE, 2" X 4"
BY A DISTANCE BETWEEN
UNITS MINUS 1/2" (1 REOD).



ANTI-SWAY BRACE


IF DESIRED, THE ANTI-SWAY BRACE CAN BE PARTIALLY
PRE-ASSEMBLED; ONE BUFFER PIECE CAN BE NAILED TO
BOTH RETAINER PIECES. THE LONG ENDS OF THE ASSEMBLY
CAN THEN BE INSTALLED INTO THE FORKLIFT OPENING OF
A LOADED PALLET PRIOR TO POSITIONING THE LATERALLY
ADJACENT PALLET UNIT.

TOP-OF-LOAD ANTI-SWAY BRACE

VERTICAL PIECE, 2" X 6" X 6'-8"
FOR A 2-HIGH LOAD, 42" FOR A
1-HIGH LOAD (6 REOD).

HORIZONTAL PIECE, 2" X 6"
BY CAR WIDTH MINUS 1/2"
IN LENGTH (4 REOD). NAIL
TO THE VERTICAL PIECES
W/3-10d NAILS AT EACH JOINT.


CAR WIDTH
MINUS 1/2"



FILL PIECE, 2" X 4" X 40"
(2 REOD). NAIL TO THE
VERTICAL PIECES W/3-10d
NAILS AT EACH JOINT.



STRUT LEDGER, 2" X 2" OR
2" X 4" BY CAR WIDTH MINUS
1/2" IN LENGTH (4 REOD).
NAIL TO THE VERTICAL PIECES
W/2-10d NAILS AT EACH JOINT.

GATE HOLD DOWN, 2" X 4" X 6"
(DOUBLED) (2 REOD). NAIL THE
FIRST PIECE TO THE FILL PIECE
W/2-10d NAILS. LAMINATE THE
SECOND PIECE TO THE FIRST IN
A LIKE MANNER. SEE SPECIAL
NOTE 7 ON PAGE 9.



CENTER GATE A

END VIEW




CRIB FILL A

CRIB FILL ASSEMBLIES "A" AND "B" SHOULD BE PREFABRICATED. CONSTRUCT TO BE 1/2" TO 3/4" LESS IN WIDTH THAN THE DISTANCE BETWEEN LATERALLY ADJACENT PALLET UNITS.


CRIB FILL B

CRIB FILL "B" IS NOT REQUIRED FOR A 1-HIGH LOAD; USE CRIB FILL "A" THROUGHOUT THE LENGTH OF THE LOAD.



STRUT LEDGER, 2" X 2" OR 2" X 4" BY CAR WIDTH MINUS 1/2" IN LENGTH (4 REOD). NAIL TO THE VERTICAL PIECES W/2-10d NAILS AT EACH JOINT.


GATE HOLD DOWN, 2" X 4" X 10" (DOUBLED) (2 REOD). NAIL THE FIRST PIECE TO THE FILL PIECE W/4-10d NAILS. LAMINATE THE SECOND PIECE TO THE FIRST IN A LIKE MANNER. SEE SPECIAL NOTE 6 ON PAGE 7.



CENTER GATE B

END VIEW


STRAPPING BOARD, 2" X 6" BY
CAR WIDTH MINUS 1" (1 REOD).
NAIL TO THE SPACER PIECE
W/4-12d NAILS.



SPACER PIECE, 2" X 4" BY
A LENGTH TO SUIT (1 REOD).

STRAPPING BOARD


VERTICAL PIECE, 2" X 3" X 72"
(2 REOD). NAIL TO A DOOR
POST W/12d NAILS.



HORIZONTAL PIECE, 1" X 6" BY DOOR
OPENING WIDTH (4 REOD). NAIL TO
THE VERTICAL PIECES W/3-6d NAILS
EACH END.

DOORWAY PROTECTION

VERTICAL PIECE, 2" X 6" BY
A LENGTH TO SUIT (4 REOD).




CAR WIDTH
MINUS 1/2"

9'-8" FOR 3-HIGH
6'-6" FOR 2-HIGH
40" FOR 1-HIGH

TIE PIECE, 2" X 4" BY CAR
WIDTH MINUS 1/2" IN LENGTH
(AS REOD). NAIL TO THE
VERTICAL PIECES W/3-10d
NAILS AT EACH JOINT.

LOAD BEARING GATE A


ADJUST HEIGHT OF TIE PIECES AS NECESSARY
TO PROVIDE FOR CLEARANCE OF CROSS MEMBERS.




CENTER GATE C

NOTE: REFER TO THE "CENTER GATE D" AND "END VIEW" DETAILS BELOW FOR HEIGHT LOCATION OF HORIZONTAL PIECES AND STRUT LEDGERS, AND FOR NAILING GUIDANCE FOR CENTER GATE "C".


VERTICAL PIECE, 2" X 6" X 6'-8" FOR A 2-HIGH LOAD, 40" FOR A 1-HIGH LOAD (3 REOD).



CENTER GATE D



END VIEW



ISOMETRIC VIEW


SPECIAL NOTES:

1. A 9'-0" WIDE (INSIDE CLEARANCE) BOXCAR EQUIPPED WITH ADJUSTABLE AND/OR FIXED WALL MEMBERS IS SHOWN. CARS OF OTHER WIDTHS CAN BE USED.
2. FIVE UNITS ARE SHOWN AS A TYPICAL LOAD QUANTITY. THE NUMBER OF UNITS CAN BE ADJUSTED TO SUIT THE QUANTITY TO BE SHIPPED.
3. TOP-OF-LOAD ANTI-SWAY BRACES, SHOWN AS PIECES MARKED ③, MUST BE INSTALLED IN EACH END OF THE CAR AND WIRE TIED TO A UNIT WITH NO. 14 GAGE WIRE. THREE BRACES ARE REQUIRED IN EACH END OF A 40'-6" OR 50'-6" LONG CAR; FOUR BRACES ARE REQUIRED IN EACH END OF A 60'-6" LONG CAR.
4. THE SPACER ASSEMBLIES, SHOWN AS PIECES MARKED ⑥, MAY ALSO BE USED IN AN UPPER LAYER OF A LOAD FOR THE OMISSION OF A PALLET UNIT. IF THE ASSEMBLIES ARE USED NEXT TO THE CAR ENDWALL IN EITHER A FIRST LAYER OR IN AN UPPER LAYER, AND THE ENDWALL IS WOOD-LINED, CUT THE ADJACENT ENDS OFF THE SUPPORT PIECES FLUSH WITH THE LATERAL PIECE. EACH ASSEMBLY CAN THEN BE SUPPORTED BY NAILING THE LATERAL PIECE TO THE CAR ENDWALL W/6-10d NAILS. IF THE ENDWALL IS NON-NAILED, CROSS MEMBERS MUST BE INSTALLED AT THE END OF THE LOAD TO SUPPORT THE SPACER ASSEMBLIES.
5. A PLUS 3" TOLERANCE IS PERMISSIBLE FOR THE LOCATION OF THE WALL MEMBER AT THE 3" LEVEL. A MINUS 3" TOLERANCE IS PERMITTED FOR THE WALL MEMBER SHOWN AT 35", HOWEVER, IF THE WALL MEMBER IS LOCATED AT LESS THAN 35", A LOAD BEARING GATE MUST BE INSTALLED BETWEEN THE ODD PALLET UNIT AND THE ADJACENT CROSS MEMBERS ON EACH SIDE. SEE THE "LOAD BEARING GATE B" DETAIL ON PAGE 21.


KEY NUMBERS

- ① WALL MEMBER, ADJUSTABLE OR FIXED. MEMBERS MUST BE LOCATED AT THE SPECIFIED HEIGHTS ABOVE THE CAR FLOOR TO PROVIDE PROPER ALIGNMENT OF CROSS MEMBERS MARKED ⑤. SEE SPECIAL NOTE 5 AT LEFT.
- ② ANTI-SWAY BRACE (2 REQD). SEE THE "ANTI-SWAY BRACE" DETAIL ON PAGE 16. INSTALL BETWEEN LATERALLY ADJACENT PALLET UNITS. SEE GENERAL NOTES "M" AND "N" ON PAGE 2.
- ③ TOP-OF-LOAD ANTI-SWAY BRACE (2 REQD). SEE THE DETAIL ON PAGE 16. WIRE TIE TO LIFTING RINGS AS SHOWN BY THE "TIE WIRE APPLICATION" DETAIL ON PAGE 45. SEE SPECIAL NOTE 3 AT LEFT.
- ④ LOAD BEARING GATE (1 REQD). SEE THE "LOAD BEARING GATE A" DETAIL ON PAGE 18. SEE SPECIAL NOTE 5 AT LEFT.
- ⑤ CROSS MEMBER (5 REQD). SEE GENERAL NOTE "X" ON PAGE 3.
- ⑥ SPACER ASSEMBLY (2 REQD). SEE THE "SPACER ASSEMBLY" DETAIL ON PAGE 21 AND SPECIAL NOTES 4 AND 5 AT LEFT. WIRE TIE TO CROSS MEMBERS W/2 WRAPS OF NO. 14 GAGE WIRE AT EACH CORNER.

TYPICAL LCL (5 UNIT LOAD) IN A BOX CAR EQUIPPED WITH
MECHANICAL BRACING DEVICES HAVING ADJUSTABLE AND/OR FIXED WALL MEMBERS




SPACER ASSEMBLY



LOAD BEARING GATE B

TYPICAL LCL (5 UNIT LOAD) IN A BOX CAR EQUIPPED WITH MECHANICAL BRACING DEVICES HAVING ADJUSTABLE AND/OR FIXED WALL MEMBERS




ISOMETRIC VIEW

SPECIAL NOTES:

1. ONLY THE CENTER PORTION OF A 9'-2" WIDE CONVENTIONAL TYPE BOX CAR IS SHOWN TO PORTRAY THE STRUTTED GATE METHOD OF PARTIAL-LAYER BRACING. CARS OF OTHER WIDTHS CAN ALSO BE USED.
2. THE PROCEDURES FOR THE ADJUSTMENT OF A LOAD QUANTITY BY THE OMISSION OF THE TOP LAYER FROM ONE LOAD UNIT ARE SHOWN AS TYPICAL. THE PRINCIPLES MAY ALSO BE APPLIED FOR THE OMISSION OF THE TOP LAYER FROM TWO LOAD UNITS.
3. ONLY THE BLOCKING AND BRACING PIECES WHICH ARE NECESSARY TO PERMIT THE OMISSION OF THE UNITS FROM THE TOP LAYER ARE SHOWN. THE QUANTITY REQUIRED FOR DUNNAGE, PIECES SUCH AS THE NUMBER OF STRUTS OR THE NUMBER OF STRUT BRACING PIECES, WILL ALSO VARY DEPENDENT UPON THE QUANTITY TO BE LOADED.

KEY NUMBERS

- ① CENTER GATE FOR 1-HIGH (2 REOD). SEE THE "CENTER GATE B" DETAIL ON PAGE 17. SEE GENERAL NOTE "M" ON PAGE 2.
- ② CENTER GATE FOR 2-HIGH (1 REOD). SEE THE "CENTER GATE B" DETAIL ON PAGE 17.
- ③ STRUT, 2" X 6" BY CUT TO FIT (DOUBLED) (12 REOD). LAMINATE W/1-10d NAIL EVERY 6". POSITION BETWEEN THE CENTER GATES, PIECES MARKED ① AND ②, IN THE FIRST LAYER AND TOENAIL W/2-12d NAILS AT EACH END. SEE GENERAL NOTE "K" ON PAGE 2. SEE GENERAL NOTES "T" AND "U" ON PAGE 3.
- ④ GATE SUPPORT PIECE, 2" X 3" BY CAR WIDTH MINUS 1" (1 REOD). NAIL TO THE VERTICAL PIECES OF THE CENTER GATE USED IN THE SECOND LAYER W/3-10d NAILS AT EACH JOINT.
- ⑤ STRUT, 2" X 6" BY CUT TO FIT (DOUBLED) (12 REOD). LAMINATE W/1-10d NAIL EVERY 6". POSITION BETWEEN THE CENTER GATES, PIECES MARKED ① AND ②, IN THE SECOND LAYER AND TOENAIL W/2-12d NAILS AT EACH END.
- ⑥ VERTICAL STRUT BRACING, 2" X 4" BY CUT TO EXTEND 3" ABOVE THE TOP STRUT (AS REOD). NAIL TO THE STRUTS W/3-10d NAILS AT EACH JOINT.
- ⑦ HORIZONTAL STRUT BRACING, 2" X 4" BY CAR WIDTH MINUS 2" IN LENGTH (AS REOD). NAIL TO THE STRUTS W/3-10d NAILS AT EACH JOINT.



ISOMETRIC VIEW

SPECIAL NOTES:


1. ONLY THE CENTER PORTION OF A 9'-2" WIDE CONVENTIONAL TYPE BOXCAR IS SHOWN TO PORTRAY THE STRUTTED GATE METHOD OF PARTIAL-LAYER BRACING. CARS OF OTHER WIDTHS CAN ALSO BE USED.
2. THE PROCEDURES FOR THE ADJUSTMENT OF A LOAD QUANTITY BY THE OMISSION OF THE TOP LAYER FROM TWO LOAD UNITS ARE SHOWN AS TYPICAL. THE PRINCIPLES MAY ALSO BE APPLIED FOR THE OMISSION OF THE TOP LAYER FROM JUST ONE LOAD UNIT.
3. ONLY THE BLOCKING AND BRACING PIECES WHICH ARE NECESSARY TO PERMIT THE OMISSION OF THE UNITS FROM THE TOP LAYER ARE SHOWN. THE QUANTITY REQUIRED FOR DUNNAGE PIECES, SUCH AS THE NUMBER OF STRUTS OR THE NUMBER OF STRUT BRACING PIECES, WILL VARY DEPENDENT UPON THE QUANTITY TO BE LOADED.
4. TO PROTECT THE LADING FROM BEING PUNCTURED WHEN A SET OF VERTICAL STRUT BRACING IS INSTALLED ABOVE THE LOWER LAYER OF A LOAD, A SUITABLE LENGTH PAD OF 2" X 4" MATERIAL, SHOWN AS PIECE MARKED ⑦, MUST BE POSITIONED UNDER AND SECURED TO EACH APPLICABLE VERTICAL STRUT BRACING PIECE.

KEY NUMBERS

- ① CENTER GATE FOR 1-HIGH (2 REOD). SEE THE "CENTER GATE A" DETAIL ON PAGE 16.
- ② CENTER GATE FOR 2-HIGH (1 REOD). SEE THE "CENTER GATE A" DETAIL ON PAGE 16.
- ③ STRUT, 4" X 4" BY CUT TO FIT (12 REOD). TOENAIL TO PIECES MARKED ① AND ② IN THE FIRST LAYER W/2-16d NAILS AT EACH END. SEE GENERAL NOTE "K" ON PAGE 2. SEE GENERAL NOTES "T" AND "U" ON PAGE 3 AND SPECIAL NOTE 3 AT LEFT.
- ④ GATE SUPPORT PIECE, 2" X 4" BY CAR WIDTH MINUS 1" IN LENGTH (1 REOD). NAIL TO THE VERTICAL PIECES OF THE CENTER GATE USED IN THE SECOND LAYER W/3-10d NAILS AT EACH JOINT.
- ⑤ STRUT, 4" X 4" BY CUT TO FIT (12 REOD). TOENAIL TO PIECES MARKED ① AND ② IN THE SECOND LAYER W/2-16d NAILS AT EACH END.
- ⑥ VERTICAL STRUT BRACING, 2" X 4" BY CUT TO EXTEND 3" ABOVE THE TOP STRUT (12 REOD). NAIL TO THE STRUTS MARKED ⑤ W/3-10d NAILS AT EACH JOINT. TOENAIL TO THE STRUT BRACING PAD, PIECE MARKED ⑦, W/1-10d NAIL AT EACH JOINT. SEE SPECIAL NOTE 4 AT LEFT.
- ⑦ STRUT BRACING PAD, 2" X 4" BY LENGTH TO SUIT (2 REOD). POSITION UNDER THE VERTICAL STRUT BRACING AS SHOWN.
- ⑧ HORIZONTAL STRUT BRACING, 2" X 4" BY A LENGTH TO SUIT (4 REOD). NAIL TO THE STRUTS W/3-10d NAILS AT EACH JOINT.

SEPARATOR GATE (1 OR 2 REQD. AS APPLICABLE). SEE THE "SEPARATOR GATE A" DETAIL ON PAGE 25. POSITION AS SHOWN WITH THE VERTICAL PIECES AGAINST THE 45-1/2" DIMENSION OF THE PALLET UNIT.

STOP PIECE, 2" X 4" BY A LENGTH TO SUIT (2 REQD). POSITION SO AS TO BE IN CONTACT WITH THE ADJACENT PALLET UNIT AND SECURE BY NAILING THRU THE HORIZONTAL PIECES OF THE SEPARATOR GATE W/3-6d NAILS AT EACH JOINT. NOTE THAT STOP PIECES ARE ONLY REQUIRED ON SEPARATOR GATES WHICH ARE IN THE DOOR OPENING OR WITHIN 6" OF BEING IN THE DOOR OPENING.




TYPICAL COMBINATION LOAD PATTERN PLAN VIEW

11 LENGTHWISE PLUS 3 CROSSWISE LOAD UNITS ARE SHOWN.


SPECIAL NOTES:

1. A 50'-6" LONG BY 9'-2" WIDE CONVENTIONAL TYPE BOXCAR IS SHOWN. WIDER CARS AND CARS OF OTHER LENGTHS CAN BE USED.
2. THE PROCEDURES ON THIS PAGE AND ON PAGE 25 ARE PRESENTED TO PROVIDE A METHOD OF OBTAINING A LOAD QUANTITY WHICH MAY NOT BE READILY ATTAINABLE BY ANY OF THE OTHER METHODS OF ADJUSTING A LOAD QUANTITY SPECIFIED HEREIN, INCLUDING THE DEPICTED LCL PROCEDURES.
3. THE BLOCKING AND BRACING FOR THE COMBINATION LOAD, OTHER THAN SEPARATOR GATE "A", HAS NOT BEEN SHOWN. REFER TO THE APPLICABLE LOAD PAGES FOR BLOCKING AND BRACING SPECIFICATIONS. SEPARATOR GATE "A" MUST BE INSTALLED AT EVERY LOCATION WHERE THE DIRECTION OF THE UNITS CHANGE. THE GATE MUST BE POSITIONED SO THAT THE VERTICAL PIECES ARE AGAINST THE 45-1/2" DIMENSION OF THE UNITS.
4. A CHART FOR THE PALLET UNIT IS SHOWN ON THIS PAGE FOR THE VARIOUS QUANTITIES WHICH CAN BE ATTAINED BY THE COMBINATION LOAD METHOD, AND THE PATTERNS REQUIRED TO PROVIDE THESE QUANTITIES, ARE SPECIFIED. FOR COMPARISON PURPOSES, THE OTHER TYPE LOADS WHICH CAN BE USED TO ATTAIN A LIKE QUANTITY, OR A QUANTITY WITHIN THE RANGE OF THE COMBINATION LOAD METHOD, AS WELL AS THE APPROXIMATE LENGTH OF THE STRUTS, ARE ALSO INCLUDED IN THE CHART.

PALLET UNIT			
CAR LENGTH	UNITS PER LAYER	LOAD PATTERN	APPROX STRUT LENGTH
40'-6" CAR	24	LENGTHWISE LOAD ON PAGE 6	28"
	22	7 LONG AT 37-5/8" PLUS 4 AT 45-29/64"	25"
	20	CROSSWISE LOAD ON PAGE 8	25"
50'-6" CAR	30	LENGTHWISE LOAD ON PAGE 6	35"
	28	11 LONG AT 37-5/8" PLUS 3 AT 45-29/64"	46"
	26	9 LONG AT 37-5/8" PLUS 5 AT 45-29/64"	31"
	24	CROSSWISE LOAD ON PAGE 8	54"
60'-8" CAR	36	LENGTHWISE LOAD ON PAGE 6	44"
	34	10 LONG AT 37-5/8" PLUS 7 AT 45-29/64"	24"
	32	5 LONG AT 37-5/8" PLUS 11 AT 45-29/64"	30"
	30	CROSSWISE LOAD ON PAGE 8	39"



SEPARATOR GATE A




ISOMETRIC VIEW

SPECIAL NOTES:

1. A PARTIAL VIEW OF A 9'-2" WIDE CONVENTIONAL TYPE BOXCAR IS SHOWN. WIDER OR NARROWER CARS CAN BE USED.
2. A UNIT OMITTED FROM THE TOP LAYER OF A 2-LAYER LOAD IS SHOWN AS TYPICAL. THE PROCEDURES ARE ALSO APPLICABLE FOR THE OMISSION OF A TOP-LAYER PALLET UNIT FROM A 1-LAYER LOAD.
3. THE OMITTED-UNIT PROCEDURES SHOULD BE APPLIED NEAR THE CENTER OF THE CAR LENGTH, BUT NOT IN THE DOORWAY AREA. ALSO, THERE SHOULD BE AT LEAST ONE LOAD UNIT BETWEEN THE OMITTED UNIT AND A CENTER GATE.
4. ONLY THE BLOCKING AND BRACING FOR THE OMITTED UNIT IS SHOWN. REFER TO THE APPLICABLE LOAD PAGE FOR THE BLOCKING AND BRACING REQUIREMENTS FOR THE BALANCE OF THE LOAD.
5. THE REFERENCE DIMENSIONS GIVEN FOR THE CUT-TO-FIT PIECES ARE BASED ON AN INSIDE CAR WIDTH OF 9'-2". THESE DIMENSIONS WILL HAVE TO BE ADJUSTED WHEN LOADING CARS OF OTHER WIDTHS.
6. THE NAILING OF THE VARIOUS PARTS OF THE GATES WILL BE AS FOLLOWS: NAIL THE 2" X 4" OR 2" X 6" HORIZONTAL PIECE(S) TO THE 2" X 6" VERTICAL PIECES W/3-10d NAILS AT EACH JOINT. NAIL THE DOUBLED 2" X 4" GATE HOLD DOWN PIECES TO A 2" X 4" HORIZONTAL PIECE W/3-10d NAILS EACH LAYER. NAIL THE 2" X 2" STRUT LEDGER TO THE VERTICAL PIECES W/2-10d NAILS AT EACH JOINT.


KEY NUMBERS

- ① LOAD BEARING GATE (2 REOD, 1 RIGHT HAND AND 1 LEFT HAND). SEE THE "LOAD BEARING GATE B" DETAIL BELOW. NAIL TO THE FILLER PIECE, PIECE MARKED ③ W/3-10d NAILS.
- ② ANTI-SWAY BEARING PIECE, 2" X 6" X 54" (1 REOD).
- ③ FILLER PIECE, 2" X 6" X 34-5/8" (1 REOD). NAIL TO THE ANTI-SWAY BEARING PIECE, PIECE MARKED ②, W/5-10d NAILS.
- ④ STRUT, 4" X 4" BY CUT TO FIT (REF: 31-5/8") (6 REOD). TOENAIL TO PIECES MARKED ① W/2-16d NAILS AT EACH END.



LOAD BEARING GATE C

ONE RIGHT HAND AND ONE LEFT HAND GATE REQUIRED. A LEFT HAND GATE IS SHOWN. SEE SPECIAL NOTES 5 AND 6 ABOVE FOR NAILING GUIDANCE.




ISOMETRIC VIEW

SPECIAL NOTES:

1. A PARTIAL VIEW OF A 9'-2" WIDE CONVENTIONAL TYPE BOXCAR IS SHOWN. WIDER OR NARROWER CARS CAN BE USED.
2. A UNIT OMITTED FROM THE TOP LAYER OF A 2-LAYER LOAD IS SHOWN AS TYPICAL. THE PROCEDURES ARE ALSO APPLICABLE FOR THE OMISSION OF A PALLET UNIT FROM A 1-LAYER LOAD.
3. THE OMITTED-UNIT PROCEDURES SHOULD BE APPLIED NEAR THE CENTER OF THE CAR LENGTH, BUT NOT IN THE DOORWAY AREA. ALSO, THERE SHOULD BE A LEAST ONE LOAD UNIT BETWEEN THE OMITTED UNIT AND A CENTER GATE.
4. ONLY THE BLOCKING AND BRACING FOR THE OMITTED UNIT IS SHOWN. REFER TO THE APPLICABLE LOAD PAGE FOR THE BLOCKING AND BRACING REQUIREMENTS FOR THE BALANCE OF THE LOAD.
5. THE REFERENCE DIMENSIONS GIVEN FOR THE CUT-TO-FIT PIECES ARE BASED ON AN INSIDE CAR WIDTH OF 9'-2". THESE DIMENSIONS WILL HAVE TO BE ADJUSTED WHEN LOADING CARS OF OTHER WIDTHS.
6. THE NAILING OF THE VARIOUS PARTS OF THE GATES WILL BE AS FOLLOWS: NAIL THE 2" X 4" OR 2" X 6" HORIZONTAL PIECE(S) TO THE 2" X 6" VERTICAL PIECES W/3-10d NAILS AT EACH JOINT. NAIL THE DOUBLED 2" X 3" GATE HOLD DOWN PIECES TO A 2" X 4" HORIZONTAL PIECE W/2-10d NAILS EACH LAYER. NAIL THE 2" X 2" STRUT LEDGERS TO THE VERTICAL PIECES W/2-10d NAILS AT EACH JOINT.


KEY NUMBERS

- ① SUPPORT PIECE, 2" X 6" X 45-1/2" (2 REQD). POSITION BENEATH THE OUTER VERTICAL PIECES OF THE LOAD BEARING GATE, PIECE MARKED ②.
- ② LOAD BEARING GATE (2 REQD, 1 RIGHT HAND AND 1 LEFT HAND). SEE THE "LOAD BEARING GATE C" DETAIL BELOW. NAIL TO PIECE MARKED ④ W/3-10d NAILS. TOENAIL TO THE SUPPORT PIECE, PIECE MARKED ①, W/2-10d NAILS AT EACH JOINT. CAUTION: USE CARE NOT TO TOENAIL INTO A CONTAINER.
- ③ BEARING PIECE, 2" X 6" X 60" (1 REQD).
- ④ FILLER PIECE, 2" X 6" X 42-1/2" (1 REQD). NAIL TO THE BEARING PIECE, PIECE MARKED ③, W/5-10d NAILS.
- ⑤ STRUT, 4" X 4" BY CUT TO FIT (REF: 39-1/2") (6 REQD). TOENAIL TO PIECES MARKED ② W/2-16d NAILS AT EACH END.



LOAD BEARING GATE D

ONE RIGHT HAND AND ONE LEFT HAND GATE REQUIRED. A LEFT HAND GATE IS SHOWN. SEE SPECIAL NOTES 5 AND 6 ABOVE FOR NAILING GUIDANCE.




SEE GENERAL NOTES "D" AND "G" ON PAGE 2.


ISOMETRIC VIEW

KEY NUMBERS

- ① ANTI-SWAY BRACE (7 REOD). SEE THE DETAIL ON PAGE 16. INSTALL BETWEEN LATERALLY ADJACENT PALLET UNITS. SEE GENERAL NOTES "M" AND "N" ON PAGE 2.
- ② TOP-OF-LOAD ANTI-SWAY BRACE (3 REOD). SEE THE DETAIL ON PAGE 16. WIRE TIE TO PALLET UNITS AS SHOWN BY THE "TIE WIRE APPLICATION" DETAIL ON PAGE 45.
- ③ STRAPPING BOARD, 2" X 6" X 31" (48 REOD/6 PER PALLET UNIT). POSITION AS SHOWN ABOVE AND IN THE "SECTION F-F" VIEW AT LEFT.
- ④ REINFORCING STRAP, 1-1/4" X .035" X 16'-0" LONG (REF) STEEL STRAPPING (24 REOD). INSTALL TO ENCIRCLE THE PALLET UNIT AND THE STRAPPING BOARDS. SECURE TO A STRAPPING BOARD W/3 STAPLES.
- ⑤ SEAL FOR 1-1/4" STRAPPING (48 REOD/2 PER STRAP). DOUBLE CRIMP EACH SEAL. SEE GENERAL NOTE "O" ON PAGE 2.
- ⑥ RISER ASSEMBLY (2 REOD). SEE THE "RISER ASSEMBLY A" DETAIL ON PAGE 29.
- ⑦ RISER ASSEMBLY (2 REOD). SEE THE "RISER ASSEMBLY B" DETAIL ON PAGE 29.
- ⑧ STOP PIECE (4 REOD). SEE THE "RISER ASSEMBLY" DETAILS ON PAGE 29 FOR LOCATION AND NAILING GUIDANCE.



SECTION F-F





SPECIAL NOTES FOR LOAD:

1. A 9'-2" WIDE CONVENTIONAL TYPE WOOD-LINED BOXCAR IS SHOWN. CARS OF OTHER WIDTHS CAN BE USED.
2. ONLY THE BLOCKING AND BRACING FOR THE RISER METHOD OF PARTIAL-LAYER BRACING IS SHOWN. REFER TO THE APPLICABLE LOAD PAGE FOR THE BLOCKING AND BRACING REQUIREMENTS FOR THE BALANCE OF THE LOAD.


SPECIAL NOTES FOR RISER ASSEMBLY:

1. A TWO-THIRDS HEIGHT RISER IS SHOWN AS RISER ASSEMBLY "A" AND AS PIECE MARKED ⑥ IN THE LOAD ON PAGE 28. THE RISER IS CONSTRUCTED TO BE 25" IN HEIGHT AFTER THE DECKING IS IN PLACE. NOTE: A PLUS OR MINUS 1" TOLERANCE IS PERMISSIBLE.
2. A ONE-THIRD HEIGHT RISER IS SHOWN AS RISER ASSEMBLY "B" AND AS PIECE MARKED ⑦ IN THE LOAD ON PAGE 28. THE RISER IS CONSTRUCTED TO BE 14" IN HEIGHT AFTER THE DECKING IS IN PLACE. NOTE: A PLUS OR MINUS 1" TOLERANCE IS PERMISSIBLE.





INDICATES A TYPICAL ANCHOR DEVICE FOR 1-1/4" STRAPPING. SEE SPECIAL NOTE 4 BELOW.



SEE GENERAL NOTE "G" ON PAGE 2.


ISOMETRIC VIEW

SPECIAL NOTES:

1. A 9'-4" WIDE ALL-METAL BOXCAR EQUIPPED WITH STRAP ANCHOR DEVICES AND HAVING AN AAR MECHANICAL DESIGNATION CLASS OF XL IS SHOWN. CARS OF OTHER WIDTHS CAN BE USED.
2. THE BULKHEAD GATE METHOD OF PARTIAL-LAYER BRACING IS SHOWN IN A LOAD HAVING THE 37-5/8" DIMENSION OF THE PALLET POSITIONED ACROSS THE CAR. THE PROCEDURES MAY ALSO BE USED FOR LOADS HAVING THE 37-5/8" DIMENSION POSITIONED LENGTHWISE IN THE CAR. NOTE THAT CRIB FILL "A" WILL BE USED IN LIEU OF ANTI-SWAY BRACES, PIECE MARKED ①.
3. A BULKHEAD GATE USED IN CONJUNCTION WITH THREE BULKHEAD STRAPS WILL RETAIN UP TO 7,500 POUNDS OF LADING (3 PALLET UNITS). A BULKHEAD GATE WITH TWO STRAPS WILL RETAIN NOT MORE THAN 5,000 POUNDS (2 PALLET UNITS). IF ONLY TWO STRAPS ARE USED, THEY MUST BE APPLIED OVER THE UPPER AND LOWER STRAPPING BOARDS.
4. THE ANCHOR DEVICES TO BE USED FOR THE ATTACHMENT OF THE BULKHEAD STRAPS MUST BE LOCATED AT LEAST 36" TOWARD THE CAR ENDWALL FROM THE OPPOSITE-THE-LOAD SIDE OF THE BULKHEAD GATE. IF THE ANCHOR DEVICES IN THE CAR BEING LOADED ARE NOT LOCATED NEAR ENOUGH TO THE END OF THE CAR SO THAT THE 36" REQUIREMENT CAN BE SATISFIED, IT WILL BE NECESSARY TO INSTALL GATES AND STRUTS AT THE END OF THE CAR. THESE GATES WILL BE 1-HIGH GATES AND WILL BE INSTALLED SIMILAR TO THE STRUTTED GATE METHOD SHOWN ON PAGE 23 FOR AN EVEN QUANTITY OF UNITS, OR THE PALLET UNIT OMITTED PROCEDURES AS SHOWN ABOVE AND ON PAGE 27 FOR A SINGLE UNIT.
5. THE STRAPPING BOARDS ON A BULKHEAD GATE ARE TO BE ALIGNED AS NEARLY AS POSSIBLE WITH THE ANCHOR DEVICES IN THE CAR TO WHICH THE BULKHEAD STRAPS ARE ATTACHED. TOLERANCES ARE SPECIFIED ON THE END VIEW OF THE BULKHEAD GATE ON PAGE 31 FOR THE LOCATION OF THE STRAPPING BOARDS IN RELATION TO THE LOCATION OF THE HORIZONTAL PIECES. THE STRAPPING BOARDS SHOULD BE LOCATED WITHIN THESE TOLERANCES. IF THIS IS NOT POSSIBLE, ADDITIONAL HORIZONTAL PIECES MUST BE APPLIED, AS NECESSARY TO PROVIDE PROPER BEARING AGAINST THE CONTAINERS.

KEY NUMBERS


- ① ANTI-SWAY BRACE (4 REOD). SEE THE "ANTI-SWAY BRACE" DETAIL ON PAGE 16. INSTALL BETWEEN LATERALLY ADJACENT PALLET UNITS. SEE GENERAL NOTES "M" AND "N" ON PAGE 2.
- ② SUPPORT PIECE, 2" X 6" X 45-1/2" (2 REOD). POSITION SO AS TO BE UNDER THE VERTICAL PIECES OF THE LOAD BEARING GATE, PIECE MARKED ③.
- ③ LOAD BEARING GATE (2 REOD, 1 RIGHT HAND AND 1 LEFT HAND). SEE THE "LOAD BEARING GATE 0" DETAIL ON PAGE 27. NAIL TO THE FILLER PIECE, PIECE MARKED ⑤, W/3-10d NAILS. TOENAIL TO THE SUPPORT PIECE, PIECE MARKED ②, W/2-10d NAILS AT EACH JOINT. CAUTION: USE CARE NOT TO TOENAIL INTO A CONTAINER.
- ④ ANTI-SWAY BEARING PIECE, 2" X 6" X 60" (1 REOD).
- ⑤ FILLER PIECE, 2" X 6" X 44" (1 REOD). NAIL TO THE ANTI-SWAY BEARING PIECE, PIECE MARKED ④, W/5-10d NAILS.
- ⑥ STRUT, 4" X 4" BY CUT TO FIT (REF: 39-1/2") (AS REOD). TOENAIL TO PIECES MARKED ③ W/2-16d NAILS AT EACH END.
- ⑦ BULKHEAD STRAP, 1-1/4" X .031" OR .035" BY A LENGTH TO SUIT STEEL STRAPPING (3 REOD). INSTALL FROM 2 EQUAL LENGTH PIECES. ATTACH TO AN ANCHOR WITH 1 SEAL. SEE THE "STRAP APPLICATION PLAN VIEW" ON PAGE 31 FOR INSTALLATION GUIDANCE. SEE SPECIAL NOTES 3 AND 4 AT LEFT.
- ⑧ BUNDLING STRAP, 1-1/4" X .035" X 15'-6" LONG (REF) STEEL STRAPPING (2 REOD). ENCIRCLE THE PALLET UNIT, THE HORIZONTAL PIECES OF THE BULKHEAD GATE, PIECE MARKED ③. TENSION AND SEAL AFTER TENSIONING THE BULKHEAD STRAPS, PIECES MARKED ⑦.
- ⑨ BULKHEAD GATE (1 REOD). SEE THE DETAIL ON PAGE 31. SEE SPECIAL NOTE 2 AT LEFT.
- ⑩ SEAL FOR 1-1/4" STRAPPING (14 REOD, 4 PER BULKHEAD STRAP, PIECE MARKED ⑦, AND 1 PER BUNDLING STRAP, PIECE MARKED ⑧). DOUBLE CRIMP EACH SEAL. SEE GENERAL NOTE "O" ON PAGE 2.
- ⑪ STRAP RETAINER, 2" X 4" BY A LENGTH TO SUIT (2 REOD). NAIL TO THE BULKHEAD GATE W/2-12d NAILS ABOVE AND BELOW EACH BULKHEAD STRAP.



STRAP APPLICATION PLAN VIEW

THE ANTI-SWAY BRACES, PIECES MARKED ①, HAVE BEEN OMITTED FOR CLARITY.

SUPPORT PIECE, 2" X 4" BY LATERAL VOID PLUS 18" (1 REOD). NAIL TO THE RISER PIECES W/3-10d NAILS AT EACH JOINT.




HORIZONTAL PIECE, 2" X 6" BY LOAD WIDTH MINUS 1" (3 REOD). NAIL TO THE VERTICAL PIECES W/3-10d NAILS AT EACH JOINT.

VERTICAL PIECE, 2" X 6" X 38" (4 REOD).

STRAPPING BOARD, 2" X 6" BY LOAD WIDTH MINUS 2" (3 REOD). NAIL TO THE VERTICAL PIECES W/3-10d NAILS AT EACH JOINT. SEE SPECIAL NOTE 5 ON PAGE 30.

BULKHEAD GATE

RISER PIECE, 2" X 4" X 38" (2 REOD). NAIL TO THE SPACER PIECES W/3-10d NAILS AT EACH JOINT.




SPACER PIECE, 2" X 6" BY CUT TO FIT (TRIPLED) (3 REOD). NAIL THE FIRST PIECE TO A HORIZONTAL PIECE W/5-10d NAILS. NAIL EACH ADDITIONAL PIECE IN LIKE MANNER.

END VIEW

(SPECIAL NOTES CONTINUED)

5. THE CENTER CLEAT, SHOWN AS PIECE MARKED ⑥, WILL BE 28" LONG FOR AN 8'-6" CAR, 36" LONG FOR A 9'-4" WIDE CAR. ADJUST THE LENGTH PROPORTIONATELY FOR CARS OF OTHER WIDTHS.




ISOMETRIC VIEW

KEY NUMBERS

SPECIAL NOTES:

1. A 9'-2" WIDE CONVENTIONAL WOOD-LINED BOXCAR IS SHOWN. WOOD-LINED CARS OF OTHER WIDTHS CAN BE USED.
2. PARTIAL-LAYER BRACING MAY BE APPLIED FOR ANY OF THE CONVENTIONAL CARLOADS DEPICTED HEREIN. THE PIECES MARKED ④ SHOULD BE LOCATED SO AS TO BEAR AGAINST THE PALLET UNITS IN THE SAME LOCATION AS THE HORIZONTAL PIECES OF A CENTER GATE.
3. THE K-BRACE METHOD OF PARTIAL-LAYER (TIER) BRACING SHOWN MAY BE USED IN WOOD-LINED CARS FOR THE SECUREMENT OF A PARTIAL TOP TIER, BE IT A SECOND TIER OR FIRST. THE TYPE "A" K-BRACE SHOWN IS ADEQUATE FOR RETAINING A PARTIAL TIER OF NOT MORE THAN 8,000 POUNDS. IF IT IS NECESSARY TO BLOCK A HEAVIER LOAD, REFER TO THE DETAILS ON PAGES 33, 34, AND 35 FOR SELECTION OF THE APPLICABLY SIZED K-BRACE TO USE AND THE DESIGN SPECIFICATIONS FOR THE BRACE.
4. CAUTION: SOME CARS ARE NOT SUITED FOR THE APPLICATION OF "PARTIAL-LAYER BRACING" BECAUSE THE LENGTH OF THE PARTIAL TIER TO BE SHIPPED AND/OR THE SIZE OR CONFIGURATION OF THE CAR DOORS WILL NOT PERMIT PROPER INSTALLATION OF THE SPECIFIED K-BRACE DUNNAGE. PIECES MARKED ③, ④, ⑤, ⑦, ⑨, AND ⑫ MUST BE SUPPORTED AT THE SIDES OF A CAR BY A CAR SIDEWALL. IT IS ALRIGHT FOR THE ENDS OF THE DIAGONAL BRACES MARKED ⑩ TO BEAR IN FRONT OF A DOOR OPENING, HOWEVER, THE ADJACENT PIECE MARKED ⑧ MUST BE DOUBLED AND EXTENDED ACROSS AND FAR ENOUGH PAST THE DOOR OPENING (REF: 50"), TO PROVIDE FOR THE SPECIFIED NAILING OF EACH PIECE. LAMINATE THE SECOND PIECE OF THE DOUBLED PIECE MARKED ⑧ TO THE FIRST W/16-16d NAILS. CLINCH THOSE NAILS WHICH PROTRUDE THRU THE HORIZONTAL WALL CLEAT WITHIN THE DOOR OPENING. NOTE THAT THE DIAGONAL BRACE WILL BE 49-1/8" LONG IN LIEU OF 50-1/4" WHEN PIECE MARKED ⑩ IS DOUBLED.


(CONTINUED ABOVE)



DIAGONAL BRACE

SEE SPECIAL NOTE 2 ABOVE.

- ① ANTI-SWAY BRACE (2 REOD). SEE THE "ANTI-SWAY BRACE" DETAIL ON PAGE 14. INSTALL BETWEEN LATERALLY ADJACENT PALLET UNITS. SEE GENERAL NOTE "M" ON PAGE 2 AND SPECIAL NOTE 3 AT LEFT.
- ② TOP-OF-LOAD ANTI-SWAY BRACE (1 REOD). SEE THE "TOP-OF-LOAD ANTI-SWAY BRACE" DETAIL ON PAGE 16. WIRE TIE TO PALLET UNITS AS SHOWN BY THE "TIE WIRE APPLICATION" DETAIL ON PAGE 45. NOTE THAT THE QUANTITY IS ONLY FOR THE PARTIAL-TIER UNITS.
- ③ SUPPORT CLEAT, 2" X 4" X 9" (2 REOD). POSITION HORIZONTALLY AS SHOWN. NAIL TO THE CAR SIDEWALL W/3-12d NAILS.
- ④ HORIZONTAL PIECE, 2" X 6" BY CAR WIDTH IN LENGTH (CUT-TO-FIT) (2 REOD). NAIL TO THE CROSS CAR BRACE, PIECE MARKED ⑤ W/1-12d NAIL EVERY 6". SEE SPECIAL NOTE 2 AT LEFT.
- ⑤ CROSS CAR BRACE, 4" X 4" BY CAR WIDTH IN LENGTH (CUT-TO-FIT) (2 REOD).
- ⑥ CENTER CLEAT, 2" X 4" X 36" (2 REOD). NAIL TO THE CROSS CAR BRACE, PIECE MARKED ⑤, W/7-16d NAILS. SEE SPECIAL NOTE 5 AT LEFT.
- ⑦ SPACER CLEAT, 2" X 4" X 25" (2 REOD). NAIL TO THE CAR SIDEWALL W/4-12d NAILS.
- ⑧ HORIZONTAL WALL CLEAT, 2" X 6" X 72" (4 REOD). NAIL TO THE CAR SIDEWALL W/16-12d NAILS.
- ⑨ POCKET CLEAT, 2" X 6" X 12" (2 REOD). NAIL TO THE HORIZONTAL WALL CLEAT, PIECE MARKED ⑧, W/4-16d NAILS.
- ⑩ DIAGONAL BRACE, 2" X 4" X 50-1/4" (4 REOD). SEE THE DETAIL AT LEFT FOR BEVEL CUTS REQUIRED. TOENAIL TO THE CROSS CAR BRACE, PIECE MARKED ⑤ AND TO THE HORIZONTAL WALL CLEAT, PIECE MARKED ⑧, W/2-16d NAILS AT EACH END.
- ⑪ BACK-UP CLEAT, 2" X 4" X 18" (2 REOD). NAIL TO THE HORIZONTAL WALL CLEAT, PIECE MARKED ⑧, W/8-16d NAILS.
- ⑫ HOLD-DOWN CLEAT, 2" X 4" X 18" (2 REOD). NAIL TO THE CAR SIDEWALL W/5-12d NAILS.




ISOMETRIC VIEW

SPECIAL NOTES:

1. THE TYPE "B" K-BRACE SHOWN IS ADEQUATE FOR RETAINING A PARTIAL TIER OF NOT MORE THAN 14,000 POUNDS. THIS WILL BE NOT MORE THAN SIX PALLET UNITS. IF IT IS NECESSARY TO BLOCK A HEAVIER LOAD, REFER TO THE DETAILS ON PAGES 34 AND 35 FOR SELECTION OF THE APPLICABLY SIZED K-BRACE TO USE AND THE DESIGN SPECIFICATIONS FOR THE BRACE. IF THE PARTIAL TIER TO BE BRACED WEIGHS 8,000 POUNDS OR LESS, THE TYPE "A" K-BRACE DEPICTED ON PAGE 32 MAY BE USED.
2. CAUTION: SOME CARS ARE NOT SUITED FOR THE APPLICATION OF "PARTIAL-LAYER BRACING" BECAUSE THE LENGTH OF THE PARTIAL TIER TO BE SHIPPED AND/OR THE SIZE OR CONFIGURATION OF THE CAR DOORS WILL NOT PERMIT PROPER INSTALLATION OF THE SPECIFIED K-BRACE DUNNAGE. PIECES MARKED ①, ②, ③, ⑥, ⑨, ⑩, AND ⑪, MUST BE SUPPORTED AT THE SIDES OF A CAR BY A CAR SIDEWALL. IT IS ALLRIGHT FOR THE ENDS OF THE DIAGONAL BRACES MARKED ⑦ TO BEAR IN FRONT OF A DOOR OPENING, HOWEVER, THE ADJACENT PIECE MARKED ⑤ MUST BE DOUBLED AND EXTENDED ACROSS AND FAR ENOUGH PAST THE DOOR OPENING (REF: 54") TO PROVIDE FOR THE SPECIFIED NAILING OF EACH PIECE. LAMINATE THE SECOND PIECE OF THE DOUBLED PIECE MARKED ⑤ TO THE FIRST W/16-16d NAILS. CLINCH THOSE NAILS WHICH PROTRUDE THRU THE HORIZONTAL WALL CLEAT WITHIN THE DOOR OPENING. NOTE THAT THE DIAGONAL BRACE WILL BE 49-1/8" LONG IN LIEU OF 50-1/4" WHEN PIECE MARKED ⑤ IS DOUBLED.
3. THE CENTER CLEAT, SHOWN AS PIECE MARKED ④, WILL BE 28" LONG FOR AN 8'-6" WIDE CAR, 36" LONG FOR A 9'-2", AND 38" LONG FOR A 9'-4" WIDE CAR. ADJUST THE LENGTH PROPORTIONATELY FOR CARS OF OTHER WIDTHS.
4. REFER TO PAGE 32 FOR A TYPICAL INSTALLATION OF A K-BRACE.

KEY NUMBERS

- ① SUPPORT CLEAT, 2" X 4" X 9" (2 REOD). POSITION HORIZONTALLY AS SHOWN. NAIL TO THE CAR SIDEWALL W/3-12d NAILS. SEE SPECIAL NOTE 2 AT LEFT.
- ② LOAD BEARING PIECE, 2" X 6" BY CAR WIDTH (CUT TO FIT) (2 REOD). NAIL TO THE CROSS CAR BRACE, PIECE MARKED ③, W/1-12d NAIL EVERY 6". SEE GENERAL NOTE "M" ON PAGE 2.
- ③ CROSS CAR BRACE, 4" X 4" BY CAR WIDTH (CUT TO FIT) (2 REOD).
- ④ CENTER CLEAT, 2" X 4" X 36" (2 REOD). NAIL TO THE CROSS CAR BRACE, PIECE MARKED ③, W/7-16d NAILS. SEE SPECIAL NOTE 3 AT LEFT.
- ⑤ HORIZONTAL WALL CLEAT, 2" X 6" X 72" (4 REOD). NAIL TO THE CAR SIDEWALL W/16-12d NAILS.
- ⑥ POCKET CLEAT, 2" X 6" X 18" (4 REOD). NAIL TO THE HORIZONTAL WALL CLEAT, PIECE MARKED ⑤, W/7-16d NAILS.
- ⑦ DIAGONAL BRACE, 4" X 4" X 50-1/4" (4 REOD). SEE THE DETAIL BELOW FOR BEVEL-CUTS REQUIRED. TOENAIL TO THE CROSS CAR BRACE, PIECE MARKED ③, AND TO THE HORIZONTAL WALL CLEAT, PIECE MARKED ⑤, W/1-60d NAIL AT EACH END.
- ⑧ BACK-UP CLEAT, 2" X 6" X 30" (4 REOD). NAIL TO THE HORIZONTAL WALL CLEAT, PIECE MARKED ⑤, W/14-16d NAILS.
- ⑨ SPACER CLEAT, 2" X 4" X 25" (2 REOD). NAIL TO THE CAR SIDEWALL W/4-12d NAILS.
- ⑩ HOLD-DOWN CLEAT, 2" X 6" X 18" (2 REOD). NAIL TO THE CAR SIDEWALL W/5-12d NAILS.
- ⑪ VERTICAL BACK-UP CLEAT, 2" X 6" X BY UNIT HEIGHT (2 REOD). NAIL TO THE CAR SIDEWALL W/8-12d NAILS.




DIAGONAL BRACE

SEE SPECIAL NOTE 2 ABOVE.

THIS BEARING SURFACE MUST BE POSITIONED SO AS TO BE IN CONTACT WITH A CROSS CAR BRACE, PIECE MARKED ③, OR A HORIZONTAL WALL CLEAT, PIECE MARKED ⑤.

TYPE "B" K-BRACE



ISOMETRIC VIEW

KEY NUMBERS

- ① SUPPORT CLEAT, 2" X 4" X 9" (2 REOD). POSITION HORIZONTALLY AS SHOWN. NAIL TO THE CAR SIDEWALL W/3-12d NAILS. SEE SPECIAL NOTE 2 AT LEFT.
- ② LOAD BEARING PIECE, 2" X 6" BY CAR WIDTH (CUT TO FIT) (2 REOD). NAIL TO THE CROSS CAR BRACE, PIECE MARKED ③, W/1-12d NAIL EVERY 6". SEE GENERAL NOTE "M" ON PAGE 2.
- ③ CROSS CAR BRACE, 4" X 4" BY CAR WIDTH (CUT TO FIT) (2 REOD).
- ④ CENTER CLEAT, 2" X 4" X 36" (2 REOD). NAIL TO THE CROSS CAR BRACE, PIECE MARKED ③, W/7-16d NAILS. SEE SPECIAL NOTE 3 AT LEFT.
- ⑤ HORIZONTAL WALL CLEAT, 2" X 6" BY CUT TO FIT (4 REOD). A CLEAT WILL BE OF A LENGTH AS NECESSARY TO EXTEND ACROSS AND FAR ENOUGH PAST THE DOOR OPENINGS TO CONTACT PIECE MARKED ③ OF THE K-BRACE IN THE OPPOSITE END OF THE CAR. NAIL TO THE CAR SIDEWALL W/40-12d NAILS.
- ⑥ POCKET CLEAT, 2" X 6" X 18" (DOUBLED) (4 REOD). NAIL THE FIRST PIECE TO THE HORIZONTAL WALL CLEAT, PIECE MARKED ⑤, W/7-16d NAILS. NAIL THE SECOND PIECE TO THE FIRST IN A LIKE MANNER.
- ⑦ DIAGONAL BRACE, 4" X 4" X 50-1/4" (4 REOD). SEE THE DETAIL BELOW FOR BEVEL-CUTS REQUIRED. TOENAIL TO THE CROSS CAR BRACE, PIECE MARKED ③, AND TO THE HORIZONTAL WALL CLEAT, PIECE MARKED ⑤. W/1-60d NAIL AT EACH END.
- ⑧ BACK-UP CLEAT, 2" X 6" X 30" (4 REOD). NAIL TO THE HORIZONTAL WALL CLEAT, PIECE MARKED ⑤, W/14-16d NAILS.
- ⑨ SPACER CLEAT, 2" X 4" X 25" (2 REOD). NAIL TO THE CAR SIDEWALL W/5-12d NAILS.
- ⑩ HOLD-DOWN CLEAT, 2" X 4" X 18" (2 REOD). NAIL TO THE CAR SIDEWALL W/5-12d NAILS.


SPECIAL NOTES:

1. THE TYPE "C" K-BRACE SHOWN IS ADEQUATE FOR RETAINING A PARTIAL TIER OF NOT MORE THAN 20,000 POUNDS. THIS WILL BE NOT MORE THAN NINE PALLET UNITS. IF IT IS NECESSARY TO BLOCK A HEAVIER LOAD, REFER TO THE DETAIL ON PAGE 35 FOR SELECTION OF THE APPLICABLY SIZED K-BRACE TO USE AND THE DESIGN SPECIFICATIONS FOR THE BRACE. IF THE PARTIAL TIER TO BE BRACED WEIGHS BETWEEN 8,000 POUNDS AND 14,000 POUNDS, THE TYPE "B" K-BRACE DEPICTED ON PAGE 33 MAY BE USED. IF THE PARTIAL TIER TO BE BRACED WEIGHS 8,000 OR LESS, THE TYPE "A" K-BRACE DEPICTED ON PAGE 32 WILL BE ADEQUATE.
2. CAUTION: SOME CARS ARE NOT SUITED FOR THE APPLICATION OF "PARTIAL-LAYER BRACING" BECAUSE THE LENGTH OF THE PARTIAL TIER TO BE SHIPPED AND/OR THE SIZE OR CONFIGURATION OF THE CAR DOORS WILL NOT PERMIT PROPER INSTALLATION OF THE SPECIFIED K-BRACE DUNNAGE. PIECES MARKED ①, ②, ③, ⑥, ⑨, AND ⑩ MUST BE SUPPORTED AT THE SIDES OF A CAR BY A CAR SIDEWALL. IT IS ALRIGHT FOR THE ENDS OF THE DIAGONAL BRACES MARKED ⑦ TO BEAR IN FRONT OF A DOOR OPENING, HOWEVER, THE ADJACENT PIECE MARKED ⑤ MUST BE DOUBLED. LAMINATE THE SECOND PIECE TO THE FIRST W/40-16d NAILS. CLINCH THOSE NAILS WHICH PROTRUDE THRU THE HORIZONTAL WALL CLEAT WITHIN THE DOOR OPENING. NOTE THAT THE DIAGONAL BRACE WILL BE 49-1/8" LONG IN LIEU OF 50-1/4" WHEN PIECE MARKED ⑤ IS DOUBLED.
3. THE CENTER CLEAT, SHOWN AS PIECE MARKED ④, WILL BE 28" LONG FOR AN 8'-6" WIDE CAR, 36" LONG FOR A 9'-2", AND 38" LONG FOR A 9'-4" WIDE CAR. ADJUST THE LENGTH PROPORTIONATELY FOR CARS OF OTHER WIDTHS.

(CONTINUED AT RIGHT)

(SPECIAL NOTES CONTINUED)

4. CAUTION: A TYPE "C" K-BRACE MUST BE USED IN BOTH ENDS OF THE CAR; THE BRACE IS NOT DESIGNED FOR USE IN ONLY ONE END. NOTE THAT EXCEPT FOR PIECES MARKED 5, THE QUANTITIES SPECIFIED ARE APPLICABLE ONLY FOR THE BRACE IN ONE END.



DIAGONAL BRACE

SEE SPECIAL NOTE 2 ABOVE.


THIS BEARING SURFACE MUST BE POSITIONED SO AS TO BE IN CONTACT WITH A CROSS CAR BRACE, PIECE MARKED ③, OR A HORIZONTAL WALL CLEAT, PIECE MARKED ⑤.

TYPE "C" K-BRACE

(SPECIAL NOTES CONTINUED)

4. CAUTION: A TYPE "D" K-BRACE MUST BE USED IN BOTH ENDS OF THE CAR; THE BRACE IS NOT DESIGNED FOR USE IN ONLY ONE END. NOTE THAT EXCEPT FOR PIECES MARKED ⑥ AND ⑩, THE QUANTITIES SPECIFIED ARE APPLICABLE ONLY FOR THE BRACE IN ONE END.

INDICATES DOOR OPENING.



ISOMETRIC VIEW


KEY NUMBERS

- ① SUPPORT CLEAT, 2" X 4" X 9" (2 REED). POSITION HORIZONTALLY AS SHOWN. NAIL TO THE CAR SIDEWALL W/3-12d NAILS. SEE SPECIAL NOTE 2 AT THE LEFT.
- ② LOAD BEARING PIECE, 2" X 6" BY CAR WIDTH (CUT TO FIT) (2 REED). NAIL TO THE CROSS CAR BRACE, PIECE MARKED ③, W/1-12d NAIL EVERY 6". SEE GENERAL NOTE "M" ON PAGE 2.
- ③ CROSS CAR BRACE, 4" X 4" BY CAR WIDTH (CUT TO FIT) (2 REED).
- ④ HORIZONTAL PIECE, 2" X 6" BY CAR WIDTH (CUT TO FIT) (2 REED). NAIL TO THE CROSS CAR BRACE, PIECE MARKED ③, W/1-12d NAIL EVERY 6".
- ⑤ CENTER CLEAT, 2" X 4" X 36" (2 REED). NAIL TO THE HORIZONTAL PIECE, PIECE MARKED ④, W/7-16d NAILS. SEE SPECIAL NOTE 3 AT LEFT.
- ⑥ HORIZONTAL WALL CLEAT, 2" X 6" BY CUT TO FIT (4 REED). A CLEAT WILL BE OF A LENGTH AS NECESSARY TO EXTEND ACROSS AND FAR ENOUGH PAST THE DOOR OPENINGS TO CONTACT PIECE MARKED ④ OF THE K-BRACE IN THE OPPOSITE END OF THE CAR. NAIL TO THE CAR SIDEWALL W/40-12d NAILS.
- ⑦ POCKET CLEAT, 2" X 6" X 36" (4 REED). NAIL TO THE HORIZONTAL WALL CLEAT, PIECE MARKED ⑥, W/10-16d NAILS.
- ⑧ POCKET CLEAT, 2" X 6" X 24" (4 REED). NAIL TO THE POCKET CLEAT, PIECE MARKED ⑦, W/7-16d NAILS.
- ⑨ DIAGONAL BRACE, 4" X 4" X 71" (4 REED). SEE THE DETAIL BELOW FOR BEVEL-CUTS REQUIRED. TOENAIL TO THE HORIZONTAL PIECE, PIECE MARKED ④, AND TO THE HORIZONTAL WALL CLEAT, PIECE MARKED ⑥, W/1-60d NAIL AT EACH END.
- ⑩ BACK-UP CLEAT, 2" X 6" BY CUT TO FIT (4 REED). A CLEAT WILL BE OF A LENGTH AS NECESSARY TO EXTEND TO CONTACT THE DIAGONAL BRACE, PIECE MARKED ⑨, IN THE OPPOSITE END OF THE CAR. NAIL TO THE HORIZONTAL WALL CLEAT, PIECE MARKED ⑥, W/18-16d NAILS. CLINCH THOSE NAILS WHICH PROTRUDE THRU THE HORIZONTAL WALL CLEAT WITHIN THE DOOR OPENING, IF APPLICABLE.
- ⑪ SPACER CLEAT, 2" X 4" X 25" (2 REED). NAIL TO THE CAR SIDEWALL W/5-12d NAILS.
- ⑫ HOLD-DOWN CLEAT, 2" X 4" X 18" (2 REED). NAIL TO THE CAR SIDEWALL W/5-12d NAILS.

SPECIAL NOTES:

1. THE TYPE "D" K-BRACE SHOWN IS ADEQUATE FOR RETAINING A PARTIAL TIER OF NOT MORE THAN 25,000 POUNDS. THIS WILL BE NOT MORE THAN ELEVEN PALLET UNITS. IF THE PARTIAL TIER TO BE BRACED WEIGHS BETWEEN 14,000 POUNDS AND 20,000 POUNDS, THE TYPE "C" K-BRACE DEPICTED ON PAGE 34 MAY BE USED. FOR A PARTIAL TIER OF 8,000 POUNDS TO 14,000, THE TYPE "B" K-BRACE DEPICTED ON PAGE 33 MAY BE USED. IF THE PARTIAL TIER TO BE BRACED WEIGHS 8,000 POUNDS OR LESS, THE TYPE "A" K-BRACE DEPICTED ON PAGE 32 WILL BE ADEQUATE.
2. CAUTION: SOME CARS ARE NOT SUITED FOR THE APPLICATION OF "PARTIAL-LAYER BRACING" BECAUSE THE LENGTH OF THE PARTIAL TIER TO BE SHIPPED AND/OR THE SIZE OR CONFIGURATION OF THE CAR DOORS WILL NOT PERMIT PROPER INSTALLATION OF THE SPECIFIED K-BRACE DUNNAGE. PIECES MARKED ①, ②, ③, ④, ⑦, ⑧, ⑩, ⑪, AND ⑫ MUST BE SUPPORTED AT THE SIDES OF A CAR BY A CAR SIDEWALL. IT IS ALLRIGHT FOR THE ENDS OF THE DIAGONAL BRACES MARKED ⑨ TO BEAR IN FRONT OF A DOOR OPENING, HOWEVER, THE ADJACENT PIECE MARKED ⑥ MUST BE DOUBLED. LAMINATE THE SECOND PIECE TO THE FIRST W/40-16d NAILS. CLINCH THOSE NAILS WHICH PROTRUDE THRU THE HORIZONTAL WALL CLEAT WITHIN THE DOOR OPENING. NOTE THAT THE DIAGONAL BRACE WILL BE 70-1/4" LONG IN LIEU OF 71" LONG WHEN PIECE MARKED ⑥ IS DOUBLED.
3. THE CENTER CLEAT, SHOWN AS PIECE MARKED ⑤, WILL BE 28" LONG FOR AN 8'-6" WIDE CAR, 36" LONG FOR A 9'-2", AND 38" LONG FOR A 9'-4" WIDE CAR. ADJUST THE LENGTH PROPORTIONATELY FOR CARS OF OTHER WIDTHS.

(CONTINUED ABOVE)




DIAGONAL BRACE

SEE SPECIAL NOTE 2 ABOVE.

THIS BEARING SURFACE MUST BE POSITIONED SO AS TO BE IN CONTACT WITH A HORIZONTAL PIECE, PIECE MARKED ④.

TYPE "D" K-BRACE




ISOMETRIC VIEW

SPECIAL NOTES:

1. A 9'-2" WIDE WOOD-LINED CONVENTIONAL TYPE BOXCAR HAVING A WOOD OR NAILABLE METAL FLOOR IS SHOWN. CARS OF OTHER WIDTHS AND CARS HAVING METAL LININGS CAN BE USED.
2. THE LOAD SHOWN DEPICTING THE KNEE BRACE METHOD OF PARTIAL-LAYER BRACING IS TYPICAL. THE QUANTITY MAY BE ADJUSTED TO SUIT, PROVIDED THE LIMITATIONS OF THE KNEE BRACE AS SET FORTH IN SPECIAL NOTE 3 ARE NOT EXCEEDED; NOTE THAT THE PALLET UNITS MAY BE POSITIONED CROSSWISE, OR THEY MAY BE POSITIONED LENGTHWISE AS SHOWN.
3. A KNEE BRACE ASSEMBLY WILL BE USED FOR EACH ROW OF PALLET UNITS. ONE KNEE BRACE ASSEMBLY IS ADEQUATE FOR RETAINING A MAXIMUM LCL LOAD OF NOT MORE THAN 8,500 POUNDS.

KEY NUMBERS


- ① ANTI-SWAY BRACE (2 REQD). SEE THE "ANTI-SWAY BRACE" DETAIL ON PAGE 16. SEE GENERAL NOTE "M" ON PAGE 2.
- ② TOP-OF-LOAD ANTI-SWAY BRACE (2 REQD). SEE THE "TOP-OF-LOAD ANTI-SWAY BRACE" DETAIL ON PAGE 16. WIRE TIE TO THE LIFTING RINGS ON THE UNIT WITH NO. 14 GAGE WIRE AS TYPICALLY SHOWN BY THE "TIE WIRE APPLICATION" DETAIL ON PAGE 45.
- ③ KNEE BRACE ASSEMBLY (4 REQD). SEE THE "KNEE BRACE ASSEMBLY" DETAIL ON PAGE 37 FOR CONSTRUCTION AND NAILING SPECIFICATIONS.



KNEE BRACE ASSEMBLY

KEY LETTERS


- (A) VERTICAL PIECE, 2" X 6" X 48" (2 REOD).
- (B) HORIZONTAL PIECE, 2" X 6" X 37-5/8" (2 REOD). NAIL TO THE VERTICAL PIECE W/3-10d NAILS AT EACH JOINT. SEE GENERAL NOTES "L" AND "M" ON PAGE 2.
- (C) HORIZONTAL PIECE, 2" X 4" X 37-5/8" (1 REOD). NAIL TO THE VERTICAL PIECES W/2-10d NAILS AT EACH JOINT.
- (D) HOLD-DOWN CLEAT, 2" X 4" X 7" (2 REOD). SEE "VIEW A" ABOVE.
- (E) FLOOR CLEAT, 2" X 6" X 90" (2 REOD). ALIGN WITH A VERTICAL PIECE AND NAIL TO THE CAR FLOOR W/1-16d NAIL EVERY 8". SEE GENERAL NOTE "M" ON PAGE 2.
- (F) HOLD-DOWN CLEAT, 2" X 6" X 12" (2 REOD). NAIL TO A VERTICAL PIECE W/5-10d NAILS.
- (G) POCKET CLEAT, 2" X 6" X 12" (TRIPLED) (2 REOD). NAIL THE FIRST PIECE TO THE FLOOR CLEAT, PIECE MARKED (E), W/4-16d NAILS. NAIL THE SECOND AND THIRD PIECES IN A LIKE MANNER AND TOENAIL THE THIRD PIECE TO THE VERTICAL PIECE MARKED (A), W/2-16d NAILS.
- (H) BRACE, 4" X 4" X 69" (2 REOD). SEE THE DETAIL AT LEFT FOR BEVEL CUTS REQUIRED. TOENAIL TO THE VERTICAL PIECE AND TO THE FLOOR CLEAT, PIECES MARKED (A) AND (E), W/2-16d NAILS AT EACH END.
- (J) BACK-UP CLEAT, 2" X 6" X 30" (2 REOD). NAIL TO THE FLOOR CLEAT, PIECE MARKED (E), W/6-40d NAILS.
- (K) FILLER PIECE, 2" X 6" X 8" (2 REOD). NAIL TO A VERTICAL PIECE W/3-10d NAILS.
- (L) REINFORCING PIECE, 2" X 6" X 8" (2 REOD). POSITION TO CONTACT PALLET COVER AND NAIL TO A FILLER PIECE, PIECE MARKED (K), W/3-10d NAILS.



BRACE


4" X 4" MATERIAL

THE BRACE MUST BE INSTALLED SO THAT THIS BEARING SURFACE WILL BE IN CONTACT WITH THE VERTICAL PIECE MARKED (A).



SEE GENERAL NOTE
"F" ON PAGE 2.


ISOMETRIC VIEW



SECTION F-F

KEY NUMBERS

- ① FLOORLINE BLOCKING, 2" X 4" BY RANDOM LENGTHS (DOUBLED) (4 REQD). POSITION AGAINST THE PALLET AND NAIL THE FIRST PIECE TO THE CAR FLOOR W/1-16d NAIL EVERY 12". NAIL THE SECOND PIECE TO THE FIRST IN A LIKE MANNER. SEE GENERAL NOTES "L" ON PAGE 2 AND "R" ON PAGE 3.
- ② CENTER GATE, (2 REQD). SEE THE "CENTER GATE E" DETAIL ON PAGE 39.
- ③ STRUT, 4" X 4" BY CUT TO FIT (6 REQD). TOENAIL TO PIECES MARKED ② W/2-16d NAILS AT EACH END. SEE GENERAL NOTES "T" AND "U" ON PAGE 3.
- ④ VERTICAL STRUT BRACING, 2" X 4" X 38" (3 REQD). NAIL TO STRUTS W/3-10d NAILS AT EACH JOINT.
- ⑤ HORIZONTAL STRUT BRACING, 2" X 4" X 36" (2 REQD). NAIL TO THE STRUTS W/3-10d NAILS AT EACH JOINT.
- ⑥ GATE HOLD DOWN, 2" X 3" BY LENGTH OF CENTER VOID PLUS 24" (2 REQD). NAIL TO THE VERTICAL PIECES OF THE CENTER GATE W/2-10d NAILS AT EACH JOINT. SEE THE "CENTER GATE E" DETAIL ON PAGE 39 FOR LOCATION GUIDANCE. SEE SPECIAL NOTE 4 ON PAGE 39.





CENTER GATE E

THIS GATE IS FOR USE WITH CROSSWISE UNITS.

SPECIAL NOTES:

1. A 50'-6" LONG BY 9'-2" WIDE CONVENTIONAL TYPE BOXCAR IS SHOWN. CARS OF OTHER WIDTHS CAN BE USED, AND SHORTER BUT NOT LONGER CARS WILL BE USED.
2. A 1-WIDE CROSSWISE LOAD IS SHOWN AS TYPICAL. THE DEPICTED PROCEDURES ARE ALSO APPLICABLE FOR 1-WIDE LENGTHWISE LOADS.
3. THE BILL OF MATERIAL AND LOAD AS SHOWN ARE BASED ON THE DEPICTED LOAD AND THEREFORE ONLY TYPICAL.
4. IF DESIRED, GATE HOLD DOWN PIECES WITH THE ASSOCIATED FILL PIECE, AS SHOWN FOR "CENTER GATE C" ON PAGE 19, MAY BE USED IN LIEU OF PIECE MARKED ⑥.



CENTER GATE F


THIS GATE IS FOR USE WITH LENGTHWISE UNITS.

BILL OF MATERIAL		
LUMBER	LINEAR FEET	BOARD FEET
2" X 2"	11	4
2" X 3"	14	7
2" X 4"	200	134
2" X 6"	45	45
4" X 4"	27	36
NAILS	NO. REED	POUNDS
10d (3")	128	2
16d (3-1/2")	204	4-1/2

LOAD AS SHOWN (TYPICAL)

ITEM	QUANTITY	WEIGHT (APPROX)
PALLET UNIT	12	31,200 LBS
DUNNAGE		459 LBS
TOTAL WEIGHT		31,659 LBS (APPROX)

FLOORLINE BLOCKING, 2" X 4" X 45"
(DOUBLED) (1 REOD). POSITION
AGAINST THE PALLET AND NAIL THE
FIRST PIECE TO THE CAR FLOOR
W/1-16d NAIL EVERY 8". NAIL THE
SECOND PIECE TO THE FIRST IN A
LIKE MANNER. SEE GENERAL NOTES
"L" ON PAGE 2 AND "R" ON PAGE 3.




SEE GENERAL NOTE "F"
ON PAGE 2.

ISOMETRIC VIEW

FLOORLINE BLOCKING, 2" X 4" X 35" (DOUBLED)
(1 REOD). POSITION AGAINST THE PALLET AND
NAIL THE FIRST PIECE TO THE CAR FLOOR
W/1-16d NAIL EVERY 12". NAIL THE SECOND
PIECE TO THE FIRST IN A LIKE MANNER. SEE
GENERAL NOTES "L" ON PAGE 2 AND "R" ON PAGE 3.

INDICATES TYPICAL
CENTER GATE.



**POSITIONING OF A PARTIAL CROSSWISE
UNIT WITHIN A LAYER**

SPECIAL NOTES:


1. SHIPMENTS OF CARTRIDGES SHOULD CONSIST OF FULL-HEIGHT AND FULL-LAYER UNITS TO THE MAXIMUM EXTENT POSSIBLE. HOWEVER, THE END OF A LOT, OR THE QUANTITY OF ITEMS NEEDED TO FILL A REQUISITION, MAY NECESSITATE THE SHIPMENT OF ONE OR MORE LESS-THAN-FULL PALLET UNITS WITHIN A LOAD. THE PROCEDURES ON THIS PAGE ARE PRESENTED AS GUIDANCE IN THE SHIPMENT OF A PARTIAL UNIT WITHIN A LOAD.
2. A LESS-THAN-FULL HEIGHT PALLET UNIT WHICH IS TO BE SHIPPED WITHIN A LAYER OF A LOAD MAY CONTAIN ONE OR TWO LAYERS OF BOXES ON THE PARTIAL UNIT. THE DEPICTED PROCEDURES SHOW THE BRACING OF A 2-LAYER UNIT WITHIN A 3-LAYER LOAD. THE PRINCIPLES CAN BE ADAPTED TO 1-HIGH PARTIAL UNITS.
3. A PARTIAL UNIT MUST CONSIST OF FULL LAYERS OF BOXES (14) WITH CARTRIDGES; OR EMPTY FILLER CONTAINERS AS SPECIFIED BY DRAWING 19-48-4232/21-20PM1007, MUST BE INSTALLED.
4. THE FILLER BOXES AS REFERENCED IN SPECIAL NOTE 3 AND THE DUNNAGE DEPICTED ABOVE FOR THE SHIPMENT OF THE PARTIAL UNIT MAY BE REMOVED WHEN A SHIPMENT REACHES DESTINATION. OR IF DESIRED, THE FILLERS MAY REMAIN WITH THE UNIT DURING STORAGE (IF APPLICABLE) FOR POSSIBLE USE IN A FUTURE SHIPMENT.
5. THE "POSITIONING OF A PARTIAL CROSSWISE UNIT WITHIN A LAYER" VIEW ABOVE DEPICTS A PORTION OF A CONVENTIONAL BOXCAR LOAD, HOWEVER, THE PROCEDURES ARE ALSO APPLICABLE FOR LOADS IN CARS EQUIPPED WITH LOAD DIVIDER BULKHEADS.

KEY NUMBERS

- ① SPACER ASSEMBLY (1 REOD). SEE THE "SPACER ASSEMBLY" DETAIL BELOW.
- ② STRAPPING BOARD, 2" X 4" X 37-1/2" (2 REOD). POSITION ON TOP OF THE SPACER ASSEMBLY, PIECE MARKED ①. NAIL TO THE STRUTS W/1-10d NAIL AT EACH JOINT.
- ③ UNITIZING STRAP, 1-1/4" X .031" OR .035" BY A LENGTH TO SUIT STEEL STRAPPING (2 REOD). PRE-POSITION.
- ④ SEAL FOR 1-1/4" STRAPPING (4 REOD, 2 PER JOINT). SEE GENERAL NOTE "0" ON PAGE 2.


CORNER BLOCK, 2" X 4" X 11"
FOR A 2-LAYER UNIT, 22" FOR
A 1-LAYER UNIT (4 REOD).
POSITION AS SHOWN.

STRUT, 2" X 6" X 42-1/2"
(6 REOD). NAIL TO
THE CORNER BLOCKS
W/2-10d NAILS.



LOAD BEARING PIECE, 2" X 6" X 37-5/8"
(4 REOD). NAIL TO THE STRUTS W/3-10d
NAILS AT EACH JOINT AND TO THE CORNER
BLOCK W/2-10d NAILS AT EACH JOINT.

SPACER ASSEMBLY




**POSITIONING OF PARTIAL LENGTHWISE
UNIT WITHIN A LAYER**

SPECIAL NOTES:


1. SHIPMENTS OF CARTRIDGES SHOULD CONSIST OF FULL-HEIGHT AND FULL-LAYER UNITS TO THE MAXIMUM EXTENT POSSIBLE. HOWEVER, THE END OF A LOT, OR THE QUANTITY OF ITEMS NEEDED TO FILL A REQUISITION, MAY NECESSITATE THE SHIPMENT OF ONE OR MORE LESS-THAN-FULL PALLET UNITS WITHIN A LOAD. THE PROCEDURES ON THIS PAGE ARE PRESENTED AS GUIDANCE IN THE SHIPMENT OF A PARTIAL UNIT WITHIN A LOAD.
2. A LESS-THAN-FULL HEIGHT PALLET UNIT WHICH IS TO BE SHIPPED WITHIN A LAYER OF A LOAD MAY CONTAIN ONE OR TWO LAYERS OF BOXES ON THE PARTIAL UNIT. THE DEPICTED PROCEDURES SHOW THE BRACING OF A 1-LAYER UNIT WITHIN A 3-LAYER LOAD; FOR A 2-LAYER UNIT, CONSTRUCT A HALF-HEIGHT PARTIAL UNIT GATE.
3. A PARTIAL UNIT MUST CONSIST OF FULL LAYERS OF FOURTEEN BOXES WITH CARTRIDGES; OR EMPTY FILLER CONTAINERS AS SPECIFIED BY DRAWING 19-48-4232/21-20PM1007, MUST BE INSTALLED.
4. THE FILLER BOXES AS REFERENCED IN SPECIAL NOTE 3 AND THE DUNNAGE DEPICTED ABOVE FOR THE SHIPMENT OF THE PARTIAL UNIT MAY BE REMOVED WHEN A SHIPMENT REACHES DESTINATION. OR IF DESIRED, THE FILLERS MAY REMAIN WITH THE UNIT DURING STORAGE (IF APPLICABLE) FOR POSSIBLE USE IN A FUTURE SHIPMENT.
5. THE "POSITIONING OF A PARTIAL LENGTHWISE UNIT WITHIN A LAYER" VIEW ABOVE DEPICTS A PORTION OF A CONVENTIONAL BOXCAR LOAD, HOWEVER, THE PROCEDURES ARE ALSO APPLICABLE FOR LOADS IN CARS EQUIPPED WITH LOAD DIVIDER BULKHEADS.

KEY NUMBERS

- ① PARTIAL-UNIT GATE (2 REOD). SEE THE DETAIL BELOW. SEE GENERAL NOTE "M" ON PAGE 2 AND SPECIAL NOTE 3 AT LEFT.
- ② STRUT, 4" X 4" X 37-5/8" (6 REOD). TOENAIL TO THE VERTICAL PIECES OF THE PARTIAL-UNIT GATE, PIECE MARKED ①, W/2-16d NAILS AT EACH END.
- ③ STRUT SUPPORT PIECE, 2" X 4" X 11" (6 REOD). NAIL TO A VERTICAL PIECE OF THE PARTIAL-UNIT GATE W/3-10d NAILS.
- ④ STRAPPING BOARD, 2" X 4" X 45-1/2" (2 REOD). NAIL TO THE STRUTS, PIECES MARKED ②, W/2-10d NAILS AT EACH JOINT.
- ⑤ UNITIZING STRAP, 1-1/4" X .031" X .035" BY A LENGTH TO SUIT STEEL STRAPPING (2 REOD). PRE-POSITION.
- ⑥ SEAL FOR 1-1/4" STEEL STRAPPING (4 REOD, 2 PER JOINT). SEE GENERAL NOTE "O" ON PAGE 2.




PARTIAL UNIT GATE




SECUREMENT OF PARTIAL UNIT ON TOP OF FULL UNIT

NOTE THAT THE PARTIAL UNIT ON TOP IS LIMITED TO NOT MORE THAN TWO LAYERS OF BOXES. FOR AN ALTERNATIVE METHOD FOR ONE OR TWO LAYERS, REFER TO THE PROCEDURES ON PAGE 41.



ENDWALL LINING


THIS VIEW DEPICTS LINING REQUIRED FOR A LOAD IN A CAR EQUIPPED WITH A STEEL ENDWALL.



SIDEWALL LINING

THIS VIEW DEPICTS LINING REQUIRED FOR A CAR EQUIPPED WITH A STEEL SIDEWALL. NOTE THAT IF THE CAR IS EQUIPPED WITH A STEEL-FACED PLUG DOOR, THE SPECIAL LINING WILL ALSO BE REQUIRED IN THE DOORWAY AREA IF THE SPECIFIED DOORWAY PROTECTION DOES NOT SUFFICE.

INDICATES A
PALLET UNIT.




INDICATES TOP-OF-LOAD
ANTI-SWAY BRACE.

TIE WIRE APPLICATION

USE NO. 14 GAGE WIRE BY A LENGTH TO SUIT.
FORM TWO LOOPS AROUND TOP-OF-LOAD ANTI-SWAY
BRACE SUPPORT PIECE AND TWIST TO PREVENT
DISPLACEMENT. THREAD EACH END OF WIRE
UNDER AND AROUND THE LIFTING RINGS ON THE
UNIT AND TWIST WIRE TO SELF AS SHOWN.

FILLER PIECE, 2" X 6" BY CAR WIDTH MINUS 1/2"
IN LENGTH (ONE REQUIRED FOR EACH HORIZONTAL
PIECE ON THE CENTER GATE). ALIGN WITH THE
HORIZONTAL PIECES AND NAIL TO THE VERTICAL
PIECES OF THE CENTER GATE W/3-10d NAILS
AT EACH JOINT.



CAR WIDTH
MINUS 1/2"

SHIM MATERIAL, 6" WIDE PLYWOOD OR
DIMENSIONAL LUMBER OF A THICKNESS
AND LENGTH AS REQUIRED TO FILL
THE VOID BETWEEN THE CAR ENDWALL
AND THE BULKHEAD. NAIL TO THE
FILLER PIECE AND/OR LAMINATE
W/1 APPLICABLY SIZED NAIL EVERY 6".

POSITION THIS SIDE OF THE
BULKHEAD GATE AGAINST
THE CAR ENDWALL.


THESE 2" X 6" HORIZONTAL AND 2" X 6"
VERTICAL PIECES ARE PART OF THE CENTER
GATE AS SHOWN ON PAGE 16.

END-OF-CAR BULKHEAD

DETAILS

INDICATES A TYPICAL CAR WIDTH CENTER GATE, WITH THE HORIZONTAL PIECES OMITTED (1 REQD). SEE THE APPLICABLE CENTER GATE DETAIL FOR LOCATION OF THE VERTICAL PIECES AND THE STRUT LEDGERS.


1/2" PLYWOOD, UNIT WIDTH OR LENGTH BY THE LOAD HEIGHT (2 REQD). NAIL TO THE VERTICAL PIECES W/1-6d NAIL EVERY 6". NOTE: THE WIDTH OF THE PLYWOOD WILL BE UNIT WIDTH IF THE LENGTH OF THE UNIT IS PARALLEL WITH THE SIDEWALL OF A CAR, AS TYPICALLY SHOWN IN THE LOAD ON PAGE 10, OR UNIT LENGTH IF THE WIDTH OF THE UNIT IS PARALLEL WITH THE SIDEWALL OF A CAR, AS TYPICALLY SHOWN IN THE LOAD ON PAGES 6 AND 8. PLYWOOD MAY BE ALLOWED TO EXTEND BEYOND THE UNIT LENGTH OR WIDTH IN THE VOID BETWEEN ROWS, IF DESIRED.



GATE HOLD DOWN PIECES MUST BE SECURED TO THE PLYWOOD.


PLYWOOD CENTER GATE ALTERNATIVE

CENTER GATE "B" IS SHOWN AS TYPICAL. PLYWOOD MAY BE USED IN LIEU OF THE HORIZONTAL PIECES ON ANY CENTER GATE DEPICTED HEREIN, INCLUDING THOSE WHICH ARE FOR THE BRACING OF A SINGLE ROW.




BEVEL-CUT

BEVEL CUTTING THE STRUTS IS ONLY APPLICABLE FOR 4" X 4" STRUTS IF THEY ARE USED IN LIEU OF DOUBLED 2" X 6" AS PERMITTED BY SPECIAL NOTE 7 ON PAGE 11. BEVEL CUTTING WILL FACILITATE INSTALLING THE STRUTS WITH A "DRIVE FIT". CAUTION: DO NOT BEVEL A CORNER MORE THAN ONE-HALF INCH.




STRUT INSTALLATION

SEE GENERAL NOTE "U" ON PAGE 3 FOR ADDITIONAL STRUT INSTALLATION GUIDANCE. NOTE THAT THIS VIEW IS ONLY APPLICABLE FOR 4" X 4" STRUTS.



STRAP JOINT A


METHOD OF SECURING A STRAP JOINT WHEN USING A NOTCH-TYPE SEALER.



STRAP JOINT B


METHOD OF SECURING A STRAP JOINT WHEN USING A CRIMP-TYPE SEALER.

END-OVER-END LAP JOINT DETAILS



ALTERNATIVE GATE HOLD-DOWN

THIS VIEW DEPICTS AN ALTERNATIVE METHOD OF CENTER GATE HOLD-DOWN WHICH CAN BE USED IF DESIRED, PROVIDING THE CAR HAS NAILABLE SIDEWALLS. THIS METHOD MAY BE APPLIED IN LIEU OF USING THE GATE HOLD-DOWN PIECES WHICH ARE PART OF A CENTER GATE. NOTE: FOR A GATE NOT LOCATED IN OR NEAR THE DOORWAY AREA, THE GATE HOLD-DOWN CLEAT MAY BE DOUBLED AND NAILED TO THE CAR SIDEWALL TO PROVIDE A HOLD-DOWN.




TIE PIECE APPLICATION

THIS PROCEDURE IS APPLICABLE FOR USE WITH ANY TWO CENTER GATES FOR SINGLE ROWS OF PALLET UNITS. NOTE THAT THE TIE PIECES SHOULD BE APPLIED AFTER THE GATES AND THE STRUTS HAVE BEEN INSTALLED.

IF THE SPACE WILL BE MORE THAN 9" MAXIMUM, REFER TO THE "ALTERNATIVE DOORWAY PROTECTION A-2" VIEW BELOW FOR GUIDANCE. SEE "NOTE ●" AT THE RIGHT.

NOTE ●:

THE TOLERANCE DIMENSION (6" MIN, 9" MAX) IS ALLOWED TO PROVIDE FOR CLEARANCE DURING THE NORMAL LONGITUDINAL SHIFTING OF A LOAD IN TRANSIT.




ALTERNATIVE DOORWAY PROTECTION A-1

THIS METHOD OF DOORWAY PROTECTION IS FOR USE IN CARS HAVING AVAILABLE SIDEWALLS AND EQUIPPED WITH CONVENTIONAL SLIDING DOORS, AND IS APPLICABLE ONLY FOR THE SIDE OPPOSITE THE LOADING SIDE OF THE CAR. THE METHOD CAN ALSO BE USED IN CARS EQUIPPED WITH PLUG DOORS; HOWEVER, "ALTERNATIVE DOORWAY PROTECTION C" DETAILED ON PAGE 51 MUST BE USED ON THE LOADING SIDE OF THE CAR.

FILLER PIECE, 1" X 6" BY A LENGTH TO PROVIDE A SPACE OF BETWEEN 6" AND 9" (2 OR 4 REOD PER LAYER). NAIL TO THE CAR SIDEWALL W/1-6d NAIL EVERY 8" (MINIMUM OF 2 NAILS). SEE "NOTE ●" ABOVE.

6" MIN, 9" MAX
SEE "NOTE ●" ABOVE.



ALTERNATIVE DOORWAY PROTECTION A-2

THIS METHOD OF DOORWAY PROTECTION IS FOR USE IN CARS HAVING AVAILABLE SIDEWALLS AND EQUIPPED WITH CONVENTIONAL SLIDING DOORS, AND IS APPLICABLE ONLY FOR THE SIDE OPPOSITE THE LOADING SIDE OF THE CAR. SEE THE NOTE UNDER "A-1" PROCEDURES.

DOOR SPANNER, 2" (MIN) X 6" BY DOOR OPENING WIDTH PLUS 24" (2 REED PER LAYER). POSITION SO AS TO MATCH THE HEIGHTS SPECIFIED FOR THE HORIZONTAL PIECES OF THE DOORWAY PROTECTION DETAIL. SEE "NOTE ●" ABOVE.

NOTE ●:

THE TOLERANCE DIMENSION (6" MIN, 9" MAX) IS ALLOWED TO PROVIDE FOR CLEARANCE DURING THE NORMAL LONGITUDINAL SHIFTING OF A LOAD IN TRANSIT.

INDICATES DOOR OPENING.

INDICATES OUTSIDE WALL OF CAR.

INDICATES CAR SIDEWALL.

SUPPORT PIECE, 2" X 4" BY A LENGTH TO SUIT (2 REED). POSITION AGAINST DOOR POST AND NAIL TO THE DOOR SPANNER PIECES W/3-10d NAILS AT EACH JOINT.

INDICATES FILL MATERIAL NAILED TO THE SIDEWALL, OR A FILLER PIECE, 2" X 6" BY A LENGTH TO EQUAL THE LENGTH OF THE FILLER PIECE ON THE OPPOSITE SIDEWALL MINUS 1" (QUANTITY TO BE THE SAME AS FOR THE DOOR SPANNERS AND/OR FILLER PIECES ON THE OPPOSITE SIDEWALL). SEE "NOTE ●" ABOVE.

ALTERNATIVE DOORWAY PROTECTION A-3

THIS VIEW DEPICTS THE DOOR OPENING OF A CAR AS IT APPEARS WHEN LOOKING AT IT FROM OUTSIDE OF THE CAR. THE METHOD OF DOORWAY PROTECTION IS FOR USE IN CARS HAVING NAILABLE SIDEWALLS AND EQUIPPED WITH CONVENTIONAL SLIDING DOORS, AND IS APPLICABLE FOR THE LOADING SIDE OF THE CAR. NOTE THAT THE ADJACENT PALLET UNITS MUST BE POSITIONED APPROXIMATELY 1-3/4" (REF) FROM THE CAR SIDEWALL (1/4" MORE THAN THE THICKNESS OF THE DOOR SPANNER PIECES) TO FACILITATE THE INSTALLATION OF THESE DOOR SPANNER PIECES. THE VIEW SHOWN ABOVE IS FOR A TWO-LAYER LOAD.

HORIZONTAL PIECE, 1" X 6" BY DOOR OPENING WIDTH (2 REED PER LAYER). NAIL TO THE VERTICAL PIECES W/3-6d NAILS AT EACH END. SEE THE "DOORWAY PROTECTION" DETAIL ON PAGE 15 FOR HEIGHT LOCATIONS.


DOORWAY PROTECTION-GATE STRAP, 1-1/4" X .035" X 3'-0" (REF) NAIL-ON TYPE STEEL STRAPPING (4 REED PER LAYER OF LOAD). NAIL TO GATE AND CAR SIDEWALL AS SHOWN BY THE "VIEW B" DETAIL BELOW. NOTE THAT TYPE 1 STRAPPING MAY BE PUNCHED FOR NAILING IF TYPE 3 STRAPPING IS NOT AVAILABLE.

INDICATES DOOR OPENING.

VIEW B

VERTICAL PIECE, 2" X 3" BY A LENGTH TO SUIT (2 REED).

INDICATES LOCATION OF 7 (MIN) 4d NAILS PER STRAP.



VIEW B

THIS VIEW DEPICTS THE LOCATION OF THE NAILS FOR SECURING THE DOORWAY PROTECTION GATE STRAP. NOTE THAT THE STRAPS MUST BE APPLIED TO THE CAR SIDEWALL PRIOR TO POSITIONING THE ADJACENT UNITS.


INDICATES CAR SIDEWALL.

INDICATES CAR SIDEWALL.


INDICATES FLOOR.

ALTERNATIVE DOORWAY PROTECTION B

THIS METHOD OF DOORWAY PROTECTION IS FOR USE IN CARS EQUIPPED WITH CONVENTIONAL SLIDING DOORS WHEN THE DOOR POSTS ARE STEEL WITHOUT NAILING HOLES AND THE CAR SIDEWALLS ARE NAILABLE. THE VIEW SHOWN ABOVE IS FOR A TWO-LAYER LOAD.



DOORWAY PROTECTION STRAP, 1-1/4" X .035" OR .031" STEEL STRAPPING BY DOOR OPENING WIDTH PLUS 8'-0" IN LENGTH (2 REOD PER LAYER). INSTALL FROM TWO PIECES. THREAD ONE END THRU A STRAP ANCHOR PLATE AS SHOWN BY THE "APPLICATION OF STRAPPING TO STRAP ANCHOR PLATE" DETAILS BELOW. NAIL STRAP ANCHOR PLATE TO CAR SIDEWALL W/4 SIGNODE MICRO-LOCK NAILS.




ISOMETRIC VIEW **VIEW A**

APPLICATION OF STRAPPING TO STRAP ANCHOR PLATE

THESE VIEWS DEPICT THE PROPER THREADING OF A DOORWAY PROTECTION STRAP THRU AN ANCHOR PLATE.


ALTERNATIVE DOORWAY PROTECTION C

THIS METHOD OF DOORWAY PROTECTION MAY BE USED IN CARS EQUIPPED WITH EITHER PLUG TYPE DOORS OR CONVENTIONAL SLIDING DOORS, BUT ONLY IF THE CAR IS EQUIPPED WITH NAILABLE SIDEWALLS. IF THE CAR IS EQUIPPED WITH SPECIAL ANCHOR RODS IN THE CAR DOOR POSTS, THE DOORWAY PROTECTION STRAPS MAY BE SECURED TO THESE RODS IN LIEU OF ATTACHING TO THE CAR SIDEWALL WITH STRAP ANCHOR PLATES. CAUTION: A VERTICAL PIECE MUST BE ADDED TO EACH END OF A CENTER GATE WHICH IS IN OR WITHIN SIX INCHES OF BEING IN THE DOOR OPENING, TO PREVENT THE GATE FROM SHIFTING LATERALLY, UNLESS PLYWOOD IS BEING USED IN LIEU OF THE 2" X 6" HORIZONTAL PIECES IN WHICH CASE THE ADDED VERTICAL PIECES WILL NOT BE REQUIRED.



ALTERNATIVE DOORWAY PROTECTION D

THIS METHOD OF DOORWAY PROTECTION IS FOR USE IN CARS EQUIPPED WITH CONVENTIONAL SLIDING DOORS WHEN THE DOOR POSTS ARE NOT NAILABLE. IF THE CAR HAS NAILABLE SIDEWALLS, NAIL-ON TYPE STRAPPING MAY BE USED TO SECURE THE GATE IN LIEU OF USING THE SPREADER PIECES. SEE THE "ALTERNATIVE DOORWAY PROTECTION B" DETAIL ON PAGE 50 FOR GUIDANCE. NOTE THAT THE DOOR SPANNER IN THIS DETAIL MAY BE USED AS A GATE HOLD-DOWN PIECE FOR THE "ALTERNATIVE GATE HOLD-DOWN METHOD" SHOWN ON PAGE 48.




INSTALLATION OF STRUT ASSEMBLY

THIS SIDE ELEVATION VIEW SHOWS THE STRUT ASSEMBLY INSTALLED BETWEEN THE LOAD DIVIDER BULKHEADS. NOTE THE 1/2" TO 3/4" (TOTAL) SPACE INTENTIONALLY PROVIDED BETWEEN THE ASSEMBLY AND THE BULKHEADS.

FABRICATE TO FIT BETWEEN LOAD DIVIDERS MINUS 1/2" TO 3/4". CAUTION: THE ASSEMBLY IS INTENTIONALLY DESIGNED FOR A LOOSE FIT BETWEEN THE LOAD DIVIDER BULKHEADS.

HOLD DOWN, 1" X 8" BY CUT-TO-FIT BETWEEN LOCKING PINS AT EACH SIDE OF THE LOAD DIVIDER (2 REQD). NAIL TO THE STRUT LEDGER W/1-6d NAIL EVERY 12".




STRUT ASSEMBLY FOR 2-PIECE BULKHEADS

A STRUT ASSEMBLY IS REQUIRED WHEN THE LOAD BEHIND EITHER LOAD DIVIDER BULKHEAD EXCEEDS 50,000 POUNDS OF HAZARD CLASS AND DIVISION 1.1, 1.2, OR 1.3 EXPLOSIVES. A STRUT ASSEMBLY IS NOT REQUIRED FOR LOADS OF HAZARD CLASS AND DIVISION 1.4 EXPLOSIVES, REGARDLESS OF THE WEIGHT OF THE LOAD. NOTE: TWO ASSEMBLIES AS SHOWN ARE REQUIRED FOR A 2-PIECE BULKHEAD IF NOT LATERALLY ALIGNED. SEE "NOTE ▲" BELOW.

FABRICATE TO FIT BETWEEN LOAD DIVIDERS MINUS 1/2" TO 3/4". CAUTION: THE ASSEMBLY IS INTENTIONALLY DESIGNED FOR A LOOSE FIT BETWEEN THE LOAD DIVIDER BULKHEADS.

HOLD DOWN, 1" X 8" BY CUT-TO-FIT BETWEEN LOCKING PINS AT EACH SIDE OF THE LOAD DIVIDER (2 REQD). NAIL TO THE STRUT LEDGER W/1-6d NAIL EVERY 12".




NOTE ▲:

THE TWO INTERMEDIATE STRUTS ARE TO BE EVENLY SPACED ON THE WIDTH OF THE DIVIDER BULKHEADS, WITH ADJUSTMENTS MADE SO AS TO ALIGN WITH VERTICAL FRAMING WITHIN THE BULKHEADS. IF THE CAR IS EQUIPPED WITH 2-PIECE DIVIDER BULKHEADS AND THE BULKHEADS ARE LATERALLY ALIGNED WITH EACH OTHER, THE STRUTS SHOULD BE ALIGNED WITH THE EDGES OF THE BULKHEADS; IF THE BULKHEADS ARE NOT ALIGNED, THE "STRUT ASSEMBLY FOR 2-PIECE BULKHEADS" MUST BE USED. SEE THE DETAIL ABOVE.

STRUT ASSEMBLY FOR 1-PIECE BULKHEADS

A STRUT ASSEMBLY IS REQUIRED WHEN THE LOAD BEHIND EITHER LOAD DIVIDER BULKHEAD EXCEEDS 50,000 POUNDS OF HAZARD CLASS AND DIVISION 1.1, 1.2, OR 1.3 EXPLOSIVES. A STRUT ASSEMBLY IS NOT REQUIRED FOR LOADS OF HAZARD CLASS AND DIVISION 1.4 EXPLOSIVES, REGARDLESS OF THE WEIGHT OF THE LOAD.




TYPICAL TYPE A

THIS VIEW SHOWS THE INSTALLATION OF A "FILL PIECE" IN A CAR EQUIPPED WITH A STANDARD ADJUSTABLE SIDE FILLER.

NOTE ▲:

NAILING OF "FILL PIECES" IS NOT REQUIRED EXCEPT THAT EACH "FILL PIECE" LOCATED NEAREST THE DOOR OPENINGS OF THE CAR WILL BE SECURED AGAINST LONGITUDINAL MOVEMENT W/1-6d NAIL DRIVEN THROUGH THE SIDE FILLER PANEL AND INTO THE "FILL PIECE".



TYPICAL TYPE B

THIS VIEW SHOWS A TYPICAL SECTION OF A CAR EQUIPPED WITH HEAVY DUTY, STEEL REINFORCED, ADJUSTABLE SIDE FILLERS. A "FILL PIECE", AS SHOWN IN THE "TYPICAL TYPE A" DETAIL ABOVE, IS NOT REQUIRED IN CARS SO EQUIPPED.

